

Part No. 060138-10, Rev. C
March 2005

OmniAccess™ 512 User Manual

Release 4.4



www.alcatel.com

An Alcatel service agreement brings your company the assurance of 7x24 no-excuses technical support. You'll also receive regular software updates to maintain and maximize your Alcatel product's features and functionality and on-site hardware replacement through our global network of highly qualified service delivery partners. Additionally, with 24-hour-a-day access to Alcatel's Service and Support web page, you'll be able to view and update any case (open or closed) that you have reported to Alcatel's technical support, open a new case or access helpful release notes, technical bulletins, and manuals. For more information on Alcatel's Service Programs, see our web page at www.ind.alcatel.com, call us at 1-800-995-2696, or email us at support@ind.alcatel.com.

**This Manual documents Release 4.4 OmniAccess 512 hardware and software.
The functionality described in this Manual is subject to change without notice.**

Copyright© 2005 by Alcatel Internetworking, Inc. All rights reserved. This document may not be reproduced in whole or in part without the express written permission of Alcatel Internetworking, Inc.

Alcatel® and the Alcatel logo are registered trademarks of Alcatel. Xylan®, OmniSwitch®, PizzaSwitch® and OmniStack® are registered trademarks of Alcatel Internetworking, Inc.

AutoTracker™, OmniAccess™, OmniCore™, Omni Switch/Router™, OmniVista™, PizzaPort™, PolicyView™, RouterView™, SwitchManager™, SwitchStart™, VoiceView™, WANView™, WebView™, X-Cell™, X-Vision™ and the Xylan logo are trademarks of Alcatel Internetworking, Inc.

All-In-OneSM is a service mark of Alcatel Internetworking, Inc. All other brand and product names are trademarks of their respective companies.



26801 West Agoura Road
Calabasas, CA 91301
(818) 880-3500 FAX (818) 880-3505
info@ind.alcatel.com

US Customer Support—(800) 995-2696
International Customer Support—(818) 878-4507
Internet—<http://www.ind.alcatel.com>

Warning

This equipment has been tested and found to comply with the limits for Class A digital device pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference when the equipment is operated in a commercial environment. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions in this guide, may cause interference to radio communications. Operation of this equipment in a residential area is likely to cause interference, in which case the user will be required to correct the interference at his own expense.

The user is cautioned that changes and modifications made to the equipment without approval of the manufacturer could void the user's authority to operate this equipment. It is suggested that the user use only shielded and grounded cables to ensure compliance with FCC Rules.

This equipment does not exceed Class A limits per radio noise emissions for digital apparatus, set out in the Radio Interference Regulation of the Canadian Department of Communications.

Avis de conformité aux normes du ministère des Communications du Canada

Cet équipement ne dépasse pas les limites de Classe A d'émission de bruits radioélectriques pour les appareils numériques, telles que prescrites par le Règlement sur le brouillage radioélectrique établi par le ministère des Communications du Canada.

Lithium Batteries Caution: There is a danger of explosion if the Lithium battery in your chassis is incorrectly replaced. Replace the battery only with the same or equivalent type of battery recommended by the manufacturer. Dispose of used batteries according to the manufacturer's instructions. The manufacturer's instructions are as follows:

Return the module with the Lithium battery to Alcatel. The Lithium battery will be replaced at Alcatel's factory.

Table of Contents

1 OmniAccess 512	1-1
Introduction	1-1
Application Example	1-2
OmniAccess 512 Hardware Options	1-3
OA-512 Chassis	1-3
OmniAccess 512 Uplink Submodules	1-4
Required Image Files	1-5
OA-512 Front Panel Information	1-6
OA-512 Hardware Specifications	1-7
General Chassis Information	1-7
OA-512 Software Specifications	1-8
Standards Supported	1-8
OmniAccess 512 Slot Designations	1-9
OmniAccess 512 Management LEDs	1-10
OmniAccess 512 Ethernet Port LEDs	1-11
Configuring the Ethernet Ports	1-12
The Console Management Port	1-12
Rear Panel	1-13
Accessing the SIMM Memory Daughtercard	1-13
Power Cords	1-15
OmniAccess 512 48V DC Power Source	1-16
OmniAccess 512 Power Supply Specifications	1-16
Connecting a DC Power Source to an OmniAccess 512-48VDC	1-17
Installation Requirements	1-17
Installing DC Power Source Wire Leads	1-18
OA-512 Uplink Submodules	1-20
OA-512-FT1/FE1 WAN Submodule	1-21
Front Panel	1-21
OA-512-FT1/FE1 Technical Specifications	1-22
Hardware Information	1-22
Software Information	1-22
Changing the OA-512-FT1/FE1 Jumper Positions (75 ohm E1 Coaxial Interface)	1-22

OA-512-BRI-U WAN Submodule	1-23
Front Panel	1-23
OA-512-BRI-U Technical Specifications	1-24
Hardware Information	1-24
Software Information	1-24
OA-512-BRI-S/T WAN Submodule	1-25
Front Panel	1-25
OA-512-BRI-S/T Technical Specifications	1-26
Hardware Information	1-26
Software Information	1-26
Changing the OA-512-BRI-S/T Jumper Positions (No Bus Termination)	1-26
OA-512-USP WAN Submodule	1-27
Front Panel	1-27
OA-512-USP Technical Specifications	1-28
Hardware Information	1-28
Software Information	1-28
2 The User Interface	2-1
Overview of Command Interfaces	2-1
Changing Between the CLI and UI Modes	2-1
Exit the Command Interface	2-2
UI to CLI Command Cross Reference	2-3
Basic Switch Management Commands	2-3
Basic Switch Management Table	2-3
Network Management Commands	2-4
Network Management Table	2-4
Layer II Switching Commands	2-5
Layer II Switching Table	2-5
Groups, VLANs, Policies Commands	2-6
Groups, VLANs, Policies Table	2-6
Routing Commands	2-8
Routing Table	2-8
ATM Access Commands	2-9
ATM Access Table	2-9
Troubleshooting Diagnostics Commands	2-11
Troubleshooting/Diagnostics Table	2-11
User Interface Menu	2-12
Main Menu Summary	2-13

General User Interface Guidelines	2-14
Entering Command Names	2-14
Quitting a Command	2-15
Scrolling	2-15
The UI Configuration Menu	2-15
Configuring the System Prompt	2-16
Configuring More Mode for the User Interface	2-17
Enabling and Disabling Verbose Mode for the User Interface	2-19
Configuring the Auto Logout Time	2-21
Viewing Commands	2-22
Changing Passwords	2-22
Command History and Re-Executing Commands	2-23
Abbreviating IP Addresses	2-25
User Interface Display Options	2-27
Setting Echo/NoEcho for User Entry	2-28
Setting the Login Banner	2-29
Creating a new Banner	2-29
Permanent Banner	2-30
Banners for Different Access Methods	2-30
Login Accounts	2-31
Multiple User Sessions	2-31
Listing Other Users	2-32
Communicating with Other Users	2-33
Deleting Other Sessions	2-34
Advanced Kill Command Options	2-35
UI Table Filtering (Using Search and Filter Commands)	2-36
The Search Command	2-37
Renewing a Search	2-38
The Filter Command	2-39
Combining Search and Filter Commands	2-41
Using Wildcards with Search and Filter Commands	2-43
Wildcard Command Options	2-43
3 Installing Switch Software	3-1
Using FTP Server	3-2
Using FTP Client	3-3
Using ZMODEM	3-4
Using ZMODEM with the load Command	3-4
Using ZMODEM With the Boot Line Prompt	3-5

4	Managing Files	4-1
	File Menu	4-1
	Displaying the Current Directory	4-2
	Listing Switch Files	4-2
	Required Command and Image Files	4-2
	Configuration and Log File Generation	4-3
	File Name Directory	4-3
	Removing Switch Files	4-5
	Removing Multiple Files	4-5
	Removing All Image Files	4-6
	Copying System Files	4-7
	Viewing Text Files	4-7
	Editing Text Files	4-8
	Adding Lines of Text to the Text Buffer	4-9
	Clearing the Text Buffer	4-9
	Deleting a Line of Text from the Text Buffer	4-9
	Editing a Line Name of Text in the Text Buffer	4-9
	Inserting a Line of Text into the Text Buffer	4-10
	Listing the Contents of the Text Buffer	4-10
	Naming the Text Buffer	4-10
	Reading an ASCII File into the Text Buffer	4-11
	Writing a Text File from the Text Buffer	4-11
	Real-World Examples	4-12
	Real-World Example 1	4-12
	Real-World Example 2	4-13
	System Menu	4-14
	Checking the Flash File System	4-15
	Creating a New File System	4-16
5	Switch Security	5-1
	Changing Passwords	5-2
	Rebooting the Switch	5-3
	Secure Switch Access	5-4
	Configuring the Secure Switch Access Filter Database	5-4
	Configuring Secure Access Filter Points	5-7
	Enabling/Disabling Security Parameters	5-9
	Adding Filters	5-9
	Deleting Filters	5-9
	Viewing Secure Access Violations Log	5-10

Managing User Login Accounts	5-11
Partition Management Requirements	5-11
Default Accounts	5-12
Adding a User Account Using the UI Command Mode	5-12
Adding a User Account Using the CLI Command Mode	5-13
Assigning Account Privileges Using the CLI Command Mode	5-13
Assigning Account Privileges Using the UI Command Mode	5-16
Command Family Table	5-18
Global Family Table	5-19
Modifying a User Account	5-20
Deleting a User	5-20
6 Configuring Switch-Wide Parameters	6-1
Summary Menu	6-1
Displaying the MIB-II System Group Variables	6-2
Displaying the Chassis Summary	6-3
Displaying Current Router Interface Status	6-4
System Menu	6-5
Displaying Basic System Information	6-6
Setting the System Date and Time	6-8
Configuring the Serial Port Parameters	6-14
Viewing Slot Data	6-16
Viewing System Statistics	6-17
Clearing System Statistics	6-18
Viewing Task Utilization Statistics	6-19
Viewing Memory Utilization	6-21
Viewing Task Utilization Statistics	6-22
Viewing MPM Memory Statistics	6-23
Configuring a System Information	6-24
Viewing CAM Information	6-25
Duplicate MAC Address Support	6-26
Multicast Claiming	6-27
Disabling Flood Limits	6-27
Saving Configurations	6-28

7	Switch Logging	7-1
	Logging Overview	7-1
	Configuring the Syslog Parameters	7-2
	Configuring Switch Logging	7-6
	Displaying the Command History Entries in the MPM Log	7-9
	Displaying the Connection Entries in the MPM Log	7-10
	Displaying Screen (Console) Capture Entries in the MPM Log	7-11
	Displaying Debug Entries in the MPM Log	7-13
	Displaying Secure Access Entries in the MPM Log	7-13
8	Health Statistics	8-1
	The Health Statistics Management Menu	8-1
	Setting Resource Thresholds	8-2
	Setting Bandwidth Thresholds	8-3
	Setting Miscellaneous Thresholds	8-4
	Setting the Sampling Interval	8-6
	View Switch-Level Statistics	8-6
	View Module-Level Statistics	8-8
	View Port-Level Statistics	8-8
	Reset Health Statistics	8-9
9	Network Time Protocol	9-1
	Introduction	9-1
	Stratum	9-2
	Using NTP in a Network	9-2
	NTP and Authentication	9-4
	Network Time Protocol Management Menu	9-5
	NTP Configuration Menu	9-6
	Configuring an NTP Client	9-6
	Configuring an NTP Client/Server	9-8
	Configuring Client/Server Authentication	9-9
	Configuring a New Peer Association	9-12
	Configuring a New Server	9-13
	Configuring a Broadcast Time Service	9-13
	Unconfigure Existing Peer Associations	9-14
	Set the Server's Advertised Precision	9-14
	NTP Information Menu	9-15
	Display List of Peers the Server Knows About	9-15
	Display Peer Summary Information	9-16
	Display Alternate Peer Summary Information	9-17
	Display Detailed Information for One or More Peers	9-18
	Print Version Number	9-20
	Display Local Server Information	9-21

NTP Statistics Menu	9-23
Display Local Server Statistics	9-23
Display Server Statistics Associated with Particular Peer(s)	9-24
Display Loop Filter Information	9-26
Display Peer Memory Usage Statistics	9-26
Display I/O Subsystem Statistics	9-27
Display Event Timer Subsystem Statistics	9-28
Reset Various Subsystem Statistics Counters	9-28
Reset Stat Counters Associated With Particular Peer(s)	9-28
Display Packet Count Statistics from the Control Module	9-29
Display the Current Leap Second State	9-30
Turn the Server's Monitoring Facility On or Off	9-31
Display Data The Server's Monitor Routines Have Collected	9-31
NTP Administration Menu	9-33
Set the Primary Receive Timeout	9-33
Set the Delay Added to Encryption Time Stamps	9-33
Specify the Host Whose NTP Server We Talk To	9-34
Specify a Password to Use for Authenticated Requests	9-34
Set Key ID to Use for Authenticated Requests	9-34
Set Key Type to Use for Authenticated Requests (DES MD5)	9-35
Set a System Flag (Auth, Bclient, Monitor, Stats)	9-35
Clear a System Flag (Auth, Bclient, Monitor, Stats)	9-35
NTP Access Control Menu	9-36
Change the Request Message Authentication Key ID	9-36
Change the Control Message Authentication Key ID	9-37
Add One or More Key IDs to the Trusted List	9-37
Display the Trusted Key ID List	9-37
Remove One or More Key IDs from the Trusted List	9-38
Display the State of the Authentication Code	9-38
Create Restrict Entry/Add Flags to Entry	9-39
View the Server's Restrict List	9-40
Remove Flags from a Restrict Entry	9-41
Delete a Restrict Entry	9-41
Configure a Trap in the Server	9-41
Display the Traps Set in the Server	9-42
Remove a Trap (Configured or Otherwise) from the Server	9-42
10 SNMP (Simple Network Management Protocol)	10-1
Introduction	10-1
Configuring SNMP Parameters and Traps	10-2
Configuring a New Network Management Station	10-4
Viewing SNMP Statistics	10-8
Trap Tables	10-11
SNMP Standard Traps	10-15
Extended Traps	10-27

11	DNS Resolver and RMON	11-1
	Introduction	11-1
	Configuring the DNS Resolver	11-1
	The Names Submenu	11-1
	Remote Network Monitoring (RMON)	11-3
	Probes and Events	11-3
	Ethernet Probes	11-3
	History Probes	11-3
	Alarm Probes	11-3
	Monitoring Probes	11-4
	Monitoring Events	11-5
12	Managing Ethernet Ports	12-1
	The Ethernet Management Menus	12-3
	Configuring 10/100 Auto-Sensing Ethernet Ports	12-4
	Configuring High-Density Ethernet Ports	12-6
	Viewing Configurations for Ethernet Ports	12-7
	OmniChannel	12-8
	Creating an OmniChannel	12-9
	Adding Ports to an OmniChannel	12-10
	Deleting an OmniChannel	12-11
	Deleting Ports from an OmniChannel	12-12
	Viewing OmniChannel Parameters	12-13
13	Managing 802.1Q Groups	13-1
	IEEE 802.1Q Sections Not Implemented	13-2
	Application Example	13-3
	Single vs. Multiple Spanning Tree	13-4
	Assigning an 802.1Q Group to a Port	13-6
	Modifying 802.1Q Groups	13-8
	Viewing 802.1Q Groups in a Port	13-9
	Deleting 802.1Q Groups from a Port	13-10
14	Configuring Bridging Parameters	14-1
	Configuration Overview	14-2
	Bridge Management Menu	14-3
	Selecting a Default Group	14-5
	Using the + or - to Change Groups	14-5

Bridging Commands	14-6
Displaying Bridge Forwarding Table	14-6
Configuring a Static Bridge Address	14-8
Modifying a Static Bridge Address	14-9
Deleting a Static Bridge Address	14-10
Displaying Static Bridge Addresses	14-11
Displaying Bridge Port Statistics	14-12
Displaying Media Access Control (MAC)	
Information for a Specific MAC address	14-14
Displaying Media Access Control (MAC) Information for all MAC addresses	14-15
Display Statistics of Bridge MAC Addresses	14-15
Clear Statistics of Bridge MAC Addresses	14-16
Display Remote Trunking Stations	14-16
View the Domain Bridge Mapping Table	14-17
Setting Flood Limits	14-19
Setting Flood Limits for a Group	14-19
Displaying Group Flood Limits	14-20
Configuring Spanning Tree	14-21
Configuring Spanning Tree Parameters	14-22
Display Spanning Tree Bridge Parameters	14-25
Configuring Spanning Tree Port Parameters	14-27
Displaying Spanning Tree Port Parameters	14-29
Configuring Fast Spanning Tree	14-31
Truncating Tree Timing & Speedy Tree Protocol	14-32
Truncating Tree Timing	14-32
Speedy Tree Protocol	14-32
Configuring Truncating Tree Timing & Speedy Tree Protocol	14-32
Displaying Fast Spanning Tree Port Parameters	14-33
Enabling Fast Spanning Tree Port Parameters	14-35
Disabling Fast Spanning Tree Port Parameters	14-36
15 Configuring Frame Translations	15-1
Protocols other than IP and IPX	15-1
The SNAP Conversion	15-2
Other Conversions	15-2
Summary of Non-IPX Encapsulation Transformation Rules	15-2
IPX Encapsulation Transformation Rules	15-3
The Network Header	15-4
Address Mapping	15-4
Address Mapping in IP: ARP	15-4
Address Mapping in IPX	15-5

Frame Size Requirements	15-6
Insertion of Frame Padding	15-6
Stripping of Padding for all IEEE 802.3 Frames.	15-6
No stripping of non-IPX Ethertype Frames	15-6
IPX Specific Stripping	15-6
MTU Handling	15-6
IP Fragmentation	15-7
ICMP Based MTU Discovery	15-7
IPX Packet Size Negotiation	15-7
Other Protocols	15-7
Banyan Vines	15-8
Configuring Encapsulation Options	15-9
Forwarding versus Flooding	15-9
Port Based Translation Options	15-9
MAC Address Based Translation Options	15-9
“Native” versus “Non-Native” on Ethernet	15-10
No Translation on Trunk or PTOp ports	15-10
The User Interface	15-11
The addvp, modvp and crgp Commands	15-12
The Default Translation Option	15-12
Ethernet Factory Default Translations	15-13
ATM LANE Factory Default Translations	15-13
The Ethertype Option	15-14
The SNAP Option	15-15
The LLC Option	15-16
Interaction with the new interface	15-16
The “vi” Command	15-17
The Switch Menu	15-18
Factory Defaults	15-18
Default Ethernet Translations	15-19
Port Translations	15-20
Configuring Additional Ports	15-21
Displaying Ethernet Switch Statistics	15-21
Any to Any MAC Translations	15-25
Default Autoencapsulation	15-26
Translational Bridging	15-27
Learning	15-27
Translations across Trunks	15-27
Dissimilar LAN Switching Capabilities	15-28
Switching Between Similar LANs	15-28
Switching Between Ethernet LANs Across a Trunked Backbone	15-29
Switching Between Similar LANs across a Native Backbone	15-30

16 Managing Groups and Ports	16-1
How Ports Are Assigned to Groups	16-2
Static Port Assignment	16-2
Dynamic Port Assignment (Group Mobility)	16-2
How Dynamic Port Assignment Works	16-3
Mobile Groups	16-5
Configuring Mobile Groups	16-5
Turning Group Mobility On or Off	16-6
Understanding Port Membership in Mobile Groups	16-7
How a Device Is Dropped from the Default Mobile Group (def_group)	16-9
How a Port's Primary Mobile Group Changes (move_from_def)	16-10
How a Port Ages Out of a Mobile Group (move_to_def)	16-11
Configuring Switch-Wide Group Mobility Variables	16-12
Viewing Ports in a Mobile Group	16-14
Viewing a Port's Mobile Group Affiliations	16-14
Non-Mobile Groups and AutoTracker VLANs	16-15
Routing in a Non-Mobile Group	16-15
Spanning Tree and Non-Mobile Groups	16-16
Group and Port Software Commands	16-17
Creating a New Group	16-18
Step 1. Entering Basic Group Information	16-19
Step 2. Configuring the Virtual Router Port (Optional)	16-20
Step 3. Set Up Group Mobility and User Authentication	16-26
Step 4. Configuring Virtual Ports	16-27
Step 5. Configuring AutoTracker Policies (Mobile Groups Only)	16-33
Creating a WAN Routing Group	16-34
Viewing Current Groups	16-37
Modifying a Group or VLAN	16-39
Viewing Your Changes	16-40
Saving Your Changes	16-40
Canceling Your Changes	16-40
Changing the IP Address	16-40
Changing the IP Subnet Mask	16-40
Enabling IP or IPX Routing	16-41
Deleting a Group	16-42
Adding Virtual Ports	16-43
Modifying a Virtual Port	16-44
Deleting a Virtual Port	16-45
Viewing Information on Ports in a Group	16-46
Viewing Detailed Information on Ports	16-48
Viewing Port Statistics	16-51

Viewing Port Errors	16-53
Port Mirroring	16-55
How Port Mirroring Works	16-55
What Happens to the Mirroring Port	16-55
Using Port Mirroring With External RMON Probes	16-56
Setting Up Port Mirroring	16-58
Disabling Port Mirroring	16-58
Port Monitoring	16-59
Port Monitoring Menu	16-59
RAM Disk System for Data Capture Files	16-60
Configuring RAM Drive Resources (pmcfg)	16-60
Changing the Default System Directory (cd)	16-60
Starting a Port Monitoring Session (pmon)	16-61
If You Chose Dump to Screen	16-62
If You Did Not Choose Dump to Screen	16-62
Ending a Port Monitoring Session	16-63
Viewing Port Monitoring Statistics (pmstat)	16-63
Port Mapping	16-64
Groups/VLANs and Port Mapping	16-64
The Details of Port Mapping	16-65
Who Can Talk to Whom?	16-66
Port Mapping Limitations	16-66
Creating a Port Mapping Set	16-67
Adding Ports to a Port Mapping Set	16-68
Removing Ports from a Port Mapping Set	16-69
Viewing a Port Mapping Set	16-70
Deleting a Port Mapping Set	16-70
Priority VLANs	16-71
Configuring VLAN Priority	16-72
Viewing VLAN Priority	16-72
17 Configuring Group and VLAN Policies	17-1
AutoTracker Policy Types	17-2
Defining and Configuring AutoTracker Policies	17-4
Where These Procedures Start	17-4
Defining a Port Policy	17-5
Defining a MAC Address Policy	17-6
Defining a Protocol Policy	17-7
Defining a Network Address Policy	17-9
Defining Your Own Rules	17-11
Defining a Port Binding Policy	17-13
Defining a DHCP Port Policy	17-17
Defining a DHCP MAC Address Policy	17-18
Viewing Mobile Groups and AutoTracker VLANs	17-19

Viewing Policy Configurations	17-20
Viewing Virtual Ports' Group/VLAN Membership	17-21
View VLAN Membership of MAC Devices	17-22
Application Example: DHCP Policies	17-23
The VLANs	17-23
DHCP Servers and Clients	17-24
DHCP Port and MAC Rules	17-25
18 Interswitch Protocols	18-1
Interswitch Protocol Commands	18-1
XMAP	18-2
XMAP Transmission States	18-3
Discovery Transmission State	18-3
Common Transmission State	18-4
Passive Reception State	18-4
Common Transmission and Remote Switches	18-4
Configuring XMAP	18-5
Enabling or Disabling XMAP	18-5
Viewing a List of Adjacent Switches	18-5
Configuring the Discovery Transmission Time	18-6
Configuring the Common Transmission Time	18-7
VLAN Advertisement Protocol (VAP)	18-8
VAP and Port Policies	18-9
Configuring VAP	18-9
GMAP	18-10
GMAP Updating Rules	18-10
Configuring GMAP	18-11
Enabling and Disabling GMAP	18-11
Configuring the Gap Time	18-11
Configuring the Interpacket Update Time	18-12
Configuring the Hold Time	18-12
Displaying GMAP Statistics by MAC Address	18-13

19	Managing AutoTracker VLANs	19-1
	The AutoTracker Menu	19-2
	AutoTracker VLANs	19-3
	AutoTracker VLAN Policies	19-3
	The Default VLAN	19-4
	How Devices are Assigned to AutoTracker VLANs	19-5
	The defvl Command	19-5
	Devices that Generate a Secondary Traffic Type	19-6
	Router Traffic in IP and IPX Network Address VLANs	19-7
	Port Policy Functionality	19-9
	Frame Flooding in AutoTracker VLANs	19-15
	Routing Between AutoTracker VLANs	19-15
	Creating AutoTracker VLANs	19-16
	Step A. Entering Basic VLAN Information	19-16
	Step B. Defining and Configuring VLAN Policies	19-18
	Step C. Configuring the Virtual Router Port (Optional)	19-19
	Modifying an AutoTracker VLAN	19-24
	Deleting an AutoTracker VLAN	19-26
	Viewing AutoTracker VLANs	19-27
	Viewing Policy Configurations	19-28
	Viewing Virtual Ports' VLAN Membership	19-29
	View VLAN Membership of MAC Devices	19-30
	Creating a VLAN for Banyan Vines Traffic	19-31
20	Multicast VLANs	20-1
	How Devices are Assigned to Multicast VLANs	20-2
	Multicast VLANs and Multicast Claiming	20-2
	Frame Flooding in Multicast VLANs	20-3
	Creating Multicast VLANs	20-4
	Step A. Entering Basic Information	20-5
	Step B. Defining the Multicast Address	20-6
	Step C. Defining the Recipients of Multicast Traffic	20-7
	Defining Recipients By Port	20-7
	Defining Recipients By MAC Address	20-8
	Modifying Multicast VLANs	20-9
	Deleting a Multicast VLAN	20-11
	Modifying a Multicast Address Policy	20-12
	Viewing Multicast VLANs	20-13
	Viewing Multicast VLAN Policies	20-14
	Viewing the Virtual Interface of Multicast VLANs	20-15

21	AutoTracker VLAN Application Examples	21-1
	Application Example 1	21-2
	VLANs Based on Logical Policies	21-2
	Application Example 2	21-4
	VLANs in IPX Networks	21-4
	IPX VLAN Assignment at Bootup	21-5
	Application Example 3	21-7
	Routing in IPX Networks	21-7
	Application Example 4	21-9
	Traversing a Backbone	21-9
22	IP Routing	22-1
	Introduction	22-1
	IP Routing Overview	22-2
	Routing Protocols	22-2
	Transport Protocols	22-3
	Application-Layer Protocols	22-3
	Additional IP Protocols	22-3
	Setting Up IP Routing on the Switch	22-4
	The Networking Menu	22-6
	The IP Submenu	22-7
	Viewing the Address Translation (ARP) Table	22-8
	Displaying All Entries in the ARP Table	22-8
	Adding Entries to the ARP Table	22-9
	Deleting Entries from the ARP Table	22-10
	Flushing Temporary Entries from the ARP Table	22-10
	Finding a Specific IP Address in the ARP Table	22-10
	Finding a Specific MAC Address in the ARP Table	22-11
	Viewing IP Statistics and Errors	22-12
	Viewing the IP Forwarding Table	22-14
	Adding an IP Static Route	22-16
	Removing an IP Static Route	22-18
	Viewing ICMP Statistics and Errors	22-19
	Using the PING Command	22-21
	Viewing UDP Statistics and Errors	22-23
	Viewing the UDP Listener Table	22-24
	Viewing RIP Statistics and Errors	22-25
	Viewing TCP Statistics	22-26
	Viewing the TCP Connection Table	22-28

Using the TELNET Command	22-29
Cancelling a Telnet request	22-29
Tracing an IP Route	22-30
Flushing the RIP Routing Tables	22-31
Configuring IP RIP Filters	22-32
Adding a “Global” IP RIP Filter	22-32
Adding an IP RIP Filter For a Specific Group or VLAN	22-33
IP RIP Filter Precedence	22-34
Deleting IP RIP Filters	22-35
Displaying IP RIP Filters	22-36
Displaying a List of All IP RIP Filters	22-36
Displaying a List of “Global” IP RIP Filters	22-37
Displaying a List of Specific IP RIP Filters	22-37
Viewing the IP-to-MAC Address Table	22-38
Displaying All Entries in the IP-to-MAC Table	22-38
Displaying Information for a Specific IP Address	22-39
Flushing Entries from the Table	22-39
Enabling/Disabling Directed Broadcasts	22-40
Path MTU Discovery	22-41
23 UDP Forwarding	23-1
UDP Relay Hardware/Software Support	23-1
UDP Relay Configuration Screen	23-2
BOOTP/DHCP Relay	23-3
Overview of DHCP	23-3
DHCP and the OmniAccess 512	23-3
BOOTP/DHCP Relay and Authentication	23-4
External BOOTP Relay	23-5
Internal BOOTP/DHCP Relay	23-6
Example 1	23-6
Example 2	23-7
Enabling BOOTP/DHCP Relay	23-8
Configuring BOOTP/DHCP Relay Parameters	23-9
NetBIOS Relays	23-10
Overview of NetBIOS	23-10
NetBIOS Relay Application	23-11
Configuring NBNS Relay	23-12
Next-Hop Addresses for NBNS	23-13
Forwarding VLANs for NBNS Relay	23-14
Configuring NBDD Relay	23-15
Next-Hop Addresses for NBDD	23-16
Forwarding VLANs for NBDD Relay	23-17

Generic Service UDP Relay	23-18
Generic Services Menu	23-18
Adding a Generic Service	23-18
Modifying a Generic Service	23-20
Deleting a Generic Service	23-21
Viewing UDP Relay Statistics	23-22
24 IPX Routing	24-1
Introduction	24-1
IPX Routing Overview	24-2
IPX Protocols	24-2
Setting Up IPX Routing on the Switch	24-3
The IPX Submenu	24-4
Viewing the IPX Routing Table	24-5
Displaying All Entries in the IPX Routing Table	24-5
Using IPXR with Frame Relay or ISDN Boards	24-6
Displaying a List of Specific IPX Routes	24-7
Viewing IPX Statistics	24-8
Viewing the IPX SAP Bindery	24-10
Using IPXSAP with Frame Relay or ISDN Boards	24-11
Displaying a List of Specific SAP Servers	24-11
Adding an IPX Static Route	24-12
Removing an IPX Static Route	24-13
Turning the IPX Router Complex On and Off	24-14
Flushing the IPX RIP/SAP Tables	24-15
Using the IPXPING Command	24-16
Configuring IPX RIP/SAP Filtering	24-18
Adding a “Global” IPX RIP/SAP Filter	24-19
Adding an IPX RIP/SAP Filter for a Specific Group or VLAN	24-20
Deleting an IPX RIP/SAP Filter	24-22
Displaying IPX RIP/SAP Filters	24-23
Displaying a List of All IPX Filters	24-23
Displaying a List of “Global” IPX Filters	24-24
Displaying a List of Specific IPX Filters	24-24
IPX RIP/SAP Filter Precedence	24-25
Configuring IPX Serialization Packet Filtering	24-26
Enabling IPX Serialization Filtering	24-26
Disabling IPX Serialization Filtering	24-27
Configuring IPX Watchdog Spoofing	24-28
Enabling IPX Watchdog Spoofing	24-28
Disabling IPX Watchdog Spoofing	24-29

Configuring SPX Keepalive Spoofing	24-30
Enabling SPX Keepalive Spoofing	24-30
Disabling SPX Keepalive Spoofing	24-31
Controlling IPX Type 20 Packet Forwarding	24-32
Configuring NetWare to Minimize WAN Connections	24-33
Configuring RIP and SAP Timers	24-35
Adding a RIP and SAP Timer	24-35
Viewing RIP and SAP Timers	24-36
Configuring Extended RIP and SAP Packets	24-37
Enabling or Disabling Extended RIP and SAP Packets	24-37
Viewing the Current Status of Extended Packets	24-37
Configuring an IPX Default Route	24-38
Adding an IPX Default Route	24-38
Viewing the Status of an IPX Default Route	24-38
Disabling an IPX Default Route	24-38
25 Managing WAN Switching Submodules	25-1
Introduction	25-1
Type of Service (ToS)	25-3
Supported Physical Interfaces	25-5
Universal Serial Port	25-5
ISDN Basic Rate Interface Port	25-5
Fractional T1 Port	25-5
Fractional E1 Port	25-5
Supported Protocols	25-6
Application Examples	25-7
Frame Relay Using Serial Ports	25-7
Back-to-Back Using T1 Ports	25-8
Combined Frame Relay with ISDN Backup	25-8
WAN Submodules	25-9
Data Compression	25-10
Loopback Detection	25-10
The WAN Port Software Menu	25-11
Setting Configuration Parameters	25-11
Modifying a Port	25-12
Serial Port Example	25-12
ISDN-BRI Port Example	25-17
Fractional T1 Port Example	25-20
Viewing Configuration Parameters for the Submodule	25-24
Viewing Parameters for all Submodules in the Chassis	25-24
Viewing Parameters for all Ports in a Single Submodule	25-25
Viewing Port Parameters	25-26

Deleting Ports	25-33
Obtaining Status and Statistical Information	25-34
Obtaining Information on All Boards in a Switch	25-34
Obtaining Information on the Ports for a Single Submodule Board	25-36
Viewing Information on a Single Port	25-38
Configuring 31 Timeslots on a WAN E1 Port	25-40
26 Managing Frame Relay	26-1
Back-to-Back Frame Relay Configurations	26-2
Universal Serial Port Cable Interfaces	26-3
“Physical” and “Logical” Devices	26-3
Virtual Circuits and DLCIs	26-4
WAN Submodule Self-Configuration and Virtual Circuits	26-5
Congestion Control	26-6
Regulation Parameters	26-6
Discard Eligibility (DE) Flag	26-7
Interaction Among Congestion Parameters	26-7
Notification By BECN	26-8
Notification By FECN	26-9
Frame Formats Supported	26-10
Bridging Services	26-11
Frame Relay IP Routing	26-12
The Frame Relay Subnet and “Split Horizon”	26-13
Frame Relay IPX Routing	26-15
Trunking	26-16
The Frame Relay Software Menu	26-17
Setting Configuration Parameters	26-18
Modifying a Port	26-18
Modifying a Virtual Circuit	26-24
Adding a Virtual Circuit	26-27
Viewing Configuration Parameters for the WAN Submodule	26-28
Viewing Parameters for all WAN submodules in the Chassis	26-28
Viewing Port Parameters	26-29
Viewing Virtual Circuit Parameters	26-30
Deleting Ports and Virtual Circuits	26-31
Deleting a Virtual Circuit	26-31
Deleting a Port and Its Virtual Circuits	26-32

Obtaining Status and Statistical Information	26-33
Information on All Boards in a Switch	26-33
Information on the Ports for One WAN submodule Board	26-36
Information on One Port	26-37
Information on One Virtual Circuit	26-44
Resetting Statistics Counters	26-47
Resetting Statistics for a WAN submodule Board	26-47
Resetting Statistics for a WAN submodule Port	26-47
Resetting Statistics for a Virtual Circuit (DLCI)	26-47
Managing Frame Relay Services	26-48
Configuring a Bridging Service	26-50
Configuring a WAN Routing Service	26-52
Step 1. Set Up a Frame Relay Routing Group	26-52
Step 2. Set Up a Frame Relay Routing Service	26-53
Configuring a Trunking Service	26-55
Viewing Frame Relay Services	26-57
Modifying a Frame Relay Service	26-58
Deleting a Frame Relay Service	26-59
27 Point-to-Point Protocol	27-1
PPP Connection Phases	27-1
Data Compression	27-2
Multi-Link PPP	27-2
Multilink Modes of Operation	27-3
PPP Fragmentation Interleaving	27-3
Overview of PPP Configuration Procedures	27-4
The PPP Submenu	27-6
PPP Configuration Overview	27-6
Setting Global PPP Parameters	27-7
Adding a PPP Entity	27-9
Modifying a PPP Entity	27-15
Viewing PPP Entity Configurations	27-16
Displaying the Configuration of All PPP Entities	27-16
Displaying the Configuration of a Specific PPP Entity	27-18
Displaying PPP Entity Status	27-19
Displaying the Status of All PPP Entities	27-19
Displaying the Status of a Specific PPP Entity	27-20
Deleting a PPP Entity	27-22

28	WAN Links	28-1
	Introduction	28-1
	Configuring WAN Interfaces	28-1
	The Link Submenu	28-2
	Adding a WAN Link	28-3
	Adding WSM Port Links	28-3
	Adding ISDN Call Links	28-4
	Modifying a WAN Link	28-9
	Modifying ISDN Links	28-9
	Modifying WSM Links	28-10
	Deleting WAN Links	28-11
	Viewing WAN Links	28-12
	Displaying All Existing WAN Links	28-12
	Displaying Information for a Specific WAN Link	28-13
	Displaying Link Status	28-15
	Displaying Status for All WAN Links	28-15
	Displaying Status for a Specific WAN Link	28-16
29	Managing ISDN Ports	29-1
	Overview of ISDN	29-1
	Basic Rate Interface (BRI) Versus Primary Rate Interface (PRI)	29-1
	“U”, “S/T”, and “R” Interfaces	29-2
	The “B,” “D,” and “H” Channels	29-2
	The ISDN Submenu	29-3
	Switch Configuration	29-3
	Modifying an ISDN Configuration Entry	29-4
	Deleting an ISDN Configuration Entry	29-5
	Viewing an ISDN Configuration Entry	29-6
	Displaying ISDN Configuration Entry Status	29-7
	Displaying Status of All ISDN Ports	29-7
	Displaying Status of a Specific ISDN Slot	29-8
	Displaying Status of a Specific ISDN Port	29-9
30	Managing T1 and E1 Ports	30-1
	T1 and E1 Overview	30-2
	The T1/E1 Menu	30-3
	Configuring a T1 Port	30-4
	Configuring an E1 Port	30-7

Viewing T1/E1 Configuration and Alarm Information	30-10
Viewing Information for all T1/E1 Ports in the Switch	30-10
Viewing Information for T1/E1 Ports	30-11
Viewing Information For a T1 Port	30-12
Viewing Information For an E1 Port	30-14
Viewing T1/E1 Local Statistics	30-16
Viewing Total Local Statistics	30-16
Viewing Current Local Statistics	30-17
Viewing Local Historical Statistics	30-18
Viewing T1 Remote Statistics	30-19
Viewing Total Remote Statistics	30-19
Viewing Current Remote Statistics	30-20
Viewing Remote Historical Statistics	30-20
Clearing the Framer Statistics for a T1/E1 Port	30-21
Running Bit Error Ratio Tests (BERT)	30-22
Displaying BERT Statistics	30-25
Clearing BERT Statistics	30-25
Configuring Port Type (T1/E1)	30-26
31 Backup Services	31-1
Introduction	31-1
Backup Services Commands	31-2
Accessing the Backup Services Menu	31-2
Adding a Backup Service	31-3
Adding a backup for a Physical Port	31-3
Backing Up a Frame Relay PVC	31-6
Modifying a Backup Service	31-8
Modifying a backup for a Physical Port	31-8
Modifying a Frame Relay PVC Backup Service	31-9
Viewing Backup Service(s) Configurations	31-10
Viewing the Configurations of All Backup Services	31-10
Viewing the Configuration of a	
Single Backup Service (bsview Command)	31-10
Deleting a Backup Service	31-10
Viewing Backup Service Statistics	31-11
Clearing Backup Service Statistics	31-12

32 Troubleshooting	32-1
Introduction	32-1
Detecting Problems	32-1
Reporting Problems	32-2
Software Problems	32-2
Can't Install Software	32-2
Operational Problems	32-2
Hardware Problems	32-5
Error Messages	32-7
Chassis Error Messages	32-10
33 Running Hardware Diagnostics	33-1
Introduction	33-1
Getting Started	33-3
Accessing the Diagnostics Submenu	33-4
Temperature Masking	33-5
Initiating Hardware Tests	33-6
Port Test Wrap Cable/Plug Requirements	33-8
Sample Test Session	33-9
If You Do Not Run Port Tests	33-11
Displaying Available Diagnostic Tests	33-12
Configuring the Diagnostic Test Environment	33-13
Configuring Tests for Ethernet Slots	33-14
Diagnostic Test Cable Schematics	33-15
A The Boot Line Prompt	A-1
Entering the Boot Prompt	A-2
Boot Prompt Basics	A-3
Resuming Switch Boot (@)	A-3
Displaying Current Configuration (p)	A-4
Loading the Last Configured Boot File (l)	A-4
Listing Available Files in the Flash Memory (L)	A-4
Deleting All Files in the Flash Memory (P)	A-5
Deleting Specific Files in the Flash Memory (R)	A-5
Saving Configuration Changes (S)	A-5
Viewing Version Number (V)	A-5
Configuring an OmniAccess 512	A-6

B OmniAccess Pinouts and Custom Cables	B-1
OmniAccess Pinouts	B-2
Console Management Port (DB-9 Connector)	B-2
Ethernet Port (RJ-45 Connector)	B-2
WAN T1/E1 Port (RJ-48C Connector)	B-2
WAN Universal Serial Port	B-3
WAN Universal Serial Port Specifications	B-4
OmniAccess Custom Cables	B-6
V.35 DTE Cable (For Alcatel Serial Port-to-DCE Device Connection)	B-6
V.35 DCE Cable (For Alcatel Serial Port-to-DTE Device Connection)	B-7
RS232 DTE Cable (For Alcatel Serial Port-to-DCE Device Connection)	B-8
RS232 DCE Cable (For Alcatel Serial Port-to-DTE Device Connection)	B-9
RS530 DTE Cable (For Alcatel Serial Port-to-DCE Device Connection)	B-10
RS530 DCE Cable (For Alcatel Serial Port-to-DTE Device Connection)	B-11
X.21 DTE Cable (For Alcatel Serial Port-to-DCE Device Connection)	B-12
X.21 DCE Cable (For Alcatel Serial Port-to-DTE Device Connection)	B-13
RS449 DTE Cable (For Alcatel Serial Port-to-DCE Device Connection)	B-14
RS-449 DCE Cable Assembly (For Alcatel Serial Port-to-DTE Device 75W Connection)	B-15
RJ-45 to DB15F Cable Assembly (For T1/E1 Port 120W Connections)	B-16
RJ-45 to BNC Cable Assembly (For E1 75W Port Connections)	B-17
Index	I-1