

Panasonic

Multi-Function Laser Fax Operating Instructions

Model No. **KX-FLM551**



FOR FAX ADVANTAGE ASSISTANCE:

– CALL

1-800-HELP-FAX (1-800-435-7329)

– E-MAIL TO

consumerproducts@panasonic.com

for customers in the U.S.A. or Puerto Rico

– REFER TO

www.panasonic.com

for customers in the U.S.A. or Puerto Rico

Please read these Operating Instructions before using the unit and save for future reference.

This model is designed to be used only in the U.S.A.

Thank you for purchasing a Panasonic facsimile.

Things you should keep a record of

Attach your sales receipt here

For your future reference

Date of purchase

Serial number

(found on the rear of the unit)

Dealer's name and address

Dealer's telephone number

Caution:

- The Telephone Protection Act of 1991 requires the following information to be clearly stated either at the top or bottom margin of the first message page when transmitting messages via telephone facsimile:
 - date and time of transmission,
 - identification of the business, entity or person(s) sending the facsimile, and
 - telephone number of the business, entity or person(s).To program this information into your unit, complete all the instructions on pages 15 to 18.
- Do not rub or use an eraser on the printed side of recording paper, as the print may smear.

Energy Star

As an ENERGY STAR® Partner, Panasonic has determined that this product meets the ENERGY STAR guidelines for energy efficiency. ENERGY STAR is a U.S. registered mark.



Trademarks

- Microsoft and Windows are either registered trademarks or trademarks of Microsoft Corporation in the United States and/or other countries.
- Pentium is a registered trademark or trademark of Intel Corporation in the United States and/or other countries.
- 3M is a trademark or registered trademark of Minnesota Mining and Manufacturing Company.
- Avery is a registered trademark of Avery Dennison Corporation.
- XEROX is a registered trademark of Xerox Corporation.
- All other trademarks identified herein are the property of their respective owners.

Copyright:

This manual is copyrighted by Kyushu Matsushita Electric Co., Ltd. (KME) and its licensee. Under the copyright laws, this manual may not be reproduced in any form, in whole or part, without the prior written consent of KME and its licensee.

© Kyushu Matsushita Electric Co., Ltd. 2001

Important safety instructions

When using this unit, basic safety precautions should always be followed to reduce the risk of fire, electric shock, or personal injury.

1. Read and understand all instructions.
2. Follow all warnings and instructions marked on this unit.
3. Unplug this unit from power outlets before cleaning. Do not use liquid or aerosol cleaners. Use a damp cloth for cleaning.
4. Do not use this unit near water, for example near a bathtub, wash bowl, kitchen sink, or the like.
5. Place the unit securely on a stable surface. Serious damage and/or injury may result if the unit falls.
6. Do not cover slots and openings on the unit. They are provided for ventilation and protection against overheating. Never place the unit near radiators, or in a place where proper ventilation is not provided.
7. Use only the power source marked on the unit. If you are not sure of the type of power supplied to your home, consult your dealer or local power company.
8. For safety purposes this unit is equipped with a grounded plug. If you do not have this type of outlet, please have one installed. Do not defeat this safety feature by tampering with the plug.
9. Do not place objects on the power cord. Install the unit where no one can step or trip on the cord.
10. Do not overload wall outlets and extension cords. This can result in the risk of fire or electric shock.
11. Never push any objects through slots in this unit. This may result in the risk of fire or electric shock. Never spill any liquid on the unit.
12. To reduce the risk of electric shock, do not disassemble this unit. Take the unit to an authorized service center when service is required. Opening or removing covers may expose you to dangerous voltages or other risks. Incorrect reassembly can cause electric shock when the unit is subsequently used.
13. Unplug this unit from the wall outlet and refer servicing to an authorized service center when the following conditions occur:
 - A. When the power supply cord or plug is damaged or frayed.

- B. If liquid has been spilled into the unit.
 - C. If the unit has been exposed to rain or water.
 - D. If the unit does not work normally by following the operating instructions. Adjust only controls covered by the operating instructions. Improper adjustment may require extensive work by an authorized service center.
 - E. If the unit has been dropped or physically damaged.
 - F. If the unit exhibits a distinct change in performance.
14. During thunderstorms, avoid using telephones except cordless types. There may be a remote risk of an electric shock from lightning.
 15. Do not use this unit to report a gas leak, when in the vicinity of the leak.

SAVE THESE INSTRUCTIONS

INSTALLATION:

- Never install telephone wiring during a lightning storm.
- Never install telephone jacks in wet locations unless the jack is specifically designed for wet locations.
- Never touch uninsulated telephone wires or terminals unless the telephone line has been disconnected at the network interface.
- Use caution when installing or modifying telephone lines.

WARNING:

- To prevent the risk of fire or electrical shock, do not expose this product to rain or any type of moisture.

OTHER INFORMATION:

- Keep the unit away from electrical noise generating devices, such as fluorescent lamps and motors.
- The unit should be kept free from dust, high temperature and vibration.
- The unit should not be exposed to direct sunlight.
- Do not place heavy objects on top of this unit.
- Do not touch the plug with wet hands.


Safety instructions

CAUTION:

Laser radiation

- The printer of this unit utilizes a laser. Use of controls or adjustments or performance of procedures other than those specified herein may result in hazardous radiation exposure.

DANGER-Invisible laser radiation when open and interlock defeated.
AVOID DIRECT EXPOSURE TO BEAM.



Fuser unit

- The fuser unit gets hot. Do not touch it.

Toner cartridge


- Be careful of the following when you handle the toner cartridge.
 - Do not leave the toner cartridge out of the protection bag for a long time. It will decrease the toner life.
 - If you ingest any toner, drink several glasses of water to dilute your stomach contents, and seek immediate medical treatment.
 - If any toner comes into contact with your eyes, flush them thoroughly with water, and seek medical treatment.
 - If any toner comes into contact with your skin, wash the area thoroughly with soap and water.

Drum unit




- Read the instructions on pages 10 and 11 before you begin installation of the drum unit. After you have read them, open the drum unit protection bag. The drum unit contains a photosensitive drum. Exposing it to light may damage the drum. Once you have opened the protection bag:
 - Do not expose the drum unit to light for more than 5 minutes.
 - Do not touch or scratch the green drum surface.
 - Do not place the drum unit near dust or dirt, or in a high humidity area.
 - Do not expose the drum unit to direct sunlight.

Static electricity

- To prevent static electricity damage to the interface connectors (parallel and USB) or other electrical components inside the unit, touch a grounded metal surface, such as the metal part under the parallel interface connector before touching the components.



Included accessories

Power cord.....1  Part No. PFJA1030Z	Telephone line cord...1  Part No. PQJA10075Z	Handset.....1  Part No. PFJXE0805Z	Handset cord.....1  Part No. PFJA1029Z
Paper stacker.....1  Part No. PFZX1FL501M	Document stacker ...1  Part No. PFKS1055Z	Paper tray1  Part No. PFZXFLM551M	Operating instructions...1  Part No. PFQX1598Z
CD-ROM.....1  Part No. PFJKFLM551Z	Drum unit.....1  Model No. KX-FA77D	Toner cartridge.....1 (complementary starter toner cartridge)  This cartridge can print approx. 800 sheets of letter size paper with a 5% image area. Refer to image area on page 76. Please purchase a replacement toner cartridge Model No. KX-FA76 for continuous use of your unit. See below for accessory information.	

- If any items are missing or damaged, check with the place of purchase.
- Save the original carton and packing materials for future shipping and transportation of the unit.
- The part numbers listed above are subject to change without notice.
- As for CD-ROM, you will receive the latest Multi-Function Station software. If your PC is not equipped with a CD-ROM drive, you can purchase the following floppy disks:
 - Part No. PFJFFLM551Z: Multi-Function Station software (without Readiris Pro OCR software) on floppy disks
 - Part No. PFJFFLM551Y: Readiris Pro OCR software on floppy disks
 To order, see below.

Accessory information

Model No.	Item	Usage	Specifications
KX-FA76	Toner cartridge	For replacement, see page 64.	See page 76.
KX-FA77D*	Drum unit	For replacement, see page 64.	See page 76.

* **DO NOT** purchase Model No. KX-FA77 (without "D"). It does not apply for this fax machine.

- To place an order:
 - Telephone:** Call 1-800-332-5368.
 - Fax:** Send a fax to 1-800-237-9080.
 Include: — your name, shipping address and telephone number,
 — credit card type, number, expiration date and your signature,
 — order model number/part number and quantity.
 - Internet:** Visit our web site: <http://www.panasonic.com/store>
 (for customers in the U.S.A. or Puerto Rico ONLY)
- If you have any questions about internet orders, please contact us at:
 - E-mail:** panasonicdirect@panasonic.com
 - Telephone:** 1-201-348-7292

For fax advantage assistance, call 1-800-435-7329.

Table of Contents

Initial Preparation

Accessories	Included accessories	5
	Accessory information	5
Help Button	Help function	8
Finding the Controls	Overview	8
	Location	9
Setup	Toner cartridge and drum unit	10
	Document stacker, paper stacker and paper tray	12
	Recording paper	13
	Connections	14
	Date and time, your logo and facsimile telephone number	15
Volume	Adjusting volume	19

Telephone

Automatic Dialing	Storing names and telephone numbers into one-touch dial	20
	Storing names and telephone numbers into JOG DIAL	21
	Editing a stored entry	22
	Erasing a stored entry	22
	Making a phone call using one-touch dial and JOG DIAL	23
Caller ID	Caller ID service from your phone company	24
	Viewing and calling back using caller information	25
	Storing caller information into one-touch dial and JOG DIAL	27

Fax

Sending Faxes	Sending a fax manually	28
	Documents you can send	29
	Sending a fax using one-touch dial and JOG DIAL	30
	Broadcast transmission	31
Receiving Faxes	Setting the unit to receive faxes	34
	TEL mode (answering all calls manually)	36
	FAX ONLY mode (all calls are received as faxes)	37
	Using the unit with an answering machine	38
	Extension telephone	39
Distinctive Ring	Using with a voice mail service	40

Copy

Copying	Making a copy	41
----------------	-------------------------	----

Multi-Function Station software

Setup (PC)	Connecting to a computer	43
	Installing Multi-Function Station software	44
	Activating Multi-Function Station software	45
Printing (PC)	Using the fax machine as a printer	46
Scanning (PC)	Using the fax machine as a scanner	49
Remote Control (PC)	Operating the fax machine from your computer	50

Programmable Features

Features Summary	Programming.	51
	Basic features	52
	Advanced features.	54

Help

Error Messages	Reports.	57
	Display	58
Operations	When a function does not work, check here before requesting help	60
	If a power failure occurs	63
Replacement	Replacing the toner cartridge and the drum unit	64
Jams	Recording paper jam.	66
	Document jams - sending	68
	No feeding or multiple feeding occurs while sending	68
Cleaning	Cleaning the inside of the unit.	69

General Information

Printed Reports	Reference lists and reports	71
FCC Information	List of FCC requirements and information	72
Limited Warranty	PANASONIC Facsimile Products Limited Warranty	73
Servicenter Directory	Servicenter directory	74
Specifications	Technical data about this product	75
Index	Program index.	77
	Index.	78

Help Button / Finding the Controls

Help function

You can print a quick reference for assistance as follows.

1 Press **HELP**.

Display:

2 Rotate **JOG DIAL** until the desired item is displayed.

1. How to set the date, time, your logo and fax number.

2. How to program the features.

3. How to store names in the JOG DIAL directory and how to dial them.

4. Help with problems sending/receiving faxes.

5. How to use the copier function.

6. Frequently asked questions and answers.


7. Explanation of error messages shown on the display.

8. List of available reports.

9. How to use the Caller ID service.

3 Press **SET**.

Overview



Location

-
- To turn on/off AUTO ANSWER (p. 34, 35).
 - To make a collated copy (p. 42).
 - To use one-touch dial (p. 20, 23, 30).
 - To transmit to multiple entries (p. 31, 33).
 - To print a quick reference (p. 8).
 - To store a scanned document into memory, and then send it (p. 28).
 - To adjust volume (p. 19).
 - To select an enlargement or reduction rate in copy mode (p. 42).
 - To select a resolution (p. 28, 41).
 - To dial without lifting the handset.
 - To access special telephone services such as call waiting or for transferring extension calls.
 - To mute your voice to the other party during a conversation. Press this button again to resume the conversation.
 - To redial the last number dialed.
 - To insert a pause during dialing.
 - To initiate or exit programming.
 - To store or edit names and telephone numbers (p. 20–22).
 - To search for a stored name (p. 23, 30).
 - To select the features or feature settings during programming (p. 51).
 - To confirm a stored telephone number (p. 23).
 - To use caller ID service (p. 25–27).
 - To initiate fax transmission or reception.
 - To store a setting during programming.
 - To initiate copying (p. 41).
 - To stop an operation or cancel programming.
 - To select stations 6–10 for one-touch dial (p. 20, 23, 30).


Setup

Toner cartridge and drum unit


Caution:

- Read the instructions below before you begin installation. After you have read them, open the drum unit protection bag. The drum unit contains a photosensitive drum. Exposing it to light may damage the drum. Once you have opened the protection bag:
 - Do not expose the drum unit to light for more than 5 minutes.
 - Do not touch or scratch the green drum surface.
 - Do not place the drum unit near dust or dirt, or in a high humidity area.
 - Do not expose the drum unit to direct sunlight.
- Do not leave the toner cartridge out of the protection bag for a long time. It will decrease the toner life.


- 1** Remove the toner cartridge and drum unit from the protection bags. Peel off the seal from the toner cartridge (①). Remove the protection bar from the drum unit (②).




- 2** With "Panasonic" face up on the toner cartridge, match the red arrows on the cartridge and the drum unit.




- 3** Slide the tab on the toner cartridge into the slot of the drum unit.




- 4a** Firmly press down on the right side of the toner cartridge to snap into position and...




- 4b** turn the two levers on the toner cartridge with firm pressure.




- 5** The toner cartridge is installed when the triangles match.



- 6** Tap on the toner cartridge several times to allow the toner to fall into the drum unit. Grab the tabs, and shake the drum and toner unit horizontally several times.





- 7** Push the front cover open button then open the front cover.




- 8** Install the drum and toner unit by holding the tabs.

- If the lower glass is dirty, clean it with a soft and dry cloth.



- 9** Close the front cover, until locked, by pushing down on both sides.



Toner save feature

- If you want to save on toner consumption, set the toner save setting to on (feature #79 on page 56). The toner cartridge will last approx. 40% longer. This feature may lower the print quality.


Setup

Document stacker, paper stacker and paper tray

Document stacker

Align with the ribs on the document exit (①).

Pull the document stacker forward gently until it clicks into place (②).




Paper stacker

Line up the slots in the paper stacker with the pegs on the bottom of the unit, then slide until locked.

Open the paper stacker extender when using legal size paper.


- The paper stacker can hold up to approx. 100 sheets of printed paper. Remove the printed paper before the paper stacker becomes full.



Paper tray

Insert the tabs on the paper tray into the two slots on the back of the unit (①).

Let it lean back until it clicks into place (②).



Note for installation:


- Do not place the unit in an area where the paper tray may be obstructed (i.e. by a wall, etc.).
- Document and recording paper will be ejected from the front of the unit. Do not place anything in front of the unit.

Recording paper


Letter, legal or A4 size recording paper can be used for fax messages. The unit can hold up to 150 sheets of 60 g/m² to 75 g/m² (16 lb. to 20 lb.) paper or 120 sheets of 90 g/m² (24 lb.) paper. See the note for paper specifications on page 76.

- The unit is set for letter size paper by default. If you want to use legal or A4 size paper, change the setting (feature #16 on page 53).



- 1** Pinch the right side of the recording paper guide, then slide it open to its full width.



- 2** Fan the stack of paper to prevent a paper jam.




- 3** Insert the paper into the recording paper entrance.
 - The paper should not be over the tab.
 - If the paper is not inserted correctly, readjust the paper, or the paper may jam.



- 4** Adjust the width of the guides to the size of the recording paper by sliding the right recording paper guide.

Adding paper


1. Remove all of the installed paper.
2. Add paper to the stack of paper you removed and straighten.
3. Follow steps 1 to 4 above.



Setup

Connections

- 1 Connect the handset cord.
- 2 Connect the telephone line cord.
- 3 Connect the power cord.
 - When the power is turned on for the first time, the unit will print some basic information.



Caution:

- When you operate this product, the power outlet should be near the product and easily accessible.

Note:


- The warranty does not cover damage due to power line surges or lightning. For additional equipment protection, we recommend the use of a surge protector. The following types are available: TELESPIKE BLOK MODEL TSB (TRIPPE MFG. CO.), SPIKE BLOK MODEL SK6-0 (TRIPPE MFG. CO.), SUPER MAX (PANAMAX) or MP1 (ITW LINX).
- You can connect an answering machine or extension telephone to the external telephone jack (EXT) on this unit (p. 38, 39).

To use the fax machine with a computer on the same line

- We recommend you use separate wall jacks for the fax machine and the computer.
- Set the fax machine to TEL mode (p. 36).
- The device which has the shortest ring setting will answer the call first.
- If the computer provides a port for a telephone line, connect the fax machine to this port on the computer.

Date and time, your logo and facsimile telephone number

You should program the date and time, your logo and facsimile telephone number. This information will be printed on each page transmitted from your unit.



Setting the date and time

1 Press **MENU**.
Display: SYSTEM SET UP

2 Press **#**, then **01**.
SET DATE & TIME

3 Press **SET**.
Example: M:01/D:01/Y:01
Cursor


4 Enter the correct month/day/year by selecting 2 digits for each, using the dial keypad.
Example: August 10, 2001
Press **08 10 01**.
M:08/D:10/Y:01

5 Press **SET**.
Example: TIME: 12:00AM

6 Enter the correct hour/minute by selecting 2 digits for each, using the dial keypad. Press ***** to select "AM" or "PM".
Example: 3:15PM
1. Press **03 15**.
TIME: 03:15AM
2. Press ***** until "PM" is displayed.
TIME: 03:15PM

7 Press **SET**.
SETUP ITEM []

8 Press **MENU**.



Note:

- You can enter the number by rotating **JOG DIAL** in steps 4 and 6. In this case, press **▶** to move the cursor.
- The accuracy of the clock is approximately ± 60 seconds a month.

To correct a mistake

- Press **▶** or **◀** to move the cursor to the incorrect number, and make the correction.

Setup

Setting your logo

The logo can be your company, division or name.

1 Press **MENU**.
Display: SYSTEM SET UP

2 Press **▣**, then **0 2**.
YOUR LOGO

3 Press **SET**.
LOGO=

4 Enter your logo, up to 30 characters, using the dial keypad. See the next page for details.

Example: "Bill"

1. Press **2** 2 times.

LOGO=B
Cursor

2. Press **4** 6 times.

LOGO=Bi

3. Press **5** 6 times.


LOGO=Bi

4. Press **▶** to move the cursor to the next space and press **5** 6 times.

LOGO=Bill

5 Press **SET**.
SETUP ITEM []

6 Press **MENU**.



To change capital or lower case letters

Pressing the **▣** key will change to capital or lower case alternatively.

1. Press **2** 2 times.

Display: LOGO=B

2. Press **4** 3 times.

LOGO=Bi

3. Press **▣**.

LOGO=Bi

4. Press **5** 3 times.

LOGO=Bi

To correct a mistake

• Press **▶** or **◀** to move the cursor to the incorrect character, and make the correction.

To delete a character

• Move the cursor to the character you want to delete and press **STOP** (Delete).

To insert a character

1. Press **▶** or **◀** to move the cursor to the position to the right of where you want to insert the character.

2. Press **HANDSET MUTE** (Insert) to insert a space and enter the character.

Note:

• You can enter your logo by rotating **JOG DIAL** (see the next page) in step 4. In this case, press **▶** to move the cursor.

To select characters with the dial keypad


Pressing the dial keys will select a character as shown below.

Keys	Characters
1	1 [] { } + - / = , . _ ` : ; ?
2	A B C a b c 2
3	D E F d e f 3
4	G H I g h i 4
5	J K L j k l 5
6	M N O m n o 6
7	P Q R S p q r s 7
8	T U V t u v 8
9	W X Y Z w x y z 9
0	0 () < > ! " # \$ % & ¥ * @ ^ ' →
⌘	To change capital or lower case letter.
FLASH	Hyphen button (To insert a hyphen.)
HANDSET MUTE	Insert button (To insert one character or one space.)
STOP	Delete button (To delete a character.)
▶	▶ key (To move the cursor to the right.) To enter another character using the same number key, move the cursor to the next space.
◀	◀ key (To move the cursor to the left.)


To select characters using JOG DIAL

Instead of pressing the dial keys, you can select characters using JOG DIAL.

1. Rotate **JOG DIAL** until the desired character is displayed.
2. Press ▶ to move the cursor to the next space.
 - The character displayed in step 1 is inserted.
3. Return to step 1 to enter the next character.



Display order of characters



Setup

Setting your facsimile telephone number

1 Press **MENU**.
Display: SYSTEM SET UP


2 Press **[+]**, then **03**.
YOUR FAX NO.

3 Press **SET**.
NO. =

4 Enter your facsimile telephone number, up to 20 digits, using the dial keypad.
Example: NO. =1234567

5 Press **SET**.
SETUP ITEM []

6 Press **MENU**.



Note:

- You can enter your facsimile telephone number by rotating **JOG DIAL** in step 4. In this case, press **[▶]** to move the cursor.
- The **[*]** button replaces the digit with a "+" and the **[+]** button replaces it with a space.
Example (using the dial keypad): +234 5678
Press **[*][2][3][4][+][5][6][7][8]**.
- To enter a hyphen in a telephone number, press **FLASH** (Hyphen).

To correct a mistake

- Press **[▶]** or **[◀]** to move the cursor to the incorrect number, and make the correction.

To delete a number

- Move the cursor to the number you want to delete and press **STOP** (Delete).

Adjusting volume

Ringer volume

4 levels (high/middle/low/off) are available.

While the unit is idle, press  or .

- If any documents are in the document entrance, you cannot adjust the ringer volume. Confirm that there are no documents in the entrance.

To turn the ringer off:

1. Press  repeatedly until the following is displayed.

Display:

RINGER OFF= OK?



YES : SET / NO : STOP

2. Press **SET**.


RINGER OFF

- To turn the ringer back on, press .

While the ringer volume is set to off:

When a call is received, the unit will not ring and will display the following.

INCOMING CALL



Ringer pattern

- You can select one of three ringer patterns. Change the setting (feature #17 on page 53). The ringer pattern you selected will sound when the unit receives a call.

Handset receiver volume

5 levels (high to low) are available.

While using the handset, press  or .

Monitor volume

8 levels (high to low) are available.

While using the monitor, press  or .


Automatic Dialing

Storing names and telephone numbers into one-touch dial

For rapid access to frequently dialed numbers, the unit provides 10 entries for one-touch dial.

- Stations 1 to 3 can be used alternatively as broadcast keys (p. 31).

1 Press **DIRECTORY PROGRAM**.



2 For stations 1–3:
Press one of the station keys.




Press **SET** to go to the next prompt.


For stations 4–5:
Press one of the station keys.

For stations 6–10:
Press **LOWER**, then press one of the station keys.


3 Enter the name, up to 10 characters (see page 17 for instructions).



4 Press **SET**.




5 Enter the telephone number, up to 30 digits, using the dial keypad.




- If you want to enter a hyphen, press **FLASH** (Hyphen).

6 Press **SET**.



- To program other entries, repeat steps 2 to 6.

7 Press **STOP** to exit the program.
• If you press **DIRECTORY PROGRAM** instead of **STOP**, you can print the one-touch label card (see right).



Helpful hint:

- You can confirm the stored entries on the display (p. 23) or on the telephone number list (p. 71).

Note:

- A hyphen or a space entered in a telephone number counts as two digits.

To correct a mistake


- Press **▶** or **◀** to move the cursor to the incorrect character/number, and then make the correction.

To delete a character/number

- Move the cursor to the character/number you want to delete, and press **STOP** (Delete).

To print the one-touch label card with stored names

Press **DIRECTORY PROGRAM** in step 7.



Press **SET** to start printing.

- Put the card in the one-touch dial location.

Storing names and telephone numbers into JOG DIAL

For rapid access to frequently dialed numbers, the unit provides a JOG DIAL directory (100 entries).

1 Press **DIRECTORY PROGRAM**.

Display:

↑

2 Rotate **JOG DIAL** until the following is displayed.

3 Enter the name, up to 10 characters (see page 17 for instructions).

Example:

4 Press **SET**.

5 Enter the telephone number, up to 30 digits, using the dial keypad.

Example:

- If you want to enter a hyphen, press **FLASH** (Hyphen).

6 Press **SET**.


↓

- To program other entries, repeat steps 3 to 6.

7 Press **DIRECTORY PROGRAM** to exit the program.

Helpful hint:

- For your convenience, **HELP-FAX (1-800-435-7329)** has been pre-programmed. If you cannot solve a problem after trying the help function (p. 8), call using this entry (p. 23). If unnecessary, you can erase it (p. 22).
- You can confirm the stored entries on the display (p. 23) or on the telephone number list (p. 71).



Note:

- When the following is displayed in step 6, you can store only 5 more entries.

Display:

- If there is no space to store new entries, the following is displayed in step 1.

Erase unnecessary entries (p. 22).

- A hyphen or a space entered in a telephone number counts as two digits.

To correct a mistake

- Press **▶** or **◀** to move the cursor to the incorrect character/number, and then make the correction.

To delete a character/number

- Move the cursor to the character/number you want to delete, and press **STOP** (Delete).

Automatic Dialing

Editing a stored entry

You can edit a name or number that is stored in one-touch dial and JOG DIAL.

- 1** Rotate **JOG DIAL** until the desired name is displayed.

Example:

Mary	<S01>
------	-------

Station key number
for one-touch dial

- 2** Press **DIRECTORY PROGRAM**.

EDIT=* DELETE=#

- 3** Press ***** to select "EDIT".

Example:

NAME=Mary

- If you do not need to edit the name, skip to step 5.

- 4** Edit the name (see page 17 for instructions).

- 5** Press **SET**.

Example:


<S01>=0123456

- If you do not need to edit the telephone number, skip to step 7.

- 6** Edit the telephone number. For further details, see page 21.

- 7** Press **SET**.

REGISTERED



Erasing a stored entry

You can erase an entry stored in one-touch dial and JOG DIAL.

- 1** Rotate **JOG DIAL** until the desired name is displayed.

Example:

Mary	<S01>
------	-------

- 2** Press **DIRECTORY PROGRAM**.

EDIT=* DELETE=#

- 3** Press **#** to select "DELETE".

DELETE OK?



YES: SET/NO: STOP

- To cancel erasing, press **STOP**.

- 4** Press **SET**.

DELETED

- The stored name and number are erased.

Making a phone call using one-touch dial and JOG DIAL

Before using this feature, program the desired names and telephone numbers into one-touch dial and JOG DIAL (p. 20, 21).

Using one-touch dial

- 1 Press **MONITOR** or lift the handset.

Display:


- Confirm that there are no documents in the document entrance.

- 2 For stations 1–5:
Press the desired station key.

For stations 6–10:
Press **LOWER**, then press the desired station key.

Example:

- The unit will start dialing automatically.



Using JOG DIAL

- 1 Rotate **JOG DIAL** until the desired name is displayed.

Example:

- If the desired name has not been stored, press **STOP** and dial the number manually.

- 2 Press **MONITOR** or lift the handset.
 - The unit will start dialing automatically.

To confirm the stored telephone number on the display

1. Rotate **JOG DIAL** until the desired name is displayed.

Example:

Station key number for one-touch dial

2. Press **NAME/TEL NO.**.

Example:

- To stop the confirmation, press **STOP**.
- To make a call, press **MONITOR** or lift the handset.

To search for a name by initial

Example: "Lisa"

1. Rotate **JOG DIAL** to enter the directory.
2. Press **5** repeatedly until any name with the initial "L" is displayed (see the character table on page 17).
 - To search for symbols (not letters or numbers), press *****.
3. Rotate **JOG DIAL** to the right until "Lisa" is displayed.
 - To stop the search, press **STOP**.
 - To make a call, press **MONITOR** or lift the handset.

Caller ID service from your phone company

This unit is compatible with the Caller ID service offered by your local telephone company. To use this feature, you must subscribe to the Caller ID service.

Change the FAX ring setting (feature #06 on page 52) to 2 or more rings beforehand.

How Caller ID is displayed

The calling party's name or telephone number will be displayed after the first ring. You then have the option of whether or not to answer the call depending on the caller.

The unit will automatically store the caller information (name, telephone number and the time of the call). You can view the caller information (see the next page) and print the caller ID list (p. 26).

Note:

- If the unit is connected to a PBX (Private Branch Exchange) system, you may not receive the caller information. Consult your PBX supplier.
- If the unit cannot receive caller information, the following will be displayed.

OUT OF AREA

The caller dialed from an area which does not provide Caller ID service.

PRIVATE CALLER

The caller requested not to send caller information.

LONG DISTANCE

The caller made a long distance call.

To confirm caller information using the Caller ID list

The unit will store information for the most recent 30 callers.

— To print manually, see page 26.

— To print automatically after every 30 new calls, activate feature #26 (p. 55).

Viewing and calling back using caller information

You can easily view caller information and call back.


Important:

- Calling back will not be possible in the following cases:
 - The telephone number includes data other than numbers (i.e. * or #).
 - The caller information does not include a telephone number.

- 1 Press **CALLER ID SEARCH**.
 (2 new calls are received)
 Example:
 ↑↓
 Display:


- 2 Rotate **JOG DIAL** to the right (clockwise) to search from the most recent caller information.
 Rotate **JOG DIAL** to the left to search from the oldest caller information.

- 3 Press **MONITOR** or lift the handset to call back the displayed party.
 - The unit will start dialing automatically.
 - To send a fax – insert the document **FACE DOWN** and press **FAX START** (p. 28).



To display the caller's telephone number and the date/time of the call

Press **NAME/TEL NO.** repeatedly after step 2.



To edit the telephone number for calling back

Press ***** repeatedly after step 2.

Each time you press *****, the telephone number will be changed as follows:

1. – – (“1” added)
2. (area code omitted)
3. –
4. – (“1” added and area code omitted)

Display while viewing

<input type="text" value="NO NAME RCVD"/>	When the unit could not receive a name.
<input type="text" value="END OF NEW CALL"/>	After the last new call has been displayed.
<input type="text" value="END"/>	After all calls have been displayed.
<input type="text" value="NO CALLER DATA"/>	When no calls have been received.

To stop viewing

Press **STOP** after step 2.

Printing and erasing the Caller ID list


- 1** Press **CALLER ID PRINT** to start printing.

Display:

- The display will show the following after printing.



- 2** Press **STOP** to exit the program, or press **SET** to erase all of the stored caller information.



To erase all caller information without printing

1. Press **MENU** repeatedly until the following is displayed.

Display:

2. Press **SET**.

3. Press **SET**.



- To cancel erasing, press **STOP**, then **MENU**.

4. Press **SET**.

5. Press **STOP** to exit the program.

Storing caller information into one-touch dial and JOG DIAL

Important:

- This feature is not available in the following cases.
 - The telephone number includes data other than numbers (i.e. * or #).
 - The caller information does not include a telephone number.

1 Press **CALLER ID SEARCH**.

Example:

↑↓

Display:

2 Rotate **JOG DIAL** until the name you want to store is displayed.

Example:

3 Press **DIRECTORY PROGRAM**.

↑↓

4 For stations 1–3:
Press the desired station key.

Press **SET**.

Example:

Press **SET**.

Example:

For stations 4–5:
Press the desired station key.

Example:

Press **SET**.

Example:

For stations 6–10:
Press **LOWER**, then press the desired station key.

Example:

Press **SET**.

Example:

For JOG DIAL:


Rotate **JOG DIAL**.

Example:

Press **SET**.

Example:

5 Press **SET**.



Note:

- You can confirm the stored entries on the display (p. 23) or on the telephone number list (p. 71).
- The unit can only store a name of up to 10 characters long.
- To edit a name and number, see page 22.
- If you enter a new entry into a station key, the previous entry will be overwritten.
- If you use stations 1–3 as broadcast keys, you cannot store caller information for stations 1–3.

Sending Faxes

Sending a fax manually

- 1 Adjust the width of the document guides to the size of the document.
- 2 Insert the document (up to 15 pages) **FACE DOWN** until the unit grasps the document and a single beep is heard.

Display:

- 3 If necessary, press **RESOLUTION** repeatedly to select the desired setting (see below).

- 4 Press **MONITOR** or lift the handset.

- 5 Dial the fax number.

Example:

- 6 **When a fax tone is heard:**
Press **FAX START**, and replace the handset if you are using it.

OR

When the other party answers your call:

Lift the handset and ask them to press their start button. When the fax tone is heard, press **FAX START** and replace the handset.


To select the resolution

Select the desired resolution according to the type of document.

- **STANDARD:** For printed or typewritten originals with normal-sized characters.
 - **FINE:** For originals with small printing.
 - **SUPER FINE:** For originals with very small printing. This setting only works with other compatible fax machines.
 - **PHOTO:** For originals containing photographs, shaded drawings, etc.
- Using the "FINE", "SUPER FINE" or "PHOTO" setting will increase transmission time.
 - If the resolution setting is changed during feeding, it will be effective from the next sheet.

To stop transmission

Press **STOP**.



To redial the last number

Press **REDIAL/PAUSE**.

- If the line is busy, the unit will automatically redial the number up to 2 times.
- During redial, the following will be displayed.

Display:

- To cancel redialing, press **STOP**.

To transmit more than 15 pages at a time

Insert the first 15 pages of the document. Add the other pages (up to 15 at a time) before the last page feeds into the unit.

Convenient way to send a fax

You can dial the fax number first before inserting the document. This is convenient if the other party's number is indicated on the document.

1. Enter the fax number.
 - The handset must be on the cradle.
2. Insert the document.
3. Press **FAX START**.

Quick scan feature

This feature is helpful when you want to send the document, then take it for other uses.

1. Insert the document.
 2. Enter the fax number.
 3. Press **QUICK SCAN START**.
- The document will be fed into the unit and scanned into memory. The unit will then transmit the data.

If the document exceeds the memory capacity (p. 75), sending will be canceled. Transmit the entire document manually.

Reports for confirmation

Sending report

This report will provide you with a printed record of transmission results. To use this feature, activate feature #04 (p. 52). For the communication message in the result column, see page 57.

Journal report




The unit stores the 30 most recent fax communication results.

— To print manually, see page 71.

— To print automatically after every 30 new fax communications, activate feature #22 (p. 54).

For the communication message in the result column, see page 57.

Documents you can send

Minimum size	Maximum size	Effective scanning area	Document weight
 <p>128 mm (5")</p> <p>128 mm (5")</p>	 <p>216 mm (8½")</p> <p>600 mm (23⅝")</p>	 <p>4 mm</p> <p>4 mm</p> <p>4 mm</p> <p>4 mm</p> <p>208 mm (8³/₁₆")</p> <p>Paper width 216 mm (8½")</p>	<p>Single sheet: 45 g/m² to 90 g/m² (12 lb. to 24 lb.)</p> <p>Multiple sheets: 60 g/m² to 75 g/m² (16 lb. to 20 lb.)</p>

Note:

- Remove clips, staples or other similar fasteners.
- Check that ink, paste or correction fluid has dried.
- Do not send the following types of documents: (Use copies for fax transmission.)
 - Chemically treated paper such as carbon or carbonless duplicating paper
 - Electrostatically charged paper
 - Badly curled, creased or torn paper
 - Paper with a coated surface
 - Paper with a faint image
 - Paper with printing on the opposite side that can be seen through the front (i.e. newspaper)
- To transmit the document(s) with a width of less than standard letter size (216 mm), we recommend using a copy machine to copy the original document onto letter-sized paper, then transmit the copied document.

Sending Faxes

Sending a fax using one-touch dial and JOG DIAL

Before using this feature, program the desired names and telephone numbers into one-touch dial and JOG DIAL (p. 20, 21).

- 1 Adjust the width of the document guides to the size of the document.
- 2 Insert the document (up to 15 pages) **FACE DOWN** until the unit grasps the document and a single beep is heard.

Display:

- 3 If necessary, press **RESOLUTION** repeatedly to select the desired setting (p. 28).

- 4 Enter the fax number.
Using stations 1–5:
Press the desired station key.


Using stations 6–10:

Press **LOWER**, then press the desired station key.

Using **JOG DIAL**:

Display the desired name and press **FAX START**.

- For further details about using the JOG DIAL, see page 23.



Fax auto redial

If the line is busy or if there is no answer, the unit will automatically redial the number up to 2 times.

- This feature is also available for delayed transmission (feature #25 on page 54).
- During redial, the following will be displayed.

Display:

- To cancel redialing, press **STOP**.

If your unit does not send a fax

- Confirm the stored telephone number on the display and check that the number dialed is answered by the other party's machine (p. 23).
- The connecting tone will be heard during dialing to tell you the status of the other party's machine (feature #76 on page 56).


Broadcast transmission

This feature is useful for sending the same document to selected parties (up to 20 entries). First program the entries, then see page 33 for transmission.

- The broadcast function utilizes stations 1–3. The one-touch dial function will be canceled.
- **BROADCAST** key 1 and 2 can accept one-touch dial and JOG DIAL entries.
- **MANUAL BROADCAST** key can also accept manual dialing entries.

Programming entries into the broadcast memory

1 Press **DIRECTORY PROGRAM**.



2 For **BROADCAST 1–2**:
Press the desired **BROADCAST** key.



Rotate **JOG DIAL** to select "BROADCAST".



For MANUAL BROADCAST:


Press **MANUAL BROAD**.



Rotate **JOG DIAL** to select "MANUAL BROAD".




3 Press **SET**.



4 Program entries.
Using stations 1–5:

Press the desired station key.



Using stations 6–10:



Press **LOWER**, then press the desired station key.

Using JOG DIAL:

Display the desired name and press **SET**.


Using the dial keypad (only for MANUAL BROADCAST):

Enter the fax number and press **SET**.




- To program other entries, repeat this step (up to 20 entries).

5 Press **SET** after programming all of the desired entries.



- To program another broadcast key, repeat steps 2 to 5.

6 Press **STOP** to exit the program.



Note:

- If you program the wrong entry, press **STOP** after step 4 to erase the entry.
- Confirm the stored entries by printing a broadcast programming list (p. 71).

Sending Faxes

Adding a new entry into the broadcast memory

1 Rotate **JOG DIAL** until the desired key name is displayed.

Example:

2 Press **DIRECTORY PROGRAM**.

3 Press ***** to select "ADD".

4 Rotate **JOG DIAL** until the desired name you want to add is displayed (only available when using JOG DIAL).

Example (JOG DIAL):


Example (Station 2):

5 Press **SET**.

Example:

- To add other entries, repeat steps 4 and 5 (up to 20 entries).

6 Press **DIRECTORY PROGRAM** to exit the program.



Erasing a stored entry in the broadcast memory

1 Rotate **JOG DIAL** until the desired key name is displayed.

Example:

2 Press **DIRECTORY PROGRAM**.

3 Press **#** to select "DELETE".

4 Rotate **JOG DIAL** until the desired name you want to erase is displayed (only available when using JOG DIAL).

Example (JOG DIAL):

Example (Station 3):

- To cancel erasing, press **STOP**.

5 Press **SET**.

↓

6 Press **SET**.

↓

Example:

- To erase other entries, repeat steps 4 to 6.

7 Press **DIRECTORY PROGRAM** to exit the program.

Sending the same document to pre-programmed parties

- 1 Insert the document FACE DOWN.
 - If necessary, press **RESOLUTION** repeatedly to select the desired setting (p. 28).
- 2 Press the desired **BROADCAST** (1–2) or **MANUAL BROAD**.
 - You can also use **JOG DIAL**. Display the desired key name, and press **FAX START**.
Example:
 - The document will be fed into the unit and scanned into memory. The unit will then transmit the data to each entry, calling each number sequentially.
 - After transmission, the stored document will be erased automatically, and the unit will automatically print a broadcast sending report.



Note:

- If you select the "FINE", "SUPER FINE" or "PHOTO" resolution, the number of pages that the unit can transmit will decrease.
- If the document exceeds the memory capacity (p. 75), sending will be canceled.
- If one of the entries is busy or does not answer, it will be skipped. All skipped entries will be redialed up to 2 times after all of the other entries have been called.

To cancel the broadcast setting

1. Press **STOP** while the unit displays the following.

Display:

- The display will show the following.

↕

2. Press **SET**.


Receiving Faxes

Setting the unit to receive faxes

Use only as a fax


With answering machine

How you want the unit to receive calls



You have a separate telephone line just for faxes.


External telephone answering machine (not included)



You want to use the fax machine with an answering machine.

You have to set this.

FAX ONLY mode (p. 37)
Turn AUTO ANSWER on by pressing **AUTO ANSWER**.



ON

Activating an answering machine (p. 38)
Connect an external telephone answering machine and change the ring setting of the answering machine to less than 4.

- Change the ring setting in FAX ONLY mode of the fax machine to "5 EXT.TAM", if you use with AUTO ANSWER on.

This is how the unit will operate.


When receiving calls:
All incoming calls will be answered as faxes.

When receiving phone calls:
The answering machine will record voice messages.

When receiving faxes:
The fax machine will disconnect the answering machine and receive documents.

Voice mail service (Distinctive Ring)

2-number example



Facsimile No. (555-1333) Telephone No. (555-1111)

You need to subscribe to Distinctive Ring Service.

Mostly phone calls



You plan to answer the calls yourself.

Other option

Remote fax activation

You can also receive a fax using an extension telephone. While hearing a fax calling tone with an extension telephone, press ***9** (pre-selected fax activation code) to receive a fax (p. 39).

Setting the Distinctive Ring pattern (p. 40)

Select the same ring pattern assigned to the facsimile number. (Default setting is B.)

A: Standard ring (one long ring)


B: Double ring (two short rings)

C: Triple ring (short-long-short rings)

D: Other triple ring (short-short-long rings)

TEL mode (p. 36)

Turn AUTO ANSWER off by pressing **AUTO ANSWER**.



When the fax machine detects a call matching the selected Distinctive Ring pattern: The fax machine will activate the fax function.

When the fax machine detects other ring patterns: The fax machine will operate based on the AUTO ANSWER setting.

When receiving calls:

You have to answer all calls manually.

To receive a fax document, press **FAX START** for each fax you are receiving.


Receiving Faxes

TEL mode (answering all calls manually)

Activating TEL mode

If the AUTO ANSWER light is on, turn it off by pressing **AUTO ANSWER**.

Display: TEL MODE



Receiving a fax manually

- 1** When the unit rings, lift the handset to answer the call.
- 2** When:
 - document reception is required,
 - a fax calling tone (slow beep) is heard, or
 - no sound is heard,press **FAX START**.

Display: CONNECTING.....

- 3** Replace the handset.
 - The unit will start fax reception.

Note:

- If you do not answer the call within 10 rings, the unit will temporarily switch to fax reception. The other party can then send a fax.

To stop receiving

Press **STOP**.

Auto reduction feature

If the other party sends a document that is longer than your recording paper, your unit will reduce the receiving document to the proper size and print it. If you want to print the original size, set feature #37 to off (p. 55).

Fax reception in memory

When a printing problem is detected, the unit will temporarily store the received document into memory.

While the document is in memory:

- the display will show an error message and the following alternately,

Display: FAX IN MEMORY

- slow beeps will sound if feature #44 is set to on (p. 55).

- Follow the instructions on pages 58 and 59 to solve the problem.
- For memory capacity, see page 75.

FAX ONLY mode --- --- (all calls are received as faxes)

Activating FAX ONLY mode

- 1 If the AUTO ANSWER light is off, turn it on by pressing **AUTO ANSWER**.
 - The display will show the number of rings before the unit answers a call in FAX ONLY mode.

Display: PICKUP & RCV FAX


Example: AFTER 3 RINGS ㉓

- 2 If you wish to change the ring setting, rotate **JOG DIAL** until the desired number is displayed, and press **SET**.
 - When receiving calls, the unit will automatically answer all calls and only receive fax documents.


Note:

- If the AUTO ANSWER light is already on and you wish to change the ring setting, turn it off once then on again by pressing **AUTO ANSWER** and follow the instructions in step 2.
- This mode should not be used with a telephone line which is used for both phone calls and faxes. Fax communication will be attempted even if someone is trying to call you. We recommend the following setup:

Example:



Only a fax machine is connected.




Receiving Faxes

Using the unit with an answering machine

Setting up the fax machine and an answering machine

- 1 Connect the answering machine.



- 2 Set the number of rings on the answering machine to less than 4.
 - This will allow the answering machine to answer the call first.
- 3 Record a greeting message on the answering machine.

Example: *"This is (your name, business and/or telephone number). We are unable to answer the phone right now. To send a fax, start transmission. To leave a message, please speak after the beep. Thank you."*

 - We recommend you record a message up to 10 seconds long, and do not pause for more than 4 seconds during the message. Otherwise, both machines will not function correctly.
- 4 Activate the answering machine.
- 5 Set the fax machine to TEL mode (p. 36) or FAX ONLY mode (p. 37).
 - If you set to FAX ONLY mode, **change the ring setting in FAX ONLY mode to "5 EXT.TAM" (feature #06 on page 52)**. Using FAX ONLY mode will allow you to receive faxes if the answering machine is full.
- 6 Check the remote access code of the answering machine and program the same code into the remote operation ID of the fax machine. See feature #12 on page 53.

How the fax machine and answering machine work

Receiving phone calls

The answering machine will record voice messages automatically.

Receiving faxes

The fax machine will receive documents automatically when the machine detects a fax calling tone.

Receiving a voice message and fax document in one call

See page 39.

Note:

- Every time the fax machine receives a document, a silent pause or fax tone may be recorded on the answering machine.

Receiving a voice message and fax document in one call

The caller can leave a voice message and send a fax document during the same call. Inform the caller of the following procedure beforehand:

1. The caller calls your fax machine.
 - The answering machine will answer the call.
2. The caller can leave a message after the greeting message.
3. The caller presses ***9** (pre-selected fax activation code).
 - The fax machine will activate the fax function.
4. The caller presses the start button to send a document.

Note:

- The fax activation code can be changed in feature #41 (p. 55).


Extension telephone

If you use the fax machine with an extension telephone, you can receive fax documents using the extension telephone. You do not have to press **FAX START** on the fax machine.

Important:

- Use a touch tone telephone as the extension telephone and enter the fax activation code **firmly**.

- 1** When the extension telephone rings, lift the handset of the extension telephone.
- 2** When:
 - document reception is required,
 - a fax calling tone (slow beep) is heard, or
 - no sound is heard,press ***9** (pre-selected fax activation code) **firmly**.
- 3** Hang up the handset.
 - The fax machine will start reception.



Note:

- You can change the fax activation code in feature #41 (p. 55).

Distinctive Ring

Using with a voice mail service

Important:

- When you have a single telephone line and subscribe to a telephone company's voice mail service, you must also subscribe to the Distinctive Ring Service if you want to receive faxes automatically as well as voice messages. For more information about telephone services, contact your telephone company.

When you subscribe to Distinctive Ring Service, your telephone company will assign you a new fax number and will also tell you the assigned ring pattern. Please complete the following setup on your fax machine to identify the assigned ring pattern.

1 Press **MENU**.
Display: SYSTEM SET UP

2 Press **⏏**, then **3** **1**.
RING DETECTION


3 Press **SET**.
MODE=B ↻

4 Rotate **JOG DIAL** to select the ring pattern assigned by the telephone company.

- A:** Standard ring (one long ring)
- B:** Double ring (two short rings) (**default setting**)
- C:** Triple ring (short-long-short-rings)
- D:** Other triple ring (short-short-long rings)
- OFF:** Turns off the feature.

5 Press **SET**.
SETUP ITEM []

6 Press **MENU**.



Note:

- Once you have programmed the assigned ring pattern into the fax machine, turn AUTO ANSWER off so that the fax machine is in TEL mode.
- In TEL mode, the fax machine will recognize incoming faxes on the first ring pattern and answer automatically. For phone calls, the fax machine will ring as a normal call.

Making a copy

The unit can make single or multiple copies (up to 99).

- 1 Adjust the width of the document guides to the size of the document.
- 2 Insert the document (up to 15 pages) **FACE DOWN** until the unit grasps the document and a single beep is heard.


Display:

- If necessary, press **RESOLUTION** repeatedly to select the desired setting (see below).
- Make sure the handset is on the cradle.

- 3 Press **COPY START**.

- If necessary, enter the number of copies (up to 99).

- 4 Press **COPY START**.
 - The unit will start copying.



Note:

- Any transmittable document can be copied (p. 29).

To select the resolution

Select the desired resolution according to the type of document.

- **FINE**: For printed or typewritten originals with small printing.

Display in step 3:

- **SUPER FINE**: For originals with very small printing.

- **PHOTO**: For originals containing photographs, shaded drawings, etc.

- If you select "STANDARD", copying will be done using "FINE" mode.

To stop copying

Press **STOP**.

Copying


To reduce or enlarge a document

To make a reduced copy, press  repeatedly and select the desired reduction rate. The unit can reduce copies to as little as 50% of the original by changing the reduction rate 5% at a time.

To make an enlarged copy, press  repeatedly and select the desired enlargement rate. The unit can enlarge copies to as much as 200% of the original by changing the enlargement rate 5% at a time.


Example: 70% reduced copy

Original document Reduced copy



Example: 150% enlarged copy

Original document Enlarged copy



Note:

- The display will show the rate you selected.

Example:

Reduction/enlargement rate

- For an enlarged copy, the unit will only enlarge the center of the upper part of the document. To make an enlarged copy of the bottom of the document, turn the document around, insert it into the unit, and then make a copy.



To collate multiple copies

The unit can collate multiple copies in the same order as the original document pages.

Press **COLLATE** until the following is displayed and start copying.

Display:

Example: Making 2 copies of a 4-page original document



Note:

- If you select collate copies, the display will show the following.

Example:

shows collating copy

- The unit will store the documents into memory while collating the copies. If memory becomes full while storing, the unit will only print out the stored pages.

Connecting to a computer


Panasonic Multi-Function Station software enables your fax machine to carry out the following functions:

- Printing on plain paper, transparencies, labels and envelopes
- Scanning documents and converting an image into text with Readiris OCR software
- Scanning from other Microsoft® Windows® applications that support TWAIN scanning
- Storing, editing or erasing entries in directories from your PC
- Programming the basic and advanced features from your PC

To run Multi-Function Station software, you need the following:


- Compatible OS: Windows 95/98/Me/2000
- CPU:
 - Windows 95/98: Pentium® 90 MHz or higher processor
 - Windows Me: Pentium 150 MHz or higher processor
 - Windows 2000: Pentium 166 MHz or higher processor
- Memory minimum:
 - Windows 95/98: 24 MB (32 MB or more is recommended.)
 - Windows Me: 32 MB (64 MB or more is recommended.)
 - Windows 2000: 64 MB
- Hard disk: More than 40 MB available space
- Other: Parallel (IEEE1284) port or USB port, and CD-ROM drive

- **When using an IEEE1284 compliant parallel cable:**
Shielded parallel cable (amphenol 36 pin) must be purchased separately.



- **When using a USB cable (Windows 95 does not offer USB support):**
Shielded USB cable must be purchased separately.

After connecting the USB cable, you must set the cable type to “USB” (feature #15 on page 53).



Note:

- If you want to replace the parallel cable with a USB cable and vice versa, see page 63.

Installing Multi-Function Station software

- 1 Start Windows 95/98/Me/2000 and close all other applications.

- The following dialog box will appear. Click **[Cancel]** to close it.



- You must be logged in as an administrator in Windows 2000.

- 2 Insert the included CD-ROM into your CD-ROM drive.

- The **[Choose Setup Language]** dialog box will appear. Select the desired language that you want to use with this software from the drop-down list. Click **[OK]**. The installation will automatically start.
- If the **[Choose Setup Language]** dialog box does not appear: The installation will automatically start.
- If the installation does not start automatically: Click **[Start]**. Choose **[Run...]**. Type "d:\setup" (where "d:" is the drive letter of your CD-ROM drive). Click **[OK]**. (If you are not sure what the drive letter is for your CD-ROM drive, use Windows Explorer and look for the CD-ROM drive.)



The installation will start.

- 3 Follow the instructions on the screen until all files have been installed.

- Readiris OCR software can also be installed. For details about OCR software, see page 49.
- If the fax machine is not connected to your computer, the **[Port Selection]** dialog box will appear. Select the port number which you want to use. If the fax machine is connected to your computer, the port number will be automatically detected.

Note:

- There is also a different way to install Multi-Function Station software. See the attached leaflet for PC setup for details.


To uninstall the software

1. Click **[Start]**.
2. Point to **[Settings]**, then click **[Control Panel]**.
3. Double-click **[Add/Remove Programs]**.
4. Select **[Panasonic Multi-Function Station]** from the list.
5. Click **[Add/Remove...]** (Windows 95/98/Me)/ **[Change/Remove...]** (Windows 2000), then follow the instructions on the screen.

- The screens shown in these instructions are from Windows Me.
- The screens may differ slightly from those of the actual product.
- The screens are subject to change for improvement without notice.

Activating Multi-Function Station software =====

- 1 Click [**Start**] in Windows.
- 2 Point to [**Programs**], point to [**Panasonic Multi-Function Station**] and click [**Launcher**].
 - [**Launcher**] will appear.



Remote Control (p. 50)

- To store, edit or erase entries in directories.
- To program the basic and advanced features.
- To view or erase items in the journal report or Caller ID list.
- To store caller information into directories.

Viewer (Scan) (p. 49)

- To display the images which support TIFF, JPEG, PCX, DCX and BMP formats.
- To create an image file by scanning the document set in the fax machine.

Readiris (OCR) (p. 49)

- To convert an image into editable text data.

Help

- For detailed instructions on Multi-Function Station.

Note:

- Each time Windows is started, the status monitor appears in the task tray on your computer. If there are any problems with the fax machine, it will display an error message on your computer.
- You can confirm if the fax machine is connected to your computer on the status monitor.

Printing (PC)


Using the fax machine as a printer

You can print not only on plain paper but also on special media (transparencies/labels/envelopes).

Printing from Windows applications

You can print a file created in a Windows application.
For example, to print from Microsoft Word, proceed as follows.

- 1 Open the document you want to print.
- 2 Select **[Print...]** from the **[File]** menu.
 - The **[Print]** dialog box will appear.
For details about the **[Print]** dialog box, click **[?]**, then click the desired item.



- 3 Select **[Panasonic FLM551/FLB751 Series]** as the active printer from the drop-down list.
 - If you want to change the printer setting, click **[Properties]** (see right).
- 4 Set the printing information.
- 5 Click **[OK]**.
 - The fax machine will start printing.

Note:

- To load paper, see page 13.
- For details about the paper specifications, see pages 47, 48 and 76.

Setting the printer properties

You can change the printer setting in the **[Paper]** tab in step 3.

We recommend that you test paper (especially special sizes and types of paper) on the fax machine before purchasing large quantities.

- Paper size
 - Letter:** 216 mm x 279 mm (8½" x 11")
 - Legal:** 216 mm x 356 mm (8½" x 14")
 - A4:** 210 mm x 297 mm (8¼" x 11¼")
 - COM10:** 105 mm x 241 mm (4⅛" x 9½")
 - DL:** 110 mm x 220 mm (4⅝" x 8⅝")
- Orientation
 - Portrait:** To print in tall format.
 - Landscape:** To print in wide format.
- Media choice
 - Plain Paper (Standard):** For standard printing. The toner save feature will be off.
 - Plain Paper (Toner Save ON):** To save on toner consumption. The print quality may be lowered.
 - Transparency:** To print on a transparency.

Transparencies

Use transparencies designed for laser printing. We recommend the following:

3M® CG3300/CG5000

- **Load transparency sheets one page at a time for printing.**
- **Remove each transparency after printing and place it on a flat surface to cool and to prevent it from curling.**
- Close the paper stacker extender (p. 12) while printing to prevent transparencies from curling.
- Do not re-use transparencies that have already been fed through the fax machine. This includes transparencies that have been fed through and ejected without being printed on.
- Some types of transparencies have instructions recommending which side to print on. If the print quality is poor, try printing on the other side.


Labels

Use labels designed for laser printing. We recommend the following:

Avery® 5160/5161/5162/5163/5164/5165/5167/5168

Xerox® LWH100/LWH110/LWH120/LWH130/LWH140

- **Load label sheets one page at a time for printing.**
- **Remove each label after printing.**
- Do not use the following types of labels:
 - Labels that are wrinkled, damaged or separated from the backing sheet.
 - Any sheet of labels that has spaces in it where some of the labels have been removed.
 - Labels that do not completely cover the backing sheet (see below).




Backing sheet

Printing (PC)


Envelopes

Use envelopes designed for laser printing. We recommend the following:

- High quality envelopes of 90 g/m² (24 lb.) paper,
- Envelopes that have thin sharply creased leading edges, and
- Envelopes that have diagonal seems as shown right.




- You can load up to 10 envelopes of 90 g/m² (24 lb.) paper at a time for printing.
- Remove each envelope after printing.
- Wrinkles may occur in some cases, even if high quality envelopes are used.
- Avoid printing in high humidity, above 70% relative humidity (RH). High humidity may cause the envelope to curl, pick up excess toner or seal the envelope.
- Avoid printing below 10 °C (50 °F) with less than 30% RH, or it may cause light printing.
- Store envelopes away from moisture and humidity, where they can lay flat and their edges will not be bent or damaged. The humidity should not exceed 70% RH.




Do not use envelopes with any of the following characteristics (using these may result in paper jams):

- Irregularly shaped envelopes
- Envelopes with curls, wrinkles, nicks, twists, dog-ears or other damage
- Envelopes with side seam construction
- Highly textured envelopes, or with extremely shiny surfaces
- Envelopes that seal by removing a peel-off strip
- Envelopes with more than one flap to be sealed
- Self-adhesive envelopes
- Envelopes that are baggy or not sharply creased
- Embossed envelopes
- Envelopes that have previously been printed on
- Envelopes that include cotton and/or fiber material



Do not attempt to print on any of the following types of envelopes (these may cause damage to the fax machine):

- Envelopes with clasps, snaps or tie strings
- Envelopes with transparent windows
- Envelopes that use encapsulated types of adhesive that do not require moistening but rely on pressure to seal them



Using the fax machine as a scanner

Using Multi-Function Viewer

- 1 Insert the document (up to 15 pages) FACE DOWN in the fax machine.
- 2 Start Multi-Function Station.
- 3 Select **[Viewer (Scan)]**.
 - The **[Multi-Function Viewer]** window will appear.
- 4 Select **[Scan...]** from the **[File]** menu, or click the **[Scan]** icon in the tool bar.
 - The **[Panasonic FLM551/FLB751 Series]** dialog box will appear.
- 5 If necessary, change the setting of **[Scan Configuration]**, **[Custom Scan Settings]**, **[Contrast]** and **[Paper]**.
- 6 Click **[Scan]**.
 - The scanned image will be displayed in the **[Multi-Function Viewer]** window after scanning.
 - To save the scanned image, select **[Save]** from the **[File]** menu.
 - To cancel scanning while the document is being scanned, click **[Cancel]**.

Note:

- You can display the images which support TIFF, JPEG, PCX, DCX and BMP formats.
- You can move, copy and delete a file or page.

Readiris OCR software

With OCR software, you can convert an image into text data that can be edited with word processor software. Readiris OCR software can be installed when installing Multi-Function Station software. To use this software, click the **[OCR]** icon in the **[Multi-Function Viewer]** window or select **[Readiris (OCR)]** from **[Launcher]**. For detailed instructions about OCR, select **[Help]**.

Using other applications

Multi-Function Station includes a TWAIN compliant scanner driver. You can also scan using other applications that support TWAIN scanning.

For example, to scan from Imaging for Windows, proceed as follows.

- 1 Insert the document (up to 15 pages) FACE DOWN in the fax machine.
- 2 Start Imaging for Windows.
- 3 Select **[Select Scanner...]** (Windows 95/98/Me) / **[Select Device...]** (Windows 2000) from the **[File]** menu, then select the **[Panasonic FLM551/FLB751 Series]** in the dialog box.
- 4 Select **[Scan New...]** (Windows 95/98/Me) / **[Acquire Image...]** (Windows 2000) from the **[File]** menu, or click the **[Scan New]** icon in the tool bar.
 - The **[Panasonic FLM551/FLB751 Series]** dialog box will appear.
 - If the dialog box will not appear, check the connection of the PC and the fax machine.
- 5 If necessary, change the setting of **[Scan Configuration]**, **[Custom Scan Settings]**, **[Contrast]** and **[Paper]**.
- 6 Click **[Scan]**.
 - The scanned image will be displayed in the **[Imaging for Windows]** window after scanning.
 - To cancel scanning while the document is being scanned, click **[Cancel]**.

Remote Control (PC)

Operating the fax machine from your computer ≡


You can easily operate the following functions from your computer.

- Storing, editing or erasing entries in directories (p. 20–22, 31, 32)
- Programming the basic and advanced features (p. 52–56)
- Viewing or erasing items in the journal report (p. 29)
- Storing the journal report as PC file
- Viewing or erasing items in the Caller ID list (p. 24)
- Storing caller information into directories (p. 27)
- Storing the Caller ID list as PC file

1 Start Multi-Function Station.

2 Select **[Remote Control]**.

- The **[Multi-Function Remote Control]** window will appear.



3 Select the desired tab.

- The latest data in the fax machine will be displayed.

4 Perform the desired operation.

- For details about each function, click **[Help]**.
- To stop operation, click **[Cancel]**.

5 Click **[OK]**.

- The new data will be transferred to the fax machine and the window will close.
- You can also click **[Apply]** to continue the next operation without closing the window.

Note:

- Some of the basic and advanced features cannot be programmed from your computer.

Programming

The unit provides various programming features. Program the desired settings by referring to the programming tables (p. 52–56).

General programming method

1 Press **MENU**.

Display: SYSTEM SET UP

2 Select the feature you wish to program.

For basic features (p. 52, 53):

Rotate **JOG DIAL** until the desired feature is displayed.

For advanced features (p. 54–56):

Rotate **JOG DIAL** until the following is displayed:

ADVANCED MODE

then press **SET** and rotate **JOG DIAL** until the desired feature is displayed.

3 Press **SET**.

- The current setting of the feature will be displayed.


4 Rotate **JOG DIAL** until the desired setting is displayed.

- This step may be slightly different depending on the feature.

5 Press **SET**.

- The setting you selected is set, and the next feature will be displayed.

6 To exit programming, press **MENU**.



Programming by entering the program code number directly

You can select a feature by directly entering the program code (# and 2-digit number) instead of using **JOG DIAL** in step 2.

1. Press **MENU**.
2. Press **#** and the 2-digit code number.
3. Follow steps 3 to 6 above.

- See programming tables for code numbers (p. 52–56).

To cancel programming

Press **MENU** to exit the program.

Features Summary

Basic features

How to set menu options

1. Press **MENU**.
2. Rotate **JOG DIAL** until the desired feature is displayed.
3. Press **SET**.
4. Rotate **JOG DIAL** until the desired setting is displayed.
5. Press **SET**.
6. Press **MENU**.

Note:

- Step 4 may be slightly different depending on the feature.
- See page 51 for more details.

Programming table

Code	Feature & Display	Settings	How the unit operates
#01	Setting the date and time <div style="border: 1px solid black; padding: 2px; width: fit-content;">SET DATE & TIME</div>	mm/dd/yy hh:mm	See page 15 for details.
#02	Setting your logo <div style="border: 1px solid black; padding: 2px; width: fit-content;">YOUR LOGO</div>	(Up to 30 characters)	See page 16 for details.
#03	Setting your facsimile telephone number <div style="border: 1px solid black; padding: 2px; width: fit-content;">YOUR FAX NO.</div>	(Up to 20 digits)	See page 18 for details.
#04	Printing the sending report <div style="border: 1px solid black; padding: 2px; width: fit-content;">SENDING REPORT</div> To print and check the sending report for fax transmission results (p. 29).	ERROR	"ERROR": The sending report will be printed only when fax transmission fails. "ON": The sending report will be printed out after every transmission.
		ON	
		OFF	
#06	Changing the ring setting in FAX ONLY mode <div style="border: 1px solid black; padding: 2px; width: fit-content;">FAX RING COUNT</div> To change the number of rings before the unit answers a call in FAX ONLY mode.	1, 2, 3 , 4, 5 EXT.TAM	This setting is also available after activating FAX ONLY mode (p. 37). If you are using the unit with an answering machine, set to "5 EXT.TAM" (p. 38).

(The default setting is in bold type.)

Features Summary

Code	Feature & Display	Settings	How the unit operates
#12	Securing the remote operation for the answering machine REMOTE TAM ACT. If you are using the unit with an answering machine, activate this feature, and set the remote activation ID to secure the remote operation for the answering machine.	ON / ID=11	To select "ON" and enter ID: 1. Press MENU . 2. Rotate JOG DIAL and select this feature. 3. Press SET . 4. Rotate JOG DIAL to select "ON". 5. Press SET . 6. Enter your ID from 1 to 5 digits, using 0–9, *, and #. 7. Press SET . 8. Press MENU .
		OFF	
#13	Setting the dialing mode DIALING MODE If you cannot dial, change the setting depending on your telephone line service.	TONE	"TONE": For tone dial service. "PULSE": For rotary pulse dial service.
		PULSE	
#15	Selecting the cable type to connect to the PC PC INTERFACE If you use Multi-Function Station, change the setting depending on the cable connected to your computer.	PARALLEL	"PARALLEL": IEEE1284 compliant parallel cable "USB": USB cable • When the setting is changed, the fax machine adjusts to new setting. Please wait.
		USB	
#16	Setting the recording paper size PAPER SIZE	LETTER	"LETTER": Letter size paper "LEGAL": Legal size paper "A4": A4 size paper
		LEGAL	
		A4	
#17	Setting the ringer pattern RINGER PATTERN	A	You can select the ringer pattern. The selected ringer pattern will sound during setting.
		B	
		C	

(The default setting is in bold type.)

Features Summary

Advanced features

How to set menu options

1. Press **MENU**.
2. Rotate **JOG DIAL** until the following is displayed:

ADVANCED MODE

then press **SET** and rotate **JOG DIAL** until the desired feature is displayed.

3. Press **SET**.

4. Rotate **JOG DIAL** until the desired setting is displayed.

5. Press **SET**.

6. Press **MENU**.

Note:

- Step 4 may be slightly different depending on the feature.
- See page 51 for more details.

Programming table

Code	Feature & Display	Settings	How the unit operates
#22	Setting the journal report to print automatically <div style="border: 1px solid black; padding: 2px; display: inline-block;">AUTO JOURNAL</div>	ON	"ON": The unit will print the journal report automatically after every 30 new fax communications (p. 29).
		OFF	
#23	Sending document overseas <div style="border: 1px solid black; padding: 2px; display: inline-block;">OVERSEAS MODE</div> If you have difficulty sending an overseas fax, activate this feature before starting transmission. This feature makes sending documents easier as the transmission speed is slowed down.	NEXT FAX	"NEXT FAX": This setting is effective only for the next attempted fax transmission. After transmission, the unit will return to the previous setting. "ERROR": When the previous fax transmission fails and you redial the same number. • This feature is not available for broadcast transmission. • The calling charge may be higher.
		ERROR	
		OFF	
#25	Sending a fax at a specific time <div style="border: 1px solid black; padding: 2px; display: inline-block;">DELAYED SEND</div> This feature allows you to take advantage of low-cost calling hours offered by your telephone company. • The setting can be reserved to take place up to 24 hours in advance.	ON / fax no. / hh:mm	To send a document: 1. Insert the document. 2. Follow steps 1–3 above. 3. Rotate JOG DIAL to select "ON". 4. Press SET . 5. Enter the fax number. 6. Press SET . 7. Enter the transmission start time. Press * to select "AM" or "PM". 8. Press SET . 9. Press MENU . • To cancel after programming, press STOP then SET .
		OFF	

(The default setting is in bold type.)

Features Summary

Code	Feature & Display	Settings	How the unit operates
#26	Setting the Caller ID list to print automatically AUTO CALL. LIST	ON	“ON”: The unit will print the Caller ID list automatically after every 30 new calls (p. 24).
		OFF	
#31	Setting the Distinctive Ring pattern RING DETECTION	A, B, C, D	See page 40 for details.
		OFF	
#37	Receiving other size documents AUTO REDUCTION To receive a fax document that is longer than your recording paper.	ON	“ON”: The unit will fit a received document onto your recording paper. “OFF”: The unit will print the original size.
		OFF	
#39	Changing the display contrast LCD CONTRAST	NORMAL	“NORMAL”: For normal contrast “DARKER”: Used when the display contrast is too light.
		DARKER	
#41	Changing the fax activation code FAX ACTIVATION If you use an extension telephone and wish to use it to receive a fax, activate this feature, and enter the code (p. 39).	ON / CODE= * 9	<ol style="list-style-type: none"> Follow steps 1–3 on page 54. Rotate JOG DIAL to select “ON”. Press SET. Enter your code from 2 to 4 digits, using 0–9 and * . Press SET. Press MENU. • Do not enter “0000”.
		OFF	
#44	Setting the memory reception alert RECEIVE ALERT To alert you with a beeping sound when a document which has been received is stored into memory due to some existing problem.	ON	If you are alerted by a slow beeping sound, clear the printing problem and make sure the unit is supplied with enough paper to print the stored document. The beeps will stop.
		OFF	
#68	Setting the Error Correction Mode (ECM) ECM SELECTION To send a fax even if there is static interference on the telephone line.	ON	This feature is available when the transmitting/receiving stations are ECM compatible. • If there are documents in the memory, clear them before making the setting (p. 36).
		OFF	

(The default setting is in bold type.)

Features Summary

Advanced features (cont.)

How to set menu options

1. Press **MENU**.
2. Rotate **JOG DIAL** until the following is displayed:

ADVANCED MODE

then press **SET** and rotate **JOG DIAL** until the desired feature is displayed.

3. Press **SET**.

4. Rotate **JOG DIAL** until the desired setting is displayed.

5. Press **SET**.

6. Press **MENU**.

Note:

- Step 4 may be slightly different depending on the feature.
- See page 51 for more details.

Programming table (cont.)

Code	Feature & Display	Settings	How the unit operates
#76	Setting the connecting tone <div style="border: 1px solid black; padding: 2px; display: inline-block;">CONNECTING TONE</div> If you often have trouble when sending a fax, this feature allows you to hear connecting tones: fax tone, ring back tone and busy tone.	ON	You can confirm the status of the other party's machine. <ul style="list-style-type: none"> • If the ring back tone continues, the other party's machine may not be a facsimile or may have run out of paper. Check with the other party. • The connecting tone volume cannot be adjusted.
		OFF	
#79	Saving on toner consumption <div style="border: 1px solid black; padding: 2px; display: inline-block;">TONER SAVE</div>	ON	"ON": The toner cartridge will last longer. <ul style="list-style-type: none"> • This feature may lower the print quality.
		OFF	
#80	Resetting advanced features to their default settings <div style="border: 1px solid black; padding: 2px; display: inline-block;">SET DEFAULT</div>	YES	<ol style="list-style-type: none"> 1. Follow steps 1–3 above. 2. Rotate JOG DIAL to select "YES". 3. Press SET. 4. Press SET again. 5. Press MENU.
		NO	

(The default setting is in bold type.)

Reports

If your unit cannot send a fax, check the following:

- the number you dialed is correct,
- the other party's machine is a facsimile.

If the problem remains, correct it by following the communication message printed on the sending and journal reports (p. 29).

COMMUNICATION ERROR

(CODE: 40–42, 46–52, 58, 65, 68, 72, FF)

- A transmission or reception error occurred. Try again or check with the other party.

COMMUNICATION ERROR

(CODE: 43, 44)

- A line problem occurred. Connect the telephone line cord to a different jack and try again.
- An overseas transmission error occurred. Try using the overseas mode of feature #23 (p. 54).

DOCUMENT JAMMED

- The document is jammed. Remove the jammed document (p. 68).

ERROR-NOT YOUR UNIT

(CODE: 54, 59, 70)

- A transmission or reception error occurred because of a problem with the other party's fax machine. Check with the other party.

MEMORY FULL

- The document was not received due to the memory being full.

NO DOCUMENT

- The document was not fed into the unit properly. Reinsert the document and try again.

OTHER FAX NOT RESPONDING

- The other party's fax machine is busy or has run out of recording paper. Try again.
- The document was not fed properly. Reinsert the document and try again.
- The other party's fax machine rings too many times. Send the fax manually (p. 28).
- The other party's machine is not a facsimile. Check with the other party.
- The number you dialed is not in service.

PRESSED THE STOP KEY

- **STOP** was pressed and fax communication was canceled.

THE COVER WAS OPENED

- The front cover was opened. Close it and try again.

OK

- Fax communication was successful.

Error Messages

Display

If the unit detects a problem, one or more of the following messages will appear on the display.

Display message	Cause & solution
CALL SERVICE	<ul style="list-style-type: none">● There is something wrong with the unit. Contact our service personnel.
CHANGE DRUM	<ul style="list-style-type: none">● There is something wrong with the drum unit. Replace the drum unit and the toner cartridge (p. 64).
CHECK DOCUMENT	<ul style="list-style-type: none">● The document was not fed into the unit properly. Reinsert the document. If misfeeding occurs frequently, clean the document feeder rollers (p. 69) and try again. If the problem remains, adjust the feeder pressure (p. 68).
CHECK DRUM	<ul style="list-style-type: none">● The drum unit is not inserted properly. Reinsert it correctly (p. 10).
CHECK MEMORY	<ul style="list-style-type: none">● The memory (telephone numbers, parameters, etc.) has been erased. Re-program.
COVER OPEN	<ul style="list-style-type: none">● The front cover is open. Close it.
DATA IN MEMORY	<ul style="list-style-type: none">● You tried to change the cable type setting (feature #15 on page 53), while the fax machine has a document in memory. Finish sending faxes, print out the document in memory (p. 36) or cancel the delayed transmission (feature #25 on page 54) and try again.
FAILED PICK UP	<ul style="list-style-type: none">● Recording paper was not fed into the unit properly. Reinsert the recording paper (p. 67).
FAX IN MEMORY	<ul style="list-style-type: none">● The unit has a document in memory. See the other displayed message instructions to print out the document.
FAX MEMORY FULL	<ul style="list-style-type: none">● The memory is full of received documents due to a lack of recording paper or a recording paper jam. Install paper (p. 13) or clear the jammed paper (p. 66).● When performing memory transmission, the document being stored exceeds the memory capacity of the unit. Transmit the entire document manually.
JOG-DIAL FULL	<ul style="list-style-type: none">● There is no space to store new entries in the JOG DIAL directory. Erase unnecessary entries (p. 22).
LINE IN USE	<ul style="list-style-type: none">● You cannot change the cable type setting (feature #15 on page 53) while using the handset or the monitor. Hang up and try again.

Error Messages

Display message	Cause & solution
MEMORY FULL	<ul style="list-style-type: none"> When making a copy, the document being stored exceeds the memory capacity of the unit. Press STOP to clear the message. Divide the document into sections.
MODEM ERROR	<ul style="list-style-type: none"> There is something wrong with the modem circuit. Contact our service personnel.
NO FAX REPLY	<ul style="list-style-type: none"> The other party's fax machine is busy or has run out of recording paper. Try again.
OUT OF PAPER	<ul style="list-style-type: none"> Recording paper is not installed or the unit has run out of paper. Install paper (p. 13). Recording paper is not fed into the unit properly. Reinstall paper (p. 13).
PAPER JAMMED	<ul style="list-style-type: none"> A recording paper jam occurred. Clear the jammed paper (p. 66).
PC FAIL OR BUSY	<ul style="list-style-type: none"> The cable or the PC power cord is not connected correctly. Check the connections (p. 43). The software is not running on the PC. Restart the software and try again.
PLEASE WAIT	<ul style="list-style-type: none"> The unit is warming up. Wait for a while.
REDIAL TIME OUT	<ul style="list-style-type: none"> The other party's fax machine is busy or has run out of recording paper. Try again.
REMOVE DOCUMENT	<ul style="list-style-type: none"> The document is jammed. Remove the jammed document (p. 68). Attempted to transmit a document longer than 600 mm. Press STOP to remove the document. Divide the document into two or more sheets and try again.
TONER EMPTY	<ul style="list-style-type: none"> The toner cartridge is empty. Replace the toner cartridge (p. 64).
TONER LOW	<ul style="list-style-type: none"> The remaining toner is low. Replace the toner cartridge as soon as possible (p. 64). We recommend you replace the drum unit every third time you replace the toner cartridge. To check the drum life and quality, please print the printer test list (p. 71).
TRANSMIT ERROR	<ul style="list-style-type: none"> A transmission error occurred. Try again.
WRONG PAPER	<ul style="list-style-type: none"> The fax message was printed on paper which is shorter than letter size paper. Use the appropriate size paper (p. 13).

When a function does not work, check here before requesting help

General

I cannot make and receive calls.

- The power cord or telephone line cord is not connected. Check the connections (p. 14).
- If you used a splitter to connect the unit, remove the splitter and connect the unit to the wall jack directly. If the unit operates properly, check the splitter.

I cannot make calls.

- The dialing mode setting is wrong. Change the setting of feature #13 (p. 53).

The unit does not work.

- Disconnect the unit from the telephone line and connect the line to a known working telephone. If the working telephone operates properly, contact our service personnel to have the unit repaired. If the working telephone does not operate properly, contact your telephone company.

The unit does not ring.

- The ringer volume is set to off. Adjust it (p. 19).

The other party complains they only hear a fax tone and cannot talk.

- FAX ONLY mode is set. Tell the other party the number is only used for faxes.
- Change to TEL mode (p. 36).
- If you use a distinctive ring service, turn AUTO ANSWER off so that the fax machine is in TEL mode.
- If you use a distinctive ring service, make sure you have set the same ring pattern assigned by the telephone company (p. 40).

The **REDIAL/PAUSE** button does not function properly.

- If this button is pressed during dialing, a pause will be inserted. If pressed immediately after a dial tone is obtained, the last number dialed will be redialed.

The receiving mode does not function properly.

- A Distinctive Ring pattern of feature #31 is set (p. 40).

During programming, I cannot enter the code or ID number.

- All or part of the numbers are the same. Change the number of features #12 (p. 53) and #41 (p. 55).

The unit beeps.

- Recording paper has run out. Press **STOP** to stop the beeps and install paper.

Whenever I try to retrieve my voice mail messages, the retrieval is interrupted by the fax tone.

- You are probably entering *98 or *99 to retrieve your messages. *9 is the default setting for the fax activation code. If you use a voice mail service, set the fax activation feature to off or reprogram the activation code (feature #41 on page 55).

Fax – sending

I cannot send documents.

- The telephone line cord is connected to the EXT jack on the unit. Connect to the LINE jack (p. 14).
- The other party's fax machine is busy or has run out of recording paper. Try again.
- The other party's machine is not a facsimile. Check with the other party.
- The other party's fax machine rings too many times. Send the fax manually (p. 28).

The other party complains that letters on their received document are distorted or not clear.

- If your line has special telephone services such as call waiting, the service may have been activated during fax transmission. Connect the unit to a line that does not have these services.
- The extension telephone on the same line is off the hook. Hang up the extension telephone and try again.
- Try copying the document. If the copied image is clear, there may be something wrong with the other party's machine.

(continued)

(continued)

Fax – sending (cont.)

The other party complains that dirty patterns or black lines appear on their received document.

- The glass or rollers are dirty. Clean them (p. 69).

I cannot send a fax overseas.

- Use the overseas transmission mode of feature #23 (p. 54).
- Add two pauses at the end of the telephone number or dial manually.

Fax – receiving

I cannot receive documents.

- The telephone line cord is connected to the EXT jack on the unit. Connect to the LINE jack (p. 14).
- When you have a single telephone line and subscribe to a telephone company's voice mail service, you must also subscribe to the Distinctive Ring Service (p. 40).

I cannot receive documents automatically.

- The receiving mode is set to TEL mode. Set to FAX ONLY mode (p. 37).
- The time taken to answer the call is too long. Decrease the number of rings of feature #06 (p. 52).

The display shows the following, but faxes are not received.

CONNECTING.....

- The incoming call is not a fax. Change the receiving mode to TEL mode (p. 36).

A blank sheet is ejected.

- The other party placed the document in their fax machine the wrong way. Check with the other party.

A white line or a dirty pattern appears on your recording paper.

- The glass or rollers are dirty. Clean them (p. 69).

(continued)

The printing quality is poor.

- The other party sent a faint document. Ask them to send a clearer copy of the document.
- Some paper has instructions recommending which side to print on. Try turning the paper over.
- You may have used paper with a cotton and/or fiber content that is over 20%, such as letterhead or resume paper.
- The remaining toner is low. Replace the toner cartridge (p. 64).
- We recommend you replace the drum unit every third time you replace the toner cartridge (p. 64). To check the drum life and quality, please print the printer test list (p. 71).
- The toner save mode of feature #79 is on (p. 56).

The other party complains that they cannot send a document.

- The memory is full of received documents due to a lack of recording paper or a recording paper jam. Install paper (p. 13) or clear the jammed paper (p. 66).

Receiving mode

I cannot select the desired receiving mode.

- If you want to set FAX ONLY mode:
— press **AUTO ANSWER** to turn on the AUTO ANSWER light.



- If you want to set TEL mode:
— press **AUTO ANSWER** to turn off the AUTO ANSWER light.



The other party complains that they cannot send a document.

- The unit is not in AUTO ANSWER mode. Press **AUTO ANSWER** to turn on the AUTO ANSWER light.

Copying

The unit does not make a copy.

- You cannot make a copy during programming. Make the copy after programming or stop programming.

A black line, a white line or a dirty pattern appears on the copied document.

- The glass or rollers are dirty. Clean them (p. 69).

The printing quality is poor.



- Some paper has instructions recommending which side to print on. Try turning the paper over.
- You may have used paper with a cotton and/or fiber content that is over 20%, such as letterhead or resume paper.
- The remaining toner is low. Replace the toner cartridge (p. 64).
- We recommend you replace the drum unit every third time you replace the toner cartridge (p. 64). To check the drum life and quality, please print the printer test list (p. 71).
- The toner save mode of feature #79 is on (p. 56).

Using an answering machine

I cannot receive documents automatically.

- Your greeting message on the answering machine is too long. Shorten the message (up to 10 seconds).
- The answering machine rings too many times. Set to 1 or 2 rings.

I cannot receive voice messages.

- Check if the answering machine is turned on and connected to the fax machine properly (p. 38).
- Set the number of rings on the answering machine to 1 or 2.

(continued)

I cannot retrieve recorded voice messages on the answering machine from a remote location.

- You did not program your remote access code into your fax machine correctly. Program the same code that is programmed on the answering machine on the fax machine with feature #12 (p. 53).

I pressed the remote access code to access the answering machine remotely, but the line was disconnected.

- The code may include “#” which is used for certain features provided by telephone companies. Change the code on the answering machine to another number which does not include “#”. Also change the code of the fax machine with feature #12 (p. 53).

Callers complain that they cannot send a document.

- Your answering machine has run out of recording tape. Rewind the tape to record messages.
- You set the answering machine to only give a greeting message.

Multi-Function Station

I cannot open a TIFF file.

- You must change the compression format of the file.
Example: To convert an image using Imaging for Windows.
 1. Click **[Start]**, point to **[Programs]** — **[Accessories]**, then click **[Imaging]**.
 2. Open the TIFF file that you cannot open in **[Multi-Function Viewer]**.
 3. Select **[Properties]** from the **[Page]** menu.
— The **[Page Properties]** dialog box will appear.
 4. Click the **[Compression]** tab, then select **[CCITT Group 3 (1d) Modified Huffman]** from the drop-down list.
 5. Click **[OK]**.
— The compression format of the file is now changed.

(continued)

Multi-Function Station (cont.)

[Launcher] disappears.

- Look in the tool bar. If you do not find the **[Launcher]** icon, it is closed. If you do find the icon, it is just minimized. Click the icon in the tool bar.

I cannot recognize the last part of an entry in the list of the [One Touch], [Directory], [Journal] or [Caller ID].

- Put the cursor on the line between the buttons, the cursor changes shape and you can expand the area by dragging or double-clicking.

When I exit Multi-Function Station, the [Multi-Function Viewer] window does not close.

- The **[Multi-Function Viewer]** window can be operated separately. Click the **[X]** button to close the window.

I cannot scan.

- The fax machine is in use. Try later on.
- There is not enough space on the hard disk. Delete unnecessary files and try again.
- There is not enough memory. Close some applications and try again.
- Restart the PC, and try again.
- Check the connection of the PC and the fax machine (p. 43).
- You attempted to scan a document longer than the paper size which you set in the **[Panasonic FLM551/FLB751 Series]** dialog box. Change the setting or divide the document into the appropriate paper size, and try again.

The document does not feed into the fax machine.

- Remove the document and reinsert it.

(continued)

Even after clicking [Cancel], scanning continues.

- Please wait. It may take a while for the cancel request to be accepted.

Multi-Function Station does not work properly.

- Click the **[X]** button to exit Multi-Function Station, and restart. If Multi-Function Station still does not close, restart the PC.
- If you connect the USB cable to USB hub, connect it to the USB port of your computer directly.
- Confirm the BIOS setting of your computer. For parallel connection, select ECP, Bi-directional or an equivalent parallel port mode. For USB connection, select USB port mode. Please refer to your PC operating instructions or consult the manufacturer.
- If you have any other multifunction softwares installed on your computer, uninstall it.

I want to replace the parallel cable with a USB cable and vice versa.

- You must change the printer properties.
 1. Replace the cables.
 2. Set the connection type (parallel or USB) by using the fax machine according to the cable type you use (feature #15 on page 53).
 3. Click **[Start]**, point to **[Settings]**, then click **[Printers]**.
 4. Right-click **[Panasonic FLM551/FLB751 Series]** and click **[Properties]**.
 - The **[Panasonic FLM551/FLB751 Series Properties]** dialog box will appear.
 5. Click the **[Details]** (Windows 98/Me) / **[Ports]** (Windows 2000) tab, select the connection type, then click **[OK]**.
 - If Multi-Function Station does not work correctly, uninstall the software, then re-install it.

If a power failure occurs

- The unit will not function.
- The unit is not designed for making emergency telephone calls when the power fails. Alternative arrangements should be made for access to emergency services.
- Fax transmission and reception will be interrupted.
- If any fax documents are stored in the memory, they will be lost. When power is restored, a power down report will be printed out stating which contents in the memory have been erased.

Replacement

Replacing the toner cartridge and the drum unit

When the display shows the following, replace the toner cartridge.

Display:

TONER LOW

or

TONER EMPTY


We recommend you replace the drum unit every third time you replace the toner cartridge. To check the drum life and quality, please print the printer test list (p. 71).

To ensure that the unit operates properly, we recommend the use of **Panasonic toner cartridge (Model No. KX-FA76) and drum unit (Model No. KX-FA77D)**. See page 5 for accessory information.

Caution:

- **The drum unit contains a photosensitive drum. Exposing it to light may damage the drum.**
Once you have opened the protection bag:
 - Do not expose the drum unit to light for more than 5 minutes.
 - Do not touch or scratch the green drum surface.
 - Do not place the drum unit near dust or dirt, or in a high humidity area.
 - Do not expose the drum unit to direct sunlight.
- **Do not unplug the fax machine to prevent loss of fax documents in memory.**
- **We cannot be responsible for any damage to the unit or degradation of print quality which may occur from the use of non-Panasonic toner cartridge and drum unit.**
- **Do not leave the toner cartridge out of the protection bag for a long time. It will decrease the toner life.**
- **Do not pour any toner into the toner cartridge.**


- 1** Remove the new toner cartridge from the protection bag. Peel off the seal from the toner cartridge.




- 2** Push the front cover open button then open the front cover.




Caution:
The fuser unit gets hot.
Do not touch it.



- 3** Tap on the used toner cartridge several times to allow the remaining toner to fall into the drum unit. Remove the drum and toner unit by holding the two tabs.
 - If you replace the toner cartridge and the drum unit at the same time, skip to step 6.




- 4** Turn the two levers on the used toner cartridge firmly.




- 5** Pull up the right edge of the used toner cartridge (①). Remove the cartridge from the drum unit (②).

- The toner may stick to the cartridge and the drum unit. Be careful when handling. See page 4 for details.
- Do not drop the toner on the green drum surface.
- Put the used toner cartridge into the protection bag.




- 6** If you replace the drum unit at the same time, remove the new drum unit from the protection bag. Remove the protection bar from the drum unit.


With "Panasonic" face up on the toner cartridge, match the red arrows on the cartridge and the drum unit.




- 7** Slide the tab on the toner cartridge into the slot of the drum unit.




- 8a** Firmly press down on the right side of the toner cartridge to snap into position and...



- 8b** turn the two levers on the toner cartridge with firm pressure.




- 9** The toner cartridge is installed when the triangles match.



(continued)



Replacement / Jams

- 10** Tap on the toner cartridge several times to allow the toner to fall into the drum unit. Grab the tabs, and shake the drum and toner unit horizontally several times.




- 11** Install the drum and toner unit by holding the tabs.

- If the lower glass is dirty, clean it with a soft and dry cloth.



- 12** Close the front cover, until locked, by pushing down on both sides.



Waste disposal method

- Waste material may be dumped or incinerated under conditions which meet all country and local environmental regulations.

Recording paper jam

When the recording paper has jammed in the unit


The display will show the following.

Display: PAPER JAMMED

- 1** Push the front cover open button then open the front cover.




Caution:
The fuser unit gets hot.
Do not touch it.




- 2** When the recording paper has jammed near the drum and toner unit:

Remove the jammed paper by pulling it toward you.




When the recording paper has jammed near the recording paper exit:

Remove the jammed paper by pulling it toward you.



- 3** Close the front cover, until locked, by pushing down on both sides.



- 4** Remove the recording paper. Straighten and reinsert it into the recording paper entrance.



When the recording paper was not fed into the unit properly

The display will show the following.

Display: FAILED PICK UP

Remove the recording paper. Straighten and reinsert it into the recording paper entrance.




Document jams - sending

- 1 Push the front cover open button then open the front cover.




Caution:
The fuser unit gets hot.
Do not touch it.




- 2 Pull down the middle guide while holding the front cover.

- 3 Remove the jammed document carefully.

- 4 Lift the middle guide firmly.



- 5 Close the front cover, until locked, by pushing down on both sides.



Note:


- Do not pull out the jammed document forcibly before opening the front cover.

No feeding or multiple feeding occurs while sending

If no feeding or multiple feeding occurs frequently, adjust the feeder pressure.

Shift the position of the green lever using a stick-like-instrument with a pointed end.

- Left:** When documents do not feed.
Center: Standard position (pre-selected)
Right: When documents multi-feed.



Cleaning the inside of the unit


If any of the following problems occurs, clean the inside of the unit:

- If misfeeding of your original occurs frequently.
- If a black line, a white line or a dirty pattern appears on your recording paper, on your original, or on the fax document received by the other party.

Caution:

- Be careful when handling the toner drum unit. See the caution for the drum unit on page 64 for details.
- Do not use paper products, such as paper towels or tissues, to clean the inside of the unit.


- 1** Disconnect the power cord and the telephone line cord.




- 2** Push the front cover open button then open the front cover.



Caution:
The fuser unit gets hot.
Do not touch it.




- 3** Pull down the middle guide while holding the front cover.



- 4** Clean the document feeder rollers with a cloth moistened with isopropyl rubbing alcohol, and let all parts dry thoroughly.

Clean the upper glass with a soft and dry cloth.


- 5** Lift the middle guide firmly.




(continued)

Cleaning


- 6** Remove the drum and toner unit by holding the two tabs.




- 7** Clean the lower glass with a soft and dry cloth.




- 8** Reinstall the drum and toner unit by holding the tabs.



- 9** Close the front cover, until locked, by pushing down on both sides.



- 10** Reconnect the power cord and the telephone line cord.



Reference lists and reports

You can print out the following lists and reports for your reference.

Setup list: provides you with the current settings of the basic and advanced programming features (p. 52–56).

Telephone number list: provides you with names and telephone numbers which are stored in one-touch dial and JOG DIAL.

Journal report: keeps records of fax transmission and reception. This report will be printed automatically after every 30 fax communications (p. 29).

Broadcast programming list: provides you with entries which are stored in the broadcast feature (p. 31).

Printer test list: allows you to check the print quality of your unit. If the test print has a dirty pattern, or blurred points or lines, clean the inside of the unit (p. 69). If printing quality is still poor, replace the toner cartridge and drum unit.

One-touch label card: provides you with names which are stored in the one-touch dial keys (p. 20). You can put the card in the one-touch dial location.

1 Press **MENU** repeatedly until the following is displayed.

Display: PRINT REPORT

2 Rotate **JOG DIAL** until the desired item is displayed.

SETUP LIST


TEL NO. LIST

JOURNAL REPORT

BROADCAST LIST

PRINTER TEST

ONE-TOUCH LABEL



3 Press **SET** to start printing.

PRINTING

- To stop printing, press **STOP**.
- After printing, the printed item will be displayed.

4 Press **MENU**.

List of FCC requirements and information

If required by the telephone company, inform them of the following.

- FCC Registration No.:
(found on the rear of the unit)
- Ringer Equivalence No.:
(found on the rear of the unit)
- The particular telephone line to which the equipment is connected.

This unit must not be connected to a coin operated line. If you are on a party line, check with your local telephone company.

Ringer Equivalence Number (REN):

This REN is useful in determining the quantity of devices you may connect to your telephone line and still have all of those devices ring when your telephone number is called. In most but not all areas, the sum of the REN's of all devices connected to one line should not exceed five (5.0). To be certain of the number of devices you may connect to your line, as determined by the REN, you should contact your local telephone company to determine the maximum REN for your calling area.

In the event that terminal equipment causes harm to the telephone network, the telephone company should notify the customer, if possible, that service may be stopped. However, where prior notice is impractical, the company may temporarily cease service providing that they:

- a) Promptly notify the customer.
- b) Give the customer an opportunity to correct the problem with their equipment.
- c) Inform the customer of the right to bring a complaint to the Federal Communication Commission pursuant to procedures set out in FCC Rules and Regulations Subpart E of Part 68.

The Telephone Company may make changes in its communications facilities, equipment operations, or procedures where such action is reasonably required in the operation of its business and is not inconsistent with the rules and regulations in FCC Part 68. If such changes can be reasonably expected to render any customer terminal equipment incompatible with telephone company communications facilities, or require modification or alteration of such terminal equipment, or otherwise materially affect its use or performance, the customer shall be given adequate notice in writing, to allow the customer an opportunity to maintain uninterrupted service.

CAUTION:

To assure continued compliance, use only shielded parallel or USB interface cable when connecting this equipment to host computer. Also, any changes or modifications not expressly approved by the party responsible for compliance could void the user's authority to operate this equipment.

When programming emergency numbers and/or making test calls to emergency numbers:

1. Remain on the line and briefly explain to the dispatcher the reason for the call before hanging up.
2. Perform such activities in the off-peak hours; such as early morning or late evenings.

This telephone provides magnetic coupling to hearing aids.

NOTE:

This equipment has been tested and found to comply with the limits for a Class B digital device, pursuant to Part 15 of the FCC Rules. These limits are designed to provide reasonable protection against harmful interference in a residential installation. This equipment generates, uses, and can radiate radio frequency energy and, if not installed and used in accordance with the instructions, may cause harmful interference to radio communications. However, there is no guarantee that interference will not occur in a particular installation. If this equipment does cause harmful interference to radio or television reception, which can be determined by turning the equipment off and on, the user is encouraged to try to correct the interference by one or more of the following measures:

- Reorient or relocate the receiving antenna.
- Increase the separation between the equipment and receiver.
- Connect the equipment into an outlet on a circuit different from that to which the receiver is connected.
- Consult the dealer or an experienced radio/TV technician for help.

Responsible Party:

Matsushita Electric Corporation of America
One Panasonic Way, Secaucus, NJ 07094

Technical Support:

Panasonic Consumer Electronics Company
Division of Matsushita Electric Corporation of America

One Panasonic Way, Secaucus, NJ 07094
Telephone: 1-800-HELP-FAX (1-800-435-7329)

Limited Warranty

Have any questions? For in warranty support, CALL 1-800-HELP-FAX (1-800-435-7329) on: operating the unit, getting repair service, and/or getting supplies.

**Panasonic Consumer Electronics Company,
Division of Matsushita Electric Corporation
of America**

One Panasonic Way,
Secaucus, New Jersey 07094

**Panasonic Sales Company,
Division of Matsushita Electric of
Puerto Rico, Inc.**

Ave. 65 de Infantería, Km. 9.5, San Gabriel
Industrial Park, Carolina, Puerto Rico 00985

PANASONIC Facsimile Products Limited Warranty

In the event of a defect in materials or workmanship, Panasonic Consumer Electronics Company or Panasonic Sales Company (collectively referred to as "the warrantor"), will repair this product with new or refurbished parts, free of charge, in the USA or Puerto Rico for one (1) year from the date of original purchase.

This Limited Warranty Excludes both Labor and Parts for: batteries, antennas, ink film, toner cartridge, drum unit, ink cartridge and cosmetic parts (cabinet).

Carry-in or mail-in service in the USA can be obtained during the warranty period by contacting a Panasonic Services Company (PASC) Factory Servicenter listed in the Servicenter Directory. Or call, toll free, 1-800-HELP-FAX (1-800-435-7329) to locate a PASC Factory Servicenter. Carry-in or mail-in service in Puerto Rico can be obtained during the warranty period by calling the Panasonic Sales Company telephone number listed in the Servicenter Directory.

This warranty is extended only to the original purchaser. A purchase receipt or other proof of date of original purchase will be required before warranty service is rendered.

This warranty only covers failures due to defects in material or workmanship which occur during normal use. The inability of this product to interface with any specific computer is not a manufacturing defect and is outside of the scope of this Limited Warranty. In no event shall the warrantor be liable by reason of such incompatibility. The warranty does not cover damages which occur in shipment, or failures which are caused by products not supplied by the warrantor such as non Panasonic ink film, toner cartridge or drum unit, or failures which result from accident, misuse, abuse, neglect, mishandling, faulty installation, misapplication, set-up adjustments, improper operation or maintenance, alteration, modification, power line surge, improper voltage supply, lightning damage, signal reception problems, rental use of the product, or service by anyone other than a PASC Factory Servicenter or a PASC authorized Servicenter, or damage that is attributable to acts of God.

LIMITS AND EXCLUSIONS

There are no express warranties except as listed above.

THE WARRANTOR SHALL NOT BE LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS WARRANTY. ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTIES OF MERCHANTABILITY, ARE LIMITED TO THE APPLICABLE WARRANTY PERIOD SET FORTH ABOVE.

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied warranty lasts, so the above exclusions or limitations may not apply to you.

This warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this product develops during or after the warranty period, you may contact your dealer or Servicenter. If the problem is not handled to your satisfaction, then write to the Customer Satisfaction Center at the company address indicated above.

For product service

- Servicenters are listed on next page.
- Call toll-free 1-800-HELP-FAX (1-800-435-7329) for the location of an authorized servicenter.

For out of warranty technical support

- After the warranty has expired, please contact our Continued Services Technical Support Line at 1-900-555-PANA (1-900-555-7262) for support on a fee basis.

When you ship the product

- Carefully pack your unit, preferably in the original carton.
- Attach a letter, detailing the symptom or problem, to the outside of the carton.
- Send the unit to an authorized servicenter, prepaid and adequately insured.
- Do not send your unit to the Panasonic Consumer Electronics Company or to any executive or regional sales offices. These locations do not repair consumer products.

Servicenter Directory

Servicenter directory

To obtain technical support within the warranty period or product service, please contact: 1-800-HELP-FAX (1-800-435-7329), Monday-Friday 9am-8pm EST.

To obtain continued technical support after the warranty has expired, please contact: 1-900-555-PANA (1-900-555-7262) for support on a fee basis.

Web Site: www.panasonic.com

(for customers in the USA or Puerto Rico ONLY)

You can purchase parts, accessories or locate your nearest servicenter by visiting our Web Site.

Factory Servicenter Locations

CALIFORNIA 6550 Katella Avenue Cypress, CA 90630 800 Dubuque Avenue S. San Francisco, CA 94080 3878 Ruffin Road Suite A San Diego, CA 92123 FLORIDA 3700 North 29 th Avenue Suite 102 Hollywood, FL 33020	GEORGIA 8655 Roswell Road Suite 100 Atlanta, GA 30350 ILLINOIS 1709 North Randall Road Elgin, IL 60123 MASSACHUSETTS 60 Glacier Drive Suite G Westwood, MA 02090	MINNESOTA 7850-12 th Avenue South Airport Business Center Bloomington, MN 55425 OHIO 2236 Waycross Road Civic Center Plaza Forest Park, OH 45240 PENNSYLVANIA 2221 Cabot Blvd. West Suite B Langhorne, PA 19047	TEXAS 13615 Welch Road Suite 101 Farmers Branch, TX 75244 WASHINGTON 20425-84 th Avenue South Kent, WA 98032 HAWAII 99-859 Iwaiwa Street Aiea, Hawaii 96701 Phone (808) 488-1996 Fax (808) 486-4369
--	---	--	---

Service in Puerto Rico

Matsushita Electric of Puerto Rico, Inc. Panasonic Sales Company / Factory Servicenter:
Ave. 65 de Infantería, Km. 9.5, San Gabriel Industrial Park, Carolina, Puerto Rico 00985
Phone (787) 750-4300 Fax (787) 768-2910

Technical data about this product

Applicable lines:	Public Switched Telephone Network
Document size:	Max. 216 mm (8½") in width / Max. 600 mm (23⅝") in length
Effective scanning width:	208 mm (8¾")
Effective printing width:	208 mm (8¾")
Transmission time*:	Approx. 8 s/page (ECM-MMR)**
Scanning density:	Horizontal: 8 pels/mm (203 pels/inch) Vertical: 3.85 lines/mm (98 lines/inch) –STANDARD 7.7 lines/mm (196 lines/inch) –FINE/PHOTO 15.4 lines/mm (392 lines/inch) –SUPER FINE
Halftone level:	64-level
Scanner type:	Contact Image Sensor (CIS)
Printer type:	Laser Beam Printer
Data compression system:	Modified Huffman (MH), Modified READ (MR), Modified Modified READ (MMR)
Modem speed:	14,400 / 12,000 / 9,600 / 7,200 / 4,800 / 2,400 bps; Automatic Fallback
Operating environment:	10 °C – 32.5 °C (50 °F – 90.5 °F), 20% – 80% RH (Relative Humidity)
Dimensions (H x W x D):	190 mm x 417 mm x 345 mm (7½" x 16⅝" x 13⅝")
Mass (Weight):	Approx. 6.5 kg (14.3 lb.)
Power consumption:	Standby: Approx. 6 W Transmission: Approx. 25 W Reception: Approx. 200 W Copy: Approx. 200 W Maximum: Approx. 560 W (When the fuser unit turns on)
Power supply:	120 V AC, 60 Hz
Memory capacity:	Approx. 150 pages of memory transmission/reception (Based on the ITU-T No. 1 Test Chart in standard resolution.)
Laser diode properties:	Laser output: Max. 5 mW Wave length: 760 nm – 800 nm Emission duration: Continuous
Print speed:	10 ppm (pages per minute)
Printing resolution:	600 x 600 dpi


* Transmission speed depends upon the contents of the pages, resolution, telephone line conditions and capability of the other party's machine.

** Transmission speed is based upon the ITU-T No. 1 Test Chart and original mode.
If the capability of the other party's machine is inferior to your unit, the transmission time may be longer.

Note:

- Any details given in these instructions are subject to change without notice.
- The pictures and illustrations in these instructions may vary slightly from the actual product.

ITU-T No. 1 Test Chart



Specifications

■ Paper specifications:

Plain paper/Transparency:	Letter:	216 mm x 279 mm (8½" x 11")
	Legal:	216 mm x 356 mm (8½" x 14")
	A4:	210 mm x 297 mm (8¼" x 11 ¹¹ / ₁₆ ")
Envelope:	COM10:	105 mm x 241 mm (4 ¹ / ₈ " x 9½")
	DL:	110 mm x 220 mm (4 ⁵ / ₁₆ " x 8 ⁵ / ₈ ")

Note:

- Do not use the following types of paper:
 - Paper with a cotton and/or fiber content that is over 20%, such as letterhead paper or paper used for resumes.
 - Extremely smooth or shiny paper, or paper that is highly textured.
 - Coated, damaged or wrinkled paper.
 - Paper with irregularities, such as tabs or staples.
 - Paper which has dust, lint or oil stains.
 - Paper that will melt, vaporize, discolor, scorch or emit dangerous fumes, near 200 °C (392 °F), such as vellum paper. These materials may transfer onto the fusing roller and cause damage.
 - Inkjet paper.
 - Moist paper.
- Some paper only accepts print on one side. Try using the other side of the paper if you are not happy with the print quality or if misfeeding occurs.
- For proper feeding and best print quality, we recommend using long-grained paper.
- Do not use paper of different types or thickness at the same time. This may cause a paper jam.
- Avoid double-sided printing.
- Do not use paper printed from this unit for double-sided printing with other copiers or printers. This may cause a paper jam.
- To avoid curling, do not open paper packs until you are ready to use the paper. Store unused paper in the original packaging, in a cool and dry location.

■ Toner life

Toner life depends on the amount of content in a received, copied or printed document. The following is the approximate relationship between image area and toner life for Model No. KX-FA76 toner cartridge. Toner life varies in actual usage.

5% image area

10% image area

15% image area

Specifications	
Main unit specifications	
1. Applicable Lines:	Public switched telephone network
2. Compatibility:	ITU-TS G3
3. Effective Scanning Width:	Max. 209mm
4. Recording Paper Size:	Letter: 216 x 279mm Legal: 216 x 356mm
5. Effective Printing Width:	206mm
6. Transmission Times:	Approx. 30sec/page (G3 Normal mode, NR) Approx. 17sec/page (G3 Original mode, NR) Approx. 15sec/page (G3 Original mode, NR)
7. Fax Redial Times:	Up to 15 times
8. Telephone Redial Times:	Up to 15 times
9. Scanning Density:	Horizontal: 80e/lcm Vertical: 3.951lines/cm (Standard mode) Half-tone mode
10. Scanner Type:	Contact image sensor

Approx. 2,000 sheets of letter size paper can be printed.

Specifications	
Main unit specifications	
1. Applicable Lines:	Public switched telephone network
2. Compatibility:	ITU-TS G3
3. Effective Scanning Width:	Max. 209mm
4. Recording Paper Size:	Letter: 216 x 279mm Legal: 216 x 356mm
5. Effective Printing Width:	206mm
6. Transmission Times:	Approx. 30sec/page (G3 Normal mode, NR) Approx. 17sec/page (G3 Original mode, NR) Approx. 15sec/page (G3 Original mode, NR)
7. Fax Redial Times:	Up to 15 times
8. Telephone Redial Times:	Up to 15 times
9. Scanning Density:	Horizontal: 80e/lcm Vertical: 3.951lines/cm (Standard mode) Half-tone mode
10. Scanner Type:	Contact image sensor
11. Printer Type:	Electrophotographic LED Array Printer
12. Data Compression System:	Modified Huffman (MH), Modified READ (MR)
13. Modem Speed:	9600/7200/4800/2400bps Automatic Fall-back
14. Operating Environment:	10-32.5 °C 20-80%RH
15. Dimensions (H x W x D):	391 x 448 x 409mm
16. Resolution:	Approx. 120p
17. Power Consumption:	Standby: 12-40W Transmission: 17-200W Reception: 12-40W Idle: 24-30W Maximum: 60W
*Transmission Time: Transmission time apply to test data using ITU-TS No. 1 test chart, between the same models at operation speed and may vary in actual usage.	

Approx. 1,000 sheets of letter size paper can be printed.

Specifications	
Main unit specifications	
1. Applicable Lines:	Public switched telephone network
2. Compatibility:	ITU-TS G3
3. Effective Scanning Width:	Max. 209mm
4. Recording Paper Size:	Letter: 216 x 279mm Legal: 216 x 356mm
5. Effective Printing Width:	206mm
6. Transmission Times:	Approx. 30sec/page (G3 Normal mode, NR) Approx. 17sec/page (G3 Original mode, NR) Approx. 15sec/page (G3 Original mode, NR)
7. Fax Redial Times:	Up to 15 times
8. Telephone Redial Times:	Up to 15 times
9. Scanning Density:	Horizontal: 80e/lcm Vertical: 3.951lines/cm (Standard mode) Half-tone mode
10. Scanner Type:	Contact image sensor
11. Printer Type:	Electrophotographic LED Array Printer
12. Data Compression System:	Modified Huffman (MH), Modified READ (MR)
13. Modem Speed:	9600/7200/4800/2400bps Automatic Fall-back
14. Operating Environment:	10-32.5 °C 20-80%RH
15. Dimensions (H x W x D):	391 x 448 x 409mm
16. Resolution:	Approx. 120p
17. Power Consumption:	Standby: 12-40W Transmission: 17-200W Reception: 12-40W Idle: 24-30W Maximum: 60W
*Transmission Time: Transmission time apply to test data using ITU-TS No. 1 test chart, between the same models at operation speed and may vary in actual usage.	

Approx. 650 sheets of letter size paper can be printed.

Note:

- The image area changes with the depth, thickness and size of the characters.
- If you change the toner save setting to on, the toner cartridge will last approx. 40% longer.

■ Drum life

The included drum unit or Model No. KX-FA77D can print approx. 6,000 sheets of letter size paper regardless of the content of the image area.

Program index

Basic features

Code	Feature name	
#01	Date and time	15
#02	Your logo.....	16
#03	Your facsimile telephone number	18
#04	Sending report	29, 52
#06	FAX ring setting	52
#12	Remote activation ID	53
#13	Dialing mode.....	53
#15	Cable selection	53
#16	Paper size.....	53
#17	Ringer pattern.....	19, 53

Advanced features

Code	Feature name	
#22	Journal report	29, 54
#23	Overseas mode	54
#25	Delayed transmission	54
#26	Caller ID list	24, 55
#31	Ring detection.....	40
#37	Auto reduction	55
#39	Display contrast	55
#41	Remote fax activation code.....	39, 55
#44	Fax receiving alert	55
#68	ECM selection	55
#76	Connecting tone	56
#79	Toner save	56
#80	Reset advanced features.....	56

Index

- A** Accessories5
 - (Document stacker)12
 - (Paper stacker)12
 - (Paper tray)12Advanced features54–56Alert
 - (Memory reception) (Feature #44) .55Answering machine38Auto reduction (Feature #37)36, 55
- B** Basic features52, 53Broadcast transmission31Buttons / Keys
 - (AUTO ANSWER)36, 37
 - (BROADCAST)31, 33
 - (CALLER ID PRINT)26
 - (CALLER ID SEARCH)25, 27
 - (COLLATE)42
 - (Delete)17
 - (DIRECTORY PROGRAM) . . .20, 21
 - (HELP)8
 - (Insert)17
 - (LOWER)20, 23, 30
 - (MANUAL BROAD)31, 33
 - (MONITOR)23
 - (NAME/TEL NO.)23, 25
 - (QUICK SCAN START)28
 - (REDIAL)28
 - (RESOLUTION)28, 41
 - (Station)20, 23, 30
- C** Cable selection (Feature #15) . . .43, 53Caller ID24
 - (Calling back)25
 - (Storing)27, 50Caller ID list (Feature #26)24, 55Character table17Cleaning69Communication messages57Connecting tone (Feature #76)56Connections14, 43Copy41
 - (Collation)42
 - (Enlarge)42
 - (Reduce)42
- D** Date and time (Feature #01)15, 52Delayed transmission (Feature #25) . .54Dialing mode (Feature #13)53Display
 - (Contrast)(Feature #39)55
 - (Error messages)58, 59Distinctive ring service
 - (Feature #31)40, 55Document size29Drum life76Drum unit10, 64
- E** ECM selection (Feature #68)55Envelope48Error messages57–59Extension telephone39
- F** Facsimile telephone number
 - (Feature #03)18, 52Fax activation code
 - (Feature #41)39, 55Fax auto redial30FAX ONLY mode37Fax receiving34, 35Feeder pressure68
- H** Help8, 45
- J** Jams
 - (Document)68
 - (Paper)66, 67JOG DIAL
 - (Making a phone call)23
 - (Selecting characters)17
 - (Sending faxes)30
 - (Storing)21, 50Journal report (Feature #22)29, 54
- L** Label47Logo (Feature #02)16, 52
- M** Memory reception36Multi-Function Station software
 - (Activating)45
 - (Installing)44

- O** OCR software49
- One-touch dial
 - (Card)20, 71
 - (Making a phone call)23
 - (Sending faxes)30
 - (Storing)20, 50
- Overseas mode (Feature #23)54
- P** Paper size (Feature #16)53
- Parallel cable43
- Power failure63
- Printer46
- Printing paper size46, 76
- R** Receiving alert (Feature #44)55
- Receiving setting34, 35
- Recording paper13
- Remote activation ID (Feature #12) .53
- Remote control50
- Reports
 - (Broadcast programming)71
 - (Broadcast sending)33
 - (Caller ID)24, 26, 50
 - (Journal)29, 50, 71
 - (One-touch label)20, 71
 - (Power down)63
 - (Printer test)71
 - (Sending)29
 - (Setup)71
 - (Telephone number)71
- Reset (Feature #80)56
- Resolution28, 41
- Ring detection (Feature #31)40, 55
- Ring setting
 - (FAX ONLY)(Feature #06)52
- Ringer pattern (Feature #17)19, 53
- S** Scanner49
- Sending
 - (Broadcast)33
 - (JOG DIAL)30
 - (Manually)28
 - (One-touch dial)30
 - (Quick scan)28
- Sending report (Feature #04)29, 52
- Set default (Feature #80)56
- Storing
 - (Broadcast)31, 50
 - (JOG DIAL)21, 50
 - (One-touch dial)20, 50
- T** TEL mode36
- Toner cartridge10, 64
- Toner life76
- Toner save (Feature #79)11, 56
- Transparency47
- U** USB cable43
- V** Viewer49
- Volume19

Panasonic FAX ADVANTAGE PROGRAM

*Free peace of mind,
direct from Panasonic*

NO EXTRA COST



- **1-year limited warranty¹: parts, labor, and toll-free help line²**
- **Free overnight replacement³ and repair program**

The Panasonic Fax Advantage Consumer Service Program.

Panasonic knows that if your fax machine is not up and running, neither is your business. That's why we created the Panasonic Fax Advantage Program. Included at no extra cost with the purchase of a new and unused Panasonic Fax Machine, the Fax Advantage Program can provide a free replacement unit³ overnight if your original unit is in need of repair.

Here's how it works:

1. If you have a problem with your fax that you purchased new and unused while it is covered by the period of limited warranty¹, call our toll-free help-line at 1-800-HELP-FAX².
2. Talk to one of our technical experts to diagnose your problem over the phone.
3. If repairs are necessary and you are entitled to service under the terms and conditions of the limited warranty⁴, we will send a refurbished replacement unit to you by UPS overnight service delivery.

A second option available under our limited warranty is to mail-in or carry-in your fax to one of our Regional Service centers, where the unit will be repaired and returned to you.

Instructions:

If you choose to receive a replacement unit under the Fax Advantage Program, Panasonic will provide a replacement unit which will be completely refurbished, quality-tested by Panasonic technicians and individually hand-inspected before it is shipped to you. You will keep the replacement unit and send the original unit to us in the replacement unit's box. UPS will pick up the unit at no charge to you, should it be determined that you are entitled to warranty service. A proof-of-purchase must be included with the returned product. Any unit that is replaced by Panasonic and not shipped with proper proof-of-purchase by you will be subject to a minimum \$100.00 charge. The original unit must be properly packaged in the same manner as the replacement unit, utilizing the packing materials provided. Damage due to improper or

inadequate packing will be charged to you as an out-of-warranty cost. If our 1-800-HELP-FAX technicians determine that your unit may be an "out-of-box failure"⁵, we will attempt to provide you with a factory-new replacement unit⁶. You must ship a copy of your receipt with your original unit to verify that you purchased the unit within 10 days prior to your 1-800-HELP-FAX call.

Requirements:

You must give our technicians a valid credit card number (Discover, VISA, Master Card, or American Express/Optima). Product that is not returned to Panasonic by 10 business days after shipment of the replacement product will be charged to your credit card account at Panasonic's Suggested Retail Price (see dealer for details). If your original unit is not eligible for warranty service, your card will be charged for the non-warranty repair of the unit at Panasonic's current rate for parts and labor and for any shipping charges associated with this program. If you do not wish to pay out-of-warranty repair costs, you will be responsible for returning the replacement unit to Panasonic and for paying all shipping charges associated with this program including the overnight delivery of the replacement product to you, shipment of the problem unit to Panasonic, shipment of the replacement unit back to Panasonic and the return of your original unit back to you. Credit status will be verified prior to sending the replacement product.

1. See dealer for limited warranty details.
2. After the fax advantage program, contact our Continued Services Technical Support Line at 1-900-555-PANA (1-900-555-7262), for fee based technical support.
3. Replacement unit is refurbished.
4. Replacement program is only available in the 50 United States and is subject to termination at any time without advance notice.
5. "Out-of-box failure" is an inoperable unit that was purchased no more than 10 days prior to your 1-800-HELP-FAX call, and would otherwise qualify for warranty service under the terms and conditions of the limited warranty.
6. Panasonic reserves the right to send a refurbished unit.

**Panasonic Consumer Electronics
Company, Division of Matsushita
Electric Corporation of America**

One Panasonic Way,
Secaucus, New Jersey 07094

**Panasonic Sales Company,
Division of Matsushita Electric of
Puerto Rico, Inc.**

Ave. 65 de Infantería, Km. 9.5
San Gabriel Industrial Park, Carolina,
Puerto Rico 00985