

# Quick Reference


## Loading paper

### Loading trays


**CAUTION—TIPPING HAZARD:** To reduce the risk of equipment instability, load each tray separately. Keep all other trays closed until needed.

1 Remove the tray.


**Note:** To avoid paper jams, do not remove trays while the printer is busy.




2 Adjust the paper guides to match the size of the paper that you are loading.



3 Flex, fan, and align the paper edges before loading.



4 Load the paper stack with the printable side facedown, and then make sure that the side guides fit snugly against the paper.



### Notes:


- Load letterhead facedown with the top edge of the sheet toward the front of the tray for one-sided printing.
- Load letterhead faceup with the bottom edge of the sheet toward the front of the tray for two-sided printing.
- Do not slide paper into the tray.
- To avoid paper jams, make sure that the stack height is below the maximum paper fill indicator.

5 Insert the tray.


If necessary, set the paper size and paper type from the control panel to match the paper loaded.

### Loading the multipurpose feeder


1 Open the multipurpose feeder.



- Adjust the guide to match the size of the paper that you are loading.



- Flex, fan, and align the paper edges before loading.



- Load paper with the printable side faceup.

**Notes:**

- Load letterhead faceup with the top edge of the sheet toward the front of the tray for one-sided printing.
- Load letterhead facedown with the bottom edge of the sheet toward the front of the tray for two-sided printing.
- Load envelopes with the flap facedown on the left side.
- Load European envelopes with the flap facedown and entering the printer first.

**Warning—Potential Damage:** Do not use envelopes with stamps, clasps, snaps, windows, coated linings, or self-stick adhesives.

- From the control panel, set the paper size and paper type to match the paper loaded.

## Setting the size and type of the specialty media

The trays automatically detect the size of plain paper. For specialty media like labels, card stock, or envelopes, do the following:

- From the home screen, navigate to:  
**Settings > Paper > Tray Configuration > Paper Size/Type > select a paper source**
- Set the size and type of the specialty media.

## Printing

### Printing from a computer

**Note:** For specialty media such as labels, card stock, and envelopes, set the paper size and type in the printer before sending the print job.

- With a document open, click **File > Print**.
- If necessary, adjust the settings.
- Send the print job.

### Printing confidential and other held jobs

#### For Windows users

- With a document open, click **File > Print**.
- Click **Properties, Preferences, Options, or Setup**.
- Click **Print and Hold**.
- Select **Use Print and Hold**, and then assign a user name.
- Select the print job type (Confidential, Repeat, Reserve, or Verify).  
If the print job is confidential, then enter a four-digit PIN.
- Click **OK or Print**.
- From the printer home screen, release the print job.
  - For confidential print jobs, navigate to:

**Held jobs > select your user name > Confidential > enter the PIN > select the print job > configure the settings > Print**

- For other print jobs, navigate to:

**Held jobs > select your user name > select the print job > configure the settings > Print**

#### For Macintosh users

- With a document open, choose **File > Print**.  
If necessary, click the disclosure triangle to see more options.
- From the print options or Copies & Pages menu, choose **Job Routing**.
- Select the print job type (Confidential, Repeat, Reserve, or Verify).  
If the print job is confidential, then assign a user name and a four-digit PIN.
- Click **OK or Print**.
- From the printer home screen, release the print job.
  - For confidential print jobs, navigate to:  
**Held jobs > select your user name > Confidential > enter the PIN > select the print job > configure the settings > Print**
  - For other print jobs, navigate to:  
**Held jobs > select your user name > select the print job > configure the settings > Print**

### Canceling a print job

#### From the printer control panel

- From the home screen, touch **Job Queue**.  
**Note:** You can also access this setting by touching the top section of the home screen.
- Select the job to cancel.


#### From the computer

- Depending on the operating system, do either of the following:
  - Open the printers folder, and then select your printer.
  - From the System Preferences in the Apple menu, navigate to your printer.
- Select the job to cancel.


## Maintaining the printer

### Replacing the toner cartridge


1 Open door A.



2 Remove the used toner cartridge.




3 Unpack the new toner cartridge, and then shake it three times to redistribute the toner.



4 Insert the new toner cartridge.


**Note:** Use the arrows inside the printer as guides.




5 Close door A.

### Replacing the imaging unit


1 Open door A.




2 Remove the toner cartridge.



3 Remove the used imaging unit.



4 Unpack the new imaging unit, and then shake it three times to redistribute the toner.




**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.

**Warning—Potential Damage:** Do not touch the photoconductor drum. Doing so may affect the quality of future print jobs.




5 Insert the new imaging unit.

**Note:** Use the arrows inside the printer as guides.



6 Insert the toner cartridge.

**Note:** Use the arrows inside the printer as guides.




7 Close door A.

## Clearing jams

### Avoiding jams


#### Load paper properly

- Make sure that the paper lies flat in the tray.



- Do not load or remove a tray while the printer is printing.
- Do not load too much paper. Make sure that the stack height is below the maximum paper fill indicator.


- Do not slide paper into the tray. Load paper as shown in the illustration.



- Make sure that the paper guides are positioned correctly and are not pressing tightly against the paper or envelopes.
- Push the tray firmly into the printer after loading paper.

### Use recommended paper

- Use only recommended paper or specialty media.
- Do not load paper that is wrinkled, creased, damp, bent, or curled.
- Flex, fan, and align the paper edges before loading.




- Do not use paper that has been cut or trimmed by hand.
- Do not mix paper sizes, weights, or types in the same tray.
- Make sure that the paper size and type are set correctly on the computer or printer control panel.
- Store paper according to manufacturer recommendations.

## Identifying jam locations

### Notes:


- When Jam Assist is set to On, the printer automatically flushes blank pages or partially printed pages after a jammed page has been cleared. Check your printed output for blank pages.
- When Jam Recovery is set to On or Auto, the printer reprints jammed pages.




	Jam location
1	Standard bin
2	Rear door
3	Tray [x]
4	Multipurpose feeder
5	Door A

## Paper jam in door A


- Remove the tray.




- Open door A.



3 Remove the toner cartridge.




4 Remove the imaging unit.



**Warning—Potential Damage:** Do not expose the imaging unit to direct light for more than 10 minutes. Extended exposure to light may cause print quality problems.



**Warning—Potential Damage:** Do not touch the photoconductor drum. Doing so may affect the quality of future print jobs.



5 Remove the jammed paper.


**CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.

**Note:** Make sure that all paper fragments are removed.




6 Insert the imaging unit.

**Note:** Use the arrows inside the printer as guides.



7 Insert the toner cartridge.

**Note:** Use the arrows inside the printer as guides.





8 Close door A.

9 Insert the tray.

### Paper jam in the rear door


1 Open the rear door.

 **CAUTION—HOT SURFACE:** The inside of the printer might be hot. To reduce the risk of injury from a hot component, allow the surface to cool before touching it.



2 Remove the jammed paper.

**Note:** Make sure that all paper fragments are removed.




3 Close the rear door.

### Paper jam in the standard bin


Remove the jammed paper.

**Note:** Make sure that all paper fragments are removed.




### Paper jam in the duplex unit

1 Remove the tray.



2 Remove the jammed paper.


**Note:** Make sure that all paper fragments are removed.



3 Insert the tray.


### Paper jam in trays

1 Remove the tray.



2 Remove the jammed paper.

**Note:** Make sure that all paper fragments are removed.



3 Insert the tray.

### Paper jam in the multipurpose feeder


1 Remove paper from the multipurpose feeder.

2 Remove the jammed paper.

**Note:** Make sure that all paper fragments are removed.



3 Flex, fan, and align the paper edges before loading.



4 Reload paper, and then adjust the paper guide.

