

---

**SX-100<sup>®</sup>/SX-200<sup>®</sup>**

---

***SUPERSET 3<sup>™</sup>***

***SUPERSET 4<sup>™</sup>***

# **User Guide**



# Introduction

---

Welcome to the Mitel SUPERSWITCH® system.

In the days ahead, you'll be able to explore the many features provided with your system.

With the SUPERSET 4™ telephone set, you'll discover that advanced call-handling is only a touch-of-a-button away.

We've prepared this guide so that you'll know exactly how to use the SUPERSET 3™ or SUPERSET 4 set.

The features available on your system have been specially selected by your company and may not include all the features described in this guide.

# **SUPERSET 4**

---

# Contents

	<b>Page</b>
Your SUPERSET 4	
Overview	1-2
Line Select Keys	1-4
Line Displays	1-4
Handsfree Operation	1-5
Placing a Call	1-6
Answering Calls	1-8
Placing a Call on Hold	1-9
Transferring Calls	1-10
Finishing Calls	1-12
Speed Calling	1-13
Conference Calls	1-16
UCD Agent	1-18
Sub-attendant	1-19
And More!	
ADD HELD	1-22
BACKGROUND MUSIC	1-22
CALLBACK	1-23
CALL FWD	1-23
CAMP ON	1-26
CANCEL	1-26
CONF	1-27
HANG-UP	1-27
MSG	1-28
NAME	1-30
NIGHT ANS	1-32
OVERRIDE	1-33
PAGE	1-33
PRIVACY REL	1-34
PROGRAM	1-34
REDIAL	1-35
RELEASE	1-35
REMINDER	1-35
SEND MSG	1-38
SPEED CALL	1-38
SPLIT	1-40
SWAP	1-40
SWAP CAMP ON	1-41
TRANS/CONF	1-42
1:FWD	1-43
2:NO DIST'B	1-44
3:AUTO ANS	1-44
4:MSG	1-45
5:ACC	1-46

# Your SUPERSET 4

---

## Overview

### **1 Speaker Volume Control**

Used to increase or decrease the speaker volume.

### **2 Ringer Volume Control**

Increases or decreases the ringer volume.

### **3 Line Status Display**

Used to display status of the line assigned to the corresponding key.

### **4 Speed Call Keys and Line Select Keys**

These keys may be assigned as internal or outgoing lines. The remaining keys can be used as speed call keys.

### **5 Hold Key**

Used to place a line on hold.

### **6 Feature Display**

A liquid crystal display used to display prompts and messages.

### **7 Feature Keys**

Six unmarked feature keys used to activate the corresponding feature named in the feature display.

### **8 Microphone**

A sensitive microphone for handsfree set operation.

### **9 Ringer Pitch Control**


Used to adjust the pitch of the ringer, making it easy to identify your set when it's ringing. Accessible through a hole in the base of the set, the control can be adjusted with a screwdriver.

### **10 Supplementary Feature Keys *display***

Used in conjunction with other keys to display saved numbers, call forward settings, identities of lines and calling or camped-on parties. To clear the display, press EXIT feature key.

# Your SUPERSET 4

---



***select features***

Used to select and enable or disable supplementary features in the features display.

***speaker on/off***

Used for handsfree SUPERSET 4 set operation.

***mic. on/off***

Used to switch the microphone ON or OFF.

**11 Dial Key Pad**

A standard 12-key telephone dial pad.

**12 Handset**

Used for private conversations.

**13 Speaker**

Both ringer and voice outputs share the same speaker. There are separate volume controls for ringer and voice.

# Your SUPERSET 4 (cont'd)
















---

## Line Select Keys

Normally, when you lift the handset or press the *speaker on/off* key, your own line is selected automatically.


To place or answer a call on a different line, press the appropriate line select key. You may have lines on your set which are assigned to other sets. Your conversations on these lines will be private, unless you add another user to the conversation by using a system feature.

## Line Displays

When a line is	the line status display appears as shown below			
Idle				
Called (incoming call)				 Alternating
Busy				
Busy at another extension				
On Hold				 Flashing
On Hold at another extension				 Flashing

# Handsfree Operation

---



## To change from handset to speaker operation

**Press the *speaker on/off* key (1) and replace handset**

Continue your conversation handsfree.

## To change from speaker to handset operation

**Lift the handset**

The speaker and microphone are now disabled.

## To consult privately during speaker operation


**Press *microphone on/off* (2)**

Speaker is still in use but microphone is now disabled.



# Placing a Call

---



## to place a call to another extension

### **Obtain dial tone**

Lift handset,

or press *speaker on/off* key (1)

**and either dial extension number,**

**or press a speed call key (2)**

if the number has been saved for speed calling.

**or dial the required number**

without lifting the handset.

## to place a call to another extension – Intercom

**Press an intercom speed call key**

# Placing a Call

---

## To place a call to an outside number

### **Obtain dial tone**

Lift handset,

or press *speaker on/off* key (1)

### **and either dial extension number**

### **or press a speed call key (2)**

if the number has been saved for speed calling.

### **or press REDIAL (3)**

if the number is the last number you dialed.

### **or press CALL (4)**

if you are returning a call in response to a message.

If your own line is free, the line is selected automatically; otherwise select a free line select key (2) and dial a number from the Dial Key Pad.


If the line indicator next to the line select key is lit, someone else is using that line.

### **or dial the required number**

without lifting the handset.

# Answering Calls

---



When a new call arrives at your set, the appropriate line status display flashes and the set may ring.

## To answer a call

**Either lift the handset**

and speak with the caller privately.

**or press the *speaker on/off* key (1)**


and speak with the caller in handsfree mode.

**or press the *flashing line select* key (2)**

and speak with the caller in handsfree mode.

# Placing a Call on Hold

---



## To place a call on hold

**Advise the caller**

**Press the *hold* key (1)**

The indicator lamp next to the line on hold flashes.

## To retrieve a call from hold from another SUPERSET 4 set with that line appearance


**Press appropriate flashing line select key (2)**

You are connected to the held call.

**Note:** You may dial a call pickup code.

# Transferring Calls

---



## o transfer a caller to another extension

Advise caller of pending transfer.

### **Press TRANS/CONF (1)**

The call is placed on temporary hold.

**Dial the number manually from the dial key pad**

**or press appropriate speed call key (2)**

# Transferring Calls

---

**If the selected extension is ringing or busy and you do not wish to stay on the line**

**Press RELEASE (3)**

The caller is transferred to the ringing extension.

The user of the busy extension hears two quick beeps indicating the waiting call. When the busy extension user hangs up, his/her phone rings and the waiting call is connected automatically.

If there is no answer after a time-out period, the transferred call returns and rings your extension.

**If you wish to stay on the line**

Wait until the ringing extension is answered.

**Speak with the extension user**

**Press *speaker on/off* key (4)**

if you are in handsfree mode,

**or replace handset**

The call is transferred.

---


**To retrieve a held call**

**Press CANCEL**

You are reconnected with the held call.

# Finishing Calls

---



## To finish a call

**Replace handset**

**or press *speaker on/off* key (1)**  
if speaker is in use.

**or press HANG-UP (2)**

# Speed Calling

---


Frequently used extension or outside telephone numbers may be saved for automatic dialing.

## To organize a number for speed calling

Before you save a number, follow the given example and write down long numbers exactly as you would dial them.

For example, a typical long-distance telephone number would be dialed as follows:

9 + 1 + 613 + 5550000



These special codes can be inserted into the saved telephone number:

- \*1 – Used to suspend speed dialing for 5 seconds to all telephone-exchange equipment, to prepare for reception of more digits.
- \*2 – Used to wait for dial tone. (You may find that in some areas, \*1 is more useful than \*2.)
- \*3 – Used to insert a predialed sequence. This code must be followed by a 1-digit number (1-9) that specifies the quantity of digits to be dialed manually.
- \*5 – Used for an intercom number. Dial the extension number of another SUPERSET, plus \*5. These calls are routed to the other set's speaker, even if the set is busy.

**Note:** If your system has the ARS feature, do not store \* codes for outside numbers.



## Speed Calling (cont'd)

---

The following example illustrates the use of \*3. The general number for directory assistance is:

1 + (area code) + 5551212

The area code determines which area you are making the inquiry in, and is unknown until you require assistance. With the set, you can save the number and make use of the \*3 code to suspend dialing until you dial the area code from the keypad.

In this case, write down the number

9 + 1 + \*3 + 3 + 5551212

where,

\*3 suspends dialing until you've dialed the area code from the keypad.

3 tells the set to wait for three digits to be dialed manually.

After pressing a key with \*3 saved in the number, you hear a beep prompting you to dial digits manually. If the digits you dial are less than the quantity specified when the number was saved, press # and dialing will begin.

Based on the above example, if you want to call the Toronto directory assistance.

**Press appropriate speed call key**

Listen for beep.


**Dial 416**

– the Toronto area code.

The system dials 9 1 416 5551212 automatically.

# Speed Calling (cont'd)

---



## To use a speed call key

### Press a speed call key (3)

The stored number is dialed for you automatically.

## To assign a speed call key

### Press PROGRAM (1)

### Press SPEED CALL (2)

### Press required speed call key (3)

### Enter digits to be saved

from the dial key pad.

### Press EXIT (1)


to abandon the new entry leaving the previously saved number intact.

### Press SAVE (5)

The new number is now saved.

# Conference Calls

---



A conference call may include up to seven parties.

## To set up a conference call

### **Press TRANS/CONF (1)**

The call is placed on temporary hold.

### **Dial extension number using dial key pad**

### **or press required speed call key (2)**

If the number is busy or unanswered, press CANCEL (3) to retrieve the held call.

If the number is ringing, wait until the ringing telephone is answered.

### **Press CONF (1)**

You now have a conference.

# Conference Calls

---

## **To speak privately with one party in a conference**

### **Press SPLIT (4)**

You are connected to one party and the other party is placed on temporary hold.

## **To alternate between callers**

### **Press SWAP (4)**

You are connected to the held party and the other caller is placed on temporary hold.

## **To exit from a conference call**

**Replace handset**

**or press HANG-UP (5)**

**or press *speaker on/off* key (6)**

if in handsfree mode. You are released from the call.

The callers are connected together.

# UCD Agent

---

## Incoming calls

If you are part of an agent group, calls will arrive at your set automatically.

You can assign an account code to a call.

To stop receiving calls temporarily use the Do Not Disturb feature.

# Sub-attendant

As a sub-attendant, you may be required to store and take messages for SUPERSET 3 or regular telephone users.

## To store messages

Press **PROGRAM**

12:35		04-OCT-83	
PROGRAM		MSG	REDIAL
▲			

Press **MSG**

PROGRAM..					
EXIT	NAME	CALL FWD	REMINDER	MSG	SPEED CALL
					▲

## Dial message number (01-15)

**Note:** 01 to 08 are already programmed for you.  
Each message can be up to 13 characters long including spaces.

You can create messages using the letters on the keypad.

### Press the key associated with the first letter of your message

Since each key is associated with three letters, press the key up to three times to display the required letter.

When that letter is displayed, press the NEXT key.


Repeat this operation for each letter in your message.

# Sub-attendant (cont'd)


**Note:** Press . . .

NEXT	to leave a space
*	to store Q, Z, ', .
←	to backspace and erase an error
EXIT	to clear the display and start over
0	not used
#	not used

## Press SAVE



## If a call is forwarded to your prime line




## Answer the call

If the caller wishes to leave a message, take the message and finish the call.

## To leave an indication at the user's set

### Dial extension number

### Press SEND MSG



# Sub-attendant (cont'd)

## Replace handset

The message indication is automatically cancelled when the station user calls any SUPERSET 4.

## To cancel a message indication for a station


### Dial the extension number

### Press MSG

The indication is cancelled.

## If the caller wishes to speak to someone else


### Press TRANS/CONF



### Dial the required number

### or press a speed call key

### Press RELEASE



**Note:** If there is no answer or the extension is busy, the call will recall to your set.



# And More!


The And More! reference section is a summary, arranged in alphabetical order, of the features appearing in the display area.

Only the features you have access to will be displayed on your set.

## ADD HELD

To add a held call to a conversation on a different line,

**Press ADD HELD**




**Press line with held call**

You are now in a conference.

## BACKGROUND MUSIC

To hear background music from your SUPERSET speaker.

**Press** 



**To turn music off**

**Press**  **again**


**Note:** Adjust volume by the speaker volume control.

# And More!

## CALLBACK

To be called back when a busy extension or outside line becomes free.

### Press **CALLBACK**



### Replace handset

## CALL FWD

Redirect your incoming calls to another extension, group or outside number.

There are four types of call forwarding:

- ALWAYS FORWARD – all your incoming calls are redirected.
- NO ANSWER – your unanswered calls are redirected.
- BUSY FORWARD – your calls are redirected whenever your set is busy.
- BUSY/NO ANSWER FORWARD – your busy or unanswered calls are redirected.

**Note:** If power failure occurs, you must reset call forwarding when power is restored.


### To set up call forwarding

### Press **PROGRAM**




# And More!

## Press CALL FWD




## Press YES or NO

to select the required type of call forwarding.



## Enter destination



## Either dial number manually, or press a speed call key


The number you want your calls redirected to may be a different extension, or an outside number (if permitted with your set).

Press ← to backspace and erase an error.

Press EXIT to clear the display and start over again.

# And More!

## Press SAVE





Call forwarding is now activated and FWD is displayed as a reminder.

## To cancel or reactivate call forwarding Press *select features* key

### Dial 1

Call forwarding is feature number 1.

**Press OFF or ON**  
to cancel or reactivate.




# And More!

## CAMP ON

Used to signal a busy extension that you wish to speak with the user.

**Listen for busy tone**

**Press CAMP ON**




Remain off-hook. You may hear music. When the extension becomes free, you are connected.


## CANCEL

Used to drop your current party and recover a party from temporary hold.


**Press CANCEL**



CANCEL is also used to cancel a callback message after the message is displayed.



# And More!




## CONF

Used to set up a conference.

**To add a party on temporary hold to your current call**

**Press CONF**




You now have a conference.

## HANG-UP

Used to finish a call.

**Press HANG-UP**



# And More!

---


## MSG

There are two types of messaging:

- Advisory – messages which you can leave for other SUPERSET 4 users to see when they call your set.
- Callback – messages which you can send to other SUPERSET 4 users when you cannot reach them.

### To display stored messages

Press MSG



Press NEXT to display next message

Press EXIT to clear the display

You can leave a message for other SUPERSET 4 users if you are going to be away from your set. You have a choice of 15 messages (01 to 15).


The following messages have already been stored on your system:

- 01 IN A MEETING
- 02 OUT OF TOWN
- 03 ON VACATION
- 04 OUT ON A CALL
- 05 OUT TO LUNCH
- 06 GONE FOR DAY
- 07 GONE HOME
- 08 IN TOMORROW



**Note:** Messages 09-15 have not been previously stored.

# And More!

**To leave or cancel a message on your set  
Press MSG**



**Dial the required message number  
or  
Press NEXT several times  
until the desired message is displayed.  
Press ON or OFF**






# And More!

**If you have callback message on your set  
you can still leave a message**

(MSG flashing in the upper right-hand corner of the display)

**Press MSG**

**Press SEND MSG**



**Dial the required message number**

**or**

**Press NEXT several times**

until the desired message is displayed.

**Press ON or OFF**

to cancel the message.


The message is displayed.

## NAME

Used to store your name for sending callback messages.


**To store your name**

**Press PROGRAM**



# And More!

## Press NAME




You can store your name using the letters on the keypad. Press the key associated with the first letter of your name. Since each key is associated with three letters, press the key up to three times to display the required letter. When that letter is displayed, press the NEXT key.

Repeat this operation for each letter in your name.

**Note:** Press . . .

NEXT	to leave a space
*	to store Q, Z, ', .
←	to backspace and erase an error
EXIT	to clear the display and start over again
0	not used
#	not used

## Press SAVE



# And More!

## NIGHT ANS

Used to answer an incoming outside call when the night bell or night extension rings.

### Listen for night bell

If your set is idle,

### Lift handset

or press *speaker on/off* key

### Press NIGHT ANS



The call is now answered handsfree.

Lift the handset for a private conversation either before or after pressing NIGHT ANS.

**If you are dialing a call,**

### Press NIGHT ANS




# And More!

## OVERRIDE

Used in an emergency to speak with a busy party.

**Listen for busy tone**

**Press OVERRIDE**



You may now speak with the user, but other parties in the original conversation will hear you as well.


All parties in the conversation hear a warning tone, which is repeated every 6 seconds until you hang up.

## PAGE

Used to make announcements to all zones on your paging system.

**Lift handset**

Listen for beep.



**Press and hold down PAGE**

Make announcement while holding down PAGE key.

Release key at end of announcement.


**Note:** PAGE prompt will not appear if you are off-hook in speaker mode.

# And More!

## PRIVACY REL

Used to permit another SUPERSET 4 set user to join in an existing conversation.

Press **PRIVACY REL**



## PROGRAM

Used to program your phone for call forwarding or for assigning speed call keys.

Press **PROGRAM**



You may now continue with call forwarding or speed call for automatic dialing.




# And More!

## REDIAL

Used to redial automatically the last manually dialed outside number.


**Press REDIAL**



## RELEASE

Used to release a call on temporary hold to the current party, and remove yourself from the call.

**Press RELEASE**




## REMINDER

Used to send a reminder to yourself.

**To set the time of a reminder**

**Press PROGRAM**



# And More!

## Press REMINDER



## Dial 4-digit time

The 24-hour clock format is used.

For example: 16:30 represents 4:30 pm.

## Press ← key

to backspace and erase an error.

## Press EXIT

to clear the display and start over.

## Press SAVE



At the time set for the reminder you will hear a beep, REMINDER prompt flashes and DISPLAY REMINDER is displayed.

---

## To acknowledge a reminder

If your set is idle,

**Press REMINDER**


**or**

If your set is busy,


**Press DISPLAY**

# And More!


Then press **REMINDER**




To cancel a timed reminder  
Press **PROGRAM**



Press **REMINDER**  
The set displays existing timed reminder.



Press **CANCEL**






# And More!

## SEND MSG

Used to send a message requesting a callback.

**Listen for ringing or busy tone**

**Press SEND MSG**




The message sent gives your extension number, and time sent.

## SPEED CALL


Used to store frequently called telephone numbers for automatic dialing.

**To set up or change a speed call key**

**Press PROGRAM**




**Press SPEED CALL**



# And More!


**Press selected speed call key**  
**Dial number to be saved**  
**Press SAVE**



**To display a saved speed call number**  
**Press *display* key**

**Press selected speed call key**  
The saved number for that key is displayed.

**Press EXIT**  
The display is now cleared.



**Note:** If the number has more than 16 digits, press → to display additional digits.

**Note:** For more information, see Speed Calling on page 1-14.

# And More!

## SPLIT

Used to speak privately with one party in a 3-way conference.

You are engaged in a conference call.

**Press SPLIT**




You may now speak privately with one of the parties. The second party is on temporary hold.

## SWAP

Used to alternate between the current party and a caller on temporary hold.

**To swap parties**

**Press SWAP**



# And More!

## SWAP CAMP ON

Used to place your current call on temporary hold while you answer or redirect a waiting call.

### To answer a waiting call

You hear a beep while connected to a call.

The display shows you who is calling.

### Press SWAP CAMP ON



Your current call is placed on temporary hold and you are connected to the waiting caller.

### To redirect a waiting call


You hear a beep while connected to a call.

The display shows you who is calling.

If call forwarding to a different extension has been set, see page 1-23.

You can now redirect the waiting call to the forwarded extension.

### Press CALL FWD



If the destination is busy, CALL FWD is not displayed.


# And More!

## TRANS/CONF

Used to transfer a call to another number or form a conference.

**To transfer a call**

**Press TRANS/CONF**



**Dial required number**

**or**

**Press a speed call key**

**Press RELEASE**




The call is transferred.

**Note:** If there is no answer, the call will recall your set.

# And More!

If 201 is busy, to return to original caller,

**Press CANCEL**



## **1:FWD**


Used to activate or cancel call forwarding.

**Press *select features* key**

**Dial 1**

**Press ON or OFF**

Call forwarding is activated or cancelled.



# And More!

## 2:NO DIST'B


Used to activate or cancel do not disturb.

**Press *select features* key**

**Dial 2**

**Press ON or OFF**

Do not disturb is activated or cancelled.



## 3:AUTO ANS



Used to automatically answer an incoming call handsfree.

**Press *select features* key**

**Dial 3**

# And More!

**Press ON or OFF**  
Auto-answer is activated or disabled.



## 4:MSG

Used to read a message while you are on a call.


### To read a message

If MSG is flashing in the upper right-hand corner of your display,

**Press *select features* key**

**Dial 4**

**Press READ MSG**





# And More!


---

**Press NEXT**  
to read the next message.

**Press CANCEL**  
to erase a message.

**To call some who has left you a message**

**Press CALL**



The call is dialed automatically.

**Press EXIT**  
to clear the display.

## **5:ACC CODE**

Used to enter an account code.

**To enter an account code during a call**

**Press *select features* key**

**Dial 5**

**Dial account code**

**Press ← key**  
to backspace to correct an error.

# **SUPERSET 3**

---

# Contents


---

	<b>Page</b>
Your SUPERSET 3	
Overview	2-2
Feature Keys	2-3
Line Select Keys and Indicators	2-4
Placing a Call	2-6
Answering Calls	2-8
Handsfree Operation	2-9
Transferring Calls	2-10
Finishing Calls	2-12
Placing a Call on Hold	2-13
Conference Calls	2-14
Speed Calling	2-16
And More! . . .	
how to use the many other features provided by your MITEL SUPERSWITCH communications system	2-19

# Your SUPERSET 3

---

## Overview



**1 Handsfree**

Speaker key and microphone switch.

**2 hold Key**

Used to place current call on hold.

**3 Feature Keys**

Five keys for automatic feature selection.

**4 Volume Control**

Controls the speaker and ringer output.

**5 Handset**

Used for private conversations.

**6 Speed Call Keys**

Used for saving up to 12 extension or outside numbers for automatic dialing.

**7 Line Select Keys and Indicators**

Used to select one of three lines.

**8 Dial Key Pad**

A standard 12-key telephone dial pad.

# Your SUPERSET 3

---

## Feature Keys

### ***hold***

Used to place a call on hold, thus freeing you to replace the handset or place another call.

### ***swap***

Used to alternate between a call on hold or camped-on and the current call.

### ***trans/conf***

Used to transfer a call or to set up a conference.

### ***redial***

Used to redial the last manually dialed outside number.

### ***cancel***

- (1) Used to cancel an unsuccessful transfer (i.e. busy) or conference call. The caller on temporary hold is automatically retrieved.
- (2) Also used to abort speed call key programming.
- (3) Acts as a hang-up during speaker operation when the handset is on-hook.

### ***program/save***

Used to program and save new numbers for automatic dialing.

### ***speaker on/off***

Used for handsfree SUPERSET 3 set operation.

### ***microphone on/off***

Used to switch the microphone ON or OFF for private local conversation during a handsfree call.

# Your SUPERSET 3 (cont'd)

---

## Line Select Keys and Indicators

One of these line select keys is your own prime line (directory number). Normally, when you lift the handset or press the *speaker on/off* key, your own line is selected automatically.

The remaining select keys are assigned by the system manager as one of the following types of lines:

### **Personal Outgoing Line**

This is another appearance of your prime line, except that incoming calls ring your prime line leaving this line free to place outgoing calls.

### **Key Line**

This line is shared by other extensions. An incoming call may ring all the extensions sharing this line and any extension user can answer the call. Only one person can use a key line at any given time; all other people trying to place a call will receive busy tone. You can retrieve a call on hold from any extension sharing this line.

### **Multiple Call Line**

This line shares its directory number with other extensions.

An incoming call may ring all the extensions sharing the line and any extension user can answer the call. All the extension users sharing the line may access this line simultaneously.

If you place a caller on hold, no other extension user may retrieve the call from hold.

### **Direct Trunk Select (DTS)**

When a DTS line is accessed, you are connected automatically to an outside Central Office (CO) trunk. Only one person can use a DTS line at any time. You can transfer a call with the *trans/conf* key.

### **Direct Line Select (DLS)**

This line is like a DTS line but you cannot transfer a call with the *trans/conf* key. However, if you place a call on hold with the red *hold* key, the call can be retrieved by another extension sharing the line.

# Your SUPERSET 3 (cont'd)

---

## **Private Line**

This is your own personal line and it does not appear elsewhere on the system.


When a line is                      the line status display is

---

Idle	unlit
Busy	lit
Ringing	flash
Held	fast flash

# Placing a Call

---



ormally, when you lift the handset or press the *speaker on/off* key, your own line is selected automatically.

o place or answer a call on a different line, press the appropriate line select key. If the line indicator above the line key is lit, someone else is using that line.

## o place a call to another extension

### Obtain dial tone

Lift handset,

or press *speaker on/off* key (1)

**and either dial manually**

**or press a speed call key (2)**

if the number has been saved for automatic dialing.



# Placing a Call

---

## To place a call to an outside number

### **Obtain dial tone**

Lift handset,

or press *speaker on/off* key (1)

### **Obtain outside line**

Dial Trunk Access Code or press a free line select key.

**and either dial manually,**

**or press a speed call key (2)**


if the number has been saved for automatic dialing.

**or press REDIAL (3)**

if the number you wish to dial is the same as the last manually dialed outside number.

# Answering Calls

---



. new call arriving at your SUPERSET 3 set flashes a line indicator lamp, and may ring the incoming call bell.

## To answer a call

**Either lift the handset**

and speak with the caller privately,

**or press the *speaker on/off* key (1)**


and speak with the caller in handsfree mode.

**or press the flashing line select key (2)**

and speak with the caller in handsfree mode.

# Handsfree Operation

---



## To change from handset to speaker operation

**Press the *speaker on/off* key (1) and replace handset**

Your conversation continues in handsfree mode.

## To change from speaker to handset operation

**Lift the handset**

The speaker and microphone are now disabled.


## To consult privately during speaker operation

**Press *microphone on/off* (2)**

Speaker is still in use but microphone is now disabled.

# Transferring Calls

---



## To transfer a caller to another extension

**Advise caller of pending transfer**

**Press *trans/conf* key (1)**

The call is placed on temporary hold.

**Dial the number manually from the dial key pad**

---

**If the selected extension is ringing or busy and you need not introduce the caller**

**Press *speaker on/off* key (2)**

if you are in handsfree mode.

**or replace handset**

The caller is transferred to the ringing extension.

The busy extension user hears two quick beeps indicating a waiting call.

# Transferring Calls

---

When the busy extension user hangs-up, his/her phone rings and the waiting call is connected automatically.

If there is no answer after a time-out period, the transferred call recalls and rings your extension.

---

## **If you want to introduce the caller**

Wait until the ringing extension is answered.

### **Introduce the caller**

**Press *speaker on/off* key (2)**

if you are in handsfree mode.

**or replace handset**

The caller is transferred.


## **To retrieve a held call**

**Press *cancel* key (3)**

You are reconnected with the held call.

# Finishing Calls

---



## To finish a call


**Replace handset**

**or press *speaker on/off* key (1)**  
if speaker is in use.

**or press *cancel* key (2)**  
during speaker operation when no one is on  
temporary hold.

# Placing a Call on Hold

---



## To place a call on hold

**Advise the caller of the pending hold**

**Press the *hold* key (1)**

The indicator lamp next to the line on hold flashes.

An outside caller will hear music if the Music-on-Hold feature is available on your system.


## To retrieve a call from hold from any SUPERSET 3 set

**Press appropriate flashing line select key (2)**

You are connected to the held call.

# Conference Calls

---



Up to six parties and the originator may be brought together in a conference call.

## To set up a conference call

You are connected with a call.

### **Press *trans/conf* key (1)**

The call is placed on temporary hold.

### **Dial each number manually from dial key pad, or press required speed call key (2)**

If the number is busy or unanswered, press *cancel* key (3) to retrieve the held call.

If the number is ringing, wait until the ringing telephone is answered.

### **Press *swap* key (4)**

if you want to place the current caller on hold and speak to the original party privately.

### **Press *trans/conf* key (1)**

You now have a conference.



# Conference Calls

---

## To exit from a conference call


**Press *speaker on/off* key (5)**  
if you are in handsfree mode.

**or replace handset**

The parties are now connected together and you are released from the call.

# Speed Calling

---



Frequently dialed extension or outside telephone numbers may be saved for automatic dialing.

Normally, when you press a speed call key, your own line is selected automatically. To place a call on another line, preselect a free line, then press the speed call key.

## To use a speed call key

**Press required speed call key (1)**

The stored number is dialed for you automatically.

## To assign a speed call key

**Press *program/save* key (2)**

**Press required speed call key (1)**

**Enter digits to be saved**

For more information on how to save a number, see Organizing speed call numbers.

# Speed Calling

---

## **Press *cancel* key (3)**

if you've made a mistake and want to leave the previously saved number intact.

## **Press *program/save* key (2)**

The new number is now saved.

## **Record identity of new number**


Carefully remove the clear plastic card cover and write the number identity on the line next to the speed call key.

## **Organizing speed call numbers**

Avoid confusion by writing down long numbers exactly as you would dial them.

For example, a typical long-distance telephone number would be dialed as follows:

9 + 1 + 613 + 5550000



These are some special codes that can be inserted into the saved telephone number:

- \*1 – This causes automatic dialing to be suspended for 5 seconds, and is used to allow telephone exchange equipment to prepare for reception of more digits.
- \*2 – Used wherever you have to wait for dial tone. You may find that in some areas, \*1 is more useful than \*2.
- \*3 – Indicates where in the number string, a predialed sequence will be inserted. This code must be followed by a 1-digit number (between 1 and 9) that specifies the quantity of digits to be dialed manually.
- \*5 – Used for an intercom number. Dial the extension number of another Superset set, plus \*5. These calls are routed to the other set's speaker, even if the set is busy.

## Automatic Dial (cont'd)

---

The following example illustrates the use of \*3.

The general number for directory assistance is:

1 + (area code) + 5551212

The area code determines which area you are making the enquiry in and is unknown until you require assistance. With the set, you can save the number and make use of the \*3 code to suspend dialing until you dial the area code from the keypad.

In this case, write down the number

9 + 1 + \*3 + 3 + 5551212

where,

\*3 suspends dialing until you've dialed the area code from the keypad.

3 tells the set to wait for three digits to be dialed manually.

After pressing a key with \*3 saved in the number, you hear a beep prompting you to dial digits manually. If the quantity of digits you now dial is less than the quantity specified when the number was saved, press # and dialing will begin.

Based on the above example, if you want to call the Toronto directory assistance:

**Press appropriate speed call key**

Listen for beep.

**Dial 416**

The Toronto area code.

The system dials 9 1 416 5551212 automatically.

**Note:** If your system has the Automatic Route Selection feature, do not store \* codes for outside numbers.

## And More!

---

Many other features are provided by MITEL SUPERSWITCH systems that you can access by dialing simple codes.

For complete information about these features and how to use them, refer to Extension Features Operation (PN9110-034-002-NA).

Some of the features described in the regular telephone section are activated by a switchhook flash; that is, pressing then quickly releasing one of the switchhook buttons. When implementing these features using a SUPERSET 3 set, substitute the *trans/conf* key for the switchhook flash.

# Speed Call List

---

Name	Memory code
	10
	11
	12
	13
	14
	15
	16
	17
	18
	19
	20
	21
	22
	23
	24
	25
	26
	27
	28
	29
	30
	31
	32
	33
	34
	35
	36
	37
	38
	39
	40
	41
	42
	43
	44
	45
	46
	47
	48
	49
	50
	51
	52
	53
	54
	55
	56
	57
	58
	59
	60
	61
	62
	63
	64
	65
	66



