

ShoreTel 560/560g IP Phone Quick Reference

PHONE OPERATION

Place Calls

Use the Speakerphone or a Headset


Use the Directory

Make a Conference Call


Use the Intercom

Redial and Check Missed Calls


Dial Paging Extension



number provided by administrator
lift handset or Answer or Speaker or Headset



Volume [] to select
select appropriate call key



Answer Calls

Send a Call to Voice Mail

Divert a Call

Select a Ring Tone

Adjust Handset, Headset
or Speakerphone Volume

Answer Call Waiting

Interact with Calls

Mute a Call

Place a Call On or Off Hold

Transfer a Call

Join Calls

Park Calls

Unpark Calls

Change Call Handling Mode

Log In and Out of Workgroups


Adjust the Display Contrast

VOICE MAIL

Log Into Main Menu

Log In from Another Extension

Note: For more information about voice mail features, please consult the Voice Mail Quick Reference.



OFFICE ANYWHERE CODES


Transfer a call

Conference a call

Hold a call

Hang up

Access other star codes



QUICK REFERENCE OF COMMON STAR CODES

Park a call

UnPark a call

Pick Up a Remote Extension

Pick Up the Night Bell

Use the Intercom

Barge In

Silent Monitor

Toggle the Hunt Group Status


Whisper Page

Change CHM and Forwarding

Change Extension Assignment

Unassign Extension Assignment


Assign Extension to External Number



TROUBLESHOOTING


View Phone Information

Reboot Your Phone



Note: For additional details on the information contained in this Quick Reference card, please consult the 560/560g User Guide.

ShoreTel 560/560g IP Phone Quick Reference



Note: You can connect a supported headset into the 560/560g IP Phone by plugging the headset into the headset jack at the left corner of the phone chassis. Contact your system administrator for details.


GUIDE TO LEDs

Your ShoreTel 560/560g IP phone also provides color cues to help you determine the operational status as follows:


- Steady Green - in use by you
- Blinking Green - (Fast) on hold or call parked
- Blinking Green - (Slow) incoming call
- Steady Red - in use by owner
- Blinking Red - incoming call, owner on a call
- Steady Orange - extension's call handling set to Do Not Disturb mode
- Blinking Orange - incoming call

GUIDE TO STATUS ICONS

ShoreTel IP 560/560g Idle Interface



ShoreTel IP 560/560g Inbound Call



Main Display

- Unheard Voice Messages
- Missed Calls
- Logged Into Workgroup
- Logged Into Workgroup, In Wrap-Up
- Logged Out of Workgroup

Custom Keys - Call

- On Hook
- Off Hook
- Inactive / Do Not Disturb
- Incoming Call (Animated)
- On a Call
- On a Conference Call
- Call On Hold / Parked
- Remote Hold

Custom Keys - Monitored Extension

- Idle
- Inactive / Do Not Disturb
- Unheard Voice Messages
- Do Not Disturb / Unheard Messages
- Incoming Call (Animated)
- On a Call
- Incoming Call and On a Call
- On a Conference Call
- Call On Hold / Parked

Custom Keys - Speed Dial

- Speed Dial Extension