



MBX IP™

Description / Programming & Operations Guide



Vertical Communications, Inc. reserves the right to revise this publication and to make changes in content without notice.

© 2011 by Vertical Communications, Inc. All rights reserved.

This publication contains proprietary and confidential information of Vertical Communications, Inc. The contents of this document may not be disclosed, copied or translated by third parties, in any form, or by any means known, or not now known or conceived, without prior explicit written permission from Vertical Communications, Inc.

LIMIT OF LIABILITY/DISCLAIMER OF WARRANTY

Vertical Communications, Inc. makes no representation or warranties with respect to the accuracy or completeness of the content of this publication and specifically disclaims any implied warranty of merchantability or fitness for any particular purpose, and shall not be liable for any loss of profit or any other commercial damage, including but not limited to, special, incidental, or consequential.

TRADEMARKS

Vertical Communications and the Vertical Communications logo and combinations thereof are trademarks of Vertical Communications, Inc. All other brand and product names are used for identification only and are the property of their respective holders.

RESTRICTED RIGHTS LEGEND

Use, duplication, or disclosure of the technical data contained in this document by the Government is subject to restrictions as set forth in subdivision (c) (1) (ii) of the Rights in Technical Data and Computer Software clause at DFARS 52.227-7013 and/or in similar or successor clauses in the FAR, or in the DOD or NASA FAR Supplement. Unpublished rights reserved under the Copyright Laws of the United States. Contractor/manufacturer is Vertical Communications, Inc., 10 Canal Park, Suite 602, Cambridge, MA 02141-2249.

Contents

Chapter 1	Introduction	
	Manual Layout -----	1-1
	Organization -----	1-1
	Feature Information -----	1-1
	System Capacities -----	1-2
	Phones & Consoles Supported -----	1-4
Chapter 2	Directory Number (DN)	
	Terms -----	2-1
	Basic Features -----	2-2
Chapter 3	System Features	
	Account Code -----	3-1
	Alarm Signal/Door Bell -----	3-3
	Authorization Codes (Password) -----	3-5
	Auto Call Release -----	3-6
	Automatic Pause Insertion -----	3-7
	Automatic Privacy/Branch Line -----	3-8
	Auto Service Mode Control -----	3-10
	Automatic System Daylight Savings Time -----	3-12
	Automatic System Time Synchronization -----	3-13
	Battery Back-up, Memory -----	3-14
	Call Forward -----	3-15
	Call Forward, Pilot Hunt -----	3-19
	Call Forward, Preset -----	3-22
	Call Park -----	3-24
	Call Pick-Up -----	3-26
	Directed Call Pick-Up -----	3-26
	Group Call Pick-Up -----	3-28

Call Transfer	3-30
Call Transfer, Station	3-30
Call Transfer, CO/IP	3-31
CO/IP Access	3-37
CO/IP Call Time Restriction	3-40
CO/IP Call Warning Tone Timer	3-43
CO/IP Queuing	3-45
Conference	3-47
Conference Room	3-47
Multi-Party Voice Conference	3-50
Consultation Conference	3-52
Unsupervised Conference	3-53
Customer Site Name	3-55
Data Line Security	3-56
Delayed CO/IP Ring	3-57
Delayed Auto Attendant	3-58
Diagnostic/Maintenance	3-60
Dial-By-Name	3-60
Dial Pulse to Tone Switchover	3-62
Dialing Restrictions	3-63
Class of Service	3-63
Day/Timed & Night Station COS	3-65
Temporary Station COS/Lock	3-68
Walking COS	3-71
Differential Ring	3-73
Digit Conversion	3-74
Do Not Disturb (DND)	3-77
Door Open	3-79
Door Phone	3-80
Emergency Call/Emergency Alert	3-82
Executive/Secretary by DN (Directory Number)	3-83
Executive/Secretary by Exec/Sec Assignment	3-85
External Auto Attendant/Voice Mail	3-87

AA/VM Group	3-87
In-band (DTMF) Signaling	3-90
SMDI (Simplified Msg Desk Interface)	3-93
Flexible Numbering Plan	3-97
Green Power Save	3-99
Headset Compatibility	3-99
Hold	3-101
Hold Recall	3-102
Automatic Hold	3-104
Hot Desk	3-106
In-Room Indication	3-108
IP Trans-coding	3-109
Last Number Redial (LNR)	3-110
Least Cost Routing (LCR)	3-112
Linked Station Pairs/Group	3-114
Loud Bell Control (LBC)	3-116
Mobile Extension	3-117
Multiple Language Selection	3-120
Multiple Voice Mailbox Support	3-122
Music-On-Hold (MOH)	3-123
Network Management System (Future Feature)	3-126
Network Security & Priority	3-127
One Digit Service	3-128
Camp-On	3-128
Call Wait	3-129
Outcall Notification	3-131
Pre-defined & Custom Text Display Messages	3-134
Registering IP Devices & Fractional Module Tables	3-137
Registration with MAC Address	3-137
Registration with ID/Password	3-139
Registration with Station Number	3-141
Remote Device Zone Management	3-143
Remote Services, Managed Net	3-144

Revertible Ring -----	3-145
Speed Dial -----	3-146
Speed Dial Pause Insertion -----	3-146
Station Speed Dial -----	3-147
System Speed Dial -----	3-150
Station Call Coverage -----	3-153
System Groups -----	3-153
Station Group -----	3-154
Greeting/Queuing Tone Service -----	3-162
CCR Service with Queuing Announcement -----	3-168
Forward Destination, Overflow Service -----	3-173
Pilot Hunt Group -----	3-178
Pick Up Group -----	3-182
Push To Talk (PTT) Group -----	3-183
Command Conference Group -----	3-184
Interphone Group -----	3-185
Paging Group -----	3-186
Station Message Detail Recording (SMDR) -----	3-187
Call Cost Display -----	3-187
SMDR Call Records -----	3-189
System Admin Programming -----	3-194
Keypad Administration -----	3-194
Multi-Level Admin Access -----	3-195
Web Administration -----	3-197
Web User Manual -----	3-199
System Networking -----	3-200
Centralized Control T-NET (LM) -----	3-200
Distributed Control Network -----	3-202
Traffic Analysis -----	3-250
System Time Management -----	3-252
System Database Backup To USB -----	3-255
Tenant Group -----	3-255
Universal Answer (UA) -----	3-257

	VMIB Integrated Auto Attd/Voice Mail - - - - -	3-258
	VMIB - - - - -	3-258
	VMIB-Auto Attendant - - - - -	3-258
	VMIB Voice Mail - - - - -	3-261
	System Voice Memo - - - - -	3-280
	Wake-up Alarm - - - - -	3-283
Chapter 4	Intercom	
	Direct Station Select/Busy Lamp Field (DSS/BLF) - - - - -	4-1
	Intercom Call (ICM Call) - - - - -	4-2
	Intercom Call Hold - - - - -	4-4
	Intercom Caller Controlled ICM Signaling - - - - -	4-5
	Intercom Lock-out - - - - -	4-6
	Intercom Step Call - - - - -	4-7
	Intercom Transfer - - - - -	4-8
	INTRUSION - - - - -	4-10
	Message Wait/Call Back - - - - -	4-11
	Station Message Wait/Call Back - - - - -	4-11
	Message Wait Reminder Tone - - - - -	4-14
	Paging - - - - -	4-15
	Internal/External & All Call Page - - - - -	4-15
	Meet Me Page Answer - - - - -	4-17
	VM Paging - - - - -	4-20
	Push-To-Talk Paging - - - - -	4-23
Chapter 5	CO/IP	
	Alternative Route Selection - - - - -	5-1
	Automatic Network Dialing - - - - -	5-2
	CO Group Access Code - - - - -	5-3
	CO Line Flash - - - - -	5-5
	CO/IP Line Groups - - - - -	5-7
	CO Line Service - - - - -	5-9
	Incoming CO Line Option - - - - -	5-9
	Outgoing CO Line Option - - - - -	5-14
	Alternate Incoming CO Service - - - - -	5-19

Alternate Outgoing CO Service ----- 5-25

Digit Sending Mode ----- 5-28

CO COS ----- 5-28

DID Name Service ----- 5-29

Incoming CO Line Holiday Service ----- 5-31

DID/DISA Restriction ----- 5-34

CO/IP LINE PRESET FORWARD ----- 5-35

CO OWN CODE SERVICE ----- 5-36

CO/IP Ring Assignment ----- 5-37

CO Line Release Guard Time ----- 5-41

CO Ring Detect ----- 5-42

CO Transit Service ----- 5-42

Dial Pulse Signaling ----- 5-44

Direct Inward Dial (DID) ----- 5-45

Direct Inward System Access (DISA) ----- 5-50

Dual Tone Multi-Frequency (DTMF) Signal Sending ----- 5-55

H.323 Multi Route Service ----- 5-55

Incoming Calling Line ID (ICLID) Call Routing ----- 5-57

IP Trunking ----- 5-59

 H.323 v4 Service ----- 5-59

 Session Initiation Protocol (SIP) Service ----- 5-61

IP WAN Dialing After Answer ----- 5-62

Integrated Service Digital Network (ISDN) ----- 5-64

 ISDN Advice of Charge (AOC) ----- 5-64

 Calling/Called Party Identification (CLIP/COLP) ----- 5-68

 Keypad Facility ----- 5-69

 Multiple Subscriber Number (MSN) ----- 5-71

 ISDN CLI ----- 5-73

ISDN Supplementary Services ----- 5-76

 ISDN Call Deflection ----- 5-76

Representative CLI Service ----- 5-77

Chapter 6 Digital Phone

 Auto Called Number Redial (ACNR) ----- 6-2

Auto Release of [Speaker] ----- 6-4
 Automatic Speaker Select ----- 6-4
 Background Music (BGM) ----- 6-5
 Call Log Display ----- 6-6
 CO Line Name Display ----- 6-8
 One Time DND ----- 6-9
 Group Listening ----- 6-10
 Intercom Signaling Mode ----- 6-11
 Mute ----- 6-13
 Off-Hook Signaling ----- 6-14
 On-Hook Dialing ----- 6-15
 Prime Line Immediately/Delayed ----- 6-16
 Differential Ring ----- 6-17
 Saved Number Redial (SNR) ----- 6-18
 Speakerphone ----- 6-19
 Station Flexible Buttons ----- 6-21
 Station Flexible LED Flash Rates ----- 6-22
 Station ICLID Call Routing ----- 6-23
 Station User Programming & Codes ----- 6-24
 Two-Way Record ----- 6-27
 Answering Machine Emulation (AME) ----- 6-30
 Voice Over ----- 6-32

Chapter 7

Attendants

Attendant Group ----- 7-1
 Night Attendant Group ----- 7-10
 Greeting/Queuing Tone Service ----- 7-14
 CCR Service for Attendant Queuing Announcement ----- 7-19
 Forward Destination, Overflow Service ----- 7-25
 Attendant Recall ----- 7-29
 Attendant Station Program Codes ----- 7-32
 Attendant Call/Queuing ----- 7-36
 Day/Night/Timed Ring Mode ----- 7-37
 DSS/DLS Consoles ----- 7-40

	EZ-Attendant -----	7-41
	System Clock Set -----	7-42
	USB Upgrade -----	7-43
	USB DB Up/Download From/To USB -----	7-45
Chapter 8	Single Line Telephone	
	Broker Call -----	8-1
	Hook-Flash Mode -----	8-2
	Howler Tone -----	8-3
	SLT Message Wait Indication -----	8-4
	SLT Name Registration -----	8-5
Chapter 9	SIP Phone	
	SIP Terminal Registration -----	9-1
	SIP Name Registration -----	9-2
	SIP Placing Calls -----	9-2
	SIP Call Pick-Up -----	9-3
	SIP Hold Call -----	9-3
	SIP Transfer Call -----	9-3
	SIP Call Forward -----	9-4
	SIP Do Not Disturb (DND) -----	9-4
	SIP 3-Party Conference -----	9-5
	SIP Call Wait/Broker Call -----	9-5
	SIP SMS -----	9-5
	SIP Voice Mail Notification -----	9-6
	SIP Video Call -----	9-6
Chapter 10	ACD (Automatic Call Distribution)	
	ACD Basic Feature -----	10-1
	ACD Group Service Status -----	10-9
	ACD Call Distribution by Priority -----	10-16
	ACD Call Queuing Service -----	10-21
	CCR Service During ACD Announcement -----	10-28
	ACD Agent State -----	10-33
	ACD Agent Log-in / Log-out Default Setting -----	10-39

ACD Call Indication ----- 10-44
 ACD Group Supervisor Functions ----- 10-50
 ACD Group Call Traffic ----- 10-58

Appendix A System Programming Tables

Initialization ----- A-1
 Program Menu Structure ----- A-2
 Administration Menu Table ----- A-2
 S/W Upgrade ----- A-6
 System Management ----- A-6
 Station Admin Programming ----- A-7
 LCD & Button Functions ----- A-7
 Alphanumeric Data Entries ----- A-7
 Required Data Entries ----- A-7
 Data Entry Mode ----- A-7
 Procedures for Data Entry ----- A-8
 PRE-PROGRAMMED DATA - TRANS/PGM Codes 100 to 108 A-8
 Location Program (TRANS/PGM 100) ----- A-8
 Slot Assignment (TRANS/PGM 101) ----- A-11
 Logical Slot Assignment (TRANS/PGM 103) ----- A-11
 DECT/IP Phone/SIP Phone Port Assignment (TRANS/PGM 104)
 A-12
 IP Phone/Phontage Registration Table (TRANS/PGM 106) A-12
 DTIM/SLTM Registration Table (TRANS/PGM 107) ----- A-13
 IP Address Plan (TRANS/PGM 108) ----- A-14
 System Information (TRANS/PGM 109) ----- A-14
 NUMBERING PLAN DATA - TRANS/PGM Codes 110 to 116 A-15
 Numbering Plan Type (TRANS/PGM 110) ----- A-15
 System Numbering Plan (TRANS/PGM 111) ----- A-15
 Flexible Station Number (TRANS/PGM 112) ----- A-16
 FEATURE NUMBERING PLAN (TRANS/PGM 113) ----- A-17
 CO Group Access Code (TRANS/PGM 114) ----- A-21
 Station Group Number (TRANS/PGM 115) ----- A-22

ACD Group Number (TRANS/PGM 118) - - - - -	A-22
STATION DATA - TRANS/PGM Codes 120-152 - - - - -	A-23
Station Type (TRANS/PGM 120) - - - - -	A-23
Station Port Attributes (TRANS/PGM 121-124) - - - - -	A-24
Station Flexible Button Assignment (TRANS/PGM 126) --	A-29
Station Number Information (TRANS/PGM 130) - - - - -	A-31
Station Number Attributes - TRANS/PGM 131-135 - - - - -	A-31
Station Class of Service (TRANS/PGM 137) - - - - -	A-37
Station Auto Attributes (TRANS/PGM 138) - - - - -	A-38
Station Preset Call Forward (TRANS/PGM 142) - - - - -	A-39
Station Call Forward (TRANS/PGM 143) - - - - -	A-40
Station VMIB Attribute (TRANS/PGM 145) - - - - -	A-40
Station Mobile Phone Attribute (TRANS/PGM 146) - - - - -	A-42
CO/IP Group Access (TRANS/PGM 150) - - - - -	A-43
Internal Page Group Access (TRANS/PGM 151) - - - - -	A-43
Command Group Access (TRANS/PGM 152) - - - - -	A-44
CO LINE DATA - TRANS/PGM 160-181 - - - - -	A-44
CO Attribute I, II, III - TRANS/PGM 160-162 - - - - -	A-44
CO CID Attributes (TRANS/PGM 163) - - - - -	A-48
CO Incoming Attribute I, II - TRANS/PGM 165-166 - - - - -	A-48
CO Ring Assignment (TRANS/PGM 167) - - - - -	A-51
Incoming CO Normal/DISA Attributes (TRANS/PGM 168)	A-52
CO Incoming Alternate Destination (TRANS/PGM 169) --	A-53
CO Outgoing Attributes I (TRANS/PGM 170) - - - - -	A-54
CO Outgoing Attributes II (TRANS/PGM 171) - - - - -	A-57
CO Outgoing Alternate Destination (TRANS/PGM 173) --	A-57
CO Outgoing Inter-Digit Timer (TRANS/PGM 174) - - - - -	A-58
CO DTMF Sending Delay Timer (TRANS/PGM 175) - - - - -	A-59
CO COS Assignment (TRANS/PGM 177) - - - - -	A-60
CO to CO Transfer Attributes (TRANS/PGM 179) - - - - -	A-60
CO Group Access Code Attribute (TRANS/PGM 180) ---	A-61
Alternate Ring Assignment (TRANS/PGM 181) - - - - -	A-63
SYSTEM GROUP DATA - TRANS/PGM 200-215 - - - - -	A-63

Station Group (TRANS/PGM 200) - - - - -	A-64
Station Group Greeting/Queuing Attributes (TRANS/PGM 201) - A-65	
Station Group Attributes (TRANS/PGM 202) - - - - -	A-68
Voice Mail Group Attributes (TRANS/PGM 203) - - - - -	A-69
Pick Up Group (TRANS/PGM 204) - - - - -	A-70
Page Group (TRANS/PGM 205) - - - - -	A-71
Command Call Group (TRANS/PGM 206) - - - - -	A-72
PTT Group (TRANS/PGM 208) - - - - -	A-73
Interphone Group (TRANS/PGM 209) - - - - -	A-73
Pilot Hunt Group (TRANS/PGM 210) - - - - -	A-74
Pilot Hunt Group Forward Attribute (TRANS/PGM 211) - -	A-75
ACD Group (TRANS/PGM 212) - - - - -	A-76
ACD Group Attribute I (TRANS/PGM 213) - - - - -	A-77
ACD Group Attribute II (TRANS/PGM 214) - - - - -	A-79
ACD Group Announcement (TRANS/PGM 215) - - - - -	A-81
SYSTEM DATA - TRANS/PGM 220-242 - - - - -	A-82
System Timers I (TRANS/PGM 220) - - - - -	A-83
System Timers II (TRANS/PGM 221) - - - - -	A-84
System Timers II (TRANS/PGM 222) - - - - -	A-84
System Attributes (TRANS/PGM 223) - - - - -	A-85
System Password (TRANS/PGM 226) - - - - -	A-86
Alarm Attributes (TRANS/PGM 227) - - - - -	A-87
External Control Contacts (TRANS/PGM 228) - - - - -	A-87
Music Sources (TRANS/PGM 229) - - - - -	A-88
RS-232 Port Settings (TRANS/PGM 230) - - - - -	A-89
Serial Port Function Selections (TRANS/PGM 231) - - - - -	A-90
SMDR Attributes (TRANS/PGM 232) - - - - -	A-91
System Date, Time (TRANS/PGM 233) - - - - -	A-94
Button LED Flash Rate (TRANS/PGM 234) - - - - -	A-95
ISDN PPP Web Admin Attributes (TRANS/PGM 235) - - - - -	A-99
Mobile Attributes (TRANS/PGM 236) - - - - -	A-100
One Digit Service Attributes (TRANS/PGM 237) - - - - -	A-101

Dummy Dial Tone Digit (TRANS/PGM 240) -----	A-101
Executive/Secretary Assign (TRANS/PGM 241) -----	A-102
Executive-Executive Access (TRANS/PGM 242) -----	A-103
TABLES DATA - TRANS/PGM 250-269 -----	A-103
Toll Tables (TRANS/PGM 250) -----	A-103
Digit Conversion Tables (TRANS/PGM 251) -----	A-104
Digit Conversion Options (TRANS/PGM 252) -----	A-106
Time Table Attributes (TRANS/PGM 253) -----	A-107
Weekly Time Table (TRANS/PGM 254) -----	A-108
LCR Time Table Attributes (TRANS/PGM 255) -----	A-109
Holiday Time Table (TRANS/PGM 256) -----	A-110
System Speed Table (TRANS/PGM 257) -----	A-110
Emergency Code Table Attributes (TRANS/PGM 258) ---	A-111
Announcement Table (TRANS/PGM 259) -----	A-111
Customer Call Routing Table (TRANS/PGM 260) -----	A-112
Customer Call Routing Table (TRANS/PGM 262) -----	A-113
CLI Conversion Table (TRANS/PGM 263) -----	A-114
CLI Conversion Table (TRANS/PGM 264) -----	A-114
Ring Table (TRANS/PGM 265) -----	A-115
Ring Freq/Cadence Table (TRANS/PGM 266) -----	A-116
Voice Mail Dialing Table (TRANS/PGM 269) -----	A-116
TENANTS DATA - TRANS/PGM 270-290 -----	A-117
Attendant Group - TRANS/PGM 270-272 -----	A-118
Night Attendant Group - TRANS/PGM 275-277 -----	A-123
Tenant Attributes - TRANS/PGM 280-281 -----	A-127
Tenant Group Access (TRANS/PGM 283) -----	A-130
CO Call Restriction - TRANS/PGM 284-285 -----	A-130
Call Prefix Table - TRANS/PGM 286-288 -----	A-132
Tenant Tone Table (TRANS/PGM 290) -----	A-133
BOARD DATA - TRANS/PGM 300-310 -----	A-138
ISDN Board Attribute (TRANS/PGM 300) -----	A-138
ISDN Board - Clock Priority (TRANS/PGM 301) -----	A-139
IPP Board Attribute (TRANS/PGM 305) -----	A-140

Reset Board (TRANS/PGM 310) -----	A-140
NETWORKING DATA - TRANS/PGM 320-321 -----	A-141
Net Basic Attribute (TRANS/PGM 320) -----	A-141
Net Numbering Plan Table (TRANS/PGM 321) -----	A-142
TNET, CENTRALIZED NETWORKING - TRANS/PGM 330-335 ---	A-143
TNET Basic Attributes (TRANS/PGM 330) -----	A-143
TNET CM Attributes (TRANS/PGM 331) -----	A-143
FOPS/TN Attributes (TRANS/PGM 333) -----	A-144
Board TNET Attributes (TRANS/PGM 334) -----	A-145
IP Phone TNET Attributes (TRANS/PGM 335) -----	A-145
H.323 DATA - TRANS/PGM 360-363 -----	A-146
H.323 Routing Attributes (TRANS/PGM 360) -----	A-146
H.323 Call Setup Info (TRANS/PGM 361) -----	A-146
H.323 Incoming Attributes (TRANS/PGM 362) -----	A-147
GK Setup Info (TRANS/PGM 363) -----	A-148
GAIN & CADENCE CONTROL - TRANS/PGM 400-440 ---	A-149
DKT RX Gain (TRANS/PGM 400) -----	A-149
SLT RX Gain (TRANS/PGM 401) -----	A-149
DECT RX Gain (TRANS/PGM 402) -----	A-150
IP-Phone RX Gain (TRANS/PGM 403) -----	A-150
Analog CO RX Gain (TRANS/PGM 404) -----	A-151
Digital CO RX Gain (TRANS/PGM 405) -----	A-152
VMIB RX Gain (TRANS/PGM 406) -----	A-152
External Page RX Gain (TRANS/PGM 407) -----	A-153
DSP RX Gain (TRANS/PGM 415) -----	A-154
RTP RX Gain (TRANS/PGM 420-426) -----	A-154
RTP RX Gain (TRANS/PGM 430-436) -----	A-157
SLT Ring Cadence (TRANS/PGM 440) -----	A-160
ACNR Tone Cadence (TRANS/PGM 441) -----	A-162
DB INITIALIZATION (TRANS/PGM 499) -----	A-162

Appendix B Hotel Management

----- System Capacity and License B-1

Hotel Service Type ----- B-3

Multiple Front Desks ----- B-7

Check In ----- B-7

Check Out ----- B-9

Call Barring ----- B-11

 CO Call Barring (Room Cut) ----- B-11

 ICM Call Barring ----- B-12

 One-Time CO Call Use ----- B-13

Room Setting ----- B-14

 Wake-Up Registration/Cancellation ----- B-14

 Do No Disturb Registration/Cancellation ----- B-17

 Message Wait Registration/Cancellation ----- B-18

 Bath Alarm ----- B-20

 Register/Change Authorization Code ----- B-21

 Register/Change Prepaid Money ----- B-22

Room Swapping ----- B-23

Maid Status ----- B-23

Room Charge/Status Print ----- B-25

 Room Charge Display/Print ----- B-25

 Print Room Status through RS-232C ----- B-29

 Deleting Service Station's SMDR Record ----- B-30

Room Rate ----- B-30

 Room Rate Register/Assign ----- B-30

 Fee For Part Time ----- B-31

 Register Bar and Mini-bar Charge ----- B-34

Call Rate ----- B-36

 Call Charge Rate Register/Assign ----- B-36

Register Hotel Name ----- B-38

Set Call Forward ----- B-38

Additional Tax Fields ----- B-39

Guest Name/Info Display ----- B-40
 Dial One Digit Service ----- B-40
 Room Monitor / Baby Listening ----- B-41
 Call Answer Recognition (not available in U.S.) ----- B-42
 Form Feed Button ----- B-44
 VIP Guest Call ----- B-44
 VIP Guest Wake-Up Call ----- B-45
 Fidelio Hotel Feature (optional with license) ----- B-46

Appendix C Quick Reference

DATABASE INDEX ----- C-1
 DEFAULT NUMBERING PLAN ----- C-8
 FIXED FUNCTION/USER PROGRAM CODES ----- C-17
 DEFAULT VALUES ----- C-21
 USER ENTRY GUIDES ----- C-105
 Alphanumeric Entry Chart ----- C-105
 Alternate Alphanumeric Entry Chart ----- C-106

Index

Chapter 1

Introduction

This chapter describes the manual and provides a table that shows the system capacities available in the MBX IP System Software.

Manual Layout**Organization**

Features are arranged alphabetically in seven different major groupings that follow two basic chapters (1 - Introduction) and (2 - Directory Number):

- 3) System features
- 4) Intercom features
- 5) CO/IP features
- 6) Digital Phone features
- 7) Attendant features
- 8) Single Line Telephone features
- 9) SIP features

This book also includes three appendices that contain specific information: System Programming tables (Appendix A), Hotel Management (Appendix B), and Quick Reference tables (Appendix C).

Feature Information

Each section is an alphabetical listing of features with the description and operation of each. The structure is divided into 6 parts when they apply:

- The description below the chapter title explains the nature of those features.
- **CONDITIONS:** explains known interactions and constraints related to the feature.
- **OPERATIONS:** gives detailed step-by-step operation of the feature for Digital Phones and SLTs.
- **PROGRAMMING:** lists database entries that may be required for proper feature operation.
- **RELATED FEATURES:** lists related information to aid in understanding the feature.
- **HARDWARE:** lists hardware required for proper feature operation.

System Capacities

The MBX IP Series is available in the configurations shown in the table below:

SYSTEM CAPACITY CHART

Items	MBX IP-100	MBX IP-300
Rack No.	2	3
Slot No. per Rack	6	6
Total Port (Extension + CO line)	200	414 (if IP Phone/DECT Cordless phone not included)
Number of extension Port	120	324
Number of extension	180 (Ext 120 + DN 60)	648 (Ext 324 + DN 324)
Number of CO Line	80	240
Number of Tenant Group	5	9
Numbering Plan	Extension: 8 Digits	Extension: 8 Digits
	Feature: 8 Digits	Feature: 8 Digits
	Trunk: 8 Digits	Trunk: 8 Digits
Attendant	5/Tenant	5/Tenant
DSS/BLF Console	5	5
Conference Members	3 Groups/13 Members	3 Groups/13 Members
Internal Page Zone	15	30
System Speed Dial	1000	2000
	(32 digits)	(32 digits)
Station Speed Dial	50 (32 digits)	50 (32 digits)
Call Log (Outgoing/Incoming/Missed Call)	100 (32 digits) (Not protected)	100 (32 digits) (Not protected)
Save Number Redial(SNR)	1 (32 digits)	1 (32 digits)
Number of SMDR Records	5000	5000

SYSTEM CAPACITY CHART

Items	MBX IP-100	MBX IP-300
Authorization Code	Max. 12 Digits 180: Extension 400: System	Max. 12 Digits 648: Extension 800: System
CO Group No	24	72
Station Group	50 member/Group)	50 member/Group
Pickup Group	20 (100 member/Group)	50 (100 member/Group)
Command Call Group	10 (12 member + 1 initiator/Group)	10 (12 member + 1 initiator /Group)
Interphone Group	10 (10 member/Group)	10 (10 member/Group)
Page Group	15 (50 member/Group)	30 (50 member/Group)
PTT Group	10 (50 member/Group)	10 (50 member/Group)
Conference Room	9	9
Number of Hot Desk Agent	60	324
Station Name Information	16 Characters	16 Characters
Digit Restriction	COS: 16	COS: 16
	Allow/Deny Entry per COS: 100	Allow/Deny Entry per COS: 100
	Max. Digit: 16	Max. Digit: 16
Digit Translation	Table No: 5	Table No: 5
	Number of Digit: 16	Number of Digit: 16
	300 per 1 table	300 per 1 table

Phones & Consoles Supported

These are the phone models supported by the MBX IP systems:

- 5000-series SIP Phones
- DECT Cordless Phones
- Edge 700
 - 8/24-Button Digital Phones
- Edge 8000
 - 8012/8024 IP Phones
 - 8312/8324 IP Phones
- SBX IP
 - 8/24-Button Digital Phones
- STS
 - 24-Button Digital Phones
- Triad & infinite
 - 8/12/24-Button Digital Phones
- Vodavi/Uniphone
 - 8/30-Button-Digital Phones
- CONSOLES
 - Edge 100: 12/24/DSS Consoles
(The SHIFT button does not function on all phone types.)
 - IBX 24/48/64 DSS Consoles
(The SHFT function does not operate on the DSS consoles.)

Chapter 2

Directory Number (DN)

Directory Number (DN) is the telephone number for internal users, which can be used exclusively by only one station or can be shared by multiple stations.

Terms

TYPES OF DN

- SADN-NORMAL : Single-Assign Directory Number (SADN) that can be used by only one station.
- SADN-HOTDESK : Single-Assign Directory Number (SADN) for Hot Desk Usage.
- MADN: Multi-Assign Directory Number (MADN) that can be used by one or multiple stations.

CATEGORY OF DN

- My DN is assigned on flexible button 1 by default. It can be moved to a different flexible button but cannot be deleted.
- My-DN (M-DN): each station must have at least one unique number that cannot be used by another station (minimum requirement, automatically assigned by board configuration). Otherwise, it is not possible to make outgoing calls or receive incoming calls. My DN is assigned on flexible button 1 by default. It can be moved to a different flexible button but cannot be deleted.
- Sub-DN (S-DN): station can have more numbers but M-DN. All numbers except M-DN are called S-DN.

NOTE: S-DN can be shared by other stations if it is MADN type.

PRIME DN

- If multiple numbers are used by a station, one DN can be selected to have higher priority over others. When only one number exists, it becomes P-DN, which will be seized first for outgoing calls, answered first if there's are multiple incoming calls, and used for idle status display for DND, Forward, Absent Message and so on that can be set independently for each DN.

RELATED PROGRAMMING

System Data

Numbering Plan, Station Number (TRANS/PGM 112) ... see details on [page A-16](#)

Station Data

Station Number Type (TRANS/PGM 130 - Flex 1) ... see details on [page A-31](#)

MADN Member (TRANS/PGM 130 - Flex 2) ... see details on [page A-31](#)

Prime Number Button (TRANS/PGM 123 - Flex 1) ... see details on [page A-26](#)

TRANS/PGM 123	BTN	RANGE	DEFAULT
PRIME NUMBER BTN -- among My-DN and several Sub-DNs which are assigned to station flex buttons, determines the first-seized DN when the user initiates a call. If prime button is not set of invalid, the system scans sequentially from flexible button 1 to flexible Button 48 and take the unused and valid flexible button as prime button NOTE: DN buttons of associated DSS box cannot be a prime number button.	1	01-48	01

Basic Features

To use DN features, or to receive incoming calls or make outgoing calls, DN must be programmed on a Flex button, except in the case of an analog phone (does not have flex buttons). One DN is stored in each station by default, which is M-DN. If there is no DN button at all, it is not possible to call a number or get a call from others.

Making Calls

When making outgoing calls, a Station User can select a DN number either by pressing the appropriate DN flex button, by going off-hook using the handset, or by dialing while the phone is on-hook.

P-DN is seized automatically if the DN button is not explicitly pressed as in the case of going off-hook or on-hook dialing. However, if the P-DN is busy at that time (P-DN can be shared by other stations), the first idle DN button is selected in the order of button number (button 1 first, button 2 second, etc.).

Once a DN is selected for an outgoing call, the tenant group number, calling station number, CLI, COS and other DN-related information are applied for the duration of the call. For example, if a different DN is selected for two outgoing calls, it is possible to have different tenant groups or COS for each call.

Receiving Calls

A physical station can receive additional calls showing on DN buttons, or through other available DN numbers that are stored in that station, even while on a call. However, if the DN is in use, it is not possible to receive a call through that DN number.

NOTE: the status of a physical station and each DN is maintained independently.

If the Station is idle, the normal ring will be provided. Otherwise, off-hook signaling is activated. The Station User can answer an incoming call by pressing the flashing DN flex button, or by going off-hook without selecting a DN flex button. If there are multiple incoming calls at the same time, going off-hook allows the user to seize P-DN if it is ringing, or to seize first ringing DN in the order of button number (btn 1 first, btn 2 second).

Even when there are incoming calls at a station, the User can make an outgoing call by pressing an idle DN button and dialing the called party number.

P-DN (PrimeDN) Feature

P-DN is automatically seized first when a station user goes off-hook or dials while on-hook when receiving or making calls. P-DN can be either M-DN or S-DN. If P-DN is not assigned explicitly, the first DN button becomes P-DN in the order of button number.

The same DN can be used as P-DN for multiple stations. If the state of shared P-DN is changed in this case, the status of P-DN will be updated to all the stations that have the shared P-DN. For example, DND, call forward, and other DN-based status notifications will be displayed at all same DN-programmed stations.

LED of DN Button

LED states of DN buttons are as follows:

- Green ON: DN being used by my station
- Red ON: DN being used by another station
- Amber flash: Held DN
- Green Flash: Ringing DN
- Red Flash: DN in DND status or DN in Call Forward

DN Tenant Group/COS

Each DN can be programmed with its own Tenant group or COS information. So, Tenant group and COS can be different for each call depending on the DN used for the calls.

If a station has DN buttons with different tenant groups, the station can make and receive calls using the different tenant groups.

Additionally, if the DN buttons have different COS, a station can have different COS according to the DN button selected.

Branch Line

When a station is using a MADN-type DN, other stations cannot access the same DN. However, if a branch line option is set to the DN, another Station can access the busy DN interrupting its call and establishing a conference call for all users.

Incoming Ring Option

When multiple stations have the same DN button, each station can have a different ring delay option.

- Immediate Ring: Ring signal is sent to station with no delay.
- Delayed Ring: Ring signal is sent to station after the programmed delay.
- No ring: Ring signal is not sent to station, but only LED flashes.

When the DN receives an incoming call, the DN button LED will flash Red regardless of the ring delay option. However, the LCD of a station modified to display the incoming call after it receives a ring signal can be automatically answered just by going off-hook.

However, before the station receives a ring signal, the incoming DN call cannot be answered automatically by going off-hook, but the station user should press the flashing DN button manually.

Access Option

When a station has multiple DN buttons, each DN button can have a different access option.

- All Call: No restriction.
- Dial After Seizure: No restriction about incoming ringing, but when making outgoing calls with this button, user should seize the DN by pressing this button even if this button is assigned to prime number button.
- Incoming Only: Outgoing call is not possible with this button.

When there is incoming call to a DN, the DN button LED will flash in red color regardless of the ring delay option. However, the LCD of station is changed to display the incoming call after it receives ring signal and the call can be answered automatically just by going off-hook. However, before the station receives ring signal, the incoming DN call cannot be answered automatically by going off-hook, but the station user should press the flashing DN button manually.

Chapter 3

System Features

This chapter provides detailed information covering description and operation of the numerous features available in the MBX IP System Software.

Account Code

Station users may enter a non-verified variable length (up to 12 digits) identifier for tracking specific calls. The identifier or “Account Code” is output as part of the Station Message Detail Record (SMDR) for the call.

CONDITIONS

- If an Authorization Code is entered as the Account Code, the SMDR record will show the station number or the bin number for a System Authorization Code rather than the user entered Authorization Code for security purposes.

OPERATION

Digital Phone

To assign a Flex button for {ACCOUNT CODE} operation:

Press [TRANS/PGM] + {FLEX} + Button Feature Type (1) + {Account Code Feature Code} + {Account Code} + * + [HOLD/SAVE]

To enter an Account Code using an {ACCOUNT CODE} button prior to placing a call when account code is not entered in the button:

1. Lift the handset
2. Press the {account code} button.
3. Dial the Account Code (1 to 12 digits).
4. Press *; Intercom dial tone is heard.
5. Place the CO/IP call as normal.

Using the programmed {ACCOUNT CODE} button prior to making a call:

1. Lift the handset.
2. Press the {account code} button; Intercom dial tone is heard.
3. Place the CO/IP call as normal.

Using an {ACCOUNT CODE} button during a call:

1. Press the {account code} button; CO line is held and the station hears dial tone.
2. Dial the Account Code (1 to 12 digits).
3. Press *; Station is re-connected with CO line.

Single Line Phone

To enter an Account Code prior to placing a call:

1. Lift the handset.
2. Dial the {Account Code Feature Code}.
3. Dial the Account Code (1 to 12 digits).
4. Press *.
5. Place the CO/IP call as normal.

To enter an Account Code during a call:

1. Press for Hook-switch.
2. Dial {Account Code Feature Code}
3. Dial the Account Code (1 to 12 digits).
4. Press *.

ADMIN PROGRAMMING

Numbering

Feature Numbering Plan (TRANS/PGM 113) ... [page A-17](#)

RELATED FEATURES

Authorization Codes (Password) ... see [page 3-5](#)

Station Message Detail Recording (SMDR) ... see [page 3-187](#)

Station Flexible Buttons ... see [page 6-21](#)

Alarm Signal/Door Bell

The system can be configured to recognize the status of an external contact (normally open or closed). The system will signal the assigned station when the contact activates. This capability is commonly employed to provide remote Alarm or Door Bell signals to the user.

A station receives the Alarm Signal, either as a single tone burst repeated at 1-minute intervals or a continuous tone. The Alarm Signal may be terminated at the User's phone by dialing the Alarm Stop code, or pressing the {ALARM STOP} button if assigned. To rearm the Alarm function, the alarm condition must be cleared and the Alarm signal terminated.

When used as a Door Bell, assigned stations receive an Alarm Signal each time the external contact is activated; reset is not required.

CONDITIONS

- The Alarm contacts must be "dry", no voltage or current source connected.
- A station with LCD assigned to receive Alarm/Door Bell signals will show "ALARM" as appropriate.
- If alarm is active during station busy, mute ring will be served to assigned station, and then after conversation, when station go to idle, the alarm signal will be sent to assigned station again.
- Assigned stations can be changed using Alarm Assign. (TRANS/PGM121-Flex12)
- Only Stations assigned with Alarm ring can terminate the alarm signal.
- IP Phone and normal digital Phone stations can be assigned as alarm stations.
- In signal mode, station will return alarm ringing again if an assigned station user does not reset the alarm signal prior to the station returning to idle.
- When the alarm is ringing, the alarm signal must be reset so phone operation will be fully functional (fixed or flex buttons do not operate and the user cannot hear the dial tone during alarm ringing).

OPERATION

System

At detection of contact operation, the Alarm/Door Bell signal is sent to assigned station.

Digital Phone

To assign a Flex button as an {ALARM STOP} button:

Press [TRANS/PGM] + {FLEX} + Button Feature Type(1) + {Sys Alarm Reset Feature Code} + [HOLD/SAVE]

To terminate an Alarm Signal while idle:

Dial the {Sys Alarm Reset Feature Code}; a confirmation tone is received and the Alarm Signal is terminated.

OR

Press the programmed {ALARM STOP} Flex button.

NOTE: If the alarm condition is cleared, the system will automatically rearm the alarm monitoring.

ADMIN PROGRAMMING

Station Data

Alarm (TRANS/PGM 121 - FLEX12) ... see details on [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
ALARM -- enable to receive system alarm signal.	12	1-3	1

System

Alarm (TRANS/PGM 121 - FLEX12) ... see details on [page A-87](#)

TRANS/PGM 227	BTN	RANGE	DEFAULT
ALARM ENABLE -- enables the external contact monitoring circuitry.	1	0: Off 1: On	Off
ALARM CONTACT TYPE -- establishes the contact state that will activate the Alarm, close or open.	2	0: Open 1: Close	Open
ALARM MODE -- the contact can be designated to function as a doorbell instead of an alarm.	3	0: Bell 1: Alarm	Alarm
ALARM SIGNAL MODE -- the assigned stations will receive a Repeating signal or single burst (ONCE) of the alarm tone.	4	0: Once 1: Repeat	Repeat

RELATED FEATURES

Door Open ... see [page 3-79](#)

HARDWARE

Digital Phone

External contact connected to Alarm input of MPB, refer to *MBX IP Hardware & Installation Manual*.

Authorization Codes (Password)

An Authorization Code is tied to a DN, and provides a means to control access to Walking COS, or DISA and may be required for outgoing CO/IP Lines based on the configuration of the database. When users dial a valid Authorization Code, the system invokes the Station COS.

The Station Authorization Code includes the associated station number and the assigned code. A Station Authorization Code is specifically related to a given station and intended for a single user.

The Administrator and Attendants are permitted to assign any Authorization code including codes for another station. Normal users may only assign the Station Authorization code for the specific station.

CONDITIONS

- A user may enter an Authorization Code from any station to place a CO/IP call using Walking COS.
- An Authorization code may include any dial pad digit except * and #.

OPERATION

Digital Phone

To assign a Station Authorization Code:

1. Press the [TRANS/PGM] button.
2. Dial 34 {Authorization Code Program}.
3. Dial the Authorization Code (1-12 digits).
4. Dial * or press the [HOLD/SAVE] button to save.

Single Line Phone

To assign a Station Authorization code:

1. Lift the handset.
2. Dial [SLT Program Mode Entry code].
3. Dial Station User Program code 34.
4. Dial Authorization Code (1-12 digits).
5. Dial *.

System Attendant

To assign an Authorization Code:

1. Press the [TRANS/PGM] button.
2. Dial Attendant Station Program Code 033.
3. Dial station number or range of stations. If one (1) station is to be programmed, enter that station number twice.
4. Dial the Authorization Code.
5. Press the [HOLD/SAVE] button.

ADMIN PROGRAMMING*Station Data*

Password (TRANS/PGM 131 - FLEX 4) ... see details on [page A-32](#)

TRANS/PGM 131	BTN	RANGE	DEFAULT
PASSWORD -- Password is employed to control access to the system resources and facilities. Walking COS, CO/IP Group access DISA callers and certain Call Forward types may require the input of a valid password.	4	0: Disable 1: Enable	Disable

Auto Call Release

Intercom calls (except Hands-free Ring Back) will be released automatically if the called party does not answer during the pre-set time.

CONDITIONS

- When the handset is used to place a call, the user will receive an error tone for 30 seconds followed by 30 seconds of Howler tone and the station is placed in a fault mode. If on-hook dialing is used, the station will receive an error tone for one (1) second and the phone will return to idle automatically.

OPERATION*System*

Auto Call Release of Intercom calls: If a station places an intercom call and the called station does not answer in the Intercom Call Release Time, the call is terminated and the calling user receives an error tone.

ADMIN PROGRAMMING*Table Data*

System Ring Table: Normal Call Ring ... use Web Admin (TRANS/PGM 265) see details on [page A-115](#)

Howler Tone (TRANS/PGM 121 - FLEX 7)... see details on [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
HOWLING TONE -- sets Anonymous Call Restrict service.	7	0: Off 1: On	On

Automatic Pause Insertion

In addition to a manually entered Pause, the system will automatically pause dialing to allow for potential connection delays. The pause will be inserted when any of the following occur:

- Flash is encountered in a Speed Dial number.
- Pulse to Tone Switchover is encountered in a Speed Dial or Redial number.
- Connect message is received on an ISDN Line.

CONDITIONS

- An automatically inserted pause is not counted as a digit in a Speed Dial number.
- The LCD of the Digital Phone will show a "P" when a pause is encountered.
- When the System inserts a Pause, "P" indication is not shown.

OPERATION*System*

The system automatically pauses dialing after an appropriate event (as listed above).

RELATED FEATURES

Auto Called Number Redial (ACNR) ... see [page 6-2](#)

Last Number Redial (LNR) ... see [page 3-110](#)

Dial Pulse to Tone Switchover ... see [page 3-62](#)

Automatic Privacy/Branch Line

Privacy is insured in all communications on the system. If desired, the customer may elect to disable the Automatic Privacy feature, allowing an uninvited station to join in an existing external conversation. In such a case, a conference is established. The Privacy feature restricts the intrusion/call-wait/camp-on/OHVA at a busy station, while the Branch Line can restrict a conference call by pressing {DN} button in use.

CONDITIONS

- With Automatic Privacy disabled, privacy is still assured on all intercom and conference calls.
- Only one station can intrude on an active call.
- An intrusion tone can be provided to the call indicating another station has accessed the line.

OPERATION

Digital Phone

To intrude into a call when Privacy is disabled:

Make a call to busy station and then press the appropriate code for intrusion/call-wait/camp-on/OHVA when receiving busy tone.

To change privacy mode in conversation:

Press the {DND} button during a conversation.

To intrude in a call when Branch Line is enabled:

Press a busy (lit steady) {DN} button, the user is connected to the call with the existing internal station user.

ADMIN PROGRAMMING

Station Data

Branch Line (TRANS/PGM 134 - FLEX 10) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
BRANCH/BRIDGE LINE -- Set branch/bridge line feature. Branch: Conference call by pressing {DN} button in use. Bridge: Bridge call by pressing {DN} button in use. Bridge (Softphone): Auto bridge if Phontage/UC Client's IP bridge is enabled.	10	0: Off 1: On	Off

Auto Privacy (TRANS/PGM 134 - FLEX 11) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
AUTO PRIVACY -- Enables auto privacy feature (to restrict the intrusion/call-wait/camp-on/OHVA in busy station)	11	0: Off 1: On	Off

System Data

Intercom Busy One-Digit Service (TRANS/PGM 237) ... see details on [page A-101](#)

TRANS/PGM 237	BTN	RANGE	DEFAULT	
STEP CALL -- determines if Step Call is enabled or disabled.	1	0:Disable 1:Enable	Disable	
DIGIT 1 -- when accessing a busy tone, user may dial for one of the one-touch services.	2	0: N/A 1: Call-Back 2: Camp On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	0: N/A	
DIGIT 2 --	3			
DIGIT 3 --	4			
DIGIT 4 --	5			
DIGIT 5 --	6			
DIGIT 6 --	7			
DIGIT 7 --	8			
DIGIT 8 --	9			
DIGIT 9 --	10			
DIGIT 0 --	11			
DIGIT * --	12			Call Wait
DIGIT # --	13			Voice-Over

RELATED FEATURES

Multi-Party Voice Conference ... see [page 3-50](#)

Station Flexible Buttons ... see [page 6-21](#)

Auto Service Mode Control

The service mode defines different ring assignments, COS and answering privileges for the system. The service mode can be controlled automatically through definitions in the Auto Ring Mode Selection Table, which defines the time of day for Day, Night and Timed shift modes. The Attendant may change the system mode selection from automatic to manual.

CONDITIONS

- If the system has Holiday information and current mode is Holiday, service mode is operated as Night mode

OPERATION

System

Operation of this feature is automatic.

ADMIN PROGRAMMING

Table Data

System Time Table (TRANS/PGM 253) ... see details on [page A-107](#)

TRANS/PGM 253	BTN	RANGE	DEFAULT
TIME ZONE COMMENT-- defines the comment of the Time Table.	1	32 characters	none
SYSTEM TIME ZONE -- defines the Time Zone of the Time Table	2	0-73	0: Sys Time
DAYLIGHT SAVINGS -- defines Daylight Saving Time of Time Table.	3	On/Off	Off
RING MODE -- defines the ring mode of Time Table.	4	0: Day 1: Night 2: Timed	0: Day
AUTO RING MODE -- defines the Auto Ring mode of the Time Table.	5	On/Off	Off

Weekly Time Table (TRANS/PGM 254) ... see details on [page A-108](#)

TRANS/PGM 254	BTN	RANGE	DEFAULT
Monday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	1	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Tuesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	2	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Wednesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	3	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Thursday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	4	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Friday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	5	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Saturday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	6	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Sunday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	7	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _

Holiday Time Table (TRANS/PGM 256) ... see details on [page A-110](#)

TRANS/PGM 256	BTN	RANGE	DEFAULT
CALENDAR TYPE -- Defines Calendar Type for Holiday Table.	1	Lunar/Gregorian	Gregorian
HOLIDAY DATE -- Defines Holiday Date for Holiday Table.	2	MM/DD	None

RELATED FEATURES

Direct Inward System Access (DISA) ... see [page 5-50](#)

Day/Night/Timed Ring Mode ... see [page 7-37](#)

CO Ring Assignment ... see [page 5-37](#)

LBC (Loud Bell Control) ... see [page 3-116](#)

Dialing Restrictions ... see [page 3-63](#)

Automatic System Daylight Savings Time

The system can automatically adjust for Daylight Saving Time (DST). When DST is enabled, the system will adjust the system time forward one hour at the DST Start time and back one hour at the DST End time. The system time is sent for display to all devices and terminals and is the basis of the various system time-based features (Wake-up Alarm, etc.).

CONDITIONS

- The DST Start and End times are set by the Web Admin interface only.
- The interval between the DST Start and End times must be at least 7 days.

OPERATION*System*

Operation of this feature is automatic.

ADMIN PROGRAMMING*System*

System Time (TRANS/PGM 233 - FLEX 1) ... see details on [page A-94](#)

TRANS/PGM 233	BTN	RANGE	DEFAULT
SYSTEM TIME/DATE -- sets the system time.	1	HH:MM	-

System Date (TRANS/PGM 233 - FLEX 2) ... see details on [page A-94](#)

TRANS/PGM 233	BTN	RANGE	DEFAULT
SYSTEM TIME/DATE -- sets the system date.	2	MMDDYY	-

DST Enable (TRANS/PGM 233 - FLEX 3) ... see details on [page A-94](#)

DST Start & End Time ... use Web Admin (TRANS/PGM 233)

TRANS/PGM 233	BTN	RANGE	DEFAULT
DST START TIME -- the DST start time.	Web Only	See DST Table	2nd Sunday of March at 2:00 AM
DST END TIME -- the DST end time.	Web Only	See DST Table	1st Sunday of November at 2:00 AM

RELATED FEATURES

Auto Service Mode Control ... see [page 3-10](#)

Automatic System Time Synchronization ... see [page 3-13](#)

System Clock Set ... see [page 7-42](#)

Automatic System Time Synchronization

When enabled, the system automatically determines and sets the time of day employing Network Time Protocol (NTP) or ISDN time messages. When using NTP, the system requests and receives GMT time at ten-minute intervals from the specified NTP time server. This feature allows the System Time to synchronize with the NTP time server automatically. If the time deviates more than two seconds, the system clock is adjusted to match the NTP server.

When using ISDN, the system receives the time of day in ISDN messages and automatically adjusts the time if the system time deviates from the ISDN time.

CONDITIONS

- NTP packets are expected over UDP port 123; verify the port is open and available.
- A secondary NTP server address can be defined should the first server not respond.
- If set, the system adjusts for the local time zone assigned in the system as the Standard System Time as well as Daylight Savings Time (DST).

OPERATION

System

Operation of this feature is automatic.

ADMIN PROGRAMMING*System*

Network Time/Date (TRANS/PGM 223 – FLEX 5) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
NETWORK DATE/TIME USE -- If set to ON, the System updates the Date & Time with Network Date & Time when the System Date & Time is different.	5	0: Off 1: On	0: Off

NTP Active ... use *Web Admin* (TRANS/PGM 233)

NTP Sever Address ... use *Web Admin* (TRANS/PGM 233)

Standard System Time, Local Time Zone ... use *Web Admin* (TRANS/PGM 233)

RELATED FEATURES

Auto Service Mode Control ... see [page 3-10](#)

Automatic System Daylight Savings Time ... see [page 3-12](#)

System Clock Set ... see [page 7-42](#)

Battery Back-up, Memory

The system database is protected from power-loss by a long life (10-year) lithium dry cell battery. Should local power fail, the battery will maintain the system memory and proper operation of the system clock.

CONDITIONS

- The Initialization switch must be in the ON position to enable Memory Battery Back-up. Otherwise, should power fail, the system will initialize the database on power-up. Refer to the MBX IP Hardware and Installation Guide for more details.
- The Lithium battery is not field-replaceable.

OPERATION*System*

When enabled, operation is automatic.

Call Forward

User may have selected incoming calls re-route to other stations (local or networked), station groups, the VMIIIB, or over a system CO/IP line (Off-Net).

The user selects the type and condition under which calls will forward by entering a Call Forward code as follows:

- Code 0, Remote Call Forward – forwards all calls to the station, except recalls, activated from a remote station, Call Forward, Follow-me.
- Code 1, Unconditional – all calls to the station, except recalls, are forwarded internally or externally immediately upon receipt.
- Code 2, Busy – if the station is busy, forwards all calls, except recalls, to the selected station.
- Code 3, No Answer – forwards all calls, except recalls, to the selected station when the station does not answer within the No Answer timer.
- Code 4, Busy/No Answer – forwards calls if the selected station is busy or does not answer within the No Answer timer.

CONDITIONS

- A station receiving a forwarded call can transfer the call to the forwarding station.
- A station, denied the use of Call Forward, will receive an error tone in response to attempts to activate Call Forward.
- A forwarded intercom call will signal the receiving station in Tone Signaling mode, regardless of the Intercom Signaling Mode at the station.
- Attempting activation of Call Forward will automatically deactivate any activated Display Text Message (Active Call Back or Queue requests do not cancel).
- When Call Forward is active, a Station can make outgoing calls (internal or external).
- For CO/IP calls, when Call Forward is manually activated, it will override any Preset Call Forward assigned for the station or CO/IP line
- Call Forward status is maintained in the System's non-volatile memory for protection from power outage.
- Off-Net Call Forward of incoming CO/IP calls is essentially an automated DISA call, which will establish an Unsupervised Conference; such calls are subject to the conditions of a DISA call and Unsupervised Conference and may require entry of an Authorization Code.
- Off-Net Forward calls are not answered until the system completes dialing of the external call. The call, internal or external, is then connected to the Off-Premise call.

- An unlimited number of stations may be set-up in a Call Forward chain, forwarding calls from one station to the next. However, the Call Forward service counter is restricted by the 'Multi-Call Forward Service Count' attribute (tenant based).
- No Answer Forward employs the Station No Answer Forward Timer.
- The No Answer Call Forward Timer can be adjusted at the TRANS/PGM 141, FLEX 4.
- A Station should have Off-Net Forward access privilege to assign a CO Access code and External Phone number to the forward destination.

OPERATION

Digital Phone

To activate Call Forward, Unconditional or Busy/No Answer:

1. Lift the handset or press the [SPEAKER] button to receive a dial tone.
2. Press the [FWD] button.
3. Dial 1-4 {Forward Code} as appropriate.
4. Dial the station or station group to receive calls.
OR
5. Dial CO Group Access code and desired external phone number.
6. Press the [HOLD/SAVE] button to save.
7. Replace the handset, return to idle.

To activate Call Forward, Remote (Follow-me):

1. Lift the handset or press [SPEAKER] button to receive Dial tone.
2. Press the [FWD] button.
3. Dial 0 {Call Forward code}.
4. Dial the Station's Authorization Code (Station number + password),
5. Dial 1-4 {Forward condition}.
6. Dial the destination station or station group. OR Dial CO Group Access code and desired external phone number.
7. Press [HOLD/SAVE] button to save.
8. Replace the handset, return to idle.

To deactivate Call Forward:

Press flashing [FWD] button, Call Forward will deactivate; [FWD] LED button is turned OFF.

Single Line Phone

To activate Call Forward, Unconditional, Busy/No-Answer:

1. Lift the handset to receive Dial tone.
2. Dial {Call Forward feature code}
3. Dial 1-4 (Call Forward code) as desired.
4. Dial station or station group to receive calls. OR Dial the CO Group Access code and the desired external phone number.
5. Press hook-switch to save.
6. Replace the handset, return to idle.

To activate Call Forward, Remote (Follow-me):

1. Lift the handset.
2. Dial {Call Forward code}.
3. Dial 0 {Remote Forward code}.
4. Enter the Station number {Station Authorization Code} +Password.
5. Dial 0 {Remote Forward condition}.
6. Dial the destination station or station group.
OR
Dial CO Group Access code and desired external phone number.
7. Press hook-switch to save.
8. Replace handset return to idle.

To deactivate the Call forward

1. Lift the handset to receive a stutter Dial tone.
2. Dial {Call Forward feature code}, as desired.
3. Dial '#' to cancel Call Forward.

ADMIN PROGRAMMING

Station Data

Call Forward Access (TRANS/PGM 132 FLEX 2) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
CALL FORWARD ACCESS -- enables Call Forward to be activated by the station.	2	0: Disable 1: Enable	Enable

OffNet Call Forward Access (TRANS/PGM 132 FLEX 3) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
OFFNET CALL FORWARD ACCESS -- a station must be allowed Off Net Fwd to forward external incoming calls outside the system or otherwise establish a CO-to-CO connection.	3	0: Disable 1: Enable	Enable

Call Forward Assignment (TRANS/PGM 143) ... see details on [page A-40](#)

TRANS/PGM 143	BTN	RANGE	DEFAULT
FORWARD TYPE -- specify call forward type.	1	0: Not Assigned 1: Unconditional 2: Busy 3: No Answer 4: Busy or No Answer	Not Assigned
FORWARD NUMBER -- specify Call Forward Destination by entering dial digits.	2	Max 32 digits	-
FORWARD APPLY TIME -- specify Call Forward Applying Time.	3	0: All 1: Day 2: Night 3: Timed	All
CALL FORWARD NO ANSWER TIMER -- if the station does not respond during the 'CFW NO ANS TMR' timer, the call is forwarded to Call Forward Destination.	4	(0-600) sec	15 sec
FORWARD DISPLAY -- enables the Forward Display Option to check forward information in idle state.	5	0: Off 1: On	On

Tenant Data

Multi-Call Forward Service Center ... see [page A-128](#)

TRANS/PGM 280	BTN	RANGE	DEFAULT
MULTI-CALL FORWARD SERVICE COUNTER -- determines the Multi-Call forward count.	8	01-10	05

RELATED FEATURES

Station Authorization Code ... see [page 3-5](#)

DND ... see [page 3-77](#)

Dialing Restriction ... see [page 3-63](#)

Station Group ... see [page 3-154](#)

Intercom Signaling Mode ... see [page 6-11](#)

Call Forward, Preset ... see [page 3-22](#)

Call Forward, Pilot Hunt

User may have selected incoming calls in his group to re-route to other stations (local or networked), station groups, or VMIIIB. The user selects the type and condition under which calls will forward by entering a Call Forward code as follows:

Code 1, Unconditional – all calls to the station, except recalls, are forwarded internally or externally immediately upon receipt.

Code 2, Busy – if the station is busy, forwards all calls, except recalls, to the selected station.

Code 3, No Answer – forwards all calls, except recalls, to the selected station when the station does not answer within the No Answer timer.

Code 4, Busy/No Answer – forwards calls if the selected station is busy or does not answer within the No Answer timer.

CONDITIONS

- Station Call Forward has higher priority than Pilot Hunt Call Forward.
- To assign Pilot Hunt Call forward, the Station should be a member of the Pilot Hunt Group.
- An external number cannot be assigned to a Pilot Hunt Forward destination.
- If a station assigns the pilot hunt Call Forward, the pilot hunt call forward in day mode is changed.

- The Pilot Hunt Ring access privilege can be assigned on a per Station basis; if the Pilot Hunt Ring access of the station is disabled, that station will not receive Pilot Hunt ringing.
- If a user activates the call forward feature using the {Pilot Hunt Call Forward code}, it is applied to the Day Forward destination.

OPERATION

Digital & Single Line Phone

To activate Call Forward, Unconditional or Busy/No Answer:

1. Lift the handset or press the [SPEAKER] button to receive dial tone.
2. Dial {Pilot Hunt Call Forward Code}
3. Dial 1-4 {Call Forward code} as desired.
4. Dial the station or station group to receive calls.
5. Press the [HOLD/SAVE] button to save.
6. Replace the handset, return to idle.

To deactivate the Call Forward:

1. Lift the handset or press the [SPEAKER] button,
2. Dial {Pilot Hunt Call Forward Cancel Code},

ADMIN PROGRAMMING

Station Data

Call Forward Access (TRANS/PGM 132 - FLEX 2) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
CALL FORWARD ACCESS -- enables Call Forward to be activated by the station.	2	0: Disable 1: Enable	Enable

Pilot Hunt Ring Access (TRANS/PGM 134 - FLEX 6) ... see details on [page A-33](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
PILOT HUNT RING -- permits station to receive pilot hunt ring.	6	0:Disable 1:Enable	Enable

Station Group Data

Pilot Hunt Group (TRANS/PGM 210 - 211) ... see details on [page A-74](#)

TRANS/PGM 210	BTN	RANGE	DEFAULT
CONDITION -- Determines call coverage condition for Pilot Hunt group.	1	0: ALL 1: Intercom 2: External	All
SERVICE TYPE -- This entry defines Service Type. (Terminal/Circular)	2	0: Terminal 1: Circular	Terminal
TIME TABLE INDEX -- Time Table index.	3	1-9	1
MEMBER ASG --Assigns stations as members of a Pilot Hunt group.	4	-	-

TRANS/PGM 211	BTN	RANGE	DEFAULT
DAY FORWARD TYPE -- determines Day time seting for Call Forward type.	1	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
DAY FORWARD DESTINATION -- determines Day time seting for Forward destination.	2	Max. 8 digits	-
NIGHT FORWARD TYPE -- determines the Night time seting for Call Forward type.	3	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
NIGHT FORWARD DESTINATION -- determines the Night time seting for Forward destination.	4	Max. 8 digits	-
TIMED FORWARD TYPE -- determines the Timed seting for Forward type.	5	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
TIMED FWD DESTINATION -- determines the Timed seting for Forward destination.	6	Max. 8 digits	-

RELATED FEATURES

Station Authorization Code ... see [page 3-5](#)

DND ... see [page 3-77](#)

Dialing Restriction ... see [page 3-63](#)

Station Group ... see [page 3-154](#)

Intercom Signaling Mode ... see [page 6-11](#)

Call Forward, Preset ... see [page 3-22](#)

Call Forward, Preset

Call Forward, Preset calls to a Station are forwarded to a pre-determined destination assigned in the system database. Preset Call Forward can define separate treatment of CO/IP calls and intercom calls. In addition, separate busy and no-answer treatments are defined:

- Internal Unconditional – all intercom calls are immediately forwarded.
- Internal Busy – Intercom calls that encounter a busy, are forwarded immediately.
- Internal No-Answer – Intercom calls, which are not answered in the No-Answer time, or busy, are forwarded.
- External Unconditional – all external calls immediately forward.
- External Busy – external calls that encounter a busy are forwarded immediately.
- External No-Answer – external calls, not answered in the No-Answer time, or busy, are forwarded.

In addition, calls can be directly forwarded to the Users Voice Mail box using Call Forward, Preset. Preset Call Forward condition and type can be selected as listed:

- Unconditional – all calls to the station, are forwarded internally or externally immediately upon receipt.
- Busy – if the station is busy, all calls are forwarded to the selected station.
- No Answer - forwards all calls to the selected station when the station does not answer within the No Answer timer.

CONDITIONS

- A station receiving a forwarded call can transfer the call to the forwarding station.
- Calls cannot be forwarded to a station in DND (error tone is returned).
- Manual forward has a higher priority than Preset Forward and overrides any Preset Forward setting.
- Preset call forward status is not shown on the Station LCD display.

- No Answer Forward employs the Station No Answer Forward timer.
- If Station No Answer Preset Call Forward and CO Preset Forward Ring Table is set the same, the CO Preset Forward Ring Table precedes Station Preset Call Forward.

OPERATION

System

When enabled, operation of Preset Call Forward is automatic.

ADMIN PROGRAMMING

Station Data

Preset Call Forward (TRANS/PGM 142) ... see details on [page A-39](#)

TRANS/PGM 142	BTN	RANGE	DEFAULT
INTERNAL UNCOND -- The unconditional preset forward destination of internal(intercom) call .	1	Max 32 digits	-
INTERNAL BUSY -- The busy preset forward destination of internal(intercom) call.	2	Max 32 digits	-
INTERNAL NO-ANSWER -- The no-answer preset forward destination of internal(intercom) .	3	Max 32 digits	-
EXTERNAL UNCOND -- The unconditional preset forward destination of external call.	4	Max 32 digits	-
EXTERNAL BUSY -- The busy preset forward destination of external call.	5	Max 32 digits	-
EXTERNAL NO-ANSWER -- The no-answer preset forward destination of external call.	6	Max 32 digits	-

Call Forward No-Answer Timer (TRANS/PGM 143 - FLEX 4) ... see details on [page A-40](#)

TRANS/PGM 143	BTN	RANGE	DEFAULT
CFW NO ANS TMR -- Busy or No Answer - employs this 'CFW NO ANS TMR' timer. If the station does not respond during the 'CFW NO ANS TMR' timer. Call is forwarded to 'Call Forward Destination'.	4	0-600 secs	15 secs

RELATED FEATURES

Call Forward... see [page 3-15](#)

DND ... see [page 3-77](#)

Auto Attendant ... see [page 3-87](#)

Preset Call Forward ... see [page 3-22](#)

VMIB Integrated Auto Attd/Voice Mail ... see [page 3-258](#)

Call Park

A User may place (Park) an active intercom or CO/IP call in a special holding location (Park Orbit) for easy access from any station in the system. The system has 50 holding locations (Park Orbits).

CONDITIONS

- If the selected Park Orbit returns a busy signal, the user may simply dial another Park Orbit without disconnecting.
- A Parked call will recall to the station that parked the call should the Call Park Timer expire. The normal Hold Recall process is then initiated.
- A Parked call will indicate busy at all appearances.

OPERATION

Digital Phone

To park an active external call:

1. Press the [TRANS] button.
2. Dial {Call Park Feature Code}.
3. Dial the Call Park No (00-49).
4. Return to idle.

To retrieve a parked call:

1. Lift the handset or press the [SPEAKER] button.
2. Dial {Call Park Feature Code}.
3. Dial the Call Park No (00-49).

Single Line Phone

To park an active external call

1. Press the hook-switch.
2. Dial {Call Park Feature Code}.
3. Dial the Call Park No (00-49).
4. Return to idle.

To retrieve a parked call

1. Lift the handset.
2. Dial {Call Park Feature Code}
3. Dial the Call Park No (00-49).

ADMIN PROGRAMMING

Numbering Data

Call Park Code (TRANS/PGM 113) ... see details on [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
36	Call Parking Location	541 + xx (Parking Location 00-49)

Tenant Data

Call Park Hold Tone Time ... see [page A-133](#)_use Web Admin (TRANS/PGM 290 - FLEX 58-59)

TRANS/PGM 290	BTN	RANGE	DEFAULT
TONE TIME -- Determines the amount of time tone is provided.	2	1-600	10

RELATED FEATURES

- Hold ... see [page 3-101](#)
- Hold Recall ... see [page 3-102](#)

Call Pick-Up

Directed Call Pick-Up

A station may answer (Pick-Up) incoming and transferred intercom, CO and IP calls ringing at another station. All ringing calls are subject to Directed Call Pick-up except queued Callbacks.

Digital phone users may assign a Flex button as a {DIRECTED CALL PICK-UP} button.

CONDITIONS

- To pick-up a CO/IP call, the station must have an idle appearance button.
- When several calls are ringing at a station simultaneously, Call Pick-up will connect the first call received.
- Queue callback calls are not subject to Call Pick-up (receives an error tone).
- Only ringing intercom calls are subject to Call Pick-up; Intercom calls announced hands free cannot be picked up by another station.

OPERATION

Digital Phone

To assign a {directed call pick-up} button:

Press [TRANS/PGM] + {Flex} + Button Feature Type (1) + {Direct Pickup Feature Code} + [HOLD/SAVE].

To Pick-up a call ringing at another station:

1. Lift the handset or press [SPEAKER].
2. Dial {Directed Call Pick-up code}.
3. Dial the intercom number of the ringing station.
You may also pick up the call by pressing the DSS button of the ringing station.
See the "pickup by DSS button" option on the next page.

OR

1. Lift the handset or press [SPEAKER].
2. Press the {DIRECTED CALL PICK-UP} button.
3. Dial the intercom number of the ringing station.

Single Line Phone

To Pick-up a call ringing at another station:

1. Lift the handset
2. Dial {Directed Call Pick-up code}.
3. Dial the number of the ringing station.

ADMIN PROGRAMMING

Numbering Data

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

Station Group Data

Station Data -- Pickup by DSS (TRANS/PGM 124 - FLEX 9) ... see details on [page A-27](#)

TRANS/PGM 124	BTN	RANGE	DEFAULT
PICKUP BY DSS BUTTON -- this value determines the method of pickup when pressing DSS button.	9	0: Disable 1: Group Pickup 2: Direct Pickup	Direct Pickup

Station Group Attributes, Pick-up Option (TRANS/PGM 200 - FLEX 5) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable

Call Pick-up Group Attributes (TRANS/PGM 204) ... see details on [page A-70](#)

TRANS/PGM 204	BTN	RANGE	DEFAULT
PICK UP CONDITION -- this entry defines pick up condition. (All/Internal/External)	1	0: All Call 1: Int Call 2: Ext Call	All Call
PICK UP MEMBER ASG -- assigns stations as members of a station pickup group.	2	-	-

RELATED FEATURES

Intercom Signaling Mode ... see [page 6-11](#)

Group Call Pick-up ... see [page 3-28](#)

Group Call Pick-Up

A Station can answer (Pick-Up) incoming and transferred intercom, CO and IP calls ringing at another station in the same station group. All ringing calls, except Private Queue Callbacks, are subject to Pick-up by other stations in the same group. Digital phone users may assign a Flex button as a {GROUP CALL PICK-UP} button.

CONDITIONS

- To pick-up a CO/IP call, the station must have an idle appearance button.
- When several calls are ringing at a station simultaneously, Call Pick-up will connect the first call received.
- Queue callback calls are not subject to Call Pick-up (receives error tone).
- Only ringing intercom calls are subject to Call Pick-up; Hands free announced intercom calls cannot be picked up by another station.
- When a station belongs to multiple groups, calls received are routed to the group with the lowest station number.

OPERATION

Digital Phone

To assign a {GROUP CALL PICK-UP} button:

PRESS [TRANS/PGM] + {FLEX} + Button Feature Type(1) + {Group Pickup Feature Code} + [HOLD/SAVE]

To Pick-up a call ringing at another station:

1. Lift the handset or press [SPEAKER].
2. Dial {Group Call Pick-up code}.
- OR
3. Press the programmed Group Call Pick-up button.

Single Line Phone

To Pick-up a call ringing at another station:

1. Lift the handset.
2. Dial {Group Call Pick-up code}.

ADMIN PROGRAMMING*Numbering Data*

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

Station Group Data

Station Group Attributes, Pick-up Option (TRANS/PGM 200 - FLEX 5) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable

Call Pick-up Group Attributes (TRANS/PGM 204) ... see details on [page A-70](#)

TRANS/PGM 204	BTN	RANGE	DEFAULT
PICK UP CONDITION -- this entry defines pick up condition. (All/Internal/External)	1	0: All Call 1: Int Call 2: Ext Call	All Call
PICK UP MEMBER ASG -- assigns stations as members of a station pickup group.	2	-	-

RELATED FEATURES

Intercom Signaling Mode ... see [page 6-11](#)

Group Call Pick-up ... see [page 3-28](#)

Station Group ... see [page 3-154](#)

Call Transfer

Call Transfer, Station

CO/IP calls can be transferred to other stations on the same System. Calls can be transferred without announcing the call (unscreened), or with announcement (screened).

When a call is transferred, the Transfer Recall Timer is initiated. If the timer expires before the call is answered, the Hold Recall process is initiated.

CONDITIONS

- The transferring station may camp on a call on to a busy station.
- To prevent Toll abuse, CO/IP lines without an active call (either incoming or dialed digits on outgoing) cannot be transferred.
- For outgoing CO Line calls, the system will monitor the CO Line for dial tone to prevent Toll abuse; when an IP Line is seized, the system does not monitor for dial tone.

OPERATION

Digital Phone

While on a CO/IP call, to perform a Screened Call Transfer:

1. Press [TRANS].
 2. Dial the station to receive the transfer.
 3. At answer or splash tone, announce the call.
 4. Hang-up to complete the transfer.
- OR
5. Press the {DSS/BLF} button for the desired station.
 6. When answered or when splash tone is heard, announce the call.
 7. Hang-up to complete the transfer.

While on a CO/IP call, to perform an Unscreened Call Transfer:

1. Press [TRANS].
 2. Dial the station to receive the transfer.
 3. Hang-up to complete the transfer.
- OR
4. Press the {DSS/BLF} button for the desired station.
 5. Hang-up to complete the transfer.

Single Line Phone

While on a CO/IP call, to perform a Screened Call Transfer:

1. Press for hook-switch.
2. Dial the station to receive the transfer.
3. When answered or when splash tone is heard, announce the call.
4. Hang-up to complete the transfer.

While on a CO/IP call, to perform an Unscreened Call Transfer:

1. Press for hook-switch.
2. Dial the station to receive the transfer.
3. Hang-up to complete the transfer.

RELATED FEATURES

Hold Recall ... see [page 3-102](#)

Call Transfer, CO/IP ... see [page 3-31](#)

Station Flexible Buttons ... see [page 6-21](#)

Call Transfer, CO/IP

A Station may be permitted to transfer a CO/IP call to another CO/IP line, establishing an Unsupervised Conference between the two external parties.

If the receiving party is called through an ISDN or VoIP path, the Transfer Hold Recall Timer is initiated and if it expires, Hold Recall is initiated.

CONDITIONS

- A call using the service of 2 CO lines and not providing call disconnection detection will be disconnected following the expiration of the Unsupervised Conference timer.
- The system provides Transfer Recall on ISDN and VoIP calls providing 'Answer Supervision'.
- If during a transfer to an external party, the user presses the CO/IP line of the original call, the outgoing call is disconnected and the original call is connected to the user.
- The CO-to-CO transfer can be enabled or disabled by using the Transit Option on CO line basis and also by using offnet forward option on station basis..
- If the transferred call is not answered by the destination Station, the call is routed to the 'Transfer No Answer Destination' of the CO Alternative Destination.
- When CO 1 is transferred to CO 2, if the CO 2 does not answer within the CO-to-CO transfer recall timer, both CO lines are disconnected.

OPERATION**Digital Phone**

While on a CO/IP call, to perform a Screened Call Transfer:

1. Press [TRANS].
2. Place a CO/IP call in the normal manner.
3. When answered, announce the call.
4. Hang-up to complete the transfer.

While on a CO/IP call, to perform an Unscreened Call Transfer:

1. Press [TRANS].
2. Place CO/IP call in the normal manner.
3. Hang-up to complete the transfer.

Single Line Phone

While on a CO/IP call, to perform a Screened Call Transfer:

1. Press for hook-switch.
2. Place CO/IP call in the normal manner.
3. When answered, announce the call.
4. Hang-up to complete the transfer.

While on a CO/IP call, to perform an Unscreened Call Transfer:

1. Press for hook-switch.
2. Place CO/IP call in the normal manner.
3. Hang-up to complete the transfer.

ADMIN PROGRAMMING***Station Number Data***

Offnet Forward Access (TRANS/PGM 132, FLEX 3) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
OFFNET FORWARD ACCESS -- a station must be allowed Off Net Fwd to forward external incoming calls outside the system or otherwise establish a CO-to-CO connection.	3	0: Disable 1: Enable	Enable

CO Line Data

CO-to-CO Attributes (TRANS/PGM 179) ... see details on [page A-60](#)

TRANS/PGM 179	BTN	RANGE	DEFAULT
STATION OUTGOING CALL TRANSFER -- while stations are connected to outgoing CO call of first CO Group, the station can transfer the call to second CO group.	1	0: Off 1: On	On
OUTGOING CALL TRANSFER -- while ATD is connected to outgoing CO call of first CO Group, the ATD can transfer the call to second CO group.	2	0: Off 1: On	On
OUTGOING CALL TRANSFER RELEASE TYPE -- if outgoing CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	3	0: None 1: Release after Release Timer	None
OUTGOING CALL TRANSFER RELEASE TIME -- if an outgoing CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'Rls after Rls Time'. Before disconnecting, a warning tone is provided.	4	000-300 (sec)	060
INCOMING CALL TRANSFER DIRECTLY -- if this feature is set to ON, CO incoming call can be transferred directly without any stations or ATD to transfer the call.	5	0: Off 1: On	Off
STATION INCOMING CALL TRANSFER -- while stations are connected to incoming CO call of first CO Group, the station can transfer the call to second CO group.	6	0: Off 1: On	On
ATD INCOMING CALL TRANSFER -- while ATD is connected to incoming CO call of first CO Group, the ATD can transfer the call to second CO group.	7	0: Off 1: On	On
INCOMING CALL TRANSFER RELEASE TYPE -- If incoming CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	8	0: None 1: Release after Release Timer	None
INCOMING CALL TRANSFER RELEASE TIME -- If an incoming CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'Rls after Rls Time'. Before disconnected, warning tone is provided.	9	000-300 (sec)	060

Unsupervised Conference Extend (TRANS/PGM 166) ... see details on [page A-50](#)

TRANS/PGM 166	BTN	RANGE	DEFAULT
UNSUP CONF ENTEND -- If this feature is set to ON, unsupervised conference timer can be extended by dial feature code after warning tone is heard.	3	0: Disable 1: Enable	Disable

Unsupervised Conference Extend (TRANS/PGM 171) ... see details on [page A-57](#)

TRANS/PGM 171	BTN	RANGE	DEFAULT
UNSUP CONF EXTEND -- If this feature is set to ON, Unsupervised Conf Timer can be extended by dialing feature code after warning tone is heard.	2	0: Off 1: On	Off

Unsupervised Conference Timer (TRANS/PGM 166) ... see details on [page A-50](#)

TRANS/PGM 166	BTN	RANGE	DEFAULT
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after timer expires. The warning tone is heard before the line is disconnected.	9	000-255 (min)	000

Unsupervised Conference Timer (TRANS/PGM 171) ... see details on [page A-57](#)

TRANS/PGM 171	BTN	RANGE	DEFAULT
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after the timer expires. The warning tone is heard before the line is disconnected.	6	000-255 (min)	000

Incoming CO Alternate Destination (TRANS/PGM 169) ... see details on [page A-54](#)

TRANS/PGM 169	BTN	RANGE	DEFAULT
Incoming CO Alternataive DAY --	1	F1: Busy F2: No Answer	Disconnect 1 sec
NIGHT --	2	F3: Invalid F4: Transfer No Answer	Disconnect 1 sec
TIMED --	3	F5: Recall No Answer F6: DND F7: Out Of Service F8: Error 1: Disconnect 2: Attendant 3: CO Ring 4: Alt Ring Table 5: Tone 6: Pilot HuntGroup	Disconnect 1 sec

Outgoing CO Alternate Destination (TRANS/PGM 173) ... see details on [page A-57](#)

TRANS/PGM 173	BTN	RANGE	DEFAULT
DAY ALT DEST -- Abnormal case can be selected as error type.	-	F1: Recall No Answer F2: Transfer No Answer F3: No Answer	-
NO ANSWER DISCONNECT-- The CO call is disconnected. Every destination is set to 'Disconnect' by default.	1	-	-
NO ANSWER ATTENDANT -- The CO call is routed to Attendant.	2	-	-
NO ANSWER CO RING ASSIGN -- The CO call is routed according to Ring Assign Table. (see TRANS/PGM 167)	3	-	-
NO ANSWER ALT RING TBL -- If destination is set to Alt Ring Table and the Table index is assigned, the CO call is routed according to Alt Ring Table. (See TRANS/PGM 181)	4	01-80	-
NO ANSWER TONE -- If destination is set to Tone, the Error / Busy tone is heard.	5	-	-

TRANS/PGM 173	BTN	RANGE	DEFAULT
NO ANSWER PILOT HUNT GROUP -- The CO call is routed to Pilot Hunt Group of the original destination.	6	-	-
NO ANSWER RING -- The call is routed to the same destination again.	7	-	-
NO ANSWERThe CO call is routed to the transferred station again. Only possible for 'Transfer No Answer' case.	8	-	-

CO-to-CO Transfer Timer (TRANS/PGM 220) ... see details on [page A-83](#)

TRANS/PGM 220	BTN	RANGE	DEFAULT
CO-CO TRANS TMR -- Determines the answer waiting time when CO line is transferred to another CO line. If not answered in this time, transferred CO call is disconnected.	1	000-300 secs	030
HOT-DESK LOGOUT TMR -- Determines the amount of time the attendant receives recall after which the system will disconnect the call.	2	00-24 hrs	00
ACNR PAUSE TMR -- This timer establishes the time between ACNR attempts.	3	005-300 secs	030
PAGE TIME OUT TMR -- Determines the maximum duration of a page after which the caller and Page Zone are released.	4	000-300 secs	15
PAUSE TMR -- A Timed pause of this duration is used in Speed Dial and during other automatically dialed digits sent to the PSTN.	5	1-9 secs	3
VM PAUSE TMR -- When the system sends a "Pause" to Voice Mail using In-band signals, the Pause interval is defined by this timer.	6	1-9 secs	3
VMIB-MSG MIN TMR -- This timer sets the minimum duration allowed for a voice mail message in the system's VMIB. Messages shorter than this period are not stored.	7	1-9 secs	4
VMIB-MSG MAX TMR -- This timer sets the maximum duration allowed for the User Greeting in the system's VMIB.	8	00-999 secs	60
CALL-WAIT WARN TMR -- Determine the call-wait indication tone repeat time.	9	010-1800 secs	030
CAMP-ON WARN TMR -- Determine the camp-on indication tone repeat time.	10	010-1800 secs	030

TRANS/PGM 220	BTN	RANGE	DEFAULT
CCR INTER-DGT TMR -- Inter-digit timer used with Customer Call Routing function.	11	01-30 secs	03
WEB PSWD GUARD TMR -- If no data packets are received during a Web Admin connection for the Guard time, a password check will be initiated by the system.	12	001-999 mins	5

RELATED FEATURES

Hold Recall ... see [page 3-102](#)

Call Transfer, Station ... see [page 3-30](#)

Unsupervised Conference ... see [page 3-53](#)

CO/IP Access

Stations can access outgoing CO/IP lines based on CO/IP Group Access programming. Digital Phones may use flexible buttons assigned to access a specific {CO} line, using a {CO ACCESS CODE} for outgoing calls.

CONDITIONS

- When a user dials a {CO Access Code}, the system will search the assigned CO group for an idle CO/IP line, if there is no idle CO/IP line then the system will search the 1st CO/IP Group for an idle CO/IP line; the user will receive a busy tone.
- A telephone user not allowed access to a CO/IP line will receive an error tone when access is attempted; the station may receive transferred calls despite denied access on the line but will not be able to flash or use the CO/IP line for an outgoing call.
- A station denied access to a CO/IP line but assigned to receive CO/IP line calls may answer incoming calls. The user may transfer calls but cannot make an outgoing call on the CO/IP line.
- CO/IP lines placed on hold may be retrieved by dialing the {Retrieve Held CO/IP code} and the CO/IP line number.
- The Tx path to a station will be muted until the system has verified the Toll Restriction for the CO/IP line.
- When a CO line is seized, the system will monitor the line for dial tone.
- The System selects lines from a group using the Round Robin, First-Choice or Last-Choice method based on Admin Programming.

OPERATION

Digital Phone

To place an outgoing CO call:

1. Lift the handset or press the [SPEAKER] button.
2. Press desired {CO} line, and enter {CO ACCESS CODE}.
OR
3. Dial the CO line or CO Access Code.
4. Dial the desired number.

To place an outgoing IP call:

1. Lift the handset or press the [SPEAKER] button.
2. Press desired {CO} line, and enter {CO ACCESS CODE}.
OR
3. Dial the CO line or CO Access Code.
4. Dial the desired number registered in H.323 Routing Attribute (TRANS/PGM 360), then the outgoing call will be made to the assigned IP-Address.

To receive an IP call:

If a call is received from the assigned IP-Address in H.323 Incoming Attribute, it is routed to the assigned incoming CO Group.

To answer an incoming CO/IP call:

1. Lift the handset or press the [SPEAKER] button.
OR
2. Press {DN} button, and lift the handset to speak privately.

Single Line Phone

To place an outgoing CO/IP call:

1. Lift the handset.
2. Dial the CO line or CO Access Code.
3. Dial the desired number.

To answer an incoming CO/IP call:

Lift handset.

ADMIN PROGRAMMING

CO Line Data

CO Group Access Code (TRANS/PGM 180) ... see details on [page A-62](#)

TRANS/PGM 180	BTN	RANGE	DEFAULT
ACCESS CODE NAME -- When a CO Grp Access code is dialed or Flex Button is pressed; name is displayed on the station's LCD.	1	Max 16 chars	-
CO LINE CHOICE -- Decide to select to CO line priority to seize. NOTE: When Outgoing Group Number is not assigned, this option is not applied.	2	0: Round Robin 1: Last Line 2: First Line	Last Line
OUTGOING GRP NO -- Determines the CO Group number used to seize. NOTE: If not assigned, the access code is used as LOOP key.	3	01-72 (MBX IP -300) 01-24 (MBX IP -100)	Not assigned to the first access code. 01-72 (MBX IP-300) 01-24 (MBX IP-100) is assigned sequentially from the second access code
AND DGT -- Automatic Network Dialing (AND) digit is sent after CO line seized. This feature allows user to initiate CO calls only by dialing CO Group Access Code.	4	Max 10 digits	-
ARS SERVICE -- If Alternate Route Selection (ARS) is set, ARS digit is dialed instead of CO Group Access code when there is no available path.	5	0: Off 1: On	Off
ARS DGT 1 -- Alternate CO Group Access code to be used when original CO Group Access code failed to find available CO line.	6	Max 8 digits	-
ARS 1 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	7	0: Off 1: On	Off
ARS DGT 2 -- Second alternate CO Group Access code to be used when original CO Group Access code and first ARS code failed to find available CO line.	8	Max 8 digits	-
ARS 2 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	9	0: Off 1: On	Off

CO Line Group (TRANS/PGM 160 - FLEX 3-4) ... see details on [page A-45](#)

TRANS/PGM 160	BTN	RANGE	DEFAULT
OUTGOING GRP NO -- Set CO Group Number to apply to outgoing calls.	3	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
INCOMING GRP NO -- Set CO Group Number to apply to incoming calls.	4	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01

H.323 Data

H.323 Routing Attribute (TRANS/PGM 360) ... see details on [page A-146](#)

TRANS/PGM 360	BTN	RANGE	DEFAULT
DIGIT (1) -- destination numbers associated with the H.323 routing system.	1	Max 8 digits	-
DEST IP ADDR -- destination IP address associated with the H.323 routing system.	2	-	0.0.0.0

Station Data

CO Group Access (TRANS/PGM 150) ... see details on [page A-43](#)

CO/IP Call Time Restriction

The System can be programmed to limit the length of calls at specified stations. When a specified Station places a call, the system initiates the Call Restrict timer, and 15 seconds prior to timer expiration, a warning tone is delivered. At expiration, the system terminates the call returning the external CO/IP line to idle.

Call time restriction can be applied differently according to call types (Local call, Long Distance call or international call).

CONDITIONS

- The warning tone can be provided periodically or once as programmed.
- Once activated, the Call Warning Tone timer continues timing while the call is connected to the system even if the call is transferred or picked up at another station.

OPERATION*System*

Operation of this feature is automatic when assigned:

ADMIN PROGRAMMING*Station Data*

Call Duration Restrict Access (TRANS/PGM 134 - FLEX 4) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
CALL DURATION RESTRICT -- restricts CO Call Duration to station.	4	0:Disable 1:Enable	Disable

Tenant Data

Call Duration Restriction (TRANS/PGM 284-285) ... see details on [page A-131](#)

TRANS/PGM 284	BTN	RANGE	DEFAULT
NORMAL CO LINE -- Determines call restriction for Normal CO line.	1	0: No Restriction 1: All Calls 2: Long/ International 3: Internationa	0: No Restriction
DEDICATED LINE -- Determines the call restriction for TIE line.	2	0: No restriction 1: Restriction	0: No Restriction
LOCAL CALL AFTER R-TIME -- Determines the operation of Local calls after the Restriction timer expires.	3	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
LONG CALL AFTER R-TIME -- Determines the operation of Long Distance calls after the Restriction timer expires.	4	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
INTERNAT AFTER R-TIME Determines the operation of International calls after the Restriction timer expires.	5	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
DEDICATED CALL AFTER R-TM -- Determines the operation of TIE calls after the Restriction timer expires.	6	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone

TRANS/PGM 285	BTN	RANGE	DEFAULT
LOCAL CALL TONE RPT-TIMER -- Determines the Tone Repeat timer of Local calls.	1	010-254	020
LONG CALL TONE RPT TMR --Determines the Tone Repeat timer of Long Distance calls.	2	010-254	020
INTNATION CALL TONE RPT -- Determines the Tone Repeat timer of International calls.	3	010-254	020
DEDICATED CALL TONE RPT -- Determines the Repeat timer of Dedicated Line calls.	4	010-254	020
LOCAL CALL DISC TMR -- Determines entry defines Disconnect timer of Local calls.	5	10-60	15
LONG CALL DISC TMR -- Determines the disconnect timer of Long Distance calls.	6	10-60	15
INTERNATIONAL DISC TMR -- Determines the Disconnect timer of International calls.	7	10-60	15
DEDICATED CALL DISC TMR -- Determines the Disconnect timer of Dedicated Line calls.	8	10-60	15
LOCAL CALL REST TMR -- Determines the Restriction timer of Local calls.	9	001-100	003
LONG CALL REST TMR -- Determines the Restriction timer of Long Distance calls.	10	001-100	003
INTERNATIONAL REST TMR -- Determines the Restriction timer of International calls.	11	001-100	003
DEDICATED CALL REST TMR -- Determines the Restriction timer of Dedicated Line calls.	12	001-100	003

Local Call Prefix Table (TRANS/PGM 286) ... see details on [page A-132](#)

Long Distance Call Prefix Table (TRANS/PGM 287) ... see details on [page A-133](#)

International Call Prefix Table (TRANS/PGM 288) ... see details on [page A-133](#)

CO/IP Call Warning Tone Timer

Stations can receive a tone indicating the elapsed time of a CO/IP call has reached the CO Warning Tone time (timer expiration). A warning tone is presented to the call parties notifying that the Warning Tone Timer is about to expire.

CONDITIONS

- Warning tone is received 15 seconds prior to expiration of the timer and can be repeated every tone repeat time.

OPERATION

System

If enabled, operation of this feature is automatic:

ADMIN PROGRAMMING

Station Data

Call Duration Restrict Access (TRANS/PGM 134 - FLEX 4) ... see details on [page A-34](#)

Tenant Data

Call Duration Restriction (TRANS/PGM 284-285)... see details on [page A-131](#)

TRANS/PGM 284	BTN	RANGE	DEFAULT
NORMAL CO LINE -- Determines call restriction for Normal CO line.	1	0: No Restriction 1: All Calls 2: Long/ International 3: Internationa	0: No Restriction
DEDICATED LINE -- Determines the call restriction for TIE line.	2	0: No restriction 1: Restriction	0: No Restriction
LOCAL CALL AFTER R-TIME -- Determines the operation of Local calls after the Restriction timer expires.	3	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
LONG CALL AFTER R-TIME -- Determines the operation of Long Distance calls after the Restriction timer expires.	4	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone

TRANS/PGM 284	BTN	RANGE	DEFAULT
INTERNAT AFTER R-TIME Determines the operation of International calls after the Restriction timer expires.	5	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
DEDICATED CALL AFTER R-TM -- Determines the operation of TIE calls after the Restriction timer expires.	6	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone

TRANS/PGM 285	BTN	RANGE	DEFAULT
LOCAL CALL TONE RPT-TIMER -- Determines the Tone Repeat timer of Local calls.	1	010-254	020
LONG CALL TONE RPT TMR --Determines the Tone Repeat timer of Long Distance calls.	2	010-254	020
INTNATION CALL TONE RPT -- Determines the Tone Repeat timer of International calls.	3	010-254	020
DEDICATED CALL TONE RPT -- Determines the Repeat timer of Dedicated Line calls.	4	010-254	020
LOCAL CALL DISC TMR -- Determines entry defines Disconnect timer of Local calls.	5	10-60	15
LONG CALL DISC TMR -- Determines the disconnect timer of Long Distance calls.	6	10-60	15
INTERNATIONAL DISC TMR -- Determines the Disconnect timer of International calls.	7	10-60	15
DEDICATED CALL DISC TMR -- Determines the Disconnect timer of Dedicated Line calls.	8	10-60	15
LOCAL CALL REST TMR -- Determines the Restriction timer of Local calls.	9	001-100	003
LONG CALL REST TMR -- Determines the Restriction timer of Long Distance calls.	10	001-100	003
INTERNATIONAL REST TMR -- Determines the Restriction timer of International calls.	11	001-100	003
DEDICATED CALL REST TMR -- Determines the Restriction timer of Dedicated Line calls.	12	001-100	003

Local Call Prefix Table (TRANS/PGM 286) ... see details on [page A-132](#)

Long Distance Call Prefix Table (TRANS/PGM 287) ... see details on [page A-133](#)

International Call Prefix Table (TRANS/PGM 288)... see details on [page A-133](#)

RELATED FEATURES

CO/IP Call Time Restriction ... see [page 3-40](#)

CO/IP Queuing

When CO/IP lines are busy, permitted users can request to be placed in queue awaiting availability of the CO/IP line or a CO/IP line in the same group. When an appropriate CO/IP line becomes available, the system calls the waiting station on a First-In, First-Out (FIFO) basis.

CONDITIONS

- A CO/IP line can have any number of simultaneous queue requests.
- A Station may only have a single active CO/IP queue request; activating a new queue request will replace (cancel), an existing queue.
- A Queue recall will always notify the station with a tone ring, ignoring the station's assigned Intercom Signaling mode.
- Queue recall will signal a station for 15 seconds, if unanswered, the station is removed from the queue.
- If a station requests CO Queuing on a busy CO line, the requesting station checks the busy CO line's status every 5 seconds and receives CO Queue Recall Ring when the status check timer expires after a busy CO line returns to idle. Therefore, Queue Recall ring may be delayed after a busy CO line returns to idle. In addition, when several stations request CO Queuing to a busy CO line, the Queue Recall Ring may not be provided sequentially.

OPERATION

Digital Phone

To request to be placed in queue for a busy CO/IP line:

1. Press the desired {CO GROUP ACCESS CODE} button or dial the CO Group Access Code.
2. Press the [MSG/CALLBK] button, a confirmation tone is received.
3. Hang-up; the [MSG/CALLBK] LED will flash.

To cancel the queue from the queued station:

Press the [MSG/CALLBK] button, the [MSG/CALLBK] LED extinguishes.

Single Line Phone

To request to be placed in queue while receiving the “All Lines Busy” signal:

1. Press the hook-switch.
2. Enter the {Call Back Feature code}.

To cancel the queue from the queued station:

1. Lift the handset.
2. Enter the {Call Back Cancel Feature code}.

System

When a CO/IP line becomes available:

A distinctive Queue Recall is sent to the station with the oldest queued call, the appropriate {CO/IP} line button LED will flash; the CO/IP line and station will appear busy to all other users.

ADMIN PROGRAMMING

Station Data

CO Queuing Access (TRANS/PGM 133 - FLEX 1) ... see details on [page A-33](#)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CO QUEUE ACCESS -- enable CO Queuing.	1	0: Disable 1: Enable	Enable

Numbering Data

CO Group Access Code (TRANS/PGM 114) ... see details on [page A-21](#)

TRANS/PGM 114	BTN	RANGE	REMARK
CO GRP ACCESS CODE (Edit By Range)	1	Start CO Grp Access Code & End CO Grp Access Code	-
CO GRP ACCESS CODE (Edit)	2	CO Grp Access Code	-

RELATED FEATURES

CO/IP Access ... see [page 3-37](#)

Conference

Conference supports communication between multiple parties (up to 13 per conference). The following table lists conference capacities for the MBX IP 100/300 systems. NOTE: There are 133 extra TDM channels for the Conference feature.

Conference Type	Total number of conferences
3-way conference	No limit
4-way conference	33
5-way conference	19
6-way conference	13
7-way conference	12
8-way conference	9
9-way conference	5
10-way conference	4
11-way conference	4
12-way conference	3
13-way conference	3

Conference Room

In addition to ad-hoc conferencing, users may establish a Conference Room. Both internal and external parties can be invited to a conference room and can join a conference room without further action by the user that established the Conference Room. A user can transfer an active call to a Conference Room. A Conference Room can be password protected restricting parties allowed to enter.

Up to 9 Conference Rooms can be set-up and each can support up to maximum 13-party.

CONDITIONS

- Once established, a Conference Room will remain opened until the Room is deleted.
- Phontage and UCS Client may also create, delete and join a Conference Room; for operation instructions, refer to the Phontage or UCS Client User Guide.

OPERATION

Digital Phone

To set-up a Conference Room:

1. Enter the {Create-Conference-Room Feature} Code.
2. Dial the desired Conference Room number (571-579).
3. If desired, enter a password for the Conference Room (Max. 6 digits).
4. Press [HOLD/SAVE] to establish the Room.

To join a Conference Room:

1. Dial the Conference Room Number.
2. Dial the Conference Room password and * for end mark if password is less than 6-digits (if the password is 6-digits, dialing * is not needed).

To delete a Conference Room:

1. Enter the {Delete-Conference-Room Feature} Code.
2. Dial the Conference Room number (571-579).
3. Dial the Conference Room password and * for end mark if password is less than 6-digits (if the password is 6-digits, dialing * is not needed).
4. Press [HOLD/SAVE] to delete the Conference Room.

To transfer a call to a Conference Room:

1. Press the [TRANS] button.
2. Dial the Conference Room Number.
3. Dial the Conference Room password and * for end mark if password is less than 6-digits (if password is 6-digits, dialing * is not needed).
4. Hang-up to complete the transfer.

Single Line Phone

To set-up a Conference Room:

1. Lift the handset.
2. Dial {Conference Room Create Code}.
3. Dial the desired Conference Room number (1-9).
4. Dial the Conference Room password.
5. Press the hook-switch.

To join a Conference Room:

1. Lift the handset.
2. Dial the Conference Room Number.
3. Dial the Conference Room password and * for end mark if the password is less than 6-digits (if password is 6-digits, dialing * is not needed).

To delete a Conference Room:

1. Lift the handset.
2. Dial {Conference Room Delete Code}.
3. Dial the Conference Room number (1-9).
4. Dial the Conference Room password and * for end mark if the password is less than 6-digits (if password is 6-digits, dialing * is not needed).
5. Press the hook-switch.

ADMIN PROGRAMMING

Station Data

Conference Access (TRANS/PGM 133 - FLEX 2) ... see details on [page A-33](#)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CONFERENCE ACCESS -- enable Conference call.	2	0: Disable 1: Enable	Enable

Numbering Data

Conference Room Create/Delete Code (TRANS/PGM 113) ... see details on [page A-19](#)

BTN	FEATURE	REMARK
49	Create Conf Room	527 + Conf. Room #
50	Delete Conf Room	528 + Conf. Room #

RELATED FEATURES

CO/IP Access ... see [page 3-37](#)

Hold Recall ... see [page 3-102](#)

Unsupervised Conference ... see [page 3-53](#)

Multi-Party Voice Conference

The system allows multiple internal and external parties to be connected on a call, in conference mode.

CONDITIONS

- The [CONF] button will remain illuminated at the phones that are temporarily out of conference for the duration of the conference.
- If the system receives a disconnect signal and no internal parties remain in the conference, the conference will be terminated and all remaining parties will be disconnected.
- The normal Hold Recall process is applied to a conference on hold using the Unsupervised Conference Recall timer for recall timing.
- If while setting up a conference, a system error tone is received, the initiator must press the [CONF] button (SLT must hook-flash) to regain the Intercom dial tone.
- A station that is busy, in DND or other non-idle state cannot be added to a conference.

OPERATION

Digital Phone

To establish an ad-hoc conference:

1. Establish the first call.
2. Press the [CONF] button; the LED will light, the connected party is placed on exclusive hold and the user receives a dial tone.
3. Place the second call.
4. When connected, press [CONF]; the new call is placed on exclusive hold.
5. Repeat steps 3 and 4 above to add additional conference parties (up to 13 total per conference).
6. Press the [CONF] button to establish conference.

To establish an ad-hoc conference: ("Conference Member Manual Add" is set to OFF)

7. Establish the first call.
8. Press the [CONF] button; the LED will light, the connected party is placed on exclusive hold and the user receives a dial tone.
9. Place the second call.
10. When connected, the called party is put into conference and calling party also returns to conference.
11. Repeat steps 3 and 4 above to add additional conference parties (up to 13 total per conference).

To get out from a conference temporarily:

Press the [CONF] button, the [CONF] button LED will flash.

To return to a conference call:

Press the flashing [CONF] button.

Single Line Phone

To establish an ad-hoc conference: ("Conference Member Manual Add" is set ON)

1. Establish the first call.
2. Press the hook-switch, the connected party is placed on exclusive hold and the user receives a dial tone.
3. Dial the {Conference Member Add Code}.
4. Place the second call.
5. When connected, repeat steps 2-4 above to add additional parties. {Conference Member Add Code} should be dialed at least once.
6. When completed adding parties, quickly press the hook-switch twice (within 2 seconds), all parties will be connected.

To establish an ad-hoc conference: ("Conference Member Manual Add" is set OFF)

1. Establish the first call.
2. Press the hook-switch, the connected party is placed on exclusive hold and the user receives a dial tone.
3. Dial the {Conference Member Add Code}.
4. Place the second call.
5. When connected, the called party is put into conference and calling party also returns to conference.
6. Repeat steps 2-5 above to add additional parties. {Conference Member Add Code} should be dialed at least once.

ADMIN PROGRAMMING*Station Data*

Conference Access (TRANS/PGM 133 - FLEX 2) ... see details on [page A-33](#)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CONFERENCE ACCESS -- enable Conference call.	2	0: Disable 1: Enable	Enable

Tenant Data

Conference Member Manual Add (TRANS/PGM 281 - FLEX 1) ... see details on [page A-128](#)

TRANS/PGM 281	BTN	RANGE	DEFAULT
CONF MEMBER MANUAL ADD -- Determines if conf-member manual add will be used; when set to ON, each CONF member can be added using the CONF button, when set to OFF, each CONF member will be added automatically.	1	0: Off 1: On	1: On

RELATED FEATURES

Automatic Speaker Select ... see [page 6-4](#)

Hold Recall ... see [page 3-102](#)

Unsupervised Conference ... see [page 3-53](#)

Broker Call ... see [page 8-1](#)

Conference Room ... see [page 3-47](#)

Consultation Conference

A Digital phone user may establish a conference while talking with a party as a screened transfer, which results in a 3-party conference.

OPERATION**Digital Phone**

To set up a Consultation Conference:

1. Press the [TRANS] button while talking with an internal or external party.
2. Make a call to another internal or external party.
3. Talking on a second call, press the [CONF] button.
Then, 3-party conference will be established.

RELATED FEATURES

Multi-Party Voice Conference ... see [page 3-50](#)

Unsupervised Conference

A Digital phone user may establish a conference with external parties and exit the conference while allowing the external parties to converse privately without supervision from the user.

The system will disconnect the Unsupervised conference if disconnect is detected with only two parties connected or at expiration of the Unsupervised Conference timer. A Disconnect Warning tone is provided fifteen seconds prior to expiration of the timer.

If enabled, either party in an Unsupervised Conference can request the Unsupervised Conference timer be extended. The party enters the Timer Extension feature code and a digit 1 to 9 indicating the Timer extension multiplier; the system will then extend the timer based on the dialed digit multiple of the Timer. For example, if the Unsupervised Conference timer is 5 minutes and the user dials the digit 4, the timer will extend to 20 minutes (4 multiplied by 5 minutes).

CONDITIONS

- The Unsupervised Conference Timer will also apply to an external call placed by a DISA user.
- An Unsupervised conference will be terminated if the system receives a disconnect signal or the Unsupervised Conference Timer expires.
- An Unsupervised Conference will not recall at the user Station.

OPERATION

Digital Phone

To set up an Unsupervised Conference:

1. Establish a conference by the normal procedure.
2. Goes On-Hook then remained External users can communicate without Supervisor.

To set up a Supervised Conference:

1. Establish a conference by the normal procedure.
2. Press the [CONF] button; the button LED will flash to indicate the Supervised Conference activation (once set up, the conference supervisor must re-enter the conference).

To reenter the Supervised Conference:

Press the flashing [CONF] button.

Conf Party To extend the Unsupervised Conference from a connected party:

Dial the Timer extension multiplier (1-9).

ADMIN PROGRAMMING

Station Data

Conference Access (TRANS/PGM 133 - FLEX 2) ... see details on [page A-33](#)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CONFERENCE ACCESS -- enable Conference call.	2	0: Disable 1: Enable	Enable

CO Line Data

Unsupervised Conference Timer (TRANS/PGM 166 - FLEX 9) ... see details on [page A-50](#)

TRANS/PGM 166	BTN	RANGE	DEFAULT
UNSUP CONF TIMER (Incoming CO) -- when there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after timer expires. The warning tone is heard before the line is disconnected.	9	000-255 (min)	000

Unsupervised Conference Timer (TRANS/PGM 171 - FLEX 6) ... see details on [page A-57](#)

TRANS/PGM 171	BTN	RANGE	DEFAULT
UNSUP CONF TIMER (Outgoing CO) -- when there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after the timer expires. The warning tone is heard before the line is disconnected.	6	000-255 (min)	000

Unsupervised Conference Extend (TRANS/PGM 171 - FLEX 2) ... see details on [page A-57](#)

TRANS/PGM 171	BTN	RANGE	DEFAULT
UNSUP CONF EXTEND -- if this feature is set to ON, Unsupervised Conf Timer can be extended by dialing feature code after warning tone is heard.	2	0: Off 1: On	Off

Numbering Data

Unsupervised Conference Extend Code (TRANS/PGM 113) ... see details on [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
45	Unsupervised Conf Extend	5##

RELATED FEATURES

Multi-Party Voice Conference ... see [page 3-50](#)

HARDWARE

Digital Phone to establish Unsupervised Conference

Customer Site Name

A Customer Name, up to 24 characters, may be entered into the system database. The name will be displayed on the SMDR and database outputs as well as during Admin. sessions.

OPERATION

System

When a name is assigned, operation of this feature is automatic.

ADMIN PROGRAMMING

System Info

Site Name (TRANS/PGM 100) ... see details on [page A-8](#)

TRANS/PGM 100	BTN	RANGE	REMARK
SITE NAME -- selects Speakerphone mode, Headset mode or Ear Mic Mode.	2	24 characters	-

Data Line Security

Data transmitted over CO lines is subject to distortion and errors if system tones such as Camp-On, Call Wait and Override are applied during transmission. To eliminate such errors, stations that use analog data (modems or Fax) can be assigned to block incoming system tones.

CONDITIONS

- Stations or an Attendant attempting to Camp-On or Override a station with Data Line Security will receive an error tone.
- When Data Line Security is enabled, the system will not apply audio gain to the call.

OPERATION

System

When Data Line Security is assigned, System tones are automatically blocked.

ADMIN PROGRAMMING

Station Data

Data Line Security (TRANS/PGM 123 - FLEX 6) ... see details on [page A-26](#)

TRANS/PGM 123	BTN	RANGE	DEFAULT
DATA SECURITY -- disables override and camp-on tones to the station to avoid occurring error when sending data.	6	0: Off 1: On	Off

Delayed CO/IP Ring

Determines if the CO/IP Ringing will be sent immediately on receipt, or delayed. The delay can be up to 30 system ring cycles, allowing other stations to answer the call.

CONDITIONS

- Delay Ring can be assigned for a station.
- The station will receive immediate ringing, if no delay is entered when programming Ring assignments.
- If stations are assigned for immediate ring, the call will be routed using the incoming CO Alternate programming.
- The delay is applied only when ring service type is 'Ring-RING'.

OPERATION

System

When assigned, Delay Ring operation is automatic.

ADMIN PROGRAMMING

CO Line Data

CO Station Ring Assignment (TRANS/PGM 167) ... see details on [page A-51](#)

TRANS/PGM 167	BTN	RANGE	DEFAULT
SERVICE TYPE -- If service type is set as 0-2, ring option is applied to ring assigned stations. Otherwise, if service type is set to 3, feature code is activated on incoming call. The service type determines where the incoming call will ring first. Options are ring to a station(s) or ring to a feature such as auto attendant, hunt group, etc.	1	0: Ring Assign 1: Feature 2: Circular 3: Feature Code	All Ring
FEATURE CODE -- If Service type is set to Feature Code and valid feature code is assigned, then assigned feature is activated when there is an incoming call. NOTE: Feature Code is not applied to rerouted calls.	2	Valid Feature Code (refer to TRANS/PGM 115)	-
FEATURE DELAY -- If Service type is set to Feature code, it can be delayed.	3	00-30	00

TRANS/PGM 167	BTN	RANGE	DEFAULT
100 (0) -- Assigned station and delay value can be displayed. Volume Up/Down key is used to scroll data.	4	-	-
MEMBER ASSIGN -- To change station's ring assign status, enter desired station range. (Max 30 stations can be assigned)	5	Start Station & End Station	-
DELAY -- Enter delay value; if delay is 0, station will start to ring immediately. If delay value is deleted, the station will not ring. Otherwise if delay is 1-9, the station will start to ring after delay time (3 times of delay value).	5-1	0-9	Sta 100 (Port 0):delay 0 Others: not assigned

Delayed Auto Attendant

An incoming CO/IP call can be routed to the VMIB Auto Attendant either immediately upon detection or after a delay time (up to 90 seconds). This allows other stations assigned for immediate ringing the opportunity to be answered before the call is routed to the Auto Attendant.

CONDITIONS

- CO Ring Assignment must be set for service type 'Ring Assign' and the Feature Code Delay Counter (TRANS/PGM 167) must be enabled including the desired VM announcement.
- When Delayed Auto Attendant Ring is assigned, following expiration of the delay, the call will no longer ring at the assigned stations and will be routed to the VMIB Auto Attendant.
- If no delay is entered, the call will ring to the ring assigned station immediately and delayed auto attendant is not operated.
- To assign a Delayed Attendant ring, at least one station must be assigned for immediate ringing.

OPERATION

System

When assigned, operation of this feature is automatic.

ADMIN PROGRAMMING

CO Line Data **CO Ring Assignment (TRANS/PGM 167) ... see details on [page A-51](#)**

TRANS/PGM 167	BTN	RANGE	DEFAULT
SERVICE TYPE -- If service type is set as 0-2, ring option is applied to ring assigned stations. Otherwise, if service type is set to 3, feature code is activated on incoming call. The service type determines where the incoming call will ring first. Options are ring to a station(s) or ring to a feature such as auto attendant, hunt group, etc.	1	0: Ring Assign 1: Feature 2: Circular 3: Feature Code	All Ring
FEATURE CODE -- If Service type is set to Feature Code and valid feature code is assigned, then assigned feature is activated when there is an incoming call. NOTE: Feature Code is not applied to rerouted calls.	2	Valid Feature Code (refer to TRANS/PGM 115)	-
FEATURE DELAY -- If Service type is set to Feature code, it can be delayed.	3	00-30	00
100 (0) -- Assigned station and delay value can be displayed. Volume Up/Down key is used to scroll data.	4	-	-
MEMBER ASSIGN -- To change station's ring assign status, enter desired station range. (Max 30 stations can be assigned)	5	Start Station & End Station	-
DELAY -- Enter delay value; if delay is 0, station will start to ring immediately. If delay value is deleted, the station will not ring. Otherwise if delay is 1-9, the station will start to ring after delay time(3 times of delay value)	5-1	0-9	Sta 100 (Port 0):delay 0 Others: not assigned

Table Data

Announcement Table (TRANS/PGM 259) ... see details on [page A-111](#)

TRANS/PGM 259	BTN	RANGE	DEFAULT
The VMIB slot & Prompt No. to be used for playing the VMIB Announcement No.	1-4	VMIB Slot (00-18) & Prompt No (01-70)	-
CCR Index used for playing the VMIB Announcement No.	5	1-100	-

Diagnostic/Maintenance

The System software incorporates various diagnostic and maintenance routines that may be “called” remotely or locally through the System RS-232 Serial ports, a TCP/IP connection using a Web browser established over IP networks.

Routines that can be accessed include trace functions at the device level, commands for diagnostics and maintenance, and tools for manipulation at the OS level.

An optional Network Management System (NMS) application is available providing remote access to the system for maintenance and diagnostics.

Dial-By-Name

A name, up to 16 characters, may be assigned to each Station and System Speed dial. In addition, each station may be assigned a 16-character name. When assigned, a user may place an intercom call to another station or select a Station or System Speed dial using the name.

The user selects from one of three Dial-by-Name directories and enters characters employing 2 dial pad buttons for each character. The system finds and displays the nearest match to the user entries. The user may continue entering characters or scroll the directory at any point using the [VOL UP]/[VOL DWN] button and select a name to call. The number associated with a selected name is displayed by using the [TRANS] button.

CONDITIONS

- Available characters are A to Z, space, and period; refer to Station Speed Dial for character entry.
- The LCD will display multiple names (one per LCD line up to 16 characters).
- If a user selects a directory with no entries or there is no match to the user entry, an “Empty List” message is displayed and the error tone is provided.
- Dial-by-Name is only available to Digital Phones with a display; other users will receive an error tone if an attempt is made to access Dial-by-Name.
- A user may both scroll and enter characters to search a directory.

OPERATION

Digital Phone

To use Dial by Name on a two-line phone:

1. Press the [SPEED] button twice.
2. Dial the desired directory:
 - 1 – Station Speed
 - 2 – System Speed
 - 3 – Station Name
3. Search the directory using the [VOL UP]/[VOL DOWN] button or by entering characters.
4. Press the [HOLD/SAVE] button to place the call.

To use Dial by Name on a three-line phone:

1. Press the {DIR} Soft button.
2. Dial the desired directory: 1 – Station Speed 2 – System Speed 3 – Station Name.
3. Search the directory using the [VOL UP]/[VOL DOWN] button or by entering characters.
4. Press the [HOLD/SAVE] button to place the call.

To program the station user name:

1. Press the [TRANS/PGM] button.
2. Dial 12 {User Name Program code}.
3. Enter the name (up to 16 characters); refer to Station Speed Dial for character entry.
4. Press [HOLD/SAVE].

Single Line Phone

To program the station user name:

1. Lift the handset
2. Dial {Name Register Code}.
3. Enter the name (up to 16 characters); refer to Station Speed Dial for character entry.
4. Press the hook-switch, confirmation tone is received.

ADMIN PROGRAMMING*Station Data*

Speed Access (TRANS/PGM 134 - FLEX 1) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
SPEED ACCESS -- gives station speed dial bins access authority.	1	0:Disable 1:Enable	Enable

RELATED FEATURES

Station Speed Dial ... see [page 3-147](#)

HARDWARE

Digital Phone w/Display

Dial Pulse to Tone Switchover

On a pulse dial CO line, the user can request the system to change the signaling mode from pulse to DTMF, allowing the user to access outside facilities that require DTMF signals such as banking services, voice mail, etc.

CONDITIONS

- In a Speed Dial, the * will automatically insert a pause before dialing the remaining digits.
- This command is only recognized for analog pulse dial CO lines.
- Dial pulse to tone switchover is not available in the Redial features.
- For VoIP calls, pulse dialing is not available; switchover is not required or supported.

OPERATION

To switch from pulse to DTMF while on a pulse CO line:

Dial * (signaling change to DTMF).

ADMIN PROGRAMMING*CO Line Data*

CO Dialing Type (TRANS/PGM 160 - FLEX 10) ... see details on [page A-45](#)

TRANS/PGM 160	BTN	RANGE	DEFAULT
DIALING TYPE -- Signal type can be selected; DTMF, Pulse, R2MFC.	10	0: DTMF 1: PULSE 2: R2	DTMF

RELATED FEATURES

Speed Dial ... see [page 3-146](#)

Dialing Restrictions

Class of Service

Dialing privileges can be assigned for each DN at a Station and CO line (up to 16 privileges). The Class of Service (COS) feature is applied in the following cases:

- When an internal station dials out through a CO line,
- When an external caller tries to make another external call using DISA or DID.

The dialing privileges are the result of the interaction of the Station and CO Class of Service (COS) assignments as shown in the following tables. Users placing an outgoing call or dialing after answering a call will be allowed the dialing privileges assigned.

Station/CO COS	Dialing Restriction
0	Intercom and Emergency number calls are allowed; incoming and transferred calls are allowed.
1	No restrictions are placed on dialing.
2 - 15	Assignments in each toll table are monitored for Allow and Deny numbers.

- Toll Tables – Each Toll Table permits entry of 100 Allow codes and 100 Deny codes. Each code can contain up to 16 digits including digits 0-9.
- Toll Table process – As digits are dialed, they are compared to entries in the appropriate Toll Table. Based on the Allow and Deny entries, the system applies the following rules to allow or deny the call.

Rule 1 – If a table has no entries, no restrictions are applied.

Rule 2 – If there are only Deny entries, restrictions are provided as Deny only.

Rule 3– If there are both Allow and Deny entries, the Deny entries are searched. If the dialed number matches a Deny entry, the call is restricted; if no match is found the call is allowed.

CONDITIONS

- There are 16 different COS; Stations and CO Lines can each have a different COS according to the Station grade and CO Line type.
- Toll Exception can be programmed differently according to the Day/Night/Timed Mode.
- If COS is set to 0, the DN can make intercom calls only; CO line access is disabled.
- If COS is set to 1, the DN can make any call (no exception).

OPERATION*System*

The assigned COS is applied automatically by the system.

ADMIN PROGRAMMING*Station*

Station COS (TRANS/PGM 137) ... see details on [page A-37](#)

TRANS/PGM 137	BTN	RANGE	DEFAULT
DAY COS -- Station's COS in Day mode.	1	00-15	1
NIGHT COS -- Station's COS in Night mode.	2	00-15	1
TIMED COS -- Station's COS in Timed mode.	3	00-15	1

CO/IP

CO COS (TRANS/PGM 177) ... see details on [page A-60](#)

TRANS/PGM 177	BTN	RANGE	DEFAULT
DAY COS -- CO COS in Day mode.	1	00-15	0
DAY COS -- CO COS in Night mode.	2	00-15	0
DAY COS -- CO COS in Timed mode.	3	00-15	0

Incoming CO Group Access, Outgoing CO Group, IC Call Transfer Directly
(TRANS/PGM 179 - FLEX 5) ... see details on [page A-60](#)

TRANS/PGM 179	BTN	RANGE	DEFAULT
INCOMING CALL TRANSFER DIRECTLY -- if this feature is set to ON, CO incoming call can be transferred directly without any stations or ATD to transfer the call.	5	0: Off 1: On	Off

CO Line Data

Toll Exception Table (TRANS/PGM 250) ... see details on [page A-103](#)

TRANS/PGM 250	BTN	RANGE	DEFAULT
ALLOW TABLE -- allow digits.	1	Max 16 digits	-
DENY TABLE -- deny digits.	2	Max 16 digits	-
TENANT -- Tenant groups to apply the table entry.	3	1-9 (MBX IP 300) 1-5 (MBX IP 100)	-

RELATED FEATURES

Temporary Station COS/Lock ... see [page 3-68](#)

Walking COS ... see [page 3-71](#)

Day/Timed & Night Station COS

CO Line Toll Exception can be applied differently in Day/Night/Timed mode at each Station. The service mode is generally controlled by the Attendant group member, and based on the mode, appropriate dialing privileges are established.

CONDITION

- If COS is set to 0, only intercom calls can be placed; CO line access is disabled.
- If COS is set to 1, there are no restrictions.

OPERATION

System

Dialing restrictions are automatically applied based on COS assignments:

ADMIN PROGRAMMING

Station Data

Station COS (TRANS/PGM 137) ... see details on [page A-37](#)

TRANS/PGM 137	BTN	RANGE	DEFAULT
DAY COS -- Station's COS in Day mode.	1	00-15	1
NIGHT COS -- Station's COS in Night mode.	2	00-15	1
TIMED COS -- Station's COS in Timed mode.	3	00-15	1

Table Data

System Time Table (TRANS/PGM 253) ... see details on [page A-107](#)

TRANS/PGM 253	BTN	RANGE	DEFAULT
TIME ZONE COMMENT-- defines the comment of the Time Table.	1	32 characters	none
SYSTEM TIME ZONE -- defines the Time Zone of the Time Table	2	0-73	0: Sys Time
DAYLIGHT SAVINGS -- defines Daylight Saving Time of Time Table.	3	On/Off	Off
RING MODE -- defines the ring mode of Time Table.	4	0: Day 1: Night 2: Timed	0:Day
AUTO RING MODE -- defines the Auto Ring mode of the Time Table.	5	On/Off	Off

Weekly Time Table (TRANS/PGM 254) ... see details on [page A-108](#)

TRANS/PGM 254	BTN	RANGE	DEFAULT
Monday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	1	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _
Tuesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	2	0000-2359	Day: 9:00 Nite: 18:00 TDS: _ _ TDE: _ _

TRANS/PGM 254	BTN	RANGE	DEFAULT
Wednesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	3	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Thursday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	4	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Friday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	5	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Saturday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	6	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Sunday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	7	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __

Holiday Time Table (TRANS/PGM 256) ... see details on [page A-110](#)

TRANS/PGM 256	BTN	RANGE	DEFAULT
CALENDAR TYPE -- Defines Calendar Type for Holiday Table.	1	Lunar/Gregorian	Gregorian
HOLIDAY DATE -- Defines Holiday Date for Holiday Table.	2	MM/DD	None

Toll Exception Table (TRANS/PGM 250) ... see details on [page A-104](#)

TRANS/PGM 250	BTN	RANGE	DEFAULT
ALLOW TABLE -- allow digits.	1	Max 16 digits	-
DENY TABLE -- deny digits.	2	Max 16 digits	-
TENANT -- Tenant groups to apply the table entry.	3	1-9 (MBX IP 300) 1-5 (MBX IP 100)	-

RELATED FEATURES

Authorization Codes (Password) ... see [page 3-5](#)

Class of Service ... see [page 3-63](#)

Temporary Station COS/Lock ... see [page 3-68](#)

Walking COS ... see [page 3-71](#)

Auto Service Mode Control ... see [page 3-10](#)

Day/Night/Timed Ring Mode ... see [page 7-37](#)

Temporary Station COS/Lock

A User or an Attendant can temporarily change the Station COS preventing unauthorized toll dialing from the station (ex., "locking the station"). When locked, the station will still be allowed to place internal calls and Emergency number calls.

CONDITIONS

- The Station is restored to the Station COS as appropriate for the active service mode (Day, Night, or Timed).

OPERATION

Digital Phone

To activate Temporary COS:

1. Press the [TRANS/PGM] button.
2. Dial 31, {Temporary COS code}.
3. Dial the applicable Authorization Code.
4. Press the [HOLD/SAVE] button. To restore the assigned COS:

To restore the assigned COS:

1. Press the [TRANS/PGM] button.
2. Dial 32 {Restore COS code}.
3. Dial the applicable Authorization Code.
4. Press the [HOLD/SAVE] button.

Single Line Phone

To activate Temporary COS:

1. Press the hook-switch.
2. Dial the {SLT Programming code}.
3. Dial 31, {Temp COS code}.
4. Dial the applicable Authorization Code.
5. Press the hook-switch.

To restore the assigned COS:

1. Press the hook-switch.
2. Dial the {SLT Programming code}.
3. Dial 32, {Restore COS code}.
4. Dial Authorization Code.
5. Press the hook-switch.

System Attendant

To activate Temporary COS:

1. Press the [TRANS/PGM] button.
2. Dial 031, {Temp COS code}.
3. Enter the Station range.
4. Press the [HOLD/SAVE] button.

To restore the assigned COS:

1. Press the [TRANS/PGM] button.
2. Dial 032, {Restore COS code}.
3. Enter the Station range.
4. Press the [HOLD/SAVE] button.

ADMIN PROGRAMMING*Station*

Station COS (TRANS/PGM 137) ... see details on [page A-37](#)

TRANS/PGM 137	BTN	RANGE	DEFAULT
DAY COS -- Station's COS in Day mode.	1	00-15	1
NIGHT COS -- Station's COS in Night mode.	2	00-15	1
TIMED COS -- Station's COS in Timed mode.	3	00-15	1

CO/IP

CO COS (TRANS/PGM 177) ... see details on [page A-60](#)

TRANS/PGM 177	BTN	RANGE	DEFAULT
DAY COS -- CO COS in Day mode.	1	00-15	0
DAY COS -- CO COS in Night mode.	2	00-15	0
DAY COS -- CO COS in Timed mode.	3	00-15	0

System

Toll Exception Table (TRANS/PGM 250) ... see details on [page A-104](#)

TRANS/PGM 250	BTN	RANGE	DEFAULT
ALLOW TABLE -- allow digits.	1	Max 16 digits	-
DENY TABLE -- deny digits.	2	Max 16 digits	-
TENANT -- Tenant groups to apply the table entry.	3	1-9 (MBX IP 300) 1-5 (MBX IP 100)	-

Walking COS

A User may temporarily override Toll Restriction at a Station to make Toll Calls from a normally Toll Restricted station. An Authorization Code is required in order to activate Walking COS.

CONDITIONS

- The Station COS applied for Walking COS is the COS of the station.
- Walking COS applies the temporary COS for only one call; terminating the call returns the station to the assigned Station COS. The user may reactivate Walking COS to place another call or press the Flash key (instead of hook-switch) at the end of previous call to maintain Walking COS.

OPERATION

Digital Phone

To activate Walking COS:

1. Press the [TRANS/PGM] button.
2. Dial 33, {Walking COS code}.
3. Enter the Station number.
4. Dial the Station Authorization code (password).
5. Dial * (end mark).
6. Place a call in the normal manner.

Single Line Phone

To activate Walking COS:

1. Dial the {SLT Programming code}.
2. Dial '33', the Walking COS code.
3. Enter the Station number.
4. Dial the Station Authorization code (password).
5. Dial * (end mark).
6. Place call as normal.

ADMIN PROGRAMMING

Station

Station COS (TRANS/PGM 137) ... see details on [page A-37](#)

TRANS/PGM 137	BTN	RANGE	DEFAULT
DAY COS -- Station's COS in Day mode.	1	00-15	1
NIGHT COS -- Station's COS in Night mode.	2	00-15	1
TIMED COS -- Station's COS in Timed mode.	3	00-15	1

CO/IP

CO COS (TRANS/PGM 177) ... see details on [page A-60](#)

TRANS/PGM 177	BTN	RANGE	DEFAULT
DAY COS -- CO COS in Day mode.	1	00-15	0
DAY COS -- CO COS in Night mode.	2	00-15	0
DAY COS -- CO COS in Timed mode.	3	00-15	0

System

Toll Exception Table (TRANS/PGM 250) ... see details on [page A-104](#)

TRANS/PGM 250	BTN	RANGE	DEFAULT
ALLOW TABLE -- allow digits.	1	Max 16 digits	-
DENY TABLE -- deny digits.	2	Max 16 digits	-
TENANT -- Tenant groups to apply the table entry.	3	1-9 (MBX IP 300) 1-5 (MBX IP 100)	-

RELATED FEATURES

Class of Service ... see [page 3-63](#)

Auto Service Mode Control ... see [page 3-10](#)

Day/Night/Timed Ring Mode ... see [page 7-37](#)

Authorization Codes (Password) ... see [page 3-5](#)

Differential Ring

Differential Ring provides one of 4 different audible Ring signals to be assigned to a Digital Phone, allowing users to determine which phone is ringing and the type of call (Intercom or CO/IP). When the phone receives an incoming call, the designated ring signal is provided over the speaker. Different selections are assigned for Intercom and CO/IP calls.

CONDITIONS

- Each DN and CO line can be set to have one of 9 digit conversion Tables.
- There are 300 entries for each digit conversion table.
- The Digit Conversion Table allows up to 16 digits to be programmed as 'dialed digit' and 'converted digit'.
- The following features have higher priority over digit conversion;
 - AND (Automatic Network Dialing)
 - Automatic CO seize
 - In Call log, dialed digit is displayed on the station's LCD.

OPERATION

Digital Phone

To select the desired ring tone:

1. Press the [TRANS/PGM] button.
2. Dial 2 (Ring Selection).
3. Dial 1 (Intercom) or 2 (CO/IP) ring.
4. Dial 1 (Ring Source).
5. Dial Ring Tone selection – 1-4: Digit Phone 1-8: IP Phone
6. Ring Tone is presented.
7. Press the [HOLD/SAVE] button.

ADMIN PROGRAMMING*Station*

Differential Ring (TRANS/PGM 124 - FLEX 3-4) ... see details on [page A-27](#)

TRANS/PGM 124	BTN	RANGE	DEFAULT
ICM DIFF RING ID -- set the intercom differential ring ID – usually 1-4 is valid.	3	000-254	On
CO DIFF RING ID -- set the CO line differential ring ID – usually 1-4 is valid.	4	000-254	Off

Digit Conversion

When a User dials digits, the dialed digits are converted according to the Digit Conversion Table before the Numbering Plan is checked. Digit conversion is performed on outside incoming CO calls, in addition to converting User dialed digits.

- Time Zone for Digit Conversion - The pressed digits can be converted into a different digit stream according to the time zone: Always, Day/Night/Timed zone, and LCR Day/Time zone. There can be up to 9 conversion matrices in the LCR Day/Time zone, while 3 conversion rules are possible in the Day/Night/Timed zone. Digit conversion is performed only when there is a conversion rule that applies based on the specific time the digits are pressed.
- Dummy CO Dial Tone - The CO line is seized following digit conversion. Therefore, it is impossible to receive a CO dial tone when digit conversion is programmed. To remove any inconveniences of users, the system can be configured to provide a dummy CO dial tone after one of the dialed digits is pressed.
- Digit information Display Before or After Conversion - Each Station can be programmed to display either the dialed digits or the digits after conversion. SMDR also can print either dialed digits or the digits after conversion.

CONDITIONS

- Each DN and CO line can be set to have one of 9 digit conversion Tables.
- There are 300 entries for each digit conversion table.
- The Digit Conversion Table allows up to 16 digits to be programmed as 'dialed digit' and 'converted digit'.
- The following features have higher priority over digit conversion:
AND (Automatic Network Dialing)
Automatic CO Seize

- In Call log, dialed digit is displayed on the station's LCD.
- The Digit Conversion Table can be applied by Apply Option (All/Station/CO Line/Disable)

OPERATION

Digit Conversion is applied automatically according to ADM programming.

ADMIN PROGRAMMING

Station Data

Digit Conversion Table Index (TRANS/PGM 131 - FLEX 3) [page A-104](#)

TRANS/PGM 131	BTN	RANGE	DEFAULT
DIGIT CONVERSION TBL -- specify Digit conversion table for station.	3	1-9	1

CO Data

Digit Conversion Table Index (TRANS/PGM 160 - FLEX 6) [page A-104](#)

TRANS/PGM 160	BTN	RANGE	DEFAULT
DGT CONVERT TBL -- Set Digit Conversion Table index.	6	1-9	2

Table Data

Digit Conversion Table (TRANS/PGM 251, TRANS/PGM 252) [page A-104](#)

TRANS/PGM 251	BTN	RANGE	DEFAULT
APPLY T-TYPE -- The Apply time type to be applied when the dialed digit is dialed.	1	0: Unconditional 1: Follow DNT 2: Follow LCR	Unconditional
DIALED DIGITS -- The dialed digits.	2	Max 16 digits	-
UNCOND CHANGED -- The CO Group Access Code and digits to be sent to PX when the dialed digit is pressed if Apply time type is 'unconditional'.	3	Max 16 digits	-
DAY CHANGED -- The CO Group Access Code and digits to be sent to PX in Day when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	4	Max 16 digits	-

TRANS/PGM 251	BTN	RANGE	DEFAULT
NIGHT CHANGED -- The CO Group Access Code and digits to be sent to PX in Night when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'	5	Max 16 digits	-
TIMED CHANGED -- The CO Group Access Code and digits to be sent to PX in Timed when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	6	Max 16 digits	-
D1/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	7	Max 16 digits	-
D1/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	8	Max 16 digits	-
D1/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	9	Max 16 digits	-
D2/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	10	Max 16 digits	-
D2/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	11	Max 16 digits	-
D2/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	12	Max 16 digits	-
D3/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	13	Max 16 digits	-
D3/T2 CHANGED -- The digits to be dialed in 'Day 3/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	14	Max 16 digits	-
D3/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	15	Max 16 digits	-
DNT TIME INDEX -- Day/Night/Timed Time Table Index.	16	1-9, none	none
LCR TIME INDEX -- LCR Time Table Index.	17	1-9, none	none

TRANS/PGM 251	BTN	RANGE	DEFAULT
NAME -- When DID destination starts to ring, the name is displayed on the ringing station's LCD.	18	Max 16 digits	-
APPLY OPTION -- The Apply Option can be applied according to the caller.	19	0:All 1:Station 2:CO Line 3:Diable	0:All

TRANS/PGM 252	BTN	RANGE	DEFAULT
DISPLAY CONV. DIGIT -- If it is set to ON, the station LCD is updated to the dialed digits when alerting message is received from the PX after dialing.	1	On/Off	Off
PRINT CONV. DIGIT -- If it is set to ON, the dialed digits are printed to the SMDR.	2	On/Off	Off

Do Not Disturb (DND)

A Station enabled with the Do Not Disturb (DND) feature, can be placed in DND to block incoming ringing for CO/IP and Intercom calls, transfers, and paging announcements.

CONDITIONS

- A station will receive an error tone if unable to access DND.
- If DND is enabled, pressing the [DND] button while ringing will activate One-Time DND.
- An Attendant may cancel DND for Stations on the System.
- DND service is available for use by Attendants.
- Recalls for CO/IP calls will override the DND feature.
- A station in DND is out-of-service for all incoming calls including Station Group calls.
- A station in DND ignores calls forwarded to the station; if the last station in a Call Forward chain is in DND, the call will ring at the previous Station in the chain.
- When calling a Station in DND, the Digital Phone display will indicate the DND status.

OPERATION**Digital Phone**

To activate DND for a P-DN (Prime Directory Number):

Press the [DND] button; the [DND] button LED illuminates.

To remove DND for a P-DN (Prime Directory Number):

Press the [DND] button; the [DND] button LED extinguishes.

To activate DND for a S-DN (Sub Directory Number):

1. Press {S-DN} button.
2. Dial the {DND Feature Code}; the {S-DN} button LED illuminates.

To remove DND for a S-DN (Sub Directory Number):

1. Press {S-Line} button.
2. Dial the {DND Feature Code}; the {S-DN} button LED extinguishes.

Single Line Phone

To activate DND:

Dial the {DND feature code}; a confirmation tone is received.

To remove DND:

Dial the {DND feature code}; a confirmation tone is received.

ADMIN PROGRAMMING*Station Data*

DND Access (TRANS/PGM 132 - FLEX 4) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
DND ACCESS -- enables DND to be activated by the station.	4	0:Disable 1:Enable	Enable

System Data

LED Color/Flash (TRANS/PGM 234) ... see details on [page A-95](#) to A-100

Door Open

The hardware is equipped with a relay that activates an External Control Contact. The contact can be assigned to one of several functions including a Door Open Contact; the contact is connected to a door-lock release mechanism. When a Station receives the Door Bell signal, the Station User may dial the Door Open code to activate the contact.

CONDITIONS

- One relay contact is available.
- The contacts are rated at 1 amp, 24 VDC.

OPERATION

Digital Phone

To assign a {DOOR OPEN} button:

[TRANS/PGM] + {FLEX} + Button Feature Type (1) + {Door Open Feature Code} + [HOLD/SAVE]

To activate the relay contact:

1. Lift handset or press [SPEAKER] button.
 2. Dial the {Door Open code}.
 3. Hang-up to return the phone to idle.
- OR
1. Lift the handset or press [SPEAKER].
 2. Press the programmed {DOOR OPEN} button.
 3. Hang-up to return the phone to idle.

ADMIN PROGRAMMING

Station Data

Door Open Access (TRANS/PGM 121 - FLEX 13) ... see details on [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
DOOR OPEN -- enable to use door open feature.	13	0:Disable 1:Enable	Disable

System

External Contact Control (TRANS/PGM 228) ... see details on [page A-87](#)

Door Open Timer (TRANS/PGM 222 - FLEX 1) ... see details on [page A-84](#)

TRANS/PGM 222	BTN	RANGE	DEFAULT
DOOR OPEN TMR -- Sets the minimum contact closure time required to activate the contact assigned as a door open contact.	1	05-99 (100 msec)	20

Numbering Data

Door Open Code (TRANS/PGM 113) ... see details on [page A-20](#)

BTN	FEATURE (113)	REMARK
82	Door Open	#*1

RELATED FEATURES

Loud Bell Control (LBC) ... see [page 3-116](#)

Door Phone

An intercom box can be connected to the System and located in a convenient place at your facility for receiving page announcements and intercom calls. Additionally, the intercom box can signal assigned Stations using the Auto Dial feature in the System.

CONDITIONS

- An Intercom box can be a member of the Page Zone group.
- To receive Intercom box calls, set the Auto Dial Digit and Pause timers (TRANS/PGM 138).
- An Intercom box can be answered automatically using Hands free mode when in ICM Answer Mode (TRANS/PGM124)
- The Intercom box has the [CALL] button.

OPERATION

To call an intercom box, perform the following Steps:

1. Lift the handset or press the [SPEAKER] button.
2. Dial the Station number of intercom box, or press the programmed flexible button for the Intercom box.
3. After answering the call from the Intercom box, announce the call.

To place a call from an intercom box:

Press the [CALL] button and assigned station will ring.

ADMIN PROGRAMMING

System

Station Auto Dial Attribute (TRANS/PGM 138 - FLEX 1-2) ... see details on [page A-38](#)

TRANS/PGM 138	BTN	RANGE	DEFAULT
AUTO DIAL DGT -- Digits will be dialed automatically.	1	Max 16 digits	-
AUTO DIAL PAUSE TIME -- Auto dial pause time.	2	00-30	0

ICM Answer Mode (TRANS/PGM 123 - FLEX 5) ... see details on [page A-26](#)

TRANS/PGM 123	BTN	RANGE	DEFAULT
ICM ANSWER MODE -- selects Handsfree, Privacy or Tone ring ICM Signaling mode.	5	1: Handsfree 2: Tone 3: Privacy	Tone

RELATED FEATURES

Door Open ... see [page 3-79](#)

Emergency Call/Emergency Alert

Regardless of Station dialing restrictions (COS), the user may dial assigned Emergency numbers as needed.

CONDITIONS

- The CO Line Group Access Code and digits to be dialed should be assigned to the emergency changed digit.
- If the dialed number for the Emergency code is the same as the Numbering code including station in the system, the Emergency code has the preference.
- Assigning emergency code, the emergency code with same dialed digit previous assigned cannot be as assigned.
- In emergency code table, the field - tenant may be leaved empty. This emergency code with empty tenant will be adapted to all stations of all tenants.

OPERATION

System

The system will automatically override any toll restrictions and process an assigned Emergency number call.

Emergency Alert

To Program an Emergency ALert button on a flex key:

Press the TRANS/PGM + button + 1 + code (563)

When a station places a 911 call, the button will light and an audible ring will be heard. The system will log the station date time the call was made. Press the flashing button to access the log.

Use the softkeys to review/delete entries

ADMIN PROGRAMMING

Table Data

Emergency Code Table (TRANS/PGM 258) ... see details on [page A-111](#)

TRANS/PGM 258	BTN	RANGE	DEFAULT
DIALED DIGIT -- The dialed digits from user.	1	Max 16 digits	-

TRANS/PGM 258	BTN	RANGE	DEFAULT
CHANGED DIGIT -- CO Group Access Code and digits to be sent to PX when user dials the dialed digit.	2	Max 16 digits	-
TENANT NO -- The tenant number to be applied when user dials emergency code. If this field be left empty, this entry will be adapted to all tenants.	3	Empty, 1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

Executive/Secretary by DN (Directory Number)

Executive/Secretary feature can be achieved by utilizing the DN (Directory Number) feature of the system (refer to DN).

For example, when a DN is set as MADN, calls for an Executive can be routed to that DN. The DN can be programmed on a flex button at the Executive station with a "no ring" option. At the Secretary station, the DN is stored on a flex button with an "immediate ring" option. In this case, the calls for the executive will ring the Secretary's station immediately. When the secretary answers the call, the call can be put on Hold. The secretary will be able to inform the executive that there's a held call on a button (requiring an additional button programmed for hands-free access to the Executive DN). When the secretary presses the button, it would be possible to tell the executive to answer the held call.

The Executive's DN button may have a "delayed ring" option instead of "no ring" option, the executive will hear the ring signal after programmed delay. Since two stations (executive and secretary) ring after delay time, either Executive or Secretary can receive the call. This setting helps when the Secretary is not at their desk temporarily.

CONDITIONS

- An Executive may have multiple Secretaries and a Secretary may have multiple Executives; each is considered a separate Executive/Secretary pair.
- If the Secretary is busy when a call is received for the Executive, the caller will receive a busy tone.
- If an Executive has multiple Secretaries, calls will automatically route to the Executive's first idle Secretary.
- The Executive may use Call Forward to send calls to stations other than the Secretary.

OPERATION

To program Executive/Secretary Forward:

1. Assign a DN as MADN to be used as Executive's Secretary for calls.
2. Register a DN flex button at the Secretary Station and Executive Station.
3. Set the DN flex button Ring option as 'No Ring' or 'Delayed Ring' at the Executive Station.
4. Enable the 'Forced Hands free Access' option at the Executive and Secretary Stations.
5. Assign the Executive station flex button as telephone number {Forced Hands free code} + {Secretary Station number} for use when Executive intercom calls the Secretary.
6. Assign Secretary station flex button as Telephone number {Forced Hands free code} + {Executive station number} to use when Secretary Intercom calls the Executive.

ADMIN PROGRAMMING*Numbering Plan*

Forced Handsfree Code (TRANS/PGM 113) ... see [page A-19](#)

FEATURE (TRANS/PGM 113)	BTN	REMARK
Forced Handsfree Call	59	537

Station

Station Number Type (TRANS/PGM 130 - FLEX 1) ... see details on [page A-31](#)

Flex Button Assign (TRANS/PGM 126) ... see details on [page A-29](#)

DN Button Ring Option (TRANS/PGM 126 - FLEX 2) ... see details on [page A-30](#)

Forced Handsfree Access (TRANS/PGM 132 - FLEX 1) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
FORCED HANDFREE ACCESS -- when placing an intercom call, a user can change the ICM signaling mode, Tone Ring to Hands free answer mode or Hands free answer to Tone Ring mode.	1	0: Disable 1: Enable	Disable

Executive/Secretary by Exec/Sec Assignment

Phones can be assigned as Executive/Secretary groups. By activating DND, the Executive also activates Unconditional Call Forward to the Secretary, which will forward Executive calls to the Secretary. With the "CO Call to Secretary" option enabled, all CO calls to the Executive forward to the Secretary regardless of the Executive's station status. In addition, if the Secretary is in DND (or, all Secretaries are DND), Executive calls sent to the Secretary route back to the Executive if the "Call Exec If First Sec in DND" or "Call Exec if All Sec in DND" option is enabled.

Each Executive access privilege can be assigned. If executive access is enabled, the call is routed to the executive directly.

If the "ICM Call to Secretary" option is enabled, all internal calls to the Executive (except for calls from the executive having executive access privilege) forward to the Secretary regardless of the Executive's station status.

Callers to an Executive can leave a Message Wait indication. The message waiting indication is given to the Executive or the first Secretary station assigned as the message wait destination.

CONDITIONS

- An Executive can have up to 3 Secretaries.
- If the Secretary is busy when a call is received for the Executive, the caller will receive busy tone.
- If an Executive has multiple Secretaries, a Secretary can be selected by 'Secretary Choice' option. There are three options, 1) First Idle 2) Longest Idle.
- An Executive cannot be a Secretary to another Executive. And a Secretary cannot be an Executive to another Secretary.
- The Executive may use Call Forward to send calls to stations other than the Secretary.
- Message wait station can be the Executive or the first Secretary
- A Secretary can call his executive.
- If a Secretary (Station B) assigns unconditional call forward to another station (Station C), the forward destination station can make a call to the Executive (Station A).
- When calls are forwarded to subsequent stations (ex., Station C assigns call forward to Station D, E, or F), Executive Call Service is not supported.

OPERATION

MBX IP Phone

To activate/deactivate Executive/Secretary forward from the Executive Phone

Press the [DND] button to toggle Executive/Secretary Forward.

ADMIN PROGRAMMING

Station

DND Access (TRANS/PGM 132 - FLEX 4) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
DND ACCESS -- enables DND to be activated by the station.	4	0: Disable 1: Enable	Enable

Station Group

Executive/Secretary Assign (TRANS/PGM 241) ... see details on [page A-102](#)

TRANS/PGM 241	BTN	RANGE	DEFAULT
EXECUTIVE NUMBER -- Assigns Executive station.	1	-	-
SECRETARY ASSIGN -- Assigns Secretary stations; enter secretary station range, or press FLEX 1-3 and enter station number to assign.	2	FLEX 1-3	-
ICM CALL TO EXEC -- Determines call forwarding when Executive/Secretary is in use. SECRETARY: all internal calls to the Exec. Station (except for calls from executives having executive access privilege) are routed to the Secretary station regardless of the Executive station status. SEC IF EXEC IN DND: internal calls are routed to secretary when executive is in 'DND'.	3	0:Secretary 1:Secretary if Executive in DND	0:Secretary
CO CALL TO EXEC -- Determines call forwarding when Executive/Secretary is in use. SECRETARY: all incoming CO calls to the Exec. Station are routed to the Secretary station regardless of the Executive status. SEC IF ECEC DND: incoming CO calls are routed to secretary when executive is in 'DND'.	4	0:Secretary 1:Secretary if Executive in DND	0:Secretary
CALL EXECUTIVE -- This option is to directly route calls to the Executive station. OFF: executive calls are routed to secretary. FIRST SEC. DND: the executive receives call when first secretary is in 'DND'. ALL SEC. DND: the executive receives call when all secretaries in 'DND'.	5	0-2	0

TRANS/PGM 241	BTN	RANGE	DEFAULT
SECRETARY CHOICE -- Determines order in which secretary stations will receive calls (First Idle/Longest Idle).	6	0-1	0
MSG WAIT STATION -- Determines if message wait indication is left at Executive Station or Secretary. EXECUTIVE: message left at Executive station. FIRST SEC: message is left at the first secretary.	7	0:Executive 1:First Secretary	0

Executive/ Executive Access (TRANS/PGM 242) ... see details on [page A-103](#)

HARDWARE

Digital Phone

External Auto Attendant/Voice Mail

AA/VM Group

The system provides support for an adjunct Auto Attendant/Voice Mail system via connection to SLT ports. When a call arrives for the External AA/VM Group, the system will search the group for an idle port and deliver the call.

Signaling information between the system and AA/VM system may be assigned for in-band DTMF signaling or the Simplified Message Desk Interface (SMDI) signaling protocol over the assigned system RS-232 port.

CONDITIONS

- Selection of SMDI or in-band signaling can be selected in Admin Programming (refer to Admin Programming Manual).
- Only one AA/VM Group can be defined in the system; multiple definitions may cause erroneous system operation.

OPERATION

System

The system will interface with the External AA/VM based on database assignments.

ADMIN PROGRAMMING

Station Groups

VM Group Assignment (TRANS/PGM 200) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
GROUP TYPE -- this entry defines the type of station group.	1	0:Not Assign 1: Terminal 2: Circular 3: Ring 4: Longest Idle 5: Voice Mail	Not Assign
GROUP NAME -- this entry defines the name of a group.	2	Max 16 chars	-
TENANT NO -- this entry assigns a tenant of a station group.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE IDX -- Time Table index,	4	1-9	1
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable
MEMBER ASSIGN -- this entry assigns stations as members of a station group.	6	-	-

VM Group Attribute (TRANS/PGM 203) ... see details on [page A-69](#)

TRANS/PGM 203	BTN	RANGE	DEFAULT
VM PUT MAIL INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Put Mail" dial code.	1	1-9	1
VM GET MAIL INDEX --For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Get Mail" dial code.	2	1-9	2
VM BUSY INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Busy" dial code.	3	1-9	3
VM NO ANSWER INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "No answer" dial code.	4	1-9	4
VM DISCONNECT -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Disconnect" dial code.	5	1-9	9

TRANS/PGM 203	BTN	RANGE	DEFAULT
SMDI TYPE -- This entry defines SMDI Type.	6	0: Type 1 1: Type 2	Type 1
SMDI CLI INFO -- This entry defines SMDI CLI Information. If this is enable, system sends SMDI with CLI.	7	0: Off 1: On	Off

Voice Mail Dialing Table (TRANS/PGM 269) ... see details on [page A-116](#)

TRANS/PGM 269	BTN	RANGE	DEFAULT
VOICE MAIL 1 -- Put Mail code sent when the voice mail is to receive call to record a message.	1	0: Prefix 1: Suffix Any digits	P#
VOICE MAIL 2 -- Get Mail code sent when the voice mail is to playback recorded messages.	2	0: Prefix 1: Suffix Any digits	P##
VOICE MAIL 3 -- Busy Mail code sent when the voice mail is to receive a call while the user is busy.	3	0: Prefix 1: Suffix Any digits	P##*3P
VOICE MAIL 4 -- DND Mail code sent when the voice mail is to receive a call while the user is in DND.	4	0: Prefix 1: Suffix Any digits	P##*4P
VOICE MAIL 5 -- No Answer Mail code sent when the voice mail is to receive a call when the user did not answer.	5	0: Prefix 1: Suffix Any digits	P##*5P
VOICE MAIL 6 -- Error Mail code sent when the voice mail is to receive a call when a dialing error exists.	6	0: Prefix 1: Suffix Any digits	P##*6P
VOICE MAIL 7 --	7	0: Prefix 1: Suffix Any digits	-
VOICE MAIL 8 --	8	0: Prefix 1: Suffix Any digits	-
VOICE MAIL 9 -- Disconnect Mail code sent when the voice mail is to disconnect a call.	9	0: Prefix 1: Suffix Any digits	*****

RELATED FEATURES

In-band (DTMF) Signaling ... [page 3-90](#)

SMDI (Simplified Msg Desk Interface) ... [page 3-93](#)

HARDWARE

External AA/VM system

In-band (DTMF) Signaling

The system may employ in-band signaling to communicate with an External AA/VM system. When a call is routed to the AA/VM SLT port, the system will send DTMF signals informing the AA/VM of the characteristics of the call. DTMF digit strings are assigned to various functions allowing the AA/VM to respond appropriately to the call. These definitions are entered in the "Voice Mail Dialing Table."

CONDITIONS

- Selection of SMDI or in-band signaling can be selected in Admin. Programming.
- Only one AA/VM Group can be defined in the system; multiple definitions may cause erroneous system operation.

OPERATION*System*

The system will interface with the External AA/VM based on database assignments:

ADMIN PROGRAMMING*Station Groups*

VM Group Assignment (TRANS/PGM 200) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
GROUP TYPE -- this entry defines the type of station group.	1	0:Not Assign 1: Terminal 2: Circular 3: Ring 4: Longest Idle 5: Voice Mail	Not Assign
GROUP NAME -- this entry defines the name of a group.	2	Max 16 chars	-

TRANS/PGM 200	BTN	RANGE	DEFAULT
TENANT NO -- this entry assigns a tenant of a station group.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE IDX -- Time Table index,	4	1-9	1
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable
MEMBER ASSIGN -- this entry assigns stations as members of a station group.	6	-	-

VM Group Attribute Assignment (TRANS/PGM 203) ... see details on [page A-69](#)

TRANS/PGM 203	BTN	RANGE	DEFAULT
VM PUT MAIL INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Put Mail" dial code.	1	1-9	1
VM GET MAIL INDEX --For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Get Mail" dial code.	2	1-9	2
VM BUSY INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Busy" dial code.	3	1-9	3
VM NO ANSWER INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "No answer" dial code.	4	1-9	4
VM DISCONNECT -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Disconnect" dial code.	5	1-9	9
SMDI TYPE -- This entry defines SMDI Type.	6	0: Type 1 1: Type 2	Type 1
SMDI CLI INFO -- This entry defines SMDI CLI Information. If this is enable, system sends SMDI with CLI.	7	0: Off 1: On	Off

Table

Voice Mail Dialing Table (TRANS/PGM 269) ... see details on [page A-116](#)

TRANS/PGM 269	BTN	RANGE	DEFAULT
VOICE MAIL 1 -- Put Mail code sent when the voice mail is to receive call to record a message.	1	0: Prefix 1: Suffix Any digits	P#
VOICE MAIL 2 -- Get Mail code sent when the voice mail is to playback recorded messages.	2	0: Prefix 1: Suffix Any digits	P##
VOICE MAIL 3 -- Busy Mail code sent when the voice mail is to receive a call while the user is busy.	3	0: Prefix 1: Suffix Any digits	P#*3P
VOICE MAIL 4 -- DND Mail code sent when the voice mail is to receive a call while the user is in DND.	4	0: Prefix 1: Suffix Any digits	P#*4P
VOICE MAIL 5 -- No Answer Mail code sent when the voice mail is to receive a call when the user did not answer.	5	0: Prefix 1: Suffix Any digits	P#*5P
VOICE MAIL 6 -- Error Mail code sent when the voice mail is to receive a call when a dialing error exists.	6	0: Prefix 1: Suffix Any digits	P#*6P
VOICE MAIL 7 --	7	0: Prefix 1: Suffix Any digits	-
VOICE MAIL 8 --	8	0: Prefix 1: Suffix Any digits	-
VOICE MAIL 9 -- Disconnect Mail code sent when the voice mail is to disconnect a call.	9	0: Prefix 1: Suffix Any digits	*****

System

Voice Mail Interface Select (TRANS/PGM 223 - FLEX 3) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
VM SMDI ENABLE -- If it is set to "ON, system interfaces SMDI protocol with external Voice Mail, If 'OFF', system interfaces In-band message with external Voice Mail.	3	0: Off 1: On	0: Off

RELATED FEATURES

AA/VM Group SMDI (Simplified Msg Desk Interface) ... see details on [page 3-87](#)

HARDWARE

External AA/VM system

SMDI (Simplified Msg Desk Interface)

The system may employ SMDI protocol to communicate with an adjunct AA/VM system. When a call is routed to an AA/VM SLT port, the system will send SMDI messages over the assigned SMDI RS-232 port, informing the AA/VM of the characteristics of the call.

SMDI Protocol - There are three types of SMDI messages (listed below). Within each message is an "Action Code", which defines the function or required action of the AA/VM system. Fields within the messages also define the called/calling station and station status. The various message types and definition of the fields are shown in the chart below.

- Type I message: cr lf MD ggg mmmm a xxxxxxxx sp yyyyyyyy sp cr lf^Y
- Type II message: cr lf MD ggg mmmm a xxxxxxxx sp sp cr lf^Y
- Type III message: cr lf MD ggg mmmm a sp yyyyyyyy sp cr lf^Y

Message Field Definitions

Field	Description	Values
cr	Carriage Return	--
lf	Line Feed	--
MD	Message Desk	--
ggg	Message Desk Number, AA/VN system	Default=001
Mmm	Message Desk terminal	Range=0001-9999 VM port
A	Action Code	--
xxx...x	Called Station Number or Station Calling the VM Group	--
yy...y	Calling Station Number	--
Sp	ASCII Space Character	--
^Y	End of SMDI Message	Control + Y (0x19)

The following table provides detailed information on the meaning and function of the various SMDI messages used.

SMDI Messages

Action Code	Reason	Purpose	In-band Code	Message Type	SMDI Message MD 001 0001
A	Unconditional forward to VM	Put Mail	P#	II	A xxxxx yyyyy
B	Called Station busy	Busy Mail	P#3P	II	B xxxxx yyyyy
C	Disconnect, connected party	Disconnect	*****	II	C xxxxx yyyyy
D	Direct Fwd to VM group	Get Mail	P##	II	D xxxxx yyyyy
E	Error, invalid number	Error	P#*5P	II	E xxxxx yyyyy
H	Two-way Record	Record	None	II	H xxxxx yyyyy
I	DND	DND	P#*6P	II	I xxxxx yyyyy
N	No Answer	No Answer	P#*4P	II	N xxxxx yyyyy
R	Direct CO/IP ring to VM group	AA	None	III	R xxxxx yyyyy

CONDITIONS

- Selection of SMDI or in-band signaling can be modified using Admin. Programming (refer to Admin. Programming Manual).
- Only one AA/VM Group can be defined in the system; multiple definitions may cause erroneous system operation.
- The calling number will display with SMDI CLI INFO attribute (TRANS/PGM203 - FLEX 7).

OPERATION*System*

The system will interface with the External AA/VM based on database assignments:

ADMIN PROGRAMMING*Station Groups*

VM Group Assignment (TRANS/PGM 200) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
GROUP TYPE -- this entry defines the type of station group.	1	0:Not Assign 1: Terminal 2: Circular 3: Ring 4: Longest Idle 5: Voice Mail	Not Assign
GROUP NAME -- this entry defines the name of a group.	2	Max 16 chars	-
TENANT NO -- this entry assigns a tenant of a station group.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE IDX -- Time Table index,	4	1-9	1
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable
MEMBER ASSIGN -- this entry assigns stations as members of a station group.	6	-	-

VM Group Attribute Assignment (TRANS/PGM 203) ... see details on [page A-69](#)

TRANS/PGM 203	BTN	RANGE	DEFAULT
VM PUT MAIL INDEX -- for external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Put Mail" dial code.	1	1-9	1
VM GET MAIL INDEX -- for external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Get Mail" dial code.	2	1-9	2
VM BUSY INDEX -- for external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Busy" dial code.	3	1-9	3
VM NO ANSWER INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "No answer" dial code.	4	1-9	4
VM DISCONNECT -- for external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Disconnect" dial code.	5	1-9	9
SMDI TYPE -- this entry defines SMDI Type.	6	0: Type 1 1: Type 2	Type 1
SMDI CLI INFO -- this entry defines SMDI CLI Information. If this is enable, system sends SMDI with CLI.	7	0: Off 1: On	Off

System

Voice Mail Interface Select (TRANS/PGM 223 - FLEX 3) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
VM SMDI ENABLE -- if it is set to "ON, system interfaces SMDI protocol with external Voice Mail, If 'OFF', system interfaces In-band message with external Voice Mail.	3	0: Off 1: On	0: Off

RELATED FEATURES

AA/VM Group ... see [page 3-87](#)

In-band (DTMF) Signaling ... see [page 3-90](#)

VMIB Integrated Auto Attd/Voice Mail ... see [page 3-258](#)

HARDWARE

External AA/VM system

Flexible Numbering Plan

User access to System resources and features is accomplished using Feature codes or Flexible buttons. The Administrator can select from one of seven different standard Numbering Plans, and if desired, can assign codes for individual functions in the Flexible Numbering Plan. The feature codes are defined in the System's Flexible Numbering Plan (refer to Appendix B).

CONDITIONS

- The System can support up to 8-digit numbering for Station numbers or Feature codes.
- To assign a Numbering Plan code, it should be matched (type) with a Prefix Numbering Plan consisting of a prefix and additional digits.
- The selected Prefix Numbering Plan cannot conflict (ex., if a prefix consists of 1 digit and 4 additional digits, then there cannot be another prefix of 10 digits with 4 additional digits).
- The additional digits of a Prefix Numbering Plan cannot be more than 4.
- When a Prefix Numbering Plan consists of more than 4 digits, the preceding digits of the prefix code are placed at more than 4 digits from end digit (called Master Prefix Digits, can be up to 3 in the MBX IP-100 system and 5 in MBX IP-300 system).
- When a conflicting Prefix is identified, the existing non-conflicting Numbering Plan is used until correctly updated.
- If Numbering Plan type 7 is selected, all numbering codes are deleted; the first user should assign the Prefix Numbering plan. After configuring the prefix, the user can assign Station Number, CO Group Access Code, Extra Numbering and Feature code (for use when user wants to reconfigure all numbering codes).

OPERATION

System

The System implements Feature activation based on the selected Flexible Numbering Plan.

ADMIN PROGRAMMING

Numbering Plan

Numbering Plan (TRANS/PGM 110) ... see details on [page A-15](#)

Prefix Numbering Plan (TRANS/PGM 111) ... see details on [page A-16](#)

TRANS/PGM 111	BTN	RANGE	REMARK
PREFIX CODE -- leading preceding digits of some numbering plan code.	1	1-8 digits	Prefix code length + more digit can be 8 at max.
MORE DIGITS -- number of digits following the Prefix code.	2	(0-4)	

Flexible Station Number (TRANS/PGM 112) ... see details on [page A-16](#)

TRANS/PGM 112	BTN	RANGE	REMARK
STATION NUMBER (edit by range)	1	Start station number & End station number	Delete all station numbers and update entered station number range only.
SINGLE STATION NUMBER (edit)	2	One station number	Bin 001-324 (MBX IP 300), bin 001-128 (MBX IP 100): 1 number per one station port (My-DNs for each stations). Bin 325-648 (MBX IP 300), bin 129-256 (MBX IP 100): Free station numbers for MADN type or extra SADN type numbers (Sub-DNs).

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

CO Group Access Code (TRANS/PGM 114) ... see details on [page A-21](#)

TRANS/PGM 114	BTN	RANGE	REMARK
CO GRP ACCESS CODE (Edit By Range)	1	Start CO Grp Access Code & End CO Grp Access Code	-
CO GRP ACCESS CODE (Edit)	2	CO Grp Access Code	-

Station Group Number (TRANS/PGM 115) ... see details on [page A-22](#)

TRANS/PGM 115	BTN	RANGE	REMARK
STATION GROUP RANGE (Edit by Range)	1	Start Station Group Number & End Station Group Number	-
STATION GROUP NUMBER (Edit)	2	Station Group Number	-

Green Power Save

The system can disable the power of a Digital Phone or SLT (Single Line Telephone) installed in the DTIB/SLIB/DSIU at night or during holiday mode. The power On/Off can be controlled by Web Admin manually or automatically according to the assigned power On/Off time.

CONDITIONS

- SLT (Single Line Telephone) is supported on DSIU, while Digital Phone is not supported.
- If phone power is disabled, calls cannot be placed and received.
- In the event of system reset, power is enabled.

OPERATION

System -- Operation of this feature is either automatic (when programmed) or by Web Admin.

ADMIN PROGRAMMING

System

Green Power Save Time ... use *Web Admin*

Green Power Save Enable ... use *Web Admin*

Headset Compatibility

An industry standard headset can be connected to a Digital Phone in place of or in addition to the handset. The Station must be set for Headset operation.

In Headset mode, pressing the [SPEAKER] button will send audio to the Headset instead of the speakerphone. Additionally when in the Headset mode, ring signals can be delivered to the speaker or the headset as defined in the System database.

CONDITIONS

- The Intercom Signaling Mode can be set in the Headset mode as with the Speakerphone mode.
- Although the phone is in the Headset mode, the system will monitor hook-switch status; if the user lifts the handset to go off-hook, audio automatically is delivered to the handset.

OPERATION

Digital Phone

To change operation from Speakerphone to Headset:

1. Press the [TRANS/PGM] button.
2. Dial 61 {Headset select code}.
3. Dial the appropriate selection:
 - 0: Headset
 - 1: Speakerphone
 - 2: Ear-Microphone
4. Press the [HOLD/SAVE] button.

To change the device to receive ring signals:

1. Press the [TRANS/PGM] button.
2. Dial 62 {Ring select code}.
3. Dial the appropriate selection:
 - 1: Speakerphone
 - 2: Headset
 - 3: Both.
4. Press the [HOLD/SAVE] button.

To place/answer calls using the headset:

Press the [SPEAKER] with the phone in Headset mode.

ADMIN PROGRAMMING

Station

Speaker/Headset Ring Mode (TRANS/PGM 121 - FLEX 3) ... see [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
HEADSET RING -- in Headset mode, this item selects device to receive incoming ring signals. - Speaker, Headset or Both.	3	0: Speaker 1: Headset 2: Both	Speaker

Speakerphone/Headset (TRANS/PGM 121 - FLEX 2) ... see [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
HEADSET MODE -- selects Speakerphone mode, Headset mode or Ear Mic Mode.	2	0:Speaker 1:Headset 2:E-MIC	Speaker

RELATED FEATURES

Speakerphone ... see [page 6-19](#)

Paging ... see [page 4-15](#)

Hold

The user can place a CO/IP line or Station on Hold during a phone conversation.

CONDITIONS

- After placing call on Hold, the station returns to an idle state and the user can make another call.
- If the Station is in the off-hook state when making a call on hold, the dial tone is heard.

OPERATION

Digital Phone

To place an active CO Call on Hold:

Press the [HOLD] button.

To retrieve the Held CO Call:

Press the {CO} OR {LOOP-KEY} button associated with the held CO, and then the CO call is connected again. (If you are just using a DN button, press HOLD again to return to the call you placed on hold.)

Single Line Phone

To place an active CO Call on Hold:

1. Press the Hook-switch during a conversation.
2. Dial {System Hold Code}; a confirmation tone is heard.
3. Place the handset.

To retrieve the Held CO call:

Lift the handset; the Station is connected with the held party.

ADMIN PROGRAMMING

Numbering Plan

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

Hold Recall

When a user places a CO/IP call on hold, a hold timer is activated. If the timer expires, the held call will recall at the station for the duration of the I-Hold Recall timer. If the call remains unanswered at timer expiration, the Attendant will then receive recall for the Attendant Recall timer. If still unanswered after timer expiration, the CO/IP call is disconnected and the circuits in use are returned to idle.

CONDITIONS

- Separate Timers are assigned for the various types of hold: System, Transfer, etc.
- Hold Timer can be assigned by Tone time in the Tone Table.
- The route destination after a Hold recall ring is programmed in Incoming/Outgoing CO Alternate. The following destinations can be assigned:
 - Disconnect
 - Attendant
 - CO Ring Assign
 - Alternative Ring Table
 - Tone
 - Pilot Hunt
 - Transfer Station (Transfer Call Only)

OPERATION

Hold Recall operation is automatic.

ADMIN PROGRAMMING

CO Line Data

Incoming CO Alternate (TRANS/PGM 169) ... see [page A-53](#)

TRANS/PGM 169	BTN	RANGE	DEFAULT
Incoming CO Alternataive DAY --	1	F1: Busy F2: No Answer	Disconnect 1 sec
NIGHT --	2	F3: Invalid F4: Transfer No Answer	Disconnect 1 sec
TIMED --	3	F5: Recall No Answer F6: DND F7: Out Of Service F8: Error 1: Disconnect 2: Attendant 3: CO Ring 4: Alt Ring Table 5: Tone 6: Pilot HuntGroup	Disconnect 1 sec

Outgoing CO Alternate (TRANS/PGM 173) ... see [page A-57](#)

TRANS/PGM 173	BTN	RANGE	DEFAULT
DAY ALT DEST -- Abnormal case can be selected as error type.	-	F1: Recall No Answer F2: Transfer No Answer F3: No Answer	-
NO ANSWER DISCONNECT-- The CO call is disconnected. Every destination is set to 'Disconnect' by default.	1	-	-
NO ANSWER ATTENDANT -- The CO call is routed to Attendant.	2	-	-
NO ANSWER CO RING ASSIGN -- The CO call is routed according to Ring Assign Table. (see TRANS/PGM 167)	3	-	-
NO ANSWER ALT RING TBL -- If destination is set to Alt Ring Table and the Table index is assigned, the CO call is routed according to Alt Ring Table. (See TRANS/PGM 181)	4	01-80	-

TRANS/PGM 173	BTN	RANGE	DEFAULT
NO ANSWER TONE -- If destination is set to Tone, the Error / Busy tone is heard.	5	-	-
NO ANSWER PILOT HUNT GROUP -- The CO call is routed to Pilot Hunt Group of the original destination.	6	-	-
NO ANSWER RING -- The call is routed to the same destination again.	7	-	-
NO ANSWERThe CO call is routed to the transferred station again. Only possible for 'Transfer No Answer' case.	8	-	-

Table Data

CO Hold Tone Timer ... see [page A-137](#) use *Web Admin* (TRANS/PGM 290 - FLEX 55)

RELATED FEATURES

Call Transfer ... see [page 3-30](#)

CO/IP ... see [page 3-37](#)

Automatic Hold

While on an active CO/IP call, the system will place the call on hold automatically. The station can be programmed to support CO/IP to CO/IP Automatic Hold. In this case, pressing a CO/IP button while on a CO/IP call will place the active call on hold and access the selected CO/IP line.

CONDITIONS

- CO/IP lines placed on hold with Automatic Hold are placed in the assigned Hold Timer.
- Hold Timer can be assigned by Tone time in the Tone Table.
- There is no limit on the number of calls that can be placed on hold using Automatic Hold.

OPERATION

Digital

To use Automatic Hold:

Press {CO} OR {LOOP-KEY} button, while on an active Station or CO/IP call; the call is placed on Hold.

ADMIN PROGRAMMING

Station Data

Automatic Hold Access (TRANS/PGM 123 - FLEX 3) | ... see [page A-26](#)

TRANS/PGM 123	BTN	RANGE	DEFAULT
PRIME NUMBER BTN -- among My-DN and several Sub-DNs which are assigned to station flex buttons, determines the first-seized DN when the user initiates a call. If prime button is not set of invalid, the system scans sequentially from flexible button 1 to flexible Button 48 and take the unused and valid flexible button as prime button NOTE: DN buttons of associated DSS box cannot be a prime number button.	1	01-48	01
ZONE NO -- this menu represents a station belonging to what zone.	2	1-9	1
AUTO HOLD -- enables Auto Hold for the station. With Auto Hold enabled, the system will place an active external call on hold if the user presses a CO/IP or DSS button.	3	0: Off 1: On	Off
ENBLOCK DIAL -- when On, the user-dialed digits are stored at the Digital Phone until explicitly sent by the user. When sent, all dialed digits are sent to the system in a block. Enblock mode is only available to Digital Phones with soft keys.	4	0: Off 1: On	Off
ICM ANSWER MODE -- selects Handsfree, Privacy or Tone ring ICM Signaling mode.	5	1: Handsfree 2: Tone 3: Privacy	Tone
DATA SECURITY -- disables override and camp-on tones to the station to avoid occurring error when sending data.	6	0: Off 1: On	Off
PROGRESS INDICATOR -- if this value is set to ON, Progress Indicator Information is included to Setup message (Origin is non-ISDN).	7	0: Off 1: On	Off
FAX MODE -- if this value is set to ON, Bearer Capability information with 3.1Khz is provided to PX.	8	0: Off 1: On	Off
DTMF WHEN REDIAL -- if this value is set to ON, DTMF tone is heard to the station user while redial. (Reserved) .	9	0: Off 1: On	On
MUTE RING SERVICE -- if this value is set to MUTE RING, system provides MUTE RING to user.	10	0: Mute Ring 1: No Ring	Mute Ring
AUTO IDLE SERVICE -- If this value is set to AUTO, system provides Auto Idle service.	11	0: Auto 1: Manual	Auto

RELATED FEATURES

Hold Recall ... see [page 3-102](#)

Hot Desk

Digital Phones can be assigned as Hot Desk (Dummy Terminal) phones allowing Users (Agents) to login to the System. The Hot Desk will become active and will take on the attributes defined for the Agent's Station number. When the Agent logs off, the Hot Desk phone becomes inactive and the Agent's calls can be forwarded to the User-entered destination. A different Agent may then login using the inactive Hot Desk phone.

CONDITIONS

- The Hot Desk station can be programmed to log-out automatically if no action has occurred by the Agent for the duration of the Hot Desk Log-out timer.
- An active (logged in) Agent can login to another inactive Hot Desk phone, however this will log-off Agent activity from the previous Hot Desk location.
- An Agent may only logout from an activated Hot Desk phone.
- The Flex button map of the Hot Desk station is fixed and will not take on the configuration associated with the Agent's station.
- The number of Hot Desk phones is limited by the physical station port number, Hot Desk users are limited by the additional station number of the System capacity.
- Each Hot Desk phone and Hot Desk user (Agent) requires a separate station number(DN) in the system.
- When a Dummy Terminal seizes a SADN-type number (Sub-DN), the Hot Desk feature cannot be supported.
- If an agent logs out without registering call forward destination, {Attendant} feature code is automatically registered so that calls to off-duty agents are directed to attendant.

OPERATION

To program a Hot Desk phone:

1. In Admin. Programming, assign digital phone as Hot Desk (Dummy Terminal).
2. Assign the DN number type as SADN - Hot Desk Agent; the Hot Desk Agent Number option will automatically be set to ON.
3. Assign a password for the Hot Desk agent station (if needed).

To login to the System through an inactive Hot Desk Station:

1. Lift the handset or press the [SPEAKER] button.
2. Dial the {Hot Desk Feature Code}.
3. Dial the Agent's Station number and password.
4. Dial * or press [HOLD/SAVE] button; the agent will be logged in.

To logout through the active Hot Desk:

1. Dial the {Hot Desk Feature Code}.
2. Dial the call forward destination for Agent calls (Dial '#' to delete existing a call forward destination)
3. Dial * or press [HOLD/SAVE] button; the Hot Desk Station will return to inactive.

ADMIN PROGRAMMING

Numbering Plan

Hot Desk Feature Code (TRANS/PGM 113) ... see [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
47	Hot Desk Log In/Log Out	525

Station

Dummy Terminal (TRANS/PGM 121 - FLEX 8) ... see details on [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
DUMMY TERMINAL -- this item defines whether a station is used for hot desk terminal. If you want to use a station as hot desk, this field must be set to 'ON'.	8	0: Off 1: On	Off

Station Number Type (TRANS/PGM 130 - FLEX 1) ... see details on [page A-31](#)

Station Password (TRANS/PGM 131 - FLEX 4) ... see details on [page A-32](#)

TRANS/PGM 131	BTN	RANGE	DEFAULT
PASSWORD-- restricts CO Call Duration to station.	4	0-12 digits	-

Hot Desk Agent Number (TRANS/PGM 131 - FLEX 8) ... see details on [page A-32](#)

TRANS/PGM 131	BTN	RANGE	DEFAULT
HOTDESK AGENT NUMBER-- sets wake-up time.	8	0: Off 1: On	Off

System Timer

Hot Desk Logout Timer (TRANS/PGM 220 - FLEX 2) ... see details on [page A-83](#)

TRANS/PGM 220	BTN	RANGE	DEFAULT
HOT-DESK LOGOUT TMR -- Determines the amount of time the attendant receives recall after which the system will disconnect the call.	2	00-24 hrs	00

RELATED FEATURES

Call Forward ... see [page 3-15](#)

HARDWARE

Digital Phone

In-Room Indication

When an Executive is in the office, their Secretary can press the programmed LED In-Room Indication button signaling other stations of the Executive's status.

CONDITIONS

- Set other Station's MADN Flex button Access Option to Disabled (Incoming only) to make the secretary station the only station able to control the DN state.

OPERATION

To program In-Room Indication:

1. Using Admin. Programming, set a MADN-type DN number to be used as an In-Room Indication button.
2. Enter {DND Status Change code} to register auto-dialing digits for the DN.
3. Assign a flex button for the DN at the Secretary station and to other Stations needing to know the Executive's status.

To Active or Deactivate In-Room Indication:

Press the {DN} button; the DND status of the DN will toggle and the LED signal will be changed at the same time.

ADMIN PROGRAMMING*Numbering Plan*

DND Status Change Code (TRANS/PGM 113) ... see details on [page A-18](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
21	DND Status Change	516

Station

Station Number Type (TRANS/PGM 130 - FLEX 1) ... see details on [page A-31](#)

Flex Button Assign (TRANS/PGM 126) ... see details on [page A-29](#)

Station Auto Dial Attributes (TRANS/PGM 138) ... see details on [page A-38](#)

TRANS/PGM 138	BTN	RANGE	DEFAULT
AUTO DIAL DGT -- Digits will be dialed automatically.	1	Max 16 digits	-
AUTO DIAL PAUSE TIME -- Auto dial pause time.	2	00-30	0

IP Trans-coding

The system employs either the IEEE g.711, g.729 or g.723 codec to digitize and compress voice signals for RTP packets between devices. IP Phone or terminals on DTIM/SLTM incorporate DSP functions to support codec conversion. Available VOIBs include DSP circuitry used to support trans-coding (converting) codecs for incoming VoIP calls to devices.

The VOIBs will trans-code the incoming voice codec (g.711, g.723, g.729) to the System codec and reverse the process for outgoing packets. When the external VoIP connection can only support g.729 and the system codec is g.723, the DSP must implement a complex trans-coding operation, which requires 2 DSP channels. In all other cases, trans-coding only requires a single channel per call.

CONDITIONS

- The system codec for the VOIB can be changed anytime within an IP call.
- The VOIB DSP can generate and detect in-band DTMF and Call Progress tones in support of DISA functionality.
- For complex trans-coding (g.723/g.729), the VOIB DSP will require 2 channels.

OPERATION*System*

IP Trans-coding is automatic.

HARDWARE

VOIB8 or VOIB24

Last Number Redial (LNR)

The last number dialed is stored (up to 32 digits) in the station's Last Number Redial (LNR) buffer. The user may request the system redial the last dialed number without the need to dial the number.

Digital Phone users can display stored LNR numbers on the phone LCD using the [REDIAL] or [SPEED] button and [VOL UP]/[VOL DOWN] buttons, to select the number to dial from the list and place a call.

CONDITIONS

- For Digital Phones with LCD display, the LNR redial buffer will store duplicate numbers unless dialed consecutively.
- When the CO/IP line used for the original call is busy, the System will select an idle line from the same CO/IP line Group to place the call.
- Using LNR will cancel Automatic Called Number Redial if active.
- The LNR is stored in volatile memory, so it is not protected in case of a power failure
- Manually dialing a Flash during an outgoing call will cause only those digits dialed after the Flash to be stored in the LNR buffer.
- LNR applies to both CO and VoIP calls.

OPERATION**Digital Phone**

To use LNR using [REDIAL] button:

1. Lift the handset or press the [SPEAKER] button.
2. Press the [REDIAL] button.
3. Press the [VOL UP]/[VOL DOWN] button to highlight the desired number.
4. Press [HOLD/SAVE] or [REDIAL] to dial the number highlighted.

To use LNR with [SPEED] button:

1. Lift the handset or press the [SPEED] button.
2. Dial *.

Single Line Phone

To use LNR:

1. Lift the handset.
2. Dial the {Last Number Redial code}.

ADMIN PROGRAMMING*Tenant Data*

Redial Method (TRANS/PGM 281 - FLEX 6) ... see details on [page A-130](#)

TRANS/PGM 281	BTN	RANGE	DEFAULT
CODEC TYPE -- System Codec type.	6	1: G711 2: G723 3: G729 4: G722	1: G711

RELATED FEATURES

Saved Number Redial (SNR) ... see [page 6-18](#)

Station Speed Dial ... see [page 3-147](#)

System Speed Dial ... see [page 3-150](#)

Least Cost Routing (LCR)

The LCR feature is supported using digit-conversion; the rule can be set differently according to the Day/Night/Timed mode or LCR Time. If digit conversion is enabled, the System will seize the CO/IP line after digit-conversion is completed. Meanwhile, the Dummy Dial tone can be provided if programmed.

CONDITIONS

- The digit conversion apply rule is applied to bin base of digit conversion table.

OPERATION

Digits are converted automatically based on the Digit Conversion table.

ADMIN PROGRAMMING

Table Data

Digit Conversion Table (TRANS/PGM 251) ... see details on [page A-104](#)

TRANS/PGM 251	BTN	RANGE	DEFAULT
APPLY T-TYPE -- The Apply time type to be applied when the dialed digit is dialed.	1	0:Unconditional 1:Follow DNT 2: Follow LCR	Unconditional
DIALED DIGITS -- The dialed digits.	2	Max 16 digits	-
UNCOND CHANGED -- The CO Group Access Code and digits to be sent to PX when the dialed digit is pressed if Apply time type is 'unconditional'.	3	Max 16 digits	-
DAY CHANGED -- The CO Group Access Code and digits to be sent to PX in Day when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	4	Max 16 digits	-
NIGHT CHANGED -- The CO Group Access Code and digits to be sent to PX in Night when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'	5	Max 16 digits	-
TIMED CHANGED -- The CO Group Access Code and digits to be sent to PX in Timed when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	6	Max 16 digits	-
D1/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	7	Max 16 digits	-

TRANS/PGM 251	BTN	RANGE	DEFAULT
D1/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	8	Max 16 digits	-
D1/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	9	Max 16 digits	-
D2/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	10	Max 16 digits	-
D2/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	11	Max 16 digits	-
D2/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	12	Max 16 digits	-
D3/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	13	Max 16 digits	-
D3/T2 CHANGED -- The digits to be dialed in 'Day 3/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	14	Max 16 digits	-
D3/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	15	Max 16 digits	-
DNT TIME INDEX -- Day/Night/Timed Time Table Index.	16	1-9, none	none
LCR TIME INDEX -- LCR Time Table Index.	17	1-9, none	none
NAME -- When DID destination starts to ring, the name is displayed on the ringing station's LCD.	18	Max 16 digits	-
APPLY OPTION -- The Apply Option can be applied according to the caller.	19	0: All 1: Station 2: CO Line 3: Diable	0:All

Digit Conversion option (TRANS/PGM 252) ... see details on [page A-106](#)

TRANS/PGM 252	BTN	RANGE	DEFAULT
DISPLAY CONV. DIGIT -- If it is set to ON, the station LCD is updated to the dialed digits when alerting message is received from the PX after dialing.	1	On/Off	Off
PRINT CONV. DIGIT -- If it is set to ON, the dialed digits are printed to the SMDR.	2	On/Off	Off

LCR Time Table (TRANS/PGM 255) ... see details on [page A-109](#)

TRANS/PGM 255	BTN	RANGE	DEFAULT
DAY ZN -- For each day of the week, a Day Zone (1 to 3) is assigned. The active Day Zone is the Zone assigned to the current day of the week (Flex button 1-7).	1	FLEX 1-7 + 1-3	Zone 1: All days of the week
DAY ZONE 1 -- This entry defines the time zone of day zone 1 when Day Zone 1 is active.	2	00-24	00-24
DAY ZONE 2 -- This entry defines the time zone of day zone 2 when Day Zone 2 is active.	3	00-24	-
DAY ZONE 3 -- This entry defines the time zone of day zone 3 when Day Zone 3 is active.	4	00-24	-

RELATED FEATURES

Digit Conversion ... see [page 3-74](#)

CO/IP Access ... see [page 3-37](#)

Station Flexible Buttons ... see [page 6-21](#)

Linked Station Pairs/Group

One MADN can be assigned to 10 stations at max so 10 stations can make a linked group, not only paired. If all of the stations set the DN to their Prime-DN, all of 10 stations act like the same station. If one of the stations uses the number, other stations cannot use the same number. Only different Sub-DN can be used at the same time.

CONDITIONS

- If a member of MADN presses the [DND] button while ringing, only the member station's ringing is stopped.

OPERATION

This is automatically supported by the system database.

ADMIN PROGRAMMING

Station

Prime Number Button (TRANS/PGM 123 - FLEX 1) ... see details on [page A-26](#)

TRANS/PGM 123	BTN	RANGE	DEFAULT
PRIME NUMBER BTN -- among My-DN and several Sub-DNs which are assigned to station flex buttons, determines the first-seized DN when the user initiates a call. If prime button is not set or invalid, the system scans sequentially from flexible button 1 to flexible Button 48 and take the unused and valid flexible button as prime button. NOTE: DN buttons of associated DSS box cannot be a prime number button.	1	01-48	01

Flex Button Assign (TRANS/PGM 126) ... see details on [page A-29](#)

Station Number Type (TRANS/PGM 130 - FLEX 1) ... see details on [page A-31](#)

RELATED FEATURES

Intercom Caller ... see [page 4-2](#)

Controlled ICM Signaling ... see [page 6-19](#)

Loud Bell Control (LBC)

The hardware is equipped with a relay that activates an External Control Contact. The contact is assigned to one of several functions including a Loud Bell Control. If used as a Loud Bell Control, the contact will activate when:

- External Page is accessed
- Assigned Station receives a call (LBC)

CONDITIONS

- A Single-Assign Directory Number (SADN) can be assigned for the LBC feature.
- A SIP Station cannot be assigned for LBC feature.
- One relay contact is available (rated at 1 amp, 24 VDC), shown in Table 2.2.4-1.
- When assigned to activate as LBC, CO Incoming ring and Intercom calls to the assigned station will activate the contacts.
- Dummy Station for Hot Desk cannot be used as LBC Station.

OPERATION

System

When set, relay Operation is automatic.

ADMIN PROGRAMMING

System

External Contact Control (TRANS/PGM 228) ... see details on [page A-87](#)

RELATED FEATURES

Door Open ... see [page 3-79](#)

HARDWARE

External Control Contact connected to an external loud bell.

Mobile Extension

A mobile phone may be registered to a station allowing the mobile phone to place and receive calls through the system. DID calls are sent to the user's Phone and the active registered mobile phone simultaneously.

Mobile phone users can access the facilities of the system to place internal and external calls as well as activate/access features. To access system facilities and resources, the mobile user calls the DID number of the corresponding Phone. When the call is received, the system matches the CLI to the mobile phone and provides the mobile user with a system dial tone.

One station can have up to 2 external numbers for their mobile extension. If a mobile extension is being used, the station is in busy state, and the LED is flash steady ON.

CONDITIONS

- When the mobile phone places an external call through the system, the CLI of the corresponding station is used.
- The Mobile Extension features are supported via system digital lines only.
- Message Wait and Callback cannot be activated for use with a mobile phone.
- The Mobile Extension feature is not supported over a distributed network environment.
- When an incoming ISDN DID call is received, the system will access an ISDN line and place a call to the mobile phone; an ISDN line must be available for the system to notify the mobile user of the incoming call.
- Hold and Transfer Recalls to the mobile phone are sent to mobile phone and Mobile Extension and Mobile phone simultaneously.
- Station Group calls can be routed to the active Mobile Extension.

OPERATION

Digital Phone

To activate a registered mobile extension from the user's station:

1. Press the [TRANS/PGM] button.
2. Dial 51 {Mobile Extension code}
3. Dial mobile phone index (1 or 2).
4. Dial digit '1' to activate, '0' to deactivate.
5. Press the [HOLD/SAVE] button.

To register a mobile phone number:

1. Press the [TRANS/PGM] button.
2. Dial 52 {Mobile Extension Registration code}.
3. Dial mobile phone index (1 or 2).
4. Dial the mobile phone number with CO access code.
5. Press the [HOLD/SAVE] button.

To place a call from the mobile extension using the system:

1. Dial the DID number of the station, the system will check the CLI information, answer the call and the user will receive intercom dial tone.
2. Place internal or external call as normal.

To Transfer a call from the mobile extension using the system:

1. Dial {Mobile Flash code}.
2. Dial the desired extension, the call is transferred and the mobile phone returns to idle.
NOTE: The mobile phone may reconnect by dialing the {Mobile Flash Code}.

System

Incoming DID calls are sent to active mobile phones automatically.

ADMIN PROGRAMMING

System Data

Mobile Attributes (TRANS/PGM 236) ... see details on [page A-100](#)

TRANS/PGM 236	BTN	RANGE	DEFAULT
FLASH DIGIT -- The flash digit from mobile extension.	1	Max 2 digits	*
INPUT TIMER -- The inter-digit timer of the mobile flash digit (2 sec).	1	01-20 (seconds)	05

Station Data

Mobile Extension Access (TRANS/PGM 132 - FLEX 6) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
MOBILE EXT ACCESS -- enables mobile extension ability.	6	0: Disable 1: Enable	Enable

Mobile Extension Number Attributes (TRANS/PGM 146) ... see details on [page A-42](#)

TRANS/PGM 146	BTN	RANGE	DEFAULT
MOBILE EXT 1 ENABLE -- Enables mobile extension ability.	1	0: Off 1: On	Off
MOBILE EXT 1 NUMBER -- Mobile extension number.	2	Max 24 digits	-
MOBILE EXT 1 CLI -- Mobile extension CLI number.	3	Max 24 digits	-
MOBILE EXT 2 ENABLE -- Enables Second mobile extension ability.	4	0: Off 1: On	Off
MOBILE EXT 2 NUMBER -- Second Mobile extension number.	5	Max 24 digits	-
MOBILE EXT 2 CLI -- Second Mobile extension CLI number.	6	Max 24 digits	-
MOBILE SERVICE MODE -- Select Mobile Service Mode.	7	0: All Call 1: Service CLI Only	All Call
MOBILE SERVICE CLI 1 -- CLI 1 for Mobile Service.	8	Max 24 digits	-
MOBILE SERVICE CLI 2 -- CLI 2for Mobile Service.	9	Max 24 digits	-
MOBILE SERVICE CLI 3 -- CLI 3for Mobile Service.	10	Max 24 digits	-
MOBILE SERVICE CLI 4 -- CLI 4for Mobile Service.	11	Max 24 digits	-
MOBILE SERVICE CLI 5 -- CLI 5for Mobile Service.	12	Max 24 digits	-

RELATED FEATURES

Do Not Disturb (DND) ... see [page 3-77](#)

Station Message Wait/Call Back ... see [page 4-11](#)

Attendant Recall ... see [page 7-29](#)

Distributed Control Network ... see [page 3-202](#)

Multiple Language Selection

With the VMIB, the system can support three (3) languages simultaneously. Prompts in the desired languages are loaded into the VMIB memory along with the Language Selection prompts. To assure the proper language is employed, the Language Selection prompt is played when an incoming call is assigned to be answered by a DID, DISA, Auto Attendant or Station Hunt group announcement. The Language Selection announcement is played in multiple phrases, one in each of the equipped languages, with a request for the caller to input a digit to select the appropriate language. The system then employs the defined announcement (DID, DISA, etc.) recorded for the selected language.

CONDITIONS

- Multi-language support is available with the VMIB/AAIB.
- Separate announcements must be recorded by the Attendant for each language supported.
- Multi-language announcement must be stored in announcement table (TRANS/PGM 259) first. And then the announcement index can be programmed in other announcement entries for multiple language support.

OPERATION

System

System automatically plays the Language Selection announcement and plays prompts in the selected language.

To record a VMIB Multi-Language Selection announcement at the Attendant:

1. Press the [TRANS/PGM] button.
2. Dial 062 {Record VM Announcement code}.
3. Dial the VMIB Slot number.
4. Dial the VMIB Multi Language selection Announcement number (01-70).
5. Dial the Language Type number (1-3).
6. Press the '#' key.
7. After the beep-tone, record the desired message.
8. Press the [HOLD/SAVE] button to stop recording and save the message.

ADMIN PROGRAMMING*Station Data*

Station VMIB Prompt Language Index (TRANS/PGM 145) ... see details on [page A-40](#)

TRANS/PGM 145	BTN	RANGE	DEFAULT
PROMPT LANGUAGE INDEX -- Selected language type prompt is played to the user when accessing the VMIB.	2	1-3	1

CO Data

CO VMIB Prompt Language Index (TRANS/PGM 161 - FLEX 8) ... see details on [page A-46](#)

TRANS/PGM 161	BTN	RANGE	DEFAULT
PROMPT LANGUAGE -- VMIB Prompt Index.	8	1-3	1

Table Data

Announcement Table (TRANS/PGM 259) ... see details on [page A-111](#)

TRANS/PGM 259	BTN	RANGE	DEFAULT
The VMIB slot & Prompt No. to be used for playing the VMIB Announcement No.	1-4	VMIB Slot (00-18) & Prompt No (01-70)	-
CCR Index used for playing the VMIB Announcement No.	5	1-100	-

RELATED FEATURES

VMIB Integrated Auto Attd/Voice Mail ... see [page 3-258](#)

HARDWARE

VMIB

Multiple Voice Mailbox Support

A station can access any Voice Mailbox by dialing the {VMIB Access} code, the mailbox number and password. Phone users may assign one or more Flex buttons to access a specific mailbox.

OPERATION

Digital Phone

For Multiple Mailbox Access

1. Change the station that you want to be able to log in as to a MADN (TRANS/PGM 130).
EXAMPLE: 100 from SADN normal to MADN.
2. Give the station that needs access a MADN button for the station (TRANS/PGM 130).
EXAMPLE: Add 101 to 100 list and assign to Flex Button 5.
3. In Flexible Button Programming for the station that needs access, program a 523 and the station you want MWI for TRANS/PGM 126.
EXAMPLE: Station 101 flex buttons change button 4 to a Dial Number with a value of 523100.
4. Now when a message is left in 100, station 101 button 4 flashes to indicate a new message.
5. To login to mailbox 100 from 101, press Button 5 (DN for 100) and the call back button. You are prompted for the mailbox password.
6. Enter the password for mailbox 100 followed by the # sign.

To assign a {VMAILBOX} Flex button:

[TRANS/PGM] + {FLEX} + Button Feature Type (1) + {VMIB Access} Code + Mailbox (station) number + [HOLD/SAVE]

To access a Voice Mailbox using the {VMAILBOX} Flex button:

1. Lift the handset or press the [SPEAKER].
2. Press the {VMAILBOX} Flex button.
3. Dial the Mailbox password.

RELATED FEATURES

VMIB Voice Mail ... see [page 3-261](#)

HARDWARE

Phone / VMIB

Music-On-Hold (MOH)

When a call is placed on Hold, the System will deliver audio from the defined MOH source. In this way, the connected user can determine that the connection is still active.

The system has connections for one music source. The MOH can be either an internal or external source connected to either of the MOH inputs.

Additionally, a message recorded in the VMIB can be employed as MOH along with Background Music (BGM). The Attendant records the VMIB announcement for MOH and VMIB MOH is assigned as the MOH source. Separate messages can be recorded for each of the 3 languages supported by the system.

CONDITIONS

- There are 5 kinds of MOH:
 - 1 - Normal Tone
 - 2 - Prompt
 - 3 - Announcement
 - 4 - VMIB MOH
 - 5 - SLT MOH
- MOH can be activated by programming the Hold Tone for MOH within the Tone Table.
- Plugging-in the BGM RCA jack on the front panel of the MPB and the BGM input on the rear panel RJ-11 jack are common; however, the external music source should only be connected to one of the inputs.

OPERATION

System -- When set, Operation of MOH is automatic:

To record a VMIB announcement for MOH:

1. Press the [TRANS/PGM] button.
2. Dial the {VMIB Record Feature Code}.
3. Dial the VMIB Slot number.
4. Dial the VMIB Multi-Language selection Announcement number.
5. Dial the Language Type number, only required with multi-language support; the current announcement is played followed by the "Press # to record" prompt.
6. Press the '#' key.
7. After the beep-tone, record the desired message.
8. Press the [HOLD/SAVE] button to stop recording and save the message.

ADMIN PROGRAMMING

Table Data

Tone Table ... use *Web Admin* (TRANS/PGM 290 - FLEX 49-61)

System Data

Music Source (TRANS/PGM 229) ... see details on [page A-88](#)

TRANS/PGM 229	BTN	RANGE	DEFAULT
ICM BOX MUSIC CH -- assigns the music source for ICM BOX.	1	00: NO BGM 01: Internal Music 02: External Music 03: VMIB BGM 1 04: VMIB BGM 2 05: VMIB BGM 3 06: VMIB BGM 4 07: SLT MOH 1 08: SLT MOH 2 09: SLT MOH 3 10: SLT MOH 4 11: SLT MOH 5	1
INT MOH TYPE -- assigns the music for internal MOH.	2	00: Romance 01: Turkish March 02: Green Sleeves 03: Fur Elise 04: Carmem 05: Waltz 06: Pavane 07: Siciliano 08: Sonata 09: Spring 10: Campanella 11: Badinerie 12: Blue Dance	-
VMIB MOH -- assigns the VMIB Prompt index of VMIB Slot X for VMIB MOH X.	3-6 for MPB300 (3-5 for MPB100)	01-70	-
SLT MOH -- assigns the SLT ports for SLT MOH.	7-11 for MPB300 (6-10 for MPB100)	-	-

RELATED FEATURES

Hold ... see [page 3-101](#)

Multiple Language Support ... see [page 3-120](#)

HARDWARE

External Music source is connected to MPB music source input.

Network Management System (*Future Feature*)

The Network Management System (NMS) is a Web-based application for monitoring and managing multiple systems using standard Simple Network Management Protocol (SNMP).

NMS is an efficient and convenient tool employing standards based protocols and a Web-based architecture to permit Administrators remote access to systems using any common Web browser.

NMS monitors the multiple systems displaying real-time detailed status information for the system devices and channels.

NMS maintains a log of alarm and fault events defined by the administrator and can alert administrators of potential service-affecting faults. In addition, call statistics are maintained and can be reported with various tables and graphs.

CONDITIONS

- NMS is subject to the conditions outlined in the NMS Manual.

OPERATION

Once configured, the operation of NMS is automatic. Administrative operations are covered in the NMS Manual.

ADMIN PROGRAMMING

System

SNMP Attributes ... use *Web Admin*

RELATED FEATURES

Diagnostic/Maintenance ... see [page 3-60](#)

Network Security & Priority

The System supports several security and priority protocols. Characteristics that can be established are:

- IEEE 802.1p/Q, VLAN - sets Virtual LAN tag and priority for Ethernet frame
- Diffserv - sets Diffserv Code Point priority for IP packet
- IPSec - enables IPSec to establish IPSec tunnel and encryption of IP packet
- SRTP - enables Secure RTP for RTP packet payload using AES (Advanced Encryption Service).

CONDITIONS

- For Web Admin, the password is encrypted using the Java Virtual Encryption plug-in. A Java Virtual Machine (MS or Sun) must be installed in the User's PC to support password encryption.
- Security and priority characteristics can be set for all devices, local or remote.
- The implementation of IPSec employs a proprietary Key exchange protocol from the MP to the System device.

OPERATION

System

Once configured, Operation of Security and Priority is automatic.

ADMIN PROGRAMMING

System Data

Web Password Encryption (TRANS/PGM 223 - FLEX 1) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
WEB ADM PSWD ENCRYPTION -- The Web Admin password can be encrypted for security using RC-6 block encryption A Java VM must be installed on the user's PC.	1	0: Off 1: On	0:Off

One Digit Service

When a User calls a Station and receives a Busy signal, the User can access the following features by dialing one digit:

- Camp-on
- Call Wait
- Voice Over
- Intrusion
- Pilot Hunt Call

Camp-On

Camp-On is used to notify a Busy Station that a call is waiting to be answered. The busy station is notified of the waiting call by a Camp-On tone. The camp-on station is placed in the Hold state while waiting.

CONDITIONS

- The user may only Camp-On to a station in the busy mode; a user may not Camp-On to a station in DND, conference, or receiving a Page, etc.
- A Camp-On tone is sent each time the calling user presses the {Camp-On} button.

OPERATION

Digital Phone/Single Line Phone

To activate a Camp-On while receiving an Intercom busy tone:

Press the {Camp-On} button, both the called and calling stations will receive Camp-On tone.

ADMIN PROGRAMMING

System Data

Camp-On Access (TRANS/PGM 133 - FLEX 8) ... see details on [page A-33](#)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CAMP ON ACCESS -- enable camp-on feature.	8	0:Disable 1:Enable	Enable

Tenant Data

Intercom Busy One-Digit Attributes (TRANS/PGM 237 - FLEX 1) ... see details on [page A-101](#)

TRANS/PGM 237	BTN	RANGE	DEFAULT
INTERCOM BUSY ONE-DIGIT SERVICE -- determines if step call is enabled or disabled.	1	0:Disable 1:Enable	Disable

Call Wait

Call Wait is used to notify a busy station that a call is waiting to be answered. The busy station is notified of the waiting call by a Call Wait tone. For Digital Phone users, the [HOLD] button LED will flash. The called station can respond by either:

- Answering the waiting call (which places the active call on Hold first),
- Activating One-Time DND
- Ignoring the Camp-On tone.

CONDITIONS

- The user may only Call Wait to a station in the busy mode; a user may not Call Wait at a station in DND, conference, or receiving a Page, etc.
- A Call Wait tone is sent each time the calling user presses the programmed {Call Wait} button.

OPERATION**Digital Phone**

To activate a Call Wait while receiving Intercom busy tone:

Press the {Call Wait} button, called and calling stations will receive the Call Wait tone.

To answer a Call Wait after receiving the Call Wait indication:

Press the [HOLD] button; the first active call is placed on hold and the station is connected with the Call Waiting station.

Digital Phone/Single Line Phone

To activate a Call Wait while receiving Intercom busy tone:

Press the {Call Wait} button, called and calling stations will receive the Call Wait tone.

To answer a Call Wait after receiving the Call Wait indication:

Press the hook-switch; the first active call is placed on Hold, and the station is connected with the Call Waiting station.

ADMIN PROGRAMMING

System Data

Call Wait Access (TRANS/PGM 133 - FLEX 7) ... see details on [page A-33](#)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CALL WAIT ACCESS -- enable to leave a call wait when a called station does not answer or in DND state.	7	0:Disable 1:Enable	Enable

Tenant Data

Intercom Busy One-Digit Attributes (TRANS/PGM 237) ... see details on [page A-101](#)

TRANS/PGM 237	BTN	RANGE	DEFAULT	
STEP CALL -- determines if Step Call is enabled or disabled.	1	0:Disable 1:Enable	Disable	
DIGIT 1 -- when accessing a busy tone, User may dial for one of the one-touch services.	2	0: N/A 1: Call-Back 2: Camp On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	0: N/A	
DIGIT 2 --	3			
DIGIT 3 --	4			
DIGIT 4 --	5			
DIGIT 5 --	6			
DIGIT 6 --	7			
DIGIT 7 --	8			
DIGIT 8 --	9			
DIGIT 9 --	10			
DIGIT 0 --	11			
DIGIT * --	12			Call Wait
DIGIT # --	13			Voice-Over

RELATED FEATURES

- Do Not Disturb (DND) ... see [page 3-77](#)
- Intercom Call (ICM Call) ... see [page 4-2](#)
- Voice Over ... see [page 6-32](#)

Outcall Notification

This feature provides a way to notify the arrival of voicemail messages to the specified telephone number. If the user enables the notification of mailbox and programs a phone number including CO access code, the system will give a call by dialing the programmed number and allows access to voice mail after checking the user's password. If the user does not answer the call, the system quits the call. Also by programming, the notification can be retried after the time interval and retry count settings have been changed.

CONDITIONS

- Analog CO lines cannot be used for this feature since there is no explicit signal when the call is answered.
- Only CO party can receive the notification call. So, the notification phone number should start with a CO access code.

OPERATION

Digital Phone

To enable/disable outcall notification:

1. Press the [TRANS] + 7 3 or dial the {Outcall Notification} feature code.
2. Dial 1 to enable or 0 to disable.
3. Press the [HOLD/SAVE] button.
4. 4.Return to idle after hearing a service set tone.

To set a value for outcall notification attempts:

1. Press the [TRANS] + 7 4 or dial the {Outcall Attempts} feature code.
2. Dial one-digit number of attempts (1-9).
3. Press the [HOLD/SAVE] button.
4. Return to idle after hearing service set tone.

To set a value for outcall notification interval for a retrial case:

1. Press the [TRANS] button + 7 5 or dial the {Outcall Interval} feature code.
2. Dial two-digit minute information (01-60).
3. Press the [HOLD/SAVE] button.
4. Return to idle after hearing service set tone.

To set a phone number for outcall notification:

1. Press the [TRANS] button + 7 6 or dial the {Outcall Phone Number} feature code.
2. Dial the phone number including CO access code (Max 24).
3. Press the [HOLD/SAVE] button.
4. Return to idle after hearing service set tone.

Single Line Phone

To enable/disable outcall notification:

1. Dial the {Outcall Notification} feature code.
2. Dial 1 to enable or 0 to disable.
3. Press the hook-switch to save.
4. Replace the handset, return to idle.

To set a value for outcall notification attempts:

1. Dial the {Outcall Attempts} feature code.
2. Dial one-digit number of attempts (1-9).
3. Press the hook-switch to save.
4. Replace the handset, return to idle.

To set a value for outcall notification interval for a retrial case:

1. Dial the {Outcall Interval} feature code.
2. Dial two-digit minute information (01-60).
3. Press the hook-switch to save.
4. Replace the handset, return to idle.

To set a phone number for outcall notification:

1. Dial the {Outcall Phone Number} feature code.
2. Dial the phone number including CO access code (Max 24).
3. Press the hook-switch to save.
4. Replace the handset, return to idle.

Called Party

To retrieve voice messages after receiving notification call:

1. When the called party answers the notification call, the system will announce the prompt similar to the followint: "This is the voice mail system. There is a message for [recorded name] or [mailbox number (xxxxxxx)]."
2. And then "Enter your password followed by pound" prompt will be heard.
3. If the called party enters the station number, its password + '#', the system will check the validity of the password entered.
4. If the verification is successful, the called party will hear the main menu of voice mail and can access its own voice mail. After that, all the mailbox features will be available.
5. The System will retry 3 times before disconnecting the call.

ADMIN PROGRAMMING

Numbering

Feature Numbering Plan (TRANS/PGM 113) ... see [page 3-97](#)

Station Data

TRANS/PGM 145	BTN	RANGE	DEFAULT
OUTCALL NOTIFICATION -- enables or disables the outcall notification feature. If you are using outcall notification on analog trunks, this field <u>MUST</u> be set to ON.	21	0:Off 1:On	Off
OUTCALL ATTEMPTS -- the number of attempts to try to reach the outcall number.	22	1-9	-
OUTCALL INTERVAL -- the interval time in between attempts.	23	01-60 mins	-
OUTCALL PHONE NUMBER -- the phone number to dial. Outcall destination.	24	Up to 24 digits	-

HARDWARE

AAFU and/or VMIB

Pre-defined & Custom Text Display Messages

When not available, a user can pre-select a text message to be shown on the LCD of an incoming caller's Digital Phone display. When a user activates Text Display Messages, incoming intercom calls will signal the user with normal ringing, and the LCD of the calling station will display the selected message. There are ten Pre-defined messages (01-10), ten System-wide Custom messages and one User-defined Custom message. Several of the ten Pre-defined messages allow for auxiliary information such as a time, date or number.

System-level Custom Messages may be entered from the Attendant or Administrator's phone or via the Web Admin. The User's Custom Message can be assigned from their own Station phone as well as at the Attendant or the Administrator.

Digital Phone users may assign a Flex button as a {Preselected Message TRANS/PGM} button.

The Pre-defined messages are:

Message Number	Display	Comment
01	LUNCH RETURN AT hh:mm	hh:mm can be set with return time
02	ON VACATION RETURN AT DATE mm:dd	mm:dd can be set with return date
03	OUT OF OFFICE RETURN AT TIME hh:mm	hh:mm can be set with return time
04	OUT OF OFFICE RETURN AT DATE mm:dd	mm:dd can be set with return date
05	OUT OF OFFICE RETURN UNKNOWN	--
06	CALL (enter up to 24 digits)	Can be set with destination to call.
07	IN OFFICE STA xxxx	xxxx is set with station number
08	IN MEETING RETURN AT TIME hh:mm	hh:mm can be set with return time
09	AT HOME	--
10	AT BRANCH OFFICE	--

CONDITIONS

- Alphanumeric characters are displayed as they are entered.
- Display Message is cancelled if the User activates DND or Call Forward.
- Custom Text Display Messages and Display Message status are stored in non-volatile memory to protect against loss during power failure.
- Incoming Caller Station will display the message.
- SLTs are notified of an active Display Message with a stutter dial tone, while Digital Phones will have a flashing [DND] button when there is an active Text Display Message.
- Activating a Text Display Message does not affect normal operation of the station.
- Pre-defined Messages 01-04, and 06-08 permit the user to input auxiliary information such as time, date or number, as applicable.
- The Attendant station can activate a Text Display Message for other stations, however this feature is not available to an Attendant.

OPERATION

Digital Phone

To assign a Flex button for Display Messages:

PRESS [TRANS/PGM] + {FLEX} + Button Feature Type(1) + {Preselected Message TRANS/PGM Code} + [HOLD/SAVE].

To activate a Display Message that will be presented to incoming callers:

1. Press the [TRANS/PGM] button.
2. Dial 41 {Display Message code}.
3. To scroll through the available messages, press [VOL UP]/[VOL DOWN] button.
4. Dial the Message number (0-9, or * for User's Custom Message).
5. Enter auxiliary input (hh:mm, mm:dd, etc. as needed).
6. Press the [HOLD/SAVE] button.

To cancel an active Display Message:

1. Press the flashing [DND] button.
OR
2. Press the [TRANS/PGM] button.
3. Dial 41 {Display Message code}.
4. Press the # key.
5. Press the [HOLD/SAVE] button.

To define the User Custom Text Message ():*

1. Press the [TRANS/PGM] button.
2. Dial 42 {Custom Message program code}.
3. Enter the Message contents (up to 16 characters, refer to Alphanumeric Entry Chart on [page C-105](#)).
4. Press the [HOLD/SAVE] button; confirmation tone is heard and the new User Custom Text Display Message is stored.

NOTE: Alphanumeric characters may be entered using the following guides as shown in the Quick Reference chapter on [page C-105](#).

Single Line Phone

To activate a Display Message:

1. Lift the handset.
2. Dial {SLT Programming code}.
3. Dial 41 {Display Message code}.
4. Dial the Message number (0-9, or * for User's Custom Message).
5. Enter auxiliary input (hh:mm, mm:dd, etc. as needed).
6. Press the hook-switch; confirmation tone is heard.

To cancel an active Display Message:

1. Lift the handset.
2. Dial {SLT Feature Cancel code}.

To enter the User Custom Message ():*

1. Lift the handset.
2. Dial {SLT Programming code}.
3. Dial 41 {Display Message code}.
4. Enter the Message contents (up to 16 characters, refer to Alphanumeric Entry Chart on [page C-105](#)).
5. Press the hook-switch, confirmation tone is received.

System Attendant

To activate Display Messages for other stations:

1. Press the [TRANS/PGM] button.
2. Dial 051 {Attendant Display Message code}.
3. Dial the desired Station range.
4. To scroll through the available messages, press [VOL UP]/[VOL DOWN] button.
5. Dial the Message number (0-9, or * for User's Custom Message).
6. Dial auxiliary input (hh:mm, mm:dd, etc. as needed).
7. Press the [HOLD/SAVE] button.

To cancel active Display Messages for other stations:

1. Press the [TRANS/PGM] button.
2. Dial 052 {Attendant Display Message Cancel code}.
3. Dial the desired Station range.
4. Press the [HOLD/SAVE] button.

RELATED FEATURES

Do Not Disturb (DND) ... see [page 3-77](#)

Call Forward ... see [page 3-15](#)

Speed Dial ... see [page 3-146](#)

HARDWARE

Digital Phone required receiving Display Messages

Registering IP Devices & Fractional Module Tables

Registration with MAC Address

Using the defined MAC address registration, the system allows IP Phones, DTIM and SLTM devices with matching MAC addresses to register regardless of the Database Protection Switch (DPS) position.

OPERATION

Registration is automatic.

ADMIN PROGRAMMING

System Info

IP Phone/Phontage Registration Table (TRANS/PGM 106) ... see details on [page A-12](#)

TRANS/PGM 106	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register an IP Phone to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-105 .)	1	-	-
USER ID -- Used to register a Phonatge to the System, by entering its User ID and Password.	2	-	-
USER PASSWORD -- Used to register a Phonatge to the System, by entering its User ID and Password.	3	-	-
STA NUMBER (VIEW) -- Once a connection is made to the System, the current Station number will be displayed.	4	-	-
IP ADDRESS (VIEW) -- Displays the IP Address of the IP phone/Phontage.	5	-	-
F/W IP ADDRESS (VIEW) -- Displays the Firewall IP Address of the IP phone/Phontage.	6	-	-
RTP SECURITY -- Enable RTP Security.	7	-	-

DTIM/SLTM Registration Table (TRANS/PGM 107) ... see details on [page A-13](#)

TRANS/PGM 107	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register a DTIM to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-105 .)	1	-	-
STA RANGE (VIEW) -- Once a connection is made to the System, the Station number assigned to DTIM/SLTM will be displayed.	2	-	-
IP ADDRESS -- Displays the IP Address of the IP phone/Phontage.	3	-	-
F/W IP ADDRESS -- Displays the Firewall IP Address of the IP phone/Phontage.	4	-	-
RTP SECURITY -- Enable RTP Security.	5	-	-

Logical Slot Assignment (TRANS/PGM 104 - FLEX 2) ... see details on [page A-12](#)

TRANS/PGM 104	BTN	RANGE	REMARK
MAX NO. OF IP PHONE -- that can be registered to the System.	2	-	32

Slot Assignment & Logical Slot Assignment (TRANS/PGM 101, TRANS/PGM 103) ... see details on [page A-11](#) and [page A-11](#)

TRANS/PGM 101	BTN	RANGE	REMARK
SLOT ASSIGNMENT-- refer to "Board Type Code" table below.	1	-	-
SLOT 02 -- enter device (port) number.	2	-	-

TRANS/PGM 103	BTN	RANGE	REMARK
CO LINE BOARD	1	-	-
STATION BOARD	2	88 (SIP Phone) 99 (IP Phone or Phontage)	-
VMIB BOARD	3	-	-

Registration with ID/Password

The System can be programmed to register a Phontage or SIP Phone using an ID & Password. Devices with matching ID & Password can be registered regardless of the Database Protection Switch position.

OPERATION

Registration is automatic.

ADMIN PROGRAMMING

System Info

IP Phone/Phontage Registration Table (TRANS/PGM 106) ... see details on [page A-12](#)

TRANS/PGM 106	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register an IP Phone to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-105 .)	1	-	-
USER ID -- Used to register a Phonatge to the System, by entering its User ID and Password.	2	-	-
USER PASSWORD -- Used to register a Phonatge to the System, by entering its User ID and Password.	3	-	-
STA NUMBER (VIEW) -- Once a connection is made to the System, the current Station number will be displayed.	4	-	-
IP ADDRESS (VIEW) -- Displays the IP Address of the IP phone/Phontage.	5	-	-
F/W IP ADDRESS (VIEW) -- Displays the Firewall IP Address of the IP phone/Phontage.	6	-	-
RTP SECURITY -- Enable RTP Security.	7	-	-

DTIM/SLTM Registration Table (TRANS/PGM 107) ... see details on [page A-13](#)

TRANS/PGM 107	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register a DTIM to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-105 .)	1	-	-
STA RANGE (VIEW) -- Once a connection is made to the System, the Station number assigned to DTIM/SLTM will be displayed.	2	-	-
IP ADDRESS -- Displays the IP Address of the IP phone/Phontage.	3	-	-
F/W IP ADDRESS -- Displays the Firewall IP Address of the IP phone/Phontage.	4	-	-
RTP SECURITY -- Enable RTP Security.	5	-	-

Logical Slot Assignment (TRANS/PGM 104 - FLEX 2) ... see details on [page A-12](#)

TRANS/PGM 104	BTN	RANGE	REMARK
MAX NO. OF IP PHONE -- that can be registered to the System.	2	-	32

Slot Assignment & Logical Slot Assignment (TRANS/PGM 101, TRANS/PGM 103) ... see details on [page A-11](#) and [page A-11](#)

TRANS/PGM 101	BTN	RANGE	REMARK
SLOT ASSIGNMENT-- refer to "Board Type Code" table below.	1	-	-
SLOT 02 -- enter device (port) number.	2	-	-

TRANS/PGM 103	BTN	RANGE	REMARK
CO LINE BOARD	1	-	-
STATION BOARD	2	88 (SIP Phone) 99 (IP Phone or Phontage)	-
VMIB BOARD	3	-	-

Registration with Station Number

System allows IP Phone registration if the IP Phone Station number matches the Station number designated regardless of the Database Protection Switch position.

CONDITIONS

- By default, the IP Phone Registration by STA Number is ON.

OPERATION

Registration is automatic.

ADMIN PROGRAMMING

System Info

Logical Slot Assignment (TRANS/PGM 104 - FLEX 2) ... see details on [page A-12](#)

TRANS/PGM 104	BTN	RANGE	REMARK
MAX NO. OF IP PHONE -- that can be registered to the System.	2	-	32

IP Address Plan (TRANS/PGM 101) ... see details on [page A-11](#)

TRANS/PGM 101	BTN	RANGE	REMARK
SLOT ASSIGNMENT-- refer to "Board Type Code" table below.	1	-	-
SLOT 02 -- enter device (port) number.	2	-	-

Slot Assignment (TRANS/PGM 103) ... see details on [page A-11](#)

TRANS/PGM 103	BTN	RANGE	REMARK
CO LINE BOARD	1	-	-
STATION BOARD	2	88 (SIP Phone) 99 (IP Phone or Phontage)	-
VMIB BOARD	3	-	-

System Attribute (TRANS/PGM 223) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
WEB ADM PSWD ENCRYPTION -- The Web Admin password can be encrypted for security using RC-6 block encryption A Java VM must be installed on the user's PC.	1	0: Off 1: On	0: Off
PULSE DIAL BREAK RATIO -- The break/make ratio for pulse dialing through analog CO line.	2	0: 60/40 1: 66/33 2: 50/50	1: 66/33
VM SMDI ENABLE -- If it is set to "ON, system interfaces SMDI protocol with external Voice Mail, If 'OFF', system interfaces In-band message with external Voice Mail.	3	0:Off 1:On	0: Off
VMIB SMTP PORT -- SMTP Port for VMIB message e-mail sending.	4	0000-9999	0025
NETWORK DATE/TIME USE -- If set to ON, the System updates the Date & Time with Network Date & Time when the System Date & Time is different.	5	0: Off 1: On	0: Off
CLI PRINT -- If set to ON, CLI information is printed.	6	0: Off 1: On	0: Off
TLS FOR WEB -- Enables Transport Layer Security (TLS for Web access.	7	0: Off 1: On	0: Off
WEB SERVER PORT -- Web Server port number.	8	1-65535	80

TRANS/PGM 223	BTN	RANGE	DEFAULT
DB AUTO DOWNLOAD(WEEK) -- Determines when system database downloads to USB automatically,	9	0: Off 1: On	0: Off
DB DOWNLOAD (TIME) -- Sets the time for system database download to USB automatically.	10	00-23	00
UC SERVER IP ADDRESS -- UC Server IP Address.	11	-	-
CTI SERVER IP ADDRESS -- CTI Server IP Address.	12	-	-
MODEM ASC CO LINE -- Modem Associate CO Line.	13	001-240	000
IP PHONE REG BY STA NUM -- Enables IP phone registration by station number.	14	0: Off 1: On	0: Off

Remote Device Zone Management

Remote devices, in particular those not reachable by the System, are managed by grouping devices by various characteristics in a Zone. Placing devices into Zones simplifies management allowing definition of common characteristics to the devices within the zone.

Zone attributes include:

- Nation Code
- Language
- RTP Relay
- RTP Relay group

CONDITIONS

- It is recommended to assign CO/IP lines and Stations of a Tenant group in the same Device Zone.
- Wake-up time is based on the time displayed in the Station LCD.

OPERATION

When set, Zone operation is automatic.

ADMIN PROGRAMMING

Zone Data

Zone Attributes ... use *Web Admin* (TRANS/PGM 395)

Zone RTP Relay Group ... use *Web Admin* (TRANS/PGM 396)

Inter-Zone Attributes ... use *Web Admin* (TRANS/PGM 397)

Station Zone Attributes ... use *Web Admin* (TRANS/PGM 399)

Remote Services, Managed Net

IP Phones, DTIM and SLTM can run on a System located on a different LAN segment or WAN without the need for additional equipment.

The System can be assigned with the IP address of the default gateway (router) running the remote device. The system will register the device through the router. Using this configuration, the device can establish a connection with the system and then establish peer-to-peer communication with other devices as needed.

CONDITIONS

- The managed network must provide appropriate security, bandwidth and QoS.

OPERATION

Operation of this feature is automatic.

ADMIN PROGRAMMING

System Info

IP Phone/Phontage Registration Table (TRANS/PGM 106) ... see details on [page A-12](#)

TRANS/PGM 106	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register an IP Phone to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-105 .)	1	-	-
USER ID -- Used to register a Phonatge to the System, by entering its User ID and Password.	2	-	-
USER PASSWORD -- Used to register a Phonatge to the System, by entering its User ID and Password.	3	-	-
STA NUMBER (VIEW) -- Once a connection is made to the System, the current Station number will be displayed.	4	-	-
IP ADDRESS (VIEW) -- Displays the IP Address of the IP phone/Phontage.	5	-	-
F/W IP ADDRESS (VIEW) -- Displays the Firewall IP Address of the IP phone/Phontage.	6	-	-
RTP SECURITY -- Enable RTP Security.	7	-	-

DTIM/SLTM Registration Table (TRANS/PGM 107) ... see details on [page A-13](#)

TRANS/PGM 107	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register a DTIM to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-105.)	1	-	-
STA RANGE (VIEW) -- Once a connection is made to the System, the Station number assigned to DTIM/SLTM will be displayed.	2	-	-
IP ADDRESS -- Displays the IP Address of the IP phone/Phontage.	3	-	-
F/W IP ADDRESS -- Displays the Firewall IP Address of the IP phone/Phontage.	4	-	-
RTP SECURITY -- Enable RTP Security.	5	-	-

Logical Slot Assignment (TRANS/PGM 103 - FLEX 2) ... see details on [page A-11](#)

TRANS/PGM 103	BTN	RANGE	REMARK
STATION BOARD	2	88 (SIP Phone) 99 (IP Phone or Phontage)	-

Reversible Ring

This feature can be used to identify the extension DN especially when a SLT is in use. Additionally, the User can verify the incoming ring signal is working correctly.

OPERATION

To listen to Reversible Ring:

1. Lift the Handset or press [SPEAKER].
2. Dial the station DN; confirmation tone is heard
3. Replace Handset (go on-hook); incoming ring will be presented.
4. Lift Handset or press [SPEAKER], confirmation tone is heard.

ADMIN PROGRAMMING

Table Data

Ring Table, Revertible Ring (*Web Admin* TRANS/PGM 265-11)

TRANS/PGM 265	BTN	RANGE	DEFAULT
Revertible Ring - (<i>Web Admin Only</i>)	11	-	-

Speed Dial

Speed Dial Pause Insertion

A pause dialing command may be inserted in a Station or System Speed Dial number. When encountered, the System will stop dialing the Speed Dial number for the assigned "pause" duration. Multiple pauses ([HOLD] button depressions) may be inserted into a Speed Dial number.

CONDITIONS

- Timed pause is used only with analog CO lines.

OPERATION

System

When set, Pause operation is automatic.

ADMIN PROGRAMMING

Station Data

Speed Access (TRANS/PGM 134, FLEX 1) ... see details on [page A-33](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
SPEED ACCESS -- gives station speed dial bins access authority.	1	0: Disable 1: Enable	Enable

Table Data

System Speed Dial Table (TRANS/PGM 257) ... see details on [page A-110](#)

TRANS/PGM 257	BTN	RANGE	DEFAULT
SYS SPD DIAL -- The System Speed Dial Digits.	1	Max 32 digits	-
SYS SPD NAME -- The System Speed Dial Name.	2	Max 16 characters	-

TRANS/PGM 257	BTN	RANGE	DEFAULT
TOLL FREE -- Assignment to apply toll free.	3	0: Off 1: On	0: Off
TENANT NO -- The tenant number to be applied to the System Speed Access.	4	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

RELATED FEATURES

Station Speed Dial ... see [page 3-147](#)

System Speed Dial ... see [page 3-150](#)

Station Speed Dial

Each User can store commonly dialed numbers for easy access using Station Speed Dial bins. Each Station has access to 50 Speed Dial numbers. Each Speed Dial number can be up to 24 digits in length and may include special instruction codes.

Special instruction codes are:

- Flash as 1st digit: Activates dial tone detect.
- Pause [CALLBACK]: Inserts a pause dialing command.
- * not 1st digit: Switches from Pulse to DTMF dialing.

Digital Phone users may assign a Flex button for One-Touch access to a specific Speed Dial bin.

CONDITIONS

- Accessing an empty Speed Dial bin will return an error tone.
- Speed Dial numbers can reference a specific CO/IP Group entered by the user. If the assigned line is busy, a line from the same group will be selected. If all lines in the group are busy, the user may queue for the next available line.
- All Speed Dial numbers are stored in protected memory in case of power loss.
- A name can be entered for a Speed Dial number to permit access from the Dial-by-Name directory.

OPERATION

Digital Phone

To dial using a Station Speed Dial:

1. Lift handset or press the [SPEAKER] button.
2. Press the [SPEED] button.
3. Dial the desired bin number.

To program a Station Speed Dial number:

1. Press the [TRANS/PGM] button.
2. Press the [SPEED] button.
3. Dial the Speed Dial bin number.
4. Dial {CO/IP Line/Group Access code}.
5. Enter the number to be stored.
6. Press the [HOLD/SAVE] button.
7. If desired, enter a name (refer to the Alphanumeric Entry Chart on [page C-105](#)).
8. Press the [HOLD/SAVE] button.

To program a Station Speed Dial number using the 3-soft-key (LCD display phones):

1. Press the {DIR} Soft key.
2. Dial 1 or Press the {OK} Soft key.
3. Press the {ADD} Soft key.
4. Dial the Speed Dial bin number or Press the {OK} button.
5. Dial the {CO/IP Group Access code}.
6. Dial the number to be stored.
7. Press the [HOLD/SAVE] button.
8. If desired, enter a name (refer to the Alphanumeric Entry Chart on [page C-105](#)).
9. Press [HOLD/SAVE] button.

Single Line Phone

To dial using Station Speed Dial:

1. Lift handset.
2. Dial {SLT Speed Dial access code}.
3. Dial the desired bin number.

To program a Station Speed Dial number:

1. Dial {SLT Programming code}.
2. Dial {SLT Speed Dial access code}.
3. Dial the Speed Dial bin number.
4. Dial the {CO/IP Group Access code}.
5. Dial the number to be stored.
6. Press for hook-switch.
7. If desired, enter a name (refer to Alphanumeric Entry Chart on [page C-105](#)).
8. Press for hook-switch.

ADMIN PROGRAMMING

Station Data

Speed Access (TRANS/PGM 134-BTN 1) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
SPEED ACCESS -- gives station speed dial bins access authority.	1	0:Disable 1:Enable	Enable

Table Data

System Speed Dial Table (TRANS/PGM 257) ... see details on [page A-110](#)

TRANS/PGM 257	BTN	RANGE	DEFAULT
SYS SPD DIAL -- The System Speed Dial Digits.	1	Max 32 digits	-
SYS SPD NAME -- The System Speed Dial Name.	2	Max 16 characters	-
TOLL FREE -- Assignment to apply toll free.	3	0:Off 1:On	0:Off
TENANT NO -- The tenant number to be applied to the System Speed Access.	4	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

RELATED FEATURES

- Dial-by-Name ... see [page 3-60](#)
- Last Number Redial (LNR) ... see [page 3-110](#)
- Dial Pulse to Tone Switchover ... see [page 3-62](#)
- Saved Number Redial (SNR) ... see [page 6-18](#)
- Speed Dial Pause Insertion ... see [page 3-146](#)
- System Speed Dial ... see [page 3-150](#)

System Speed Dial

Commonly dialed numbers can be stored by the System Attendant or by the Administrator using Web Admin. for easy access to Stations allowed use of System Speed Dial bins. Each Speed Dial number can be up to 24 characters in length and may include special instruction codes.

Special instruction codes are:

- Flash as 1st digit: Activates dial tone detect.
- Pause [CALLBACK]: Inserts a pause dialing command.
- * not 1st digit: Switches from Pulse to DTMF dialing.
- Digital Phone users may assign a Flex button for One-Touch access to a specific System Speed Dial bin.

CONDITIONS

- Accessing an empty Speed Dial bin will return an error tone.
- Speed Dial numbers can reference a specific CO/IP Group entered by the user. If the assigned line is busy, a line from the same group will be selected. If all lines in the group are busy, the user may queue for the next available line.
- All Speed Dial numbers are stored in protected memory in case of power loss.
- A name can be entered for a Speed Dial number to permit access from the Dial-by-Name directory.

OPERATION

Digital Phone

To dial using a System Speed Dial:

1. Lift handset or press the [SPEAKER] button.
2. Press the [SPEED] button.
3. Dial the desired bin number

Single Line Phone

To dial using a System Speed Dial:

1. Lift handset.
2. Dial {SLT Speed Dial access code}.
3. Dial the desired bin number

Attendant

To program a System Speed Dial number:

1. Press the [TRANS/PGM] button.
2. Press the [SPEED] button.
3. Dial the Speed Dial bin number
4. Dial the {CO/IP Group Access code}.
5. Dial the number to be stored.
6. Press the [HOLD/SAVE] button.
7. If desired, enter a name (refer to the Alphanumeric Entry Chart on [page C-105](#)).
8. Press the [HOLD/SAVE] button.

To program a Station Speed Dial number using the 3-soft-key (LCD display phones):

1. Press the {DIR} Soft key.
2. Dial 1 or Press the {OK} Soft key.
3. Press the {ADD} Soft key.
4. Dial the Speed Dial bin number or Press the {OK} button.
5. Dial the {CO/IP Group Access code}.
6. Dial the number to be stored.
7. Press the [HOLD/SAVE] button.
8. If desired, enter a name (refer to Alphanumeric Entry Chart on [page C-105](#)).
9. Press [HOLD/SAVE] button.

ADMIN PROGRAMMING*Station Data*

Speed Access (TRANS/PGM 134 - FLEX 1) [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
SPEED ACCESS -- gives station speed dial bins access authority.	1	0:Disable 1:Enable	Enable

Table Data

System Speed Dial Table (TRANS/PGM 257) [page A-110](#)

TRANS/PGM 257	BTN	RANGE	DEFAULT
SYS SPD DIAL -- The System Speed Dial Digits.	1	Max 32 digits	-
SYS SPD NAME -- The System Speed Dial Name.	2	Max 16 characters	-
TOLL FREE -- Assignment to apply toll free.	3	0: Off 1: On	0: Off
TENANT NO -- The tenant number to be applied to the System Speed Access.	4	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

RELATED FEATURES

Dial-by-Name ... see [page 3-60](#)

Last Number Redial (LNR) ... see [page 3-110](#)

Dial Pulse to Tone Switchover ... see [page 3-62](#)

Saved Number Redial (SNR) ... see [page 6-18](#)

Speed Dial Pause Insertion ... see [page 3-146](#)

System Speed Dial ... see [page 3-150](#)

Station Call Coverage

The DN button at a Station can be set for incoming calls only by disabling outgoing calls. If the MADN-type DN button has a delayed ring option, the button will operate as a call coverage button. This feature must be programmed by the Administrator; individual users cannot set this feature.

OPERATION

If Programmed, Station Call Coverage is automatic.

ADMIN PROGRAMMING

Station

Station Number Type (TRANS/PGM 130 - FLEX 1) ... see details on [page A-31](#)

Flex Button Assign (TRANS/PGM 126) ... see details on [page A-29](#)

DN Flex Button Ring Option (TRANS/PGM 126 - FLEX 2) ... see details on [page A-30](#)

DN Flex Button Access (TRANS/PGM 126 - FLEX 3) ... see details on [page A-30](#)

System Groups

Stations can be grouped for call routing, dialing, call pick-up, or other various purposes. The following groups can be defined:

Station Group: Terminal / Circular / Ring / Longest Idle / VM

Pilot Hunt Group

Pick-Up Group

PTT Group

Command Conference Group

Interphone Group

Paging Group

Station Group

Stations can be grouped so incoming calls may be routed to an idle station in the group. The different types of Station Groups are described:

- Terminal Group – Calls to a station in a Terminal Station Group that encounter an unavailable or go unanswered will be routed through the hunt process. The call will proceed to the next listed station in the group until reaching the last listed station. The queued call may be taken out of the group if set to forward to an overflow destination.
- Circular Group – Calls to a station in the Circular Group will go to the station, if unavailable or unanswered in the hunt no answer time; the call will be directed to the next station defined in the group. The call will continue to hunt until each station in the group has been tried. The queued call may be taken out of the group if set to forward to an overflow destination.
- Ring Group – An incoming call to any station in the Group will cause all stations in the group to ring, and any station in the group may answer the call. Multiple calls can be received by a Station Ring Group and can be serviced in any order according to Station availability. The queued call may be taken out of the group if set to forward to an overflow destination.
- Longest Idle (UCD) Group – Calls are sent to the group by dialing the Hunt group Number or assigning CO lines to directly terminate at the group. Calls are directed to the Station in the group that has been idle for the longest time. If all stations in the group are busy when a call is received for the group, the call may be routed to an alternate location, or may continue to wait (queue) for a station in the group to become available. The queued call may be taken out of the group if set to forward to an overflow destination.
- Station VM Group – Can be enabled to support an external Auto Attendant/Voice Mail (AA/VM) system that employs SLT ports to interface with the system. An External AA/VM group is assigned for either Circular, Terminal, or Longest Idle hunt. The External AA/VM may employ either in-band signaling over the audio channel or SMDI protocol with a signaling connection to the System RS-232 channel.

CONDITIONS

- Station Group calls are not routed to member stations that are in DND.
- A call transferred to a Station Group will follow the routing for the group and will not initiate the Transfer Recall process.
- Calls to a Station Group receive either a ring-back tone or MOH while queued to the group.
- Calls can be routed to the defined Overflow destination according to Forward type, Station, Group, etc. If Forward type is set to NOT USED, the call is dropped about each Forward case.
- Stations can be a member of one or more Station Groups (Multiple Member Assignment).
- A User can program Queue Count for each member of the Station group (0-99).
- The System can provide a call to a group member during the Greeting according to the Call in Greeting option.
- A User can assign a Group Name for each Station Group.

OPERATION

When programmed, Station Group operation is automatic.

To pick-up a call that comes in to the Station Group:

1. When a call is ringing in to the Group, lift handset or press the [SPEAKER] button.
2. Stations can be set to be Disabled, receive All calls, receive Intercom calls, or to receive External calls.

ADMIN PROGRAMMING

Station

DND Access (TRANS/PGM 132 - FLEX 4) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
DND ACCESS -- enables DND to be activated by the station.	4	0: Disable 1: Enable	Enable

Station Group

Executive/Secretary Assign (TRANS/PGM 241) ... see details on [page A-102](#)

TRANS/PGM 241	BTN	RANGE	DEFAULT
EXECUTIVE NUMBER -- Assigns Executive station.	1	-	-
SECRETARY ASSIGN -- Assigns Secretary stations; enter secretary station range, or press FLEX 1-3 and enter station number to assign.	2	FLEX 1-3	-
ICM CALL TO EXEC -- Determines call forwarding when Executive/Secretary is in use. SECRETARY: all internal calls to the Exec. Station (except for calls from executives having executive access privilege) are routed to the Secretary station regardless of the Executive station status. SEC IF EXEC IN DND: internal calls are routed to secretary when executive is in 'DND'.	3	0:Secretary 1:Secretary if Executive in DND	0:Secretary
CO CALL TO EXEC -- Determines call forwarding when Executive/Secretary is in use. SECRETARY: all incoming CO calls to the Exec. Station are routed to the Secretary station regardless of the Executive status. SEC IF ECEC DND: incoming CO calls are routed to secretary when executive is in 'DND'.	4	0:Secretary 1:Secretary if Executive in DND	0:Secretary
CALL EXECUTIVE -- This option is to directly route calls to the Executive station. OFF: executive calls are routed to secretary. FIRST SEC. DND: the executive receives call when first secretary is in 'DND'. ALL SEC. DND: the executive receives call when all secretaries in 'DND'.	5	0-2	0
SECRETARY CHOICE -- Determines order in which secretary stations will receive calls (First Idle/Longest Idle).	6	0-1	0
MSG WAIT STATION -- Determines if message wait indication is left at Executive Station or Secretary. EXECUTIVE: message left at Executive station. FIRST SEC: message is left at the first secretary.	7	0:Executive 1:First Secretary	0

Executive/ Executive Access (TRANS/PGM 242) ... see details on [page A-103](#)

Station Group (TRANS/PGM 200) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
GROUP TYPE -- this entry defines the type of station group.	1	0: Not Assign 1: Terminal 2: Circular 3: Ring 4: Longest Idle 5: Voice Mail	Not Assign
GROUP NAME -- this entry defines the name of a group.	2	Max 16 chars	-
TENANT NO -- this entry assigns a tenant of a station group.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE IDX -- Time Table index,	4	1-9	1
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable
MEMBER ASSIGN -- this entry assigns stations as members of a station group.	6	-	-

Station Group Greeting/Queuing Attribute (TRANS/PGM 201) ... see details on [page A-65](#)

TRANS/PGM 201	BTN	RANGE	DEFAULT
GREETING TYPE -- this entry defines the type of greeting tone.	1	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10: SLT MOH1 11: SLT MOH2 12: SLT MOH3 13: SLT MOH4 14: SLT MOH5	1
GREETING PLAY -- this entry defines greeting play time.	2	000-180 (secs)	000

TRANS/PGM 201	BTN	RANGE	DEFAULT
GREETING TONE NO -- This entry defines greeting tone number in case greeting type is normal.	3	01-19	Not Assigned
GREETING PRT/ANNC -- This entry defines greeting prompt / annc. Number in case greeting type is PROMPT/ANNC.	4	001-255	Not Assigned
GREETING REPEAT NO -- This entry defines greeting repeat number.	5	000-100	3
GREETING RPT DELAY -- This entry defines the pause timer before greeting repeat.	6	000-100 (secs)	0
QUEUING TYPE -- This entry defines the type of queuing tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	3
QUEUING TIMER -- This entry defines the timer for queuing forward or second queuing announcement.	8	000-300 (secs)	30
QUEUING TONE NO -- This entry defines queuing tone number in case queuing type is normal.	9	01-19	Not Assigned
QUEUING PRT/ANNC -- This entry defines queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	10	001-255	Not Assigned
QUEUING REPEAT NO -- This entry defines queuing repeat number.	11	000-100	3
QUEUING RPT DELAY -- This entry defines the pause timer before queuing repeat.	12	000-100 (secs)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0
MOH FOR ANNC. -- This entry defines MOH option during queuing annc. Pause time.	14	01-12	none

TRANS/PGM 201	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	15	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
SECOND Q. TIMER -- This entry defines the timer for forward destination.	16	000-300 (secs)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	17	01-19	Not Assigned
SECOND PRT/ANNC -- This entry defines second queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	18	001-255	Not Assigned
SECOND REPEAT NO -- This entry defines second queuing repeat number.	19	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	20	000-100 (secs)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	21	0-1	0
MOH FOR ANNC, -- This entry defines MOH option during second queuing annc. Pause time.	22	01-12	none

Station Group Attributes (TRANS/PGM 202) ... see details on [page A-68](#)

TRANS/PGM 202	BTN	RANGE	DEFAULT
CALL IN GREETING -- This entry defines if a call is routed to a destination during greeting tone is played.	1	0: After Greeting 1. In Greeting	After Greeting
MAX QUEUE COUNT -- This entry defines queue count.	2	00-99	00

TRANS/PGM 202	BTN	RANGE	DEFAULT
FORWARD TYPE -- This entry defines forward type. 0. Not used 1. Unconditional: a call is routed to a forward destination unconditionally. 2. Queuing overflow: a call is routed to a forward destination when a queue is overflow. 3. Timeout: a call is routed to a forward destination when a timeout timer is expired. 4. All: a call is routed to a forward destination when a queue is overflow or Timeout timer is expired.	3	0: 1: Uncond 2: Q Overflow 3: Time out 4: All	Not Used
APPLY TIME TYPE -- This entry defines a time to apply forward type.	4	0: ALL 1: DAY 2: NIGHT 3: TIMED	ALL
FWD DESTINATION -- This entry defines a forward destination. (Trunk access code should be included).	5	Max 16 digits	None
WRAP UP TMR -- This entry defines a wrap up timer. A member is available when this timer is expired after a member goes to idle.	6	000-600	010
MEMBER NO ANS TMR -- This entry defines no answer timer about each member. If this timer is expired, a call is routed to the next member.	7	05-60	15
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer is expired, a call is routed to the forward destination according to forward type.	8	0-180	0
PROVIDE ANNC.-- This entry defines if system answer the call when a greeting or queuing announcement is provided	9	0: With Answer 1: W/o Answer	With Answer

VM Group Attributes (TRANS/PGM 203) ... see details on [page A-69](#)

TRANS/PGM 203	BTN	RANGE	DEFAULT
VM PUT MAIL INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Put Mail" dial code.	1	1-9	1
VM GET MAIL INDEX --For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Get Mail" dial code.	2	1-9	2
VM BUSY INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Busy" dial code.	3	1-9	3

TRANS/PGM 203	BTN	RANGE	DEFAULT
VM NO ANSWER INDEX -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "No answer" dial code.	4	1-9	4
VM DISCONNECT -- For external analog Voice Mail groups, an index to the Voice Mail Dial Table, which contains the "Disconnect" dial code.	5	1-9	9
SMDI TYPE -- This entry defines SMDI Type.	6	0: Type 1 1: Type 2	Type 1
SMDI CLI INFO -- This entry defines SMDI CLI Information. If this is enable, system sends SMDI with CLI.	7	0: Off 1: On	Off

Table Data

Announcement Table (TRANS/PGM 259) ... see details on [page A-111](#)

TRANS/PGM 259	BTN	RANGE	DEFAULT
The VMIB slot & Prompt No. to be used for playing the VMIB Announcement No.	1-4	VMIB Slot (00-18) & Prompt No (01-70)	-
CCR Index used for playing the VMIB Announcement No.	5	1-100	-

Tenant Data

Tone Table ... use *Web Admin* (TRANS/PGM 290)

Numbering Plan

Station Group Number (TRANS/PGM 115) ... see details on [page A-22](#)

TRANS/PGM 115	BTN	RANGE	REMARK
STATION GROUP RANGE (Edit by Range)	1	Start Station Group Number & End Station Group Number	-
STATION GROUP NUMBER (Edit)	2	Station Group Number	-

RELATED FEATURES

- Executive/Secretary ... see [page 3-85](#)
- Music On Hold ... see [page 3-123](#)
- Call Forward ... see [page 3-15](#)
- VMIB Integrated ... see [page 3-258](#)
- Auto Attd/Voice Mail ... see [page 3-258](#)

HARDWARE

Digital Phone


Greeting/Queuing Tone Service

The System can provide a Greeting tone or Queuing tone when a call is routed to Station Group. When a call is routed to Station Group, the pre-assigned Greeting or Queuing Tone will be provided to the caller. The tone will be provided according to the Tone Time/Delay Time/Repeat counters. There are 7 types of Tones:

- NORMAL - System Tone (01-19, Tone Freq. in TRANS/PGM 264)
- PROMPT - VMIB Prompt
- ANNOUNCEMENT - VMIB Announcement
- INT MOH
- EXT MOH
- VMIB MOH (1-4 for MBX IP-300, 1-3 for MBX IP-100)
- SLT MOH (1-5)

OPERATION

If set, Greeting/Queuing Tone Service operation is automatic.



ADMIN PROGRAMMING

Tenant Data

Attendant Group Attribute (TRANS/PGM 271-272) ... see details on [page A-118](#)

TRANS/PGM 271	BTN	RANGE	DEFAULT
GREETING TYPE -- Determines the type of Greeting Tone to be used.	1	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	1: Normal
GREETING PLAY -- Determines the Greeting Play time.	2	000-180 (sec)	000
GREETING TONE NO --- Determines the Greeting Tone number when greeting type is set to Normal.	3	01-19	04
GREETING PROMPT/ANNC -- Determines the Greeting Prompt/ Announce Number when Greeting Type is set to Prompt or Announce.	4	001-255	Not Asg
GREETING REPEAT NO -- Determines the number of times the Greeting will repeat.	5	000-100	3
GREETING RPT DELAY -- Determines the length of time the timer will pause before the greeting is repeated.	6	000-100 (seconds)	0

TRANS/PGM 271	BTN	RANGE	DEFAULT
QUEUING TYPE -- Determines the type of Queuing Tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
QUEUING TIMER -- Determines the Greeting/Queuing Timeout Timer.	8	010-300 (sec)	030
QUEUING TONE NO -- Determines the Queuing Tone number used when Queuing Type is set to Normal.	9	01-19	00
QUEUING PROMPT ANNC -- Determines the Queuing Prompt/ Announce Number when the Queuing Type is set to Prompt or Announce.	10	001-255	Not Asg
QUEUING REPEAT NO -- determines the Queuing Repeat number.	11	000-100	3
GREETING RPT DELAY -- Determines the Pause Timer before Queuing is repeated.	12	000-100 (seconds)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0

TRANS/PGM 271	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	14	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10: SLT MOH1 11: SLT MOH2 12: SLT MOH3 13: SLT MOH4 14: SLT MOH5	4: INT MOH
SECOND Q. TIMER -- This entry defines the timer for forward destination.	15	000-300 (seconds)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	16	01-19	Not Asg
SECOND PRT ANNCThis entry defines second queuing prompt / annc.Number in case queuing type is PROMPT/ANNC.	17	001-255	Not Asg
SECOND REPEAT NO -- This entry defines second queuing repeat number.	18	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	19	000-100 (seconds)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	20	0-1	0

TRANS/PGM 272	BTN	RANGE	DEFAULT
CALL IN GREETING -- Determines if call is routed to the Attendant when Greeting Tone is played.	1	0: After Greeting 1: In Greeting	1: In Greeting
MAX QUEUE COUNT -- Determines the Queue count.	2	00-99	05

TRANS/PGM 272	BTN	RANGE	DEFAULT
FORWARD TYPE -- Determines the Forward type to use. 0: Not used 1: Unconditional - call is routed to a forward destination unconditionally. 2: Queuing overflow - call is routed to a forward destination when a queue overflows. 3: Queuing timeout - call is routed to a forward destination when queuing time expires. 4: Queuing all - call is routed to a forward destination when a queue overflows or queuing time expires.	3	0: Not Used 1: Uncond 2: Q Overflow 3: Time out 4: All	0: Not Used
APPLY TIME TYPE -- Determines the time setting for applying the Forward type.	4	0: All 1: Day 2: Night 3: Timed	0: All
FWD DESTINATION -- Determines the forward destination (trunk access code should be included).	5	Max 16 digits	-
WRAP UP TMR -- Determines the Wrap-up Timer; a member is available when this timer expires after a member goes to idle.	6	000-600 (100ms)	5
MEMBER NO ANS TMR -- Determines the No Answer timer; if this timer expires, a call is routed to the next attendant	7	05-60 (seconds)	15
ATD CALL BY STA NO -- This entry defines attendant call by dialing attendant member. 0 : the call for attendant follows normal call. 1: the call for attendant follows attendant group call	8	-	Off
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer expires, a call is routed to the forward destination according to forward type.	9	0-180 (seconds)	0
PROVIDE ANNC-- This entry defines if system answer the call when a greeting or queuing announcement is provided.	10	0: With Answer 1: W/O Answer	0: With Answer

Table Data

Tone Frequency/Cadence (TRANS/PGM 264) ... see details on [page A-114](#)

CCR Service with Queuing Announcement

The System can provide CCR Service during queuing announcement according to the CCR option.

A CCR Table defines a dialed digit (0-9, #, and *) to a designated route; each individual digit corresponds with a route:

- Station
- Station Group
- CO Group Access Code
- Internal Page Zone
- Voice Mail Access Code
- CCR Access Code + VMIB Announcement
- CCR Access and Drop Code + VMIB Announcement
- Conference Room
- Net Number

In addition, the System will monitor digits for a system numbering plan(eg station number). if the User dials a Station number, Group Queuing Service is finished and a call is routed to the dialed destination .

OPERATION

If set, Greeting/Queuing Tone Service operation is automatic.

CONDITIONS

- SIP/ISDN Terminal does not support CCR feature.

ADMIN PROGRAMMING

Tenant Data

Station Group Attribute (TRANS/PGM 201-202) ... see details on [page A-65](#) and [page A-68](#)

TRANS/PGM 201	BTN	RANGE	DEFAULT
GREETING TYPE -- this entry defines the type of greeting tone.	1	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10: SLT MOH1 11: SLT MOH2 12: SLT MOH3 13: SLT MOH4 14: SLT MOH5	1
GREETING PLAY -- this entry defines greeting play time.	2	000-180 (secs)	000
GREETING TONE NO -- This entry defines greeting tone number in case greeting type is normal.	3	01-19	Not Assigned
GREETING PRT/ANNC -- This entry defines greeting prompt / annc. Number in case greeting type is PROMPT/ANNC.	4	001-255	Not Assigned
GREETING REPEAT NO -- This entry defines greeting repeat number.	5	000-100	3
GREETING RPT DELAY -- This entry defines the pause timer before greeting repeat.	6	000-100 (secs)	0

TRANS/PGM 201	BTN	RANGE	DEFAULT
QUEUING TYPE -- This entry defines the type of queuing tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	3
QUEUING TIMER -- This entry defines the timer for queuing forward or second queuing announcement.	8	000-300 (secs)	30
QUEUING TONE NO -- This entry defines queuing tone number in case queuing type is normal.	9	01-19	Not Assigned
QUEUING PRT/ANNC -- This entry defines queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	10	001-255	Not Assigned
QUEUING REPEAT NO -- This entry defines queuing repeat number.	11	000-100	3
QUEUING RPT DELAY -- This entry defines the pause timer before queuing repeat.	12	000-100 (secs)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0
MOH FOR ANNC. -- This entry defines MOH option during queuing annc. Pause time.	14	01-12	none

TRANS/PGM 201	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	15	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
SECOND Q. TIMER -- This entry defines the timer for forward destination.	16	000-300 (secs)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	17	01-19	Not Assigned
SECOND PRT/ANNC -- This entry defines second queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	18	001-255	Not Assigned
SECOND REPEAT NO -- This entry defines second queuing repeat number.	19	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	20	000-100 (secs)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	21	0-1	0
MOH FOR ANNC, -- This entry defines MOH option during second queuing annc. Pause time.	22	01-12	none

TRANS/PGM 202	BTN	RANGE	DEFAULT
CALL IN GREETING -- This entry defines if a call is routed to a destination during greeting tone is played.	1	0: After Greeting 1. In Greeting	After Greeting
MAX QUEUE COUNT -- This entry defines queue count.	2	00-99	00

TRANS/PGM 202	BTN	RANGE	DEFAULT
FORWARD TYPE -- This entry defines forward type. 0. Not used 1. Unconditional: a call is routed to a forward destination unconditionally. 2. Queuing overflow: a call is routed to a forward destination when a queue is overflow. 3. Timeout: a call is routed to a forward destination when a timeout timer is expired. 4. All: a call is routed to a forward destination when a queue is overflow or Timeout timer is expired.	3	0: 1: Uncond 2: Q Overflow 3: Time out 4: All	Not Used
APPLY TIME TYPE -- This entry defines a time to apply forward type.	4	0: ALL 1: DAY 2: NIGHT 3: TIMED	ALL
FWD DESTINATION -- This entry defines a forward destination. (Trunk access code should be included).	5	Max 16 digits	None
WRAP UP TMR -- This entry defines a wrap up timer. A member is available when this timer is expired after a member goes to idle.	6	000-600	010
MEMBER NO ANS TMR -- This entry defines no answer timer about each member. If this timer is expired, a call is routed to the next member.	7	05-60	15
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer is expired, a call is routed to the forward destination according to forward type.	8	0-180	0
PROVIDE ANNC.-- This entry defines if system answer the call when a greeting or queuing announcement is provided	9	0: With Answer 1: W/o Answer	With Answer

Table Data

Tone Frequency/Cadence (TRANS/PGM 264) ... see details on [page A-114](#)

Announcement Table (TRANS/PGM 259) ... see details on [page A-111](#)

TRANS/PGM 259	BTN	RANGE	DEFAULT
The VMIB slot & Prompt No. to be used for playing the VMIB Announcement No.	1-4	VMIB Slot (00-18) & Prompt No (01-70)	-
CCR Index used for playing the VMIB Announcement No.	5	1-100	-

CCR Table (TRANS/PGM 260) ... see details on [page A-112](#)

TRANS/PGM 260	BTN	RANGE	DEFAULT
CCR TABLE -- The destination of CCR input digit; the destination can be a Station number, Station group number or Feature code. NOTE: For Feature codes, refer to the Numbering Plan for the applicable codes.	1-12	Max 8 digits	-

Forward Destination, Overflow Service

This can be assigned as Station/Hunt Group/Telephone Number, covering Station Group Call according to the Forward type of the Station Group. There are 4 kinds of Forward type in an Station Group:

- Unconditional
- Queuing Overflow
- Queuing Timeout
- Queuing Overflow or Queuing Timeout

The Overflow Destination can be programmed as Station/Station Group/External number/NET Destination.

OPERATION

To use the Unconditional Forward Overflow Destination:

1. Dial the {Station Group Number}.
2. The Call is Routed to the Forward Destination.

To use the Queuing Overflow Forward Destination:

1. Dial the {Station Group Number}.
2. The Call is Queued when all Member Stations are in Busy mode.

NOTE: The Call will be Routed to the Forward Destination when max. queue has been Overflowed.

To use Queuing Timeout Forward Destination:

3. Dial the {Station Group Number}.
4. The call is Queued when all Member Stations are in Busy mode.

NOTE: Calls will be Routed to the Forward Destination when Queuing Time has expired.

To use Queuing Overflow or Timeout as Forward Destination:

5. Dial the {Station Group Number}.
6. The Call is Queued when all Member Stations are in Busy mode.

NOTE: The Call will be routed to the Forward destination when Queuing Time expires or Max. Queue is overflowed.

ADMIN PROGRAMMING

Tenant Data

Station Group Attribute (TRANS/PGM 201-202) ... see details on [page A-65](#) and [page A-68](#)

TRANS/PGM 201	BTN	RANGE	DEFAULT
GREETING TYPE -- this entry defines the type of greeting tone.	1	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10: SLT MOH1 11: SLT MOH2 12: SLT MOH3 13: SLT MOH4 14: SLT MOH5	1
GREETING PLAY -- this entry defines greeting play time.	2	000-180 (secs)	000
GREETING TONE NO -- This entry defines greeting tone number in case greeting type is normal.	3	01-19	Not Assigned
GREETING PRT/ANNC -- This entry defines greeting prompt / annc. Number in case greeting type is PROMPT/ANNC.	4	001-255	Not Assigned
GREETING REPEAT NO -- This entry defines greeting repeat number.	5	000-100	3
GREETING RPT DELAY -- This entry defines the pause timer before greeting repeat.	6	000-100 (secs)	0

TRANS/PGM 201	BTN	RANGE	DEFAULT
QUEUING TYPE -- This entry defines the type of queuing tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	3
QUEUING TIMER -- This entry defines the timer for queuing forward or second queuing announcement.	8	000-300 (secs)	30
QUEUING TONE NO -- This entry defines queuing tone number in case queuing type is normal.	9	01-19	Not Assigned
QUEUING PRT/ANNC -- This entry defines queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	10	001-255	Not Assigned
QUEUING REPEAT NO -- This entry defines queuing repeat number.	11	000-100	3
QUEUING RPT DELAY -- This entry defines the pause timer before queuing repeat.	12	000-100 (secs)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0
MOH FOR ANNC. -- This entry defines MOH option during queuing annc. Pause time.	14	01-12	none

TRANS/PGM 201	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	15	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
SECOND Q. TIMER -- This entry defines the timer for forward destination.	16	000-300 (secs)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	17	01-19	Not Assigned
SECOND PRT/ANNC -- This entry defines second queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	18	001-255	Not Assigned
SECOND REPEAT NO -- This entry defines second queuing repeat number.	19	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	20	000-100 (secs)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	21	0-1	0
MOH FOR ANNC, -- This entry defines MOH option during second queuing annc. Pause time.	22	01-12	none

TRANS/PGM 202	BTN	RANGE	DEFAULT
CALL IN GREETING -- This entry defines if a call is routed to a destination during greeting tone is played.	1	0: After Greeting 1. In Greeting	After Greeting
MAX QUEUE COUNT -- This entry defines queue count.	2	00-99	00

TRANS/PGM 202	BTN	RANGE	DEFAULT
FORWARD TYPE -- This entry defines forward type. 0. Not used 1. Unconditional: a call is routed to a forward destination unconditionally. 2. Queuing overflow: a call is routed to a forward destination when a queue is overflow. 3. Timeout: a call is routed to a forward destination when a timeout timer is expired. 4. All: a call is routed to a forward destination when a queue is overflow or Timeout timer is expired.	3	0: 1: Uncond 2: Q Overflow 3: Time out 4: All	Not Used
APPLY TIME TYPE -- This entry defines a time to apply forward type.	4	0: ALL 1: DAY 2: NIGHT 3: TIMED	ALL
FWD DESTINATION -- This entry defines a forward destination. (Trunk access code should be included).	5	Max 16 digits	None
WRAP UP TMR -- This entry defines a wrap up timer. A member is available when this timer is expired after a member goes to idle.	6	000-600	010
MEMBER NO ANS TMR -- This entry defines no answer timer about each member. If this timer is expired, a call is routed to the next member.	7	05-60	15
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer is expired, a call is routed to the forward destination according to forward type.	8	0-180	0
PROVIDE ANNC.-- This entry defines if system answer the call when a greeting or queuing announcement is provided	9	0: With Answer 1: W/o Answer	With Answer

Pilot Hunt Group

A Station can be grouped for Pilot Hunt Feature. Users may select incoming calls in the group to re-route to other stations (local or networked), station groups, the VMIB according to ring mode (Day/Night/Timed). A member of the Pilot Hunt Group may have Pilot Hunt Ring Access authority set for call coverage on another member Station in a group.

CONDITIONS

- Pilot Hunt Ring Access of a member should be enabled to receive the Pilot Hunt Group calls.
- Pilot Hunt Group members can register a Forward as a Day destination using the {Pilot H. CFW Register} feature code.
- If a Station's busy service is set to Pilot Hunt and the Station is in conversation with an internal/external party, and another station calls, the call is routed to an idle member in the same Pilot Hunt.

OPERATION

If programmed, Pilot Hunt Group is automatic.

ADMIN PROGRAMMING

Numbering Plan

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

Station Data

Call Forward Access (TRANS/PGM 132 - FLEX 2) ... see details on [page A-33](#)

TRANS/PGM 132	BTN	RANGE	DEFAULT
FORWARD ACCESS -- enables Call Forward to be activated by the station.	2	0: Disable 1: Enable	Enable

Pilot Hunt Ring Access (TRANS/PGM 134 - FLEX 6) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
PILOT HUNT RING -- permits station to receive pilot hunt ring.	6	0:Disable 1:Enable	Enable

Busy Service (TRANS/PGM 131 - FLEX 5) ... see details on [page A-32](#)

TRANS/PGM 131	BTN	RANGE	DEFAULT
BUSY SVC-- when an SLT extension attempts to transfer a CO call to a CO line it is blocked and the call is released.	5	0:Busy Tone 1:Camp-on 2:Call Wait 3:Pilot Hunt	Busy Tone

CO Line Data

Incoming CO Alternate (TRANS/PGM 169) ... see details on [page A-53](#)

TRANS/PGM 169	BTN	RANGE	DEFAULT
Incoming CO Alternataive DAY --	1	F1: Busy F2: No Answer	Disconnect 1 sec
NIGHT --	2	F3: Invalid F4: Transfer No Answer F5: Recall No Answer	Disconnect 1 sec
TIMED --	3	F6: DND F7: Out Of Service F8: Error 1: Disconnect 2: Attendant 3: CO Ring 4: Alt Ring Table 5: Tone 6: Pilot HuntGroup	Disconnect 1 sec

Outgoing CO Alternate (TRANS/PGM 173) ... see details on [page A-57](#)

TRANS/PGM 173	BTN	RANGE	DEFAULT
DAY ALT DEST -- Abnormal case can be selected as error type.	-	F1: Recall No Answer F2:Transfer No Answer F3: No Answer	-
NO ANSWER DISCONNECT-- The CO call is disconnected. Every destination is set to 'Disconnect' by default.	1	-	-
NO ANSWER ATTENDANT -- The CO call is routed to Attendant.	2	-	-

TRANS/PGM 173	BTN	RANGE	DEFAULT
NO ANSWER CO RING ASSIGN -- The CO call is routed according to Ring Assign Table. (see TRANS/PGM 167)	3	-	-
NO ANSWER ALT RING TBL -- If destination is set to Alt Ring Table and the Table index is assigned, the CO call is routed according to Alt Ring Table. (See TRANS/PGM 181)	4	01-80	-
NO ANSWER TONE -- If destination is set to Tone, the Error / Busy tone is heard.	5	-	-
NO ANSWER PILOT HUNT GROUP -- The CO call is routed to Pilot Hunt Group of the original destination.	6	-	-
NO ANSWER RING -- The call is routed to the same destination again.	7	-	-
NO ANSWERThe CO call is routed to the transferred station again. Only possible for 'Transfer No Answer' case.	8	-	-

Station Group

Pilot Hunt Group (TRANS/PGM 210) ... see details on [page A-74](#)

TRANS/PGM 210	BTN	RANGE	DEFAULT
CONDITION -- Determines call coverage condition for Pilot Hunt group.	1	0: ALL 1: Intercom 2: External	All
SERVICE TYPE -- This entry defines Service Type. (Terminal/Circular)	2	0: Terminal 1: Circular	Terminal
TIME TABLE INDEX -- Time Table index.	3	1-9	1
MEMBER ASG --Assigns stations as members of a Pilot Hunt group.	4	-	-

Pilot Group Forward Attributes (TRANS/PGM 211) ... see details on [page A-17](#)

TRANS/PGM 211	BTN	RANGE	DEFAULT
DAY FORWARD TYPE -- determines Day time seting for Call Forward type.	1	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
DAY FORWARD DESTINATION -- determines Day time seting for Forward destination.	2	Max. 8 digits	-
NIGHT FORWARD TYPE -- determines the Night time seting for Call Forward type.	3	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
NIGHT FORWARD DESTINATION -- determines the Night time seting for Forward destination.	4	Max. 8 digits	-
TIMED FORWARD TYPE -- determines the Timed seting for Forward type.	5	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
TIMED FWD DESTINATION -- determines the Timed seting for Forward destination.	6	Max. 8 digits	-

Table Data

Ring Table use Web Admin (TRANS/PGM 265)

RELATED FEATURES

Call Forward Pilot Hunt ... see [page 3-19](#)

Pick Up Group

A Station can be assigned to a Call Pick-Up group and may pick-up (answer) calls to other stations in the group employing the System's Group Call Pick-Up feature.

Station Groups can be added as Pick -Up Groups with Pick-Up Attributes. Pick-up Groups can be set to pick-up all calls, internal calls only or external calls only.

OPERATION

To use Group Call Pickup:

Dial the {Group Call Pick Up} feature code.

To use Direct Call Pickup:

1. Dial {Direct Call Pick Up} feature code.
2. Dial DN number to pick up the call.

ADMIN PROGRAMMING

Station Group

Station Group (TRANS/PGM 200 - FLEX 5) ... see details on [page A-64](#)

TRANS/PGM 200	BTN	RANGE	DEFAULT
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable

Pickup Group (TRANS/PGM 204) Numbering Plan ... see details on [page A-70](#)

TRANS/PGM 204	BTN	RANGE	DEFAULT
PICK UP CONDITION -- this entry defines pick up condition. (All/Internal/External)	1	0: All Call 1: Int Call 2: Ext Call	All Call
PICK UP MEMBER ASG -- assigns stations as members of a station pickup group.	2	-	-

Group Pick-Up Code (TRANS/PGM 113) ... see details on [page A-18](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
33	Group Call Pickup	564

RELATED FEATURES

Group Call Pick-Up ... see [page 3-28](#)

Push To Talk (PTT) Group

Each Phone can be assigned as a member of one or more of the System Push-To-Talk (PTT) groups. The Phone user may log-in or log-out of any one, or all PTT groups to which it is assigned. Once logged in, the user may place or receive one-way page announcements to/from other users who are logged in to the same PTT group. Additionally, each user can log in or log out PTT group using the {PTT Group Log-In/Out Feature Code}.

CONDITIONS

- Only a SADN can be assigned as a member of Paging Group (PTT Group).
- SIP Stations cannot be assigned to Paging Groups.
- PTT Group 0 is a specific PTT Group, so if a member of the PTT group 0 tries to make a PTT announcement, all of the members in all of groups will receive the announcement. Additionally, each group member can make PTT calls, then all members of Group 0 will receive the announcement.

OPERATION

Log-in PTT Group with Feature Code:

1. Dial the {PTT Group Log-In/Out Feature Code}; the PTT Group status and registration will be displayed.
2. Dial a PTT Group Number.

Log-out PTT Group with Feature Code:

1. Dial {PTT Group Log-In/Out Feature Code}; the PTT Group status and registration will be displayed.
2. Dial * (Log-Out Code).

To make a PTT Group Call:

1. Press the programmed {PTT} button.
2. When finished, press the {PTT} button to end the call.

ADMIN PROGRAMMING*Station Group*

PTT Group (TRANS/PGM 208) Numbering Plan ... see details on [page A-73](#)

TRANS/PGM 208	BTN	RANGE	DEFAULT
PTT MEMBER ASG -- this entry assigns stations as members of a PTT group.	1	-	-

PTT Group Log In/Out (TRANS/PGM 113) ... see details on [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
46	PTT Group Access	524 + PTT Group # (0-9) + * (Log out)

Command Conference Group

A Station or external telephone number can be assigned as a member of a Command Conference Group.

Stations and external contacts (up to 12 members) can be arranged in groups so that a user may create a conference with all members of the group through a single call. Additionally, the user can make paging calls with same group.

There are 2 kinds of Command Conference Groups:

- **Command One Way:** A user can make announcements (paging) to members of the Command Group.
- **Command Conference:** A user can make conference calls with members of the Command Group.

On-Hook Service – An internal user can receive a command call while the Station is On-Hook. When an internal user receives a command group call and the call goes unanswered, the System will make a recall to the user station.

One- or Both-Way Busy – When an internal user receives command group call while in busy status, the command group call is ignored, and can be queued. When an internal user receives a command group call while in busy status, the current call will be disconnected and the command group call automatically is connected.

OPERATION

To initiate a Command Group (One Way):

1. Dial the {One Way Command Group Call} feature code.
2. Enter the Command Group number.

To initiate a Command Group Conference:

1. Dial the {Conference Command Group Call} feature code.
2. Enter the Command Group number.

ADMIN PROGRAMMING

Station Data

Command Group Access (TRANS/PGM 152) ... see details on [page A-44](#)

Station Group

Command Conference Group ... use Web Admin (TRANS/PGM 206)

Numbering Plan

Command Group (TRANS/PGM 113) ... see details on [page A-20](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
65	Command Call Conf	580

Interphone Group

To call Stations using a simple, one-touch digit, Stations can be gathered into an Interphone Group (up to 10 members).

OPERATION

To use the Interphone Group feature:

1. Dial {Interphone Group Access} feature code.
2. Dial One Digit.

ADMIN PROGRAMMING

Station Group

Interphone Group (TRANS/PGM 209) ... see details on [page A-73](#)

TRANS/PGM 209	BTN	RANGE	DEFAULT
DGT DESTINATION -- this entry defines the digit destination of Interphone group.	1	Station Number	-

Numbering Plan

Interphone Group Access Code (TRANS/PGM 113) ... see details on [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
56	Inter-Phone Group Access	534

Paging Group

A Station is permitted to access page facilities for each Paging Group, to connect and transmit voice announcements to any or all System Paging Groups.

CONDITIONS

- Only SADN can be assigned as the member of a Paging Group.
- SIP Station cannot be assigned as member of a Paging Group.

OPERATION

To perform an Internal Page:

1. Dial {INT Page code}.
2. Dial Page Group number (01 – 30). To perform an External Page: 1. Dial {EXT Page code}.

ADMIN PROGRAMMING*Station Data*

Page Access (TRANS/PGM 134 - FLEX 2) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
PAGE ACCESS -- permits station to make page.	2	0:Disable 1:Enable	Enable

Meet-Me Access (TRANS/PGM 134 - FLEX 3) ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
MEET ME ACCESS -- enables 'meet me' feature when there is a page.	3	0:Disable 1:Enable	Enable

Page Group Access (TRANS/PGM 151) ... see details on [page A-43](#)

Station Group

Page Group (TRANS/PGM 205) ... see details on [page A-71](#)

TRANS/PGM 205	BTN	RANGE	DEFAULT
PAGE MEMBER ASG -- assign stations as members of a Page group.	-	-	-

Numbering Plan

Internal Page Calling Answer Code (TRANS/PGM 113) ... see details on [page A-18](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
15	Internal Page Answer (Meet-Me Page)	547

Station Message Detail Recording (SMDR)

Call Cost Display

Each SMDR call record includes a Cost field; a calculated estimate for the cost of the call. When set, the call cost will update in real-time and display on the Digital Phone LCD in place of the call duration.

The cost is determined by:

- Fixed charge per Call Meter Pulse
- ISDN Advice of Charge
- Estimated cost updated based on the Elapsed Call Timer and any assigned costing.

The technique selected to determine cost is based on the type of facility (analog CO, ISDN, or VoIP), services provided by the carrier, and the system database.

Analog CO – When the Call Metering Pulse service is available from the carrier, the system will apply the SMDR Cost per Unit Pulse and the SMDR Decimal to Call Metering received to estimate call cost.

When no “Metering Type” is selected, the system call duration is used with the cost/pulse and decimal values to estimate the cost of the call. The cost is updated periodically using the “Elapsed Call Timer” duration.

ISDN – ISDN providers may support Advice of Charge information in the ISDN Facility Message. If assigned, the system will employ this information to display and output the call cost.

VoIP – For VoIP calls, the system employs the call duration, cost/pulse and decimal values to establish a call cost estimate. The cost is updated periodically at intervals of the Elapsed Call Timer.

CONDITIONS

- If enabled, Call Cost display begins after the SMDR Start Timer expires, or at receipt of the first Call Meter Pulse.
- Once connected to the system, the call duration includes the total time the call is connected including periods when the call is on hold, in queue, etc.
- To enable Call Cost Display, the SMDR Cost per Unit Pulse and SMDR Decimal must be assigned; when not assigned, call duration is provided by the System.
- SMDR MAX record message number is 5000; alarm message is automatically received at the Attendant Station if recorded number is 4000 or 4500.

OPERATION

System When set, Call Cost is estimated automatically and output to Digital Phone displays and the SMDR RS-232 port.

ADMIN PROGRAMMING*CO Line Data*

Metering Type (TRANS/PGM 160 - FLEX 12) ...see details on [page A-45](#)

TRANS/PGM 160	BTN	RANGE	DEFAULT
METERING TYPE -- According to PSTN service type, metering type can be selected among 00-12 to manage call charge. 01-06 can be applied to LCO lines, 07-12 can be applied to ISDN lines.	12	00: None 01: 12KHz 02: 16KHz 03: 50KHz 04: SPR 05: PPR 06: NPR 07: AOC 0(Standard) 08: AOC 1 (Italy & Spain) 09: AOC 2 (Finland) 10: AOC 3 (Australia) 11: AOC 4 (Belgium) 12: AOC 5 (Netherlands)	None

System Data

SMDR Cost per Unit Pulse (TRANS/PGM 232 - FLEX 8) ...see details on [page A-91](#)

TRANS/PGM 232	BTN	RANGE	DEFAULT
CURRENCY UNIT -- The unit of currency used for call cost can be identified with 3 alpha characters for easy reference.	8	Max 3 characters	-

SMDR Fraction (TRANS/PGM 232 - FLEX 9) ...see details on [page A-91](#)

TRANS/PGM 232	BTN	RANGE	DEFAULT
COST PER PULSE -- When metering is provided by the PSTN, the cost per metering pulse can be assigned.	9	6 digits	000000

RELATED FEATURES

Station Message Detail Recording (SMDR) ... see [page 3-187](#)

Traffic Analysis ... see [page 3-250](#)

CO/IP Call Warning Tone Timer ... see [page 3-43](#)

HARDWARE

RS-323 device to capture SMDR

SMDR Call Records

SMDR provides detailed information on incoming and outgoing calls. Assignable options in the System database permit recording of all calls, all outgoing calls or toll calls and calls that exceed a fixed duration. Call records are output either upon completion of the call (real-time) or in response to a request from the System Attendant. SMDR may be sent periodically via e-mail to a defined e-mail address.

The various fields or items for a Call Record are:

- 8-digit Station call originator (terminating for incoming) filed
- 3-digit used CO line field
- 8-digit call duration field (HH:MM:SS)
- 8-digit year, month, and day (YY/MM/DD)
- 7-digit time of day call originator field
- 1 digit call identification digit-first digit in digit dial field
- 24-digit collected dialed digit field

- 5-digit pulse metering count field
- 10-digit call cost field
- 12-digit account code field

OPERATION

System

For real-time SMDR, records are output after completion of the call.

System Attendant

To print SMDR records (based on Station range):

1. Press the [TRANS/PGM] button.
2. Dial 011 {SMDR Print code}.
3. Enter the desired station range.
4. Press the [HOLD/SAVE] button.

To delete stored SMDR records (based on Station range):

1. Press the [TRANS/PGM] button.
2. Dial 012 {SMDR delete code}.
3. Enter the desired station range.
4. Press the [HOLD/SAVE] button.

To print Non-Station Based SMDR records:

1. Press the [TRANS/PGM] button.
2. Dial 013 {SMDR Print code}.
3. Press the [HOLD/SAVE] button.

To delete Non-Station Based SMDR records:

1. Press the [TRANS/PGM] button.
2. Dial 014 {SMDR delete code}.
3. Press the [HOLD/SAVE] button.

To print ALL SMDR records (all of SMDR):

1. Press the [TRANS/PGM] button.
2. Dial 015 {SMDR print code}.
3. Press the [HOLD/SAVE] button.

To delete All SMDR records (all of SMDR):

1. Press the [TRANS/PGM] button.
2. Dial 016 {SMDR delete code}.
3. Press the [HOLD/SAVE] button.

ADMIN PROGRAMMING

System

SMDR Attributes (TRANS/PGM 232) ... see details on [page A-91](#)

TRANS/PGM 232	BTN	RANGE	DEFAULT
SMDR SERVICE -- SMDR Service Option. On-Line / Off-Line SMDR / SMDR-Interface / Email Service .can be enabled	1	0: Not Use 1: On-Line 2: Off-Line 3: On-Line/Off-Line 4: SMDR-Interface 5: SMDR E-Mail 6: Off-Line & E-Mail 7: On/Off-Line & E-Mail 8: Interface & E-Mail	0:Not Use
OUTGOING REPORT -- Outgoing Call Report Option for SMDR Service. If this option is set, outgoing call will be included at SMDR data	2	0:Off 1:On	0:Off
INCOMING REPORT -- Incoming Call Report Option for SMDR Service. If this option is set, incoming call will be included at SMDR data	3	0:Off 1:On	0:Off
ICM REPORT -- Internal Call Report Option for SMDR Service.If this option is set, internal call will be included at SMDR data	4	0:Off 1:On	0:Off
LOST CALL REPORT -- Outgoing or Incoming Lost Call Report Option for SMDR Service. If this option is set, CO lost call will be included at SMDR data	5	0:Off 1:On	0:Off
RECORD TYPE -- If set to on, LD calls are identified by the LONG DIST CALL DGT Counter; the system can record all outgoing calls or only long distance calls.	6	0:All Call 1:LD	0:All Call

TRANS/PGM 232	BTN	RANGE	DEFAULT
LONG DIST CALL DGT CNT -- Dialed numbers, which exceed the assigned LD Digit count, are considered long distance calls for SMDR.	7	07-15	07
CURRENCY UNIT -- The unit of currency used for call cost can be identified with 3 alpha characters for easy reference.	8	Max 3 characters	-
COST PER PULSE -- When metering is provided by the PSTN, the cost per metering pulse can be assigned.	9	6 digits	000000
SMDR FRACTION -- Determines the position of the decimal in the Cost per Pulse, starting from the right-most digit.	10	0-5	0
HIDDEN DIALED DGT -- Determines the number of dialed digits to hide for security purposes, and replaced with "*". Button 13 below defines whether leading or trailing digits are hidden. In addition, the station must be assigned for SMDR HIDE, TRANS/PGM CODE 131 button 7.	11	0-9	0
HIDDEN DGT POSITION -- When "HIDDEN DIALED DIGIT" is enabled, button 12 above, this field determines if leading or trailing digits are hidden.	12	0:Left 1:Right	1:Right
TRANSFER CHARGE MODE -- 1. INDIVIDUAL: When a call is transferred to another station, the transferred call is charged to two stations respectively. 2. INTEGRATE XFERING: When a call is transferred to another station, the call is charged to the transferring station. 3. INTEGRATE XFERED: When a call is transferred to another station, the call is charged to the transferred station.	13	0:Individual 1:Integrate Xfering 2:Integrate Xfered	0:Individual

TRANS/PGM 232	BTN	RANGE	DEFAULT
<p>TRANSFER CHARGE --</p> <p>1. NORMAL CHARGING: When Attendant make outgoing call and transfer this call to another station, the transferred will follow the Transfer Charge Mode.</p> <p>2. ATD CHARGING: When Attendant makes outgoing call and transfers this call to another station, the call is charged to the Attendant.</p> <p>3. XFERED CHARGING: When Attendant makes outgoing call and transfers this call to another station, the call is charged to the transferred station.</p>	14	0:Normal Charging 1:Atd Charging 2:Xfered Charging	0:Normal Charging
<p>WARNING TONE SVC -- if this option is enabled and SMDR service type is off-line, the system check free records space. And if free space is less than 1000, warning tone will be served as alarm to Attendant.</p>	15	0:Off 1:On	0:Off
<p>SMDR CONN TYPE -- This assigns port to be used for SMDR Interface. SMDR Interface is served through LAN or SIO.</p>	16	0:SIO 1:LAN	0:SIO
- SMTP MAIL SERVER ADDRESS -- SMTP Mail Server IP Address.	Web Only	-	-
- SMTP MAIL SERVER PORT -- SMTP Mail Server Port Number		-	-
- SMDR REPORTED MAIL ADDRESS -- SMDR User Mail Address.		Max 64 characters	-
- SMDR SMTP MAIL SERVER ID -- SMTP Mail Server User ID		-	-
- SMDR SMTP MAIL SERVER PASSWORD -- SMTP Mail Server User Password		-	-
- SMDR SMTP SENDER ADD -- Sender Address of Reported SMDR E-Mail		Max 64 characters	-
- SMDR SMTP SEND WEEKLY SET -- Select SMDR Mail Send Day		N/A (Monday- Sunday)	N/A
- SMDR MAIL SEND DAILY SET -- Sets time-of-day for SMDR data to be sent on a daily basis (00 for no daily records, 01-23 for hour of the day).		00-23	00

TRANS/PGM 232	BTN	RANGE	DEFAULT
- SMDR MAIL AUTO SEND MODE -- If the SMDR buffer is full, the system can automatically send a notification by e-mail.	Web Only	0:Off 1:On	1:On
- SMDR MAIL AUTO DELETE MODE -- Deletes SMDR records after sending e-mail.		0:Off 1:On	1:On

RELATED FEATURES

Call Cost Display ... see [page 3-187](#)

Traffic Analysis ... see [page 3-250](#)

Authorization Codes (Password) ... see [page 3-5](#)

HARDWARE

RS-323 device to capture SMDR

System Admin Programming

Keyset Administration

The System database can be accessed and modified using the Keypad and Flex buttons of a Digital Phone. The Digital Phone LCD is employed to view items on the System database. The user may be required to enter a password for access to Keyset Admin. Based on a set-up of Multi-level passwords, the User may have access to specified System database program codes. For detailed information on database administration and maintenance, refer to the Admin. Programming Manual.

CONDITIONS

- Only stations assigned with Admin. access can enter and change System database items. As a default, the First station (Station 100, Administrator and/or Attendant) can access the database.

OPERATION

Keyset Administration operation is detailed in the Admin. Manual.

ADMIN PROGRAMMING*Station*

Admin. Access (TRANS/PGM 121 - FLEX 5) ...see details on [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
KEYSET ADMIN -- Determines if the station is allowed to access administration in programming. Default = Station 100 only	5	0:Disable 1:Enable	Disable

System

Admin. Access Authority ... use *Web Admin*

System Password (TRANS/PGM 226) ...see details on [page A-86](#)

TRANS/PGM 226	BTN	RANGE	DEFAULT
USER PASSWORD -- Includes configurable database access in Web Admin., and cannot access Keyset Administration functions.	1	12 digits	none
ADMIN PASSWORD -- Includes configurable database access in Web Admin., and can access Keyset Admin.	2	12 digits	none
MAINT PASSWORD -- Includes full and unlimited access to database and maintenance functions.	3	12 digits	none

RELATED FEATURES

Web Administration ... see [page 3-197](#)

Multi-Level Admin Access ... see [page 3-195](#)

Multi-Level Admin Access

Access to the System Admin database is password protected. Up to three (3) levels of access to the database can be established by assigning a different password to each level.

- The Maintenance level has access to the entire database, all maintenance routines, and defines the Admin. Access Authority of the two remaining passwords.
- A User password can only access specific database items and cannot access Station Program pages.
- The Admin. password has access to specific database items as well as Station Program pages. In Web Admin, the Maintenance password user can establish the

Access Authority for each password selecting the Admin. Program Codes available to each password level.

CONDITIONS

- Admin. Access Authority is defined only in Web Admin.; it cannot be defined using Keyset Admin.
- Admin. Access Authority applies to all Admin. access whether accessed via a Digital Phone, ISDN or IP channels.

OPERATION

Detailed operation of Admin. access and assigning access authority for each level is given in the Admin. Programming Manual.

ADMIN PROGRAMMING

Station

Keyset Admin (TRANS/PGM 121 - FLEX 5) ...see details on [page A-24](#)

TRANS/PGM 121	BTN	RANGE	DEFAULT
KEYSET ADMIN -- when an SLT extension attempts to transfer a CO call to a CO line it is blocked and the call is released.	5	0:Disable 1:Enable	Disable

System

Admin Access Authority ... use *Web Admin*

System Password (TRANS/PGM 226) ...see details on [page A-91](#)

TRANS/PGM 226	BTN	RANGE	DEFAULT
USER PASSWORD -- Includes configurable database access in Web Admin., and cannot access Keyset Administration functions.	1	12 digits	none
ADMIN PASSWORD -- Includes configurable database access in Web Admin., and can access Keyset Admin.	2	12 digits	none
MAINT PASSWORD -- Includes full and unlimited access to database and maintenance functions.	3	12 digits	none

RELATED FEATURES

Web Administration ... see [page 3-197](#)

Web Administration

The System database can be accessed and modified using a Digital Phone, the LAN interface or an ISDN PRI line. Both the LAN and ISDN access the System Web server delivers the database as a set of Web pages to the a Web browser. Under the proper conditions, both also allow for remote access to the System database.

- For remote access with a LAN interface, the System must be assigned a remotely accessible IP address. The IP address should be fixed either as a public IP address or through a NAPT server with port forwarding. The User's browser should be pointed to the System IP address and the TCP port assigned in the System database.

When accessed, the System will return the Administration Web page. From this page, selecting Admin & Maintenance will return the login page where the user must enter a registered password. Based on the password entered, the user is permitted access to specified System program codes (refer to Admin. Programming Manual).

CONDITIONS

- For Web Admin., a password can be encrypted using the LG-Nortel Java Virtual Encryption plug-in. A Java Virtual Machine (MS or Sun) must be installed on the User PC to support password encryption.

OPERATION

Operation is detailed in the Admin. Programming Manual.

ADMIN PROGRAMMING

Pre-programmed Data

System IP Address Plan (TRANS/PGM 108) ... see details on [page A-14](#)

TRANS/PGM 108	BTN	RANGE	REMARK
IP ADDR -- Public IP Address required for remote user and Web-admin. IPv4 format.	1	-	10.10.10..1
SUBNET MASK -- Used to register a Phonatge to the System, by entering its User ID and Password.	2	-	255.255.0.0
ROUTER IP ADDR -- IP Address of router for external network (WAN/IP) access. Required for shared voice and data LAN and remote Web access.	3	-	10.10.10.254
FIREWALL IP ADDR -- When the system is installed behind a NAPT server, the fixed IP Address provided by the NAPT server must be assigned in this field. Also, use this IP address for the MFIM address in remote devices.	4	-	0.0.0.0

TRANS/PGM 108	BTN	RANGE	REMARK
DNS IP ADDR -- IP Address of Domain Name Server, which MBX IP will use to resolve URLs to an IP address. The DNS provides the resolution after receiving the name from MBX IP.	5	-	0.0.0.0
H.323 PORT -- H.323 UDP Port.	6	-	1720
SIP PORT -- SIP UDP Port.	7	-	5060
DHCP USAGE -- If this field is set to 'ON', the system gets the IP-address from the DHCP Server when it is booting.	8	-	Off
DIFFSERV -- Diff-Serv pretag value.	9	-	04

System

WEB Password Encryption (TRANS/PGM 223 - FLEX 1) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
WEB ADM PSWD ENCRYPTION -- The Web Admin password can be encrypted for security using RC-6 block encryption A Java VM must be installed on the user's PC.	1	0: Off 1: On	0: Off

Admin Access Authority ... use *Web Admin*

RELATED FEATURES

Keyset Administration ... see [page 3-194](#)

Multi-Level Admin Access ... see [page 3-195](#)

Web User Manual

The Web Admin. User Guide is available on-line as part of Web services. The main Web page permits access to the Web User guide. The guide is an HTML document, which can be modified by replacing the HTML ROM image in the System with an external ROM image in accordance with the appropriate LG-Nortel R&D STI.

CONDITIONS

- Access to the User Guide is not password protected.
- To support local languages, the HTML ROM image of a translated Web User guide may be loaded into System memory.

OPERATION

Operation is detailed in the Admin Programming Manual.

RELATED FEATURES

Web Administration ... see [page 3-197](#)

The MBX IP System supports office building mobility employing Digital Enhanced Cordless Telecommunications (DECT). The DECT Base stations (GDC-400B/GDC-600B) connect to the Wireless Telephone Interface Module (WTIB). The WTIB manages up to 8 base stations; up to 2 WTIBs may be installed in the System. DECT handsets (GDC-400H and GDC-450H) can roam and maintain uninterrupted communications link to features and resources through the base station to the WTIB.

CONDITIONS

- Multiple WTIBs may be installed to support DECT.

OPERATION

DECT operation is automatic when configured.

ADMIN PROGRAMMING

DECT Data

- DECT Registration (#0)
- DECT Attributes (TRANS/PGM 492).

HARDWARE

- WTIBs GDC-400B/GDC-600B Base stations
- GDC-400H/GDC-450H Handsets

System Networking

Centralized Control T-NET (LM)

The System supports Centralized Control T-NET (Transparent Network) as a role of the Local Mode (LM). If the MBX IP System is set for LM, all modules and terminals which are physically connected to the System can transparently access all the features and functions of the central MBX IP as well as connected resources. An MBX IP System set to work in Central Mode (CM) controls all remote modules and terminals connected to the System as if they are connected transparently without a local MBX IP System.

The voice connection provided locally will not be controlled by a central MBX IP system directly. Therefore, a VOIP channel should be configured for voice relay between phones in the Local MBX IP system and those in the Central office system.

Under normal circumstances, the Central MBX IP system controls devices in the Local MBX IP System. However, should the WAN connection between the Central system and remote devices fail, the Local MBX IP-System will assume Call Server responsibility for the local devices. The Local MBX IP-System provides local survivability and may provide PSTN back-up service (fail-over) for internal calls that normally route over the WAN, based on configuration.

Under certain operating conditions, this equipment cannot be relied upon for Emergency calls. Alternative arrangements should be made for access to Emergency services.

CONDITIONS

- A VOIB channel in the Vertical MBX IP System is required.
- In a Centralized Network, the maximum number of channels available is the maximum number of channels supported by the central MBX IP system.
- In a Centralized T-NET, miscellaneous functions (Relay support, MOH, BGM, Alarms and External Pages) are not supported.
- When NATP or other firewall functions are implemented, packet relay for RTP packets is required; packet relay requires VoIP channels for each simultaneous call desired.
- The local MBX IP System will take over operation of registered devices if the Central office does not respond to three consecutive poll attempts over a period of 10-102 seconds; once connection to the WAN is re-established, the central office will automatically re-gain control.

The MBX IP system can be installed behind a NATP, however Fixed NAT-Port forwarding is required for the host to be reachable using remote devices.

OPERATION

System -- Operation of Centralized Network is automatic when configured and defined.

ADMIN PROGRAMMING

T-Net Data

T-Net Attributes (TRANS/PGM 330) ... see details on [page A-143](#)

TRANS/PGM 330	BTN	RANGE	DEFAULT
T-NET ENABLE -- enable T-NET function	1	0: Off 1: On	Off

CM Attributes (TRANS/PGM 331) ... see details on [page A-143](#)

TRANS/PGM 331	BTN	RANGE	DEFAULT
CH REGISTER REQ -- determines if the LM will attempt registration with the CM; must be set to ON for proper registration.	1	0:Off 1:On	On
CH IP ADDRESS -- This field defines the IP address of the CM that will be used by the LM.	2	IPv4 address	0.0.0.0
CH PKTS PORT -- In the TNET environment, the IP KTS protocol signaling UDP port is defined; at present, this field is not used, do not change this port number.	3	0001-9999	5588
CH TOTAL PORT -- Determines if the total number of Ports the LM will request will be allocated by the CM for devices attached to the LM; this value must be equal to or less than the port count in the CM for the LM devices.	4	000-999	000
POLLING COUNT -- This field defines the maximum polling failures an LM considers a WAN fault.	5	00-99	05
POLLING INTERVAL -- This field defines the interval time between LM to CM polling attempts.	6	00-99	02

Fail-over PSTN Attributes (TRANS/PGM 333) ... see details on [page A-144](#)

TRANS/PGM 333	BTN	RANGE	DEFAULT
ENABLE FoPSTN -- Determines if Fail-over operation is enabled or disabled from the CM or LM.	1	0:Off 1:On	-
INIT FoPSTN TABLE -- Determines how to initialize the FO Table	2	-	-

TRANS/PGM	BTN	RANGE	DEFAULT
FoPSTN Attributes	3	1-100 (MBX IP-100) 1-200 (MBX IP-300)	-
FoPSTN NUM PLANS -- Station numbers associated with the remote System.	3-1	Max 16	-
FoPSTN CO GROUP -- Determines the CO Group of the Local System that will be used to place calls to the stations entered in the FO Numbering Plan, should a WAN failure occur.	3-2	1-24 (MBX IP-100) 1-72 (MBX IP-300)	-
FoPSTN TEL NUMBER -- Determines the telephone number the System should dial to place a call to the Stations entered in the FO Numbering Plan, should WAN failure occur.	3-3	Max 10	-

T-Net Board Attributes (TRANS/PGM 334) ... see details on [page A-145](#)

IP Phone T-Net Enable (TRANS/PGM 335) ... see details on [page A-145](#)

Numbering Plan

T-NET Login/Logout Code (TRANS/PGM 113) ... see details on [page A-20](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
84	T-Net Log-In/Out	586

HARDWARE

VOIB MBX IP System

Distributed Control Network

In the Distributed Control Network, each System maintains control over the devices registered to it. Networked systems communicate allowing other networked systems access to resources over the network.

In addition, other features and functions as detailed in the following sections of this manual are available to users provided by a distributed network environment. The System permits remote access to various resources through registered gateway Modules and Terminals.

In addition, the System will request access to resources of remote systems. A user-dialed number is analyzed and the call routed according to the NET Numbering Table. Should the main path fail to respond, the System re-routes the call employing the designated Alternative Speed Dial route.

The System supports 2 standard protocols (QSIG over ISDN, and H.450 over IP), for basic networking functions. QSIG employs ISDN PRI channels only with support for ESTI standards ETS 300-237/238/256/257/260/261/361/362/363/364.

CONDITIONS

- To use the networking features, software lock-key installation is required; there are two types of software lock-keys, for QSIG-based networking, and VOIP-based networking.
- Unified Dialing Plan (UDP) specifies that each Station can have a unique number up to 8 digits in the Networked Systems, depending on the Numbering Plan.
- An Alternative Speed Dial route can be used to place a call, but is not a Networked call, so Distributed Control Network features are not available.

OPERATION

Operation of Distributed Networking is automatic when configured and defined.

ADMIN PROGRAMMING

Numbering Plan

System Numbering Plan (TRANS/PGM 111) ... see details on [page A-16](#)

TRANS/PGM 111	BTN	RANGE	REMARK
PREFIX CODE -- leading preceding digits of some numbering plan code.	1	1-8 digits	Prefix code length + more digit can be 8 at max.
MORE DIGITS -- number of digits following the Prefix code.	2	(0-4)	

Voice Network

Voice Network (TRANS/PGM 320) ... see details on [page A-141](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0: Off 1: On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0: Off 1: On	On
NET CONP ENABLE -- Reserved for future usage.	3	0: Off 1: On	Off

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0: UUS 1: FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0: Off 1: On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0: Off 1: On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Voice Network Numbering Plan (TRANS/PGM 321) ... see details on [page A-142](#)

TRANS/PGM 321	BTN	RANGE	DEFAULT
NUMBER TYPE -- Select Number Type	1	0: Net 1: Transit	Net
NUM PLAN CODE -- 'X' means any digits can be inserted between 0-9. (Select 'MUTE" button to input X).	2	8 digits	-
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0: Off 1: On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock).	6	0: Overlap 1: Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking.	8	-	0.0.0.0

TRANS/PGM 321	BTN	RANGE	DEFAULT
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address.	10	0: Off 1: On	On

Net Call

A Station user can make a call to a Station on another System by dialing just the Station number, as an Intercom call within the same System.

CONDITIONS

- Net call must be used without seizing a CO line.
- User hears an error tone if there is no idle networking path.
- In spite of ICM mode, the called party receives a ringing signal for Net Calls.
- When the System detects a fatal error from the Network, the System sends digit streams to the Network using the Alternate Dial bin (not a Net Call).
- The CO Call Restriction Timer is also applied to Net Call (TRANS/PGM180 - FLEX 14).

OPERATION

To configure Net Call Numbering Plan programming:

Press [TRANS/PGM] + 111 (Prefix Code) + (1) + Prefix code for Networking Numbering + [HOLD/SAVE]

To perform a Net Call:

1. Lift Handset or press the [SPEAKER] button; dial tone will be provided.
2. Dial a Station number on another System, or press the {NET DSS} button for the other System.
3. The Station seizes the network CO Line according to the Net Routing Table, and the System sends a modified digit stream.
4. The called System receives a digit stream sent by the Calling Party, and analyzes it using the net routing table to determine the right destination, sending it to the Called Party (ring signal).

5. When Net Call is established, a network CO Line is used; when Net Call is cleared, the network CO Line is released.
6. The [Network CO] button LED will be extinguished when Net Call is cleared.

ADMIN PROGRAMMING

Numbering Plan

System Numbering Plan (TRANS/PGM 111) ... see details on [page A-16](#)

TRANS/PGM 111	BTN	RANGE	REMARK
PREFIX CODE -- leading preceding digits of some numbering plan code.	1	1-8 digits	Prefix code length + more digit can be 8 at max.
MORE DIGITS -- number of digits following the Prefix code.	2	(0-4)	

CO Line Data

CO Line Attribute (TRANS/PGM 160) ... see details on [page A-45](#)

TRANS/PGM 160	BTN	RANGE	DEFAULT
CO TYPE -- Displays physical line type of selected CO line.	1	Display Only	-
SVC TYPE -- Set CO line type as DID or Normal.	2	0:Normal 1:DID	Normal
OUTGOING GRP NO -- Set CO Group Number to apply to outgoing calls.	3	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
INCOMING GRP NO -- Set CO Group Number to apply to incoming calls.	4	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
TENANT NO -- Set Tenant group number to apply to CO lines.	5	1-9 (MBX IP-300) 1-3 (MBX IP-100)	1
DGT CONVERT TBL -- Set Digit Conversion Table index.	6	1-9	2
SIGNAL TYPE -- Set Answer Signal Type.	7	0: No Signal 1: Send Wink (IC) 2: Wait Seize Ack (OG) 3: Send Wink & Wait Sz Ack 4: Send & Wait Sans 5: Send Wink & Send Answer (IC) 6: Wait Ack & Send Answer (OG) 7: Send All & Wait All	No Signal

TRANS/PGM 160	BTN	RANGE	DEFAULT
RLS TIMING -- If Release Timing is set to first release, CO line is released when one party release the call. If Caller or Called Release is set, CO line is released when caller or called party released the call.	8	0: First Release 1: Caller Release 2: Called Release	First RLS
INC/OUT MODE -- Each CO lines can be set to only incoming call is allowed or outgoing is allowed only.	9	0: Incoming Only 1: Outgoing Only 2: Allow Both	Both
DIALING TYPE -- Signal type can be selected; DTMF, Pulse, R2MFC.	10	0: DTMF 1: PULSE 2: R2	DTMF
CHARGE MODE -- If 'FREE', the external call though CO line is not printed/saved to SMDR even though SMDR is enabled. If 'REPORT', the external call though CO, line is included to SMDR according to the SMDR Attributes.	11	0: Free 1: Report	Report
METERING TYPE -- According to PSTN service type, metering type can be selected among 00-12 to manage call charge. 01-06 can be applied to LCO lines, 07-12 can be applied to ISDN lines.	12	00: None 01: 12KHz 02: 16KHz 03: 50KHz 04: SPR 05: PPR 06: NPR 07: AOC 0(Standard) 08: AOC 1 (Italy & Spain) 09: AOC 2 (Finland) 10: AOC 3 (Australia) 11: AOC 4 (Belgium) 12: AOC 5 (Netherlands)	None

CO Line Attribute (TRANS/PGM 161) ... see details on [page A-46](#)

TRANS/PGM 161	BTN	RANGE	DEFAULT
CO SERVICE MODE -- Determines if SIP/PRI, H.323/BRI or Qsig is selected for each VOIP(or ISDN) lines.	1	1: SIP/PRI 2: H.323 3: Qsig 4: T1 PRI 5: T1 Qsig	SIP/PRI
DROP TYPE -- LCO line drop type.	2	0:Loop 1:Polarity Reverse	Loop
FLASH TYPE -- LCO line Flash type.	3	0:Loop 1:Ground	Loop
FLASH TMR -- CO Flash Timer.	4	001-300	050
OPEN LOOP TMR -- Open Loop Timer.	5	00-20 (100ms base)	00
LINE LENGTH -- LCO line length.	6	0: 0km 1: 3km 2: 5km 3: 7km	0km
ZONE NO -- Zone number of CO lines.	7	1-9	1
PROMPT LANGUAGE -- VMIB Prompt Index.	8	1-3	1
GAIN TABLE IDX -- Determines Gain Table for CO line.	9	1-3	1

Station

CO/IP Group Access (TRANS/PGM 150) ... see details on [page A-43](#)

Voice Network

Network Basic Attribute (TRANS/PGM 320) ... see details on [page A-141](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0:Off 1:On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0:Off 1:On	On

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET CONP ENABLE -- Reserved for future usage.	3	0:Off 1:On	Off
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0:UUS 1:FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Network Numbering Plan (TRANS/PGM 321) ... see details on [page A-142](#)

TRANS/PGM 321	BTN	RANGE	DEFAULT
NUMBER TYPE -- Select Number Type	1	0:Net 1:Transit	Net
NUM PLAN CODE -- 'X' means any digits can be inserted between 0-9. (Select 'MUTE" button to input X).	2	8 digits	-
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0:Off 1:On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0:Overlap 1:Enblock	Overlap

TRANS/PGM 321	BTN	RANGE	DEFAULT
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0:Off 1:On	On

Net Transfer

A Station User can transfer any kind of CO call to a Station on other systems by pressing the [TRANS] button and dialing a transfer destination Station, as a Call Transfer within the same system. There are two kinds of Transfer, Screened and Unscreened.

NOTE: There are two kinds of standard transfer method in QSIG and H.450; Transfer by Join and Transfer by Rerouting. The main difference is how the connecting path is controlled between the transferring and transfer destination Stations. Transfer by join uses an additional connecting path for transferring the call to another station. Transfer by rerouting, uses a new connecting path to transfer the call and the old connecting path of transferring station is cleared.

CONDITIONS

- If both of the transferred and destination Stations are located on the same system, the networking path is cleared; the transfer call will be setup as an Intercom call.
- The Transfer will be canceled when the transferring Station User presses the flashing [CO line access code] or [TRANS] button.
- Net Transfer calls do not recall at the origination Station.
- The User will hear an error tone if the Networking Path is unavailable.
- Net transfer is not activated at a Busy station.

OPERATION

To perform a Screened Transfer to another Station on a different Networked System:

FÈ Ú!^••Á@ÄÜÇÈÙá~ ç} ÁÁÁÜçá } Á~ | á * ÁÁÜÁÁ^Á } ç!•çá } L@ÁÜÁÁ^Á Á
] | á á Á } Áç&~ • ç^Á [| á Ä
 GÈ ÖáÁ@Á^•ç á } Áçá } Á~ { à^!Á } Á [ç!ÁÜ•ç { Á Á á •-!Á@Áç|Á@Áçá } Á
 [] Á@Á ç!ÁÜ•ç { Á^&ç^ÁÁ * Á á } çÈ
 HÈ Ç } [~ } &Á@ÁçÁ @ } Á@Áç|Á Á •, ^!áL@ÁÜÁç|Á Á | á Á Áç&~ • ç^Á [| á Á
 , ç^Á@Áçá } Á { { ~ } çÁ•Á á@ÁÁ^•ç á } Áçá } È
 I È Pá * È] Á Á { } | ^çÁ@Á á •-!Ä

To perform an Unscreened Transfer to another Station on a different Networked Station:

FÈ Ú!^••Á@ÄÜÇÈÙá~ ç} ÁÁÁÜçá } Á~ | á * ÁÁÜÁÁ^Á } ç!•çá } L@ÁÜÁÁ^Á Á
] | á á Á } Áç&~ • ç^Á [| á Ä
 GÈ ÖáÁ@Á^•ç á } Áçá } Á~ { à^!Á } Á [ç!ÁÜ•ç { Á Á á •-!Á@Áç|Á@Áçá } Á
 [] Á@Á ç!ÁÜ•ç { Á^&ç^ÁÁ * Á á } çÈ
 HÈ Pá * È] Á Á { } | ^çÁ@Á á •-!Ä

ADMIN PROGRAMMING

Numbering Plan

Ù•ç{ Á~ { à^!á * Á | á } ÄÜÇÈÙáÜÖT ÁFFD Á^ÁÁçá } Á } Á ç^ çÈ í

VÜÇÈÙáÜÖT ÁFF	ÓV	ÜÇÈÖÖ	ÜÖT ÇÜS
ÚÜÖÇÁÜÜÖÁÁ^çá * Á!^&áá * Á á á Á-Á [{ ^Á } ~ { à^!á * Á á } Á [á È	F	FÈ Á á á	Ú!^çÁ { à^! } * çÈ [!^Á á á á Á Á Á çÈ
TUUÖÖÖÜÁ~ { à^!Á Á á á Á , á * Á@Á Ú!^çÁ á È	G	ÇÈ D	

CO Line Data

ÖUÁÜUÁÜÇÈÙáÜÖT Áí í D Á^ÁÁçá } Á } Á ç^ çÈ €

VÜÇÈÙáÜÖT Áí í	ÓV	ÜÇÈÖÖ	ÖÖÇÈSV
ÖÜÁÜUÁÜÖUÁÜUÁÜÖÁ Á ç Á [á È	F	€Èí	€
ÖÜÁÜUÁÜÖUÁÜUÁÜÖÁ á @ Á [á È	G	€Èí	€
ÖÜÁÜUÁÜÖUÁÜUÁÜÖÁ á^ á Á [á È	H	€Èí	€

CO to CO Attribute (TRANS/PGM 179) ... see details on [page A-60](#)

TRANS/PGM 179	BTN	RANGE	DEFAULT
STATION OUTGOING CALL TRANSFER -- while stations are connected to outgoing CO call of first CO Group, the station can transfer the call to second CO group.	1	0: Off 1: On	On
OUTGOING CALL TRANSFER -- while ATD is connected to outgoing CO call of first CO Group, the ATD can transfer the call to second CO group.	2	0: Off 1: On	On
OUTGOING CALL TRANSFER RELEASE TYPE -- if outgoing CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	3	0: None 1: Release after Release Timer	None
OUTGOING CALL TRANSFER RELEASE TIME -- if an outgoing CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'RIs after RIs Time'. Before disconnecting, a warning tone is provided.	4	000-300 (sec)	060
INCOMING CALL TRANSFER DIRECTLY -- if this feature is set to ON, CO incoming call can be transferred directly without any stations or ATD to transfer the call.	5	0: Off 1: On	Off
STATION INCOMING CALL TRANSFER -- while stations are connected to incoming CO call of first CO Group, the station can transfer the call to second CO group.	6	0: Off 1: On	On
ATD INCOMING CALL TRANSFER -- while ATD is connected to incoming CO call of first CO Group, the ATD can transfer the call to second CO group.	7	0: Off 1: On	On
INCOMING CALL TRANSFER RELEASE TYPE -- If incoming CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	8	0: None 1: Release after Release Timer	None
INCOMING CALL TRANSFER RELEASE TIME -- If an incoming CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'RIs after RIs Time'. Before disconnected, warning tone is provided.	9	000-300 (sec)	060

TRANS/PGM 321	BTN	RANGE	DEFAULT
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0:Off 1:On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0:Overlap 1:Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0:Off 1:On	On

Identification Service

When a user makes a Net Call, the System provides the name registered at the Station to the Called Party between Systems.

OPERATION

If set, CNIP operation is automatic.

ADMIN PROGRAMMING

Numbering Plan

System Numbering Plan (TRANS/PGM 111) ... see details on [page A-16](#)

TRANS/PGM 111	BTN	RANGE	REMARK
PREFIX CODE -- leading preceding digits of some numbering plan code.	1	1-8 digits	Prefix code length + more digit can be 8 at max.
MORE DIGITS -- number of digits following the Prefix code.	2	(0-4)	

TRANS/PGM 321	BTN	RANGE	DEFAULT
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0:Off 1:On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0:Overlap 1:Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0:Off 1:On	On

Call Completion

There are two kinds of Call Completion:

- Completion of Calls to Busy Subscribers (CCBS) – After calling a User on another System using basic call and encountering a busy tone, a Station-user can be notified when the busy destination of another system becomes idle. If the user wants to make a call to the destination when that notification is received, the call can be reinitiated to the destination of the other system again.
- Completion of Calls on No Reply (CCNR) – After calling a User in another System using basic call and encountering No Reply (No Answer), the caller can set to be notified when the destination becomes idle again. If the caller wants to make a call to the destination when notification is received, the call can be reinitiated to the destination on the other System again.
- CONDITIONS
- A stand-alone IP Phone that supports H.450 can activate Call Completion.
- A station can leave or have only one callback message, and a new request will be left as a message wait indication on the busy Station.

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Network Numbering Plan (TRANS/PGM 321) ... see details on [page A-142](#)

TRANS/PGM 321	BTN	RANGE	DEFAULT
NUMBER TYPE -- Select Number Type	1	0:Net 1:Transit	Net
NUM PLAN CODE -- 'X' means any digits can be inserted between 0-9. (Select 'MUTE" button to input X).	2	8 digits	-
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0:Off 1:On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0:Overlap 1:Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0

TRANS/PGM 237	BTN	RANGE	DEFAULT	
DIGIT 1 -- when accessing a busy tone, User may dial for one of the one-touch services.	2	0: N/A 1: Call-Back 2: Camp On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	0: N/A	
DIGIT 2 --	3			
DIGIT 3 --	4			
DIGIT 4 --	5			
DIGIT 5 --	6			
DIGIT 6 --	7			
DIGIT 7 --	8			
DIGIT 8 --	9			
DIGIT 9 --	10			
DIGIT 0 --	11			
DIGIT * --	12			Call Wait
DIGIT # --	13			Voice-Over

Call Offer

A busy user on one node can be given notification that another call is waiting from another node. It is similar to the Camp-On function.

CONDITIONS

- Call Offer is only applied to a Station that in Busy status.
- During Conference or Paging, Call Offer is not activated.
- The System does not support the standard QSIG specification path reservation mode.

OPERATION

To activate Call Offer:

1. Dial a Station number on another System; when busy tone is received, press the [Call Wait] button, or {Call Wait Feature Code}.
2. The Busy Station will receive an Off-Hook Muted Ring; the calling station will hear a ring-back tone instead of a busy-tone.

Network Numbering Plan (TRANS/PGM 321) ... see details on [page A-142](#)

TRANS/PGM 321	BTN	RANGE	DEFAULT
NUMBER TYPE -- Select Number Type	1	0: Net 1: Transit	Net
NUM PLAN CODE -- 'X' means any digits can be inserted between 0-9. (Select 'MUTE' button to input X).	2	8 digits	-
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0: Off 1: On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0: Overlap 1: Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0: Off 1: On	On

Numbering Plan

System Numbering Plan (TRANS/PGM 111) ... see details on [page A-16](#)

TRANS/PGM 111	BTN	RANGE	REMARK
PREFIX CODE -- leading preceding digits of some numbering plan code.	1	1-8 digits	Prefix code length + more digit can be 8 at max.
MORE DIGITS -- number of digits following the Prefix code.	2	(0-4)	

Øæ ! ^ Á ~ { à ^ | ä * Á | } Æ Ü Ö Æ Ü Ö J Ö T Á F H D S Á ^ Á ^ Á ^ ç Æ Á } Á æ ^ Ö F Í Á

System Data

Q ç ! & { Á Ö • ^ Á } ^ È ã ä Á Æ Ü Ö Æ Ü Ö J Ö T Á G H I D S Á ^ Á ^ Á ^ ç Æ Á } Á æ ^ Ö F Í F

VÜÖËÜÖJÖT ÁGHÍ	ÓVP	ÜÖËÖÒ	ÖÖËÖSV
ÜVÖÚÁÖÖSSÁÆÁ ç ! { ä ^ • Á Á ç } Á ç / Á Á } æ / á Á ! Á ä æ / á È	F	Æ Á Ö ä æ / ^ F Á Ö } æ / ^	Ö ä æ / ^
Ö Ö Q Á F Á Ä @ } Á æ & • ä * Á ä ~ • ^ Á } ^ È V Á Á æ Á ä Á Á } ^ Á ~ ç Á } ^ È ~ & ç Á ç Á • È	G	ç Á Ö È F Á Ö ç È Ö æ G Á Ö ç } Á } H Á Ö ç Á ç I Á Ö ç • ä } J Á Ö ç } ç	ç Á Ö È Ö ä æ / ^
Ö Ö Q Á G Á È	H		
Ö Ö Q Á Á Á Ä	I		
Ö Ö Q Á Á Á Ä	Í		
Ö Ö Q Á Á Á Ä	Ĵ		
Ö Ö Q Á Á Á Ä	İ		
Ö Ö Q Á Á Á Ä	ì		
Ö Ö Q Á Á Á Ä	J		
Ö Ö Q Á Á Á Ä	F€		
Ö Ö Q Á Á Á Ä	FF		
Ö Ö Q Á Á Á Ä	FG		
Ö Ö Q Á Á Á Ä	FH		
			X æ Á È Ç !

Net Conference

Þ Á Ö [} Á ^ } & Á Á Á ^ Á ç Á Á Á Á Ö [} Á ^ } & Á Á ç ! Á È ä ç ç Á ä ä ä } ç Á
•] ^ ä ä ç ç } Á ç ç Á ç [\ | á Á ç ç } Á ç Á Á • ä } ^ á Á Á ç } Á ^ } & Á ^ { à ^ È Ö ç Á Á Á
Ü ç ç } Á } Á } ^ Á [á ^ ç ç } Á ^ } & Á Á ç ç Á } Á ç ~ Á ç ! Á [á È Á ^ { à ^ • Á Á ç } Á ^ } & Á
ç ç } • ä ç Á } Á Á ç ç } • Á } Á ç Á ç [\ | È

CONDITIONS

È Á T ~ | ç ä ^ Á } Á ^ } & Á Á ^ Á Á [ç ç } | ä á Á } Á ç [\ | á Á È ç ç Á } Á ^ } &

OPERATION

To perform Net Conference:

FÈ Ú ! • • Á ç Á Ö Ü Þ ç á ç | Á ~ | ä * Á Á Á Ö ç Á } ç ! • ç ç } È
GÈ V @ Á ç á ç * Á ç Á Á | æ ~ á Á } Á ç | á Á á Á Á Ö T Á ç Á } ^ Á Á | ç ç á È

3. Make a Net Call to another Station on another node.
4. Press the [CONF] button when the 3rd party answers.
5. The second call is placed on Hold and an ICM Dial tone is provided.
6. Press the [CONF] button again at the Master Station; all parties will be connected.

To clear a Net Conference:

1. Any Station in the Net Conference can hang-up during the conference.
2. After all parties disconnect, the net conference will be cancelled and the network path will be cleared.

ADMIN PROGRAMMING

Voice Network

Network Basic Attribute (TRANS/PGM 320) ... see details on [page A-141](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0:Off 1:On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0:Off 1:On	On
NET CONP ENABLE -- Reserved for future usage.	3	0:Off 1:On	Off
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0:UUS 1:FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001

VÜCEÛEÛÖT ÁGE	ÓVP	ÜCEÖÖ	ÖÖCEŠV
ÖWÜCE/ÜPÁJÖÖSÖUVUÁEÖ iæq } Á{ !Á^} äq * Á@ ÖSÖÁ cæ • Á { ^•æ^Á{ Á@ ÖSÖÁ^!ç!ÁE	J	€EJ	FE
ÖSÖÁ CEÖÖÜÁWÁEÖÁa!^•Á -ÖSÖÁ^!ç!Á•^áÁ } Á @ } ÁÁ T ÖYÁWÁÁ } -á~!áÁ æ@ @!Á•c{ •Á{ !Á[&Á^c [!ã* Á Ü^•^!ç!ÁE	FE	Ë	€€€€

Þ^c [!Á~ { à!ã * ÁU}æ ÁVÜCEÛEÛÖT ÁGFÖ Á^Á^æ• Á } Áæ^ ÖEFG

VÜCEÛEÛÖT ÁGF	ÓVP	ÜCEÖÖ	ÖÖCEŠV
ÞWT ÖÖÜÁYUÖÁEÁ^!&Á~ { à!Á^ } ^	F	€Á^c FÁV!æ • æ	Þ^c
ÞWT ÁSÖPÁÖÜÖÁEÖÁ^æ • Áæ ~ Áæ æ Áæ Á^Á • ^!cÁÁ^c ^^} Á €EÁÜ^!&Á~ WÖÁÁ~ ç } Á Á } ^ ÁE	G	ì Áæ æ	Ë
ÖUÁÖÜUWÁUÁEÖUÁÖ: [~ } Á~ { à!	H	€E G	Ë
CEÖÖÖQÁEÖÖÁCE ç { æÁ^c [!ÁÖæq * DÖæ æ	I	FEÁæ æ	Ë
ÖÖQÁÖÜÖCEÁEÖ^c! { q ^ÁÁCEÖÁæ æ Á & ~ á!áÁ Á@ ÁÜÖWÁ { ^•æ^Á!Á [E	í	€Á~ FÁÜ}	U~
ÖÖQÁÖÜÖCEÖÁEÁ^!&Áæ á^} äq * Á [áÁÜç! æ Á!ÁÖ) à[& D	î	€Áç! æ FÁÖ) à[&	Uç! æ
XUÁÖÜPÁÖÜÁEÁEÁEÁÜUÁÖÜPÁÖÜÁE GÁEÁÜUÁÖÜPÁÖÜÁE HÁEÁÜUÁÖÜPÁÖÜÁE IÁEÁÜUÁÖÜPÁÖÜÁE	ï	Ë	Ë
ÖSÖÁYÜVÖT ÁWÁEÖÁa!^•Á -ÖSÖÁ^!ç!Á•^áÁ } Á @ } Á ÖYÁ WÁÁ } -á~!áÁ æ@ @!Á•c{ •Á{ !Á[æÁ^c [!ã*	ì	Ë	€€€€
ÖSÖÁYÜVÖT ÁUÜVÁWÖUÁ [!Á{ !Á^} äq * ÖSÖÁ ^•æ^Á{ ÖSÖÁ T æ æ^!E	J	Ë	Jí €€
ÖÖY ÖSÁUWÖÖÁEÁ^!&ÁWÁa!^•ÁÖÁ, æÁWÁa!^•Á!Á P[] Eá^, æÁWÁa!^•ÖÁÖÁ^c æq } Á~c{ Á Áæ ^ÁÜPÁ @ } Á [] Eá^, æÁWÁa!^•Á @ ~ ÁÁ^Á } ÖÜ@!, á^Á@ÁÁ, æÁWÁ æá!^•Á @ ~ ÁÁ^Á } ÖÜPÁ } áÁÁ, æÁWÁa!^• UÖÁ^ } áÁ [] Eá^, æÁÖc! } æÁWÁa!^•	FE	€Á~ FÁÜ}	U}

Message Waiting Indication (MWI)

Message Waiting Indication (MWI) is the same as Calling Line Indication (CLI) message wait service. On a normal ISDN call, a Station can leave a Message Wait for an unavailable station on another node (CLI message wait must be enabled). MWI is indicated by the CLI message on the Station LCD panel. Additionally, it can be supported by supplementary service (without CLI) by pressing the {MSG WAIT} button when the Net Call Ring-Back tone is received.

CONDITIONS

- MWI only can be registered at the Station hearing a ring back tone.
- MWI notification is displayed at the Called Station LCD.
- When the System presents the Call-Back according to MWI data, the CO Line is selected within the Network CO group.

OPERATION

To register and retrieve MWI:

1. Initiate a Net Call to another station on another node; the caller will hear a Ring-Back tone.
2. While hearing the Ring-Back tone, the caller can either,
 - a.) Press the [MSG/Callbk] button.
 - OR
 - b.) Press the [TRANS] button and dial the {Message Wait Register Feature Code}.
3. MWI is left to the called station, and a flashing [MSG/Callbk] button indicates the message waiting.
4. At the called Station, press the flashing [MSG/Callbk] button; the Calling Station number is displayed.

ADMIN PROGRAMMING

Voice Network

Network Basic Attribute (TRANS/PGM 320) ... see details on [page A-141](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0:Off 1:On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0:Off 1:On	On

TRANS/PGM 321	BTN	RANGE	DEFAULT
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0: Off 1: On	On

Numbering Plan

System Numbering Plan (TRANS/PGM 111) ... see details on [page A-16](#)

TRANS/PGM 111	BTN	RANGE	REMARK
PREFIX CODE -- leading preceding digits of some numbering plan code.	1	1-8 digits	Prefix code length + more digit can be 8 at max.
MORE DIGITS -- number of digits following the Prefix code.	2	(0-4)	

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

Net Call Forward (Unconditional/Busy/No-Answer)

A User can remotely forward to another Station immediately over the network. NOTE: The System supports both Rerouting and Join methods according to Admin. Programming.

CONDITIONS

- If both the Originating and Forwarded To Stations are located within the same System, the Networking Path will be cleared; the Forwarded Call will be setup as Intercom Call.
- The System does not check the status of the diverted-to station in DND, CFW or Empty.

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0:UUS 1:FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Network Numbering Plan (TRANS/PGM 321) ... see details on [page A-142](#)

TRANS/PGM 321	BTN	RANGE	DEFAULT
NUMBER TYPE -- Select Number Type	1	0: Net 1: Transit	Net
NUM PLAN CODE -- 'X' means any digits can be inserted between 0-9. (Select 'MUTE" button to input X).	2	8 digits	-
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0: Off 1: On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0: Overlap 1: Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-

TRANS/PGM 177	BTN	RANGE	DEFAULT
DAY COS -- CO COS in Night mode.	2	00-15	0
DAY COS -- CO COS in Timed mode.	3	00-15	0

Voice Network

Network Basic Attribute (TRANS/PGM 320) ... see details on [page A-141](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0:Off 1:On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0:Off 1:On	On
NET CONP ENABLE -- Reserved for future usage.	3	0:Off 1:On	Off
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0:UUS 1:FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

CONDITIONS

- To use CO transit-out, the Sub-System User must seize the CO Line.
- The Original Station COS will receive toll restriction as configured.
- The Outside Caller will hear a busy tone if a Networking Path is not available during the Transit-Out attempt.

OPERATION

To use CO Transit-Out, perform the following:

1. A Station of a Sub-System seizes a CO line.
2. The Dummy CO Dial tone (PRI=real dial tone) is provided from the Main System or the Sub-System; according to the CO Dial Send Mode (En-Block or Overlap), the origination of the CO Dial tone is determined.
3. Dial the Telephone number of Public Network User; the Called Station will receive the ringing, and Station placing the call will hear the Ring-Back tone.
4. When Call is answered, the public network telephone and the station of sub-system will be connected.

ADMIN PROGRAMMING*CO Line Data*

CO COS (TRANS/PGM 177) ... see details on [page A-60](#)

TRANS/PGM 177	BTN	RANGE	DEFAULT
DAY COS -- CO COS in Day mode.	1	00-15	0
DAY COS -- CO COS in Night mode.	2	00-15	0
DAY COS -- CO COS in Timed mode.	3	00-15	0

CO to CO Attribute (TRANS/PGM 179) ... see details on [page A-60](#)

TRANS/PGM 179	BTN	RANGE	DEFAULT
STATION OUTGOING CALL TRANSFER -- while stations are connected to outgoing CO call of first CO Group, the station can transfer the call to second CO group.	1	0: Off 1: On	On
OUTGOING CALL TRANSFER -- while ATD is connected to outgoing CO call of first CO Group, the ATD can transfer the call to second CO group.	2	0: Off 1: On	On

TRANS/PGM 180	BTN	RANGE	DEFAULT
OUTGOING GRP NO -- Determines the CO Group number used to seize. NOTE: If not assigned, the access code is used as LOOP key.	3	01-72 (MBX IP-300) 01-24 (MBX IP-100)	Not assigned to the first access code. 01-72 (MBX IP-300) 01-24 (MBX IP-100) is assigned sequentially from the second access code
AND DGT -- Automatic Network Dialing (AND) digit is sent after CO line seized. This feature allows user to initiate CO calls only by dialing CO Group Access Code.	4	Max 10 digits	-
ARS SERVICE -- If Alternate Route Selection (ARS) is set, ARS digit is dialed instead of CO Group Access code when there is no available path.	5	0: Off 1: On	Off
ARS DGT 1 -- Alternate CO Group Access code to be used when original CO Group Access code failed to find available CO line.	6	Max 8 digits	-
ARS 1 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	7	0: Off 1: On	Off
ARS DGT 2 -- Second alternate CO Group Access code to be used when original CO Group Access code and first ARS code failed to find available CO line.	8	Max 8 digits	-
ARS 2 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	9	0: Off 1: On	Off

Voice Network

Network Basic Attribute (TRANS/PGM 320) ... see details on [page A-141](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0:Off 1:On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0:Off 1:On	On

TRANS/PGM 321	BTN	RANGE	DEFAULT
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0: Off 1: On	On

Do-Not-Disturb (DND)

A call to a Station in DND mode can be denied though it is received from a Station on another System; the calling party will receive a busy tone.

CONDITIONS

- When a Station is in DND mode, the [Station] button of the DND Station will flash (BLF manager must be activated).

OPERATION

To use DND in a Networked environment:

1. Press the [DND] button to activate DND mode.
2. When a Station on another System calls in to the Station in DND mode, the busy tone will be received, and DND will display on the LCD.

TRANS/PGM 321	BTN	RANGE	DEFAULT
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0: Off 1: On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0: Overlap 1: Enblock	Overlap
VOIP CPN INFO -- 1: 001 VOIP CPN INFO 1 2: 001 VOIP CPN INFO 2 3: 001 VOIP CPN INFO 3 4: 001 VOIP CPN INFO 4	7	-	-
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0
BLF SYSTEM PORT -- UDP port for sending BLF message to BLF Manager.	9	-	9500
FIREWALL ROUTING -- Select IP address (Firewall IP address or Non-firewall IP address). If the destination system is in same VPN then Non-firewall IP address should be sent. Otherwise the firewall IP address should be sent. ON: Send firewall IP address OFF: Send Non-firewall (Internal) IP address	10	0: Off 1: On	On

Attendant Call (CAS)

An Attendant Call from any node can be routed to the Centralized Attendant (CAS); the call will be queued when all Centralized Attendants are busy.

CONDITIONS

- A Recall Call is not routed to CAS on the Master System.
- The CAS DN Number can be converted to Attendant Call code using the Digit Conv. Table.
- An Attendant Call can be rerouted to CAS according to the Forward type and Destination.
- If all Attendants press [DND] button, CAS will be covered by the Night Attendant Group.
- If the Forward Destination of Night Attendant group is CAS, the Attendant Call will be routed to CAS.

OPERATION

Q\| | *!æ { ^áÈÖc} áæ cÓæ|Á] ^!ææ } Á Áæ ç { ææÈÁ

ADMIN PROGRAMMING

Tenant Data

Öc} áæ cÖc ä ~ cÁVÜÖE ÜBUÖT ÁG GÁZÖSÖYÁHÁZÖSÖYÁ DÖ Á^^Á^æá Á } Á æ ^ ÖÈFG

VÜÖEÜBUÖT ÁG G	ÓVP	ÜÖEÖÖ	ÖÖÖEVS
<p>ÖÜY ÖÛÖÁYÜÖÁÈÖ^c{ á^•Á@Á! , æáÁ] ^Á Á^Á €Á[c^•á/ÁV & } áææ } æÁæ/Á Á~ c^Á ÁÁ! , æáÁ á^•cææ } Á } & } áææ } æÈÁÜ^ ^ á * Á ç^!- , Áæ/Á Á !~ c^Á ÁÁ! , æáÁ^•cææ } Á @} ÁÁ^ ^ ^Á ç^!- , ÈÁÁ Ü^ ^ á * Á Á ^ [~ cÁæ/Á Á Á~ c^Á ÁÁ! , æáÁ^•cææ } Á , @} Á^ ^ á * Á Á Á c} á^•ÈÁÜ^ ^ á * Áæ/Á Á Á~ c^Á Á æÁ! , æáÁ^•cææ } Á @} ÁÁ^ ^ ^Á ç^!- , •ÁÁ^ ^ á * Á ç^ Á Á c} á^•È</p>	H	<p>€Á[cÁV^á FÁV & } á GÁÜÁ ç^!- , HÁV Á Á^ c KÖ</p>	€Á[cÁV^á
<p>ÖY ÖÖÖÜVÖÖVÖÜÖÁÈÖ^c{ á^•Á@Á! , æáÁ^•cææ } Á G^ } \ ÁæÁ^•Á Á á Á @^ áÁ^Á & } á^•ÁÈ</p>	Í	T æÁÍ Áá æ	È

pã cÖc} áæ cÖ| [~] ÖE•á } ÁVÜÖE ÜBUÖT ÁG Í DÖ Á^^Á^æá Á } Á æ ^ ÖÈGH

VÜÖEÜBUÖT ÁG Í	ÓVP	ÜÖEÖÖ	ÖÖÖEVS
<p>PÖPVÁÖVÖÖÜÁYÜÖÁÈÖ^c{ á^•Á@Á! ^Á Áá @Á Öc} áæ cÁ [~] È</p>	F	<p>€Á^! { á æ FÁÖá& æ GÁÜá * HÁ[] *^•cÁ^</p>	€Á^! { á æ
<p>PÖPVÁÖVÖÖÜÁÖEÁÈÖ^c{ á^•Á@Áæ ^Á Á@Áá @Á Öc} áæ cÁ [~] È</p>	G	T æÁÍ	È
<p>PÖPVÁ ÖT ÖÖÜÖÜÖÁÈÖ^c{ ÁÖææ } •ÁÁ^ { á^•Á Áá @Á Öc} áæ cÁ [~] È</p>	H	È	È

Digit Conv. Table (TRANS/PGM 251, TRANS/PGM 252) ... see details on [page A-104](#)

TRANS/PGM 251	BTN	RANGE	DEFAULT
APPLY T-TYPE -- The Apply time type to be applied when the dialed digit is dialed.	1	0:Unconditional 1:Follow DNT 2: Follow LCR	Unconditional
DIALED DIGITS -- The dialed digits.	2	Max 16 digits	-
UNCOND CHANGED -- The CO Group Access Code and digits to be sent to PX when the dialed digit is pressed if Apply time type is 'unconditional'.	3	Max 16 digits	-
DAY CHANGED -- The CO Group Access Code and digits to be sent to PX in Day when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	4	Max 16 digits	-
NIGHT CHANGED -- The CO Group Access Code and digits to be sent to PX in Night when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'	5	Max 16 digits	-
TIMED CHANGED -- The CO Group Access Code and digits to be sent to PX in Timed when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	6	Max 16 digits	-
D1/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	7	Max 16 digits	-
D1/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	8	Max 16 digits	-
D1/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	9	Max 16 digits	-
D2/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	10	Max 16 digits	-
D2/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	11	Max 16 digits	-
D2/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	12	Max 16 digits	-

VÜÇÈÙÈÛÖT ÁÍ F	ÓVP	ÜÇÈÖÒ	ÖÒØÇVŠV
ÖÈV/FÓPÇÈÖÖÖÆV@ÁUÁÖ;[~] ÁB&••ÁÖ[á^Áç áÁä ä Á ç Á^Á^} ç ÁÚYÁ ÁÇæ ÁEVÁ ^ÁÇ @} Á@Áç áÁä ä Á]!••^áÁÇ] Áç ^Áç] ^ÁÇ ÁÇUŠŠUY ÁÖÜÈ	FH	T æÁÍ Áä ä	È
ÖÈV/GÓPÇÈÖÖÖÆV@Áä ä Á Á^Áç áÁä ä Á Çæ ÁEVÁ ^ÁÇÁ , @} Á@Áç áÁä ä Á]!••^áÁÇ] Áç ^Áç] ^ÁÇ Á ÇUŠŠUY ÁÖÜÈ	FI	T æÁÍ Áä ä	È
ÖÈV/HÓPÇÈÖÖÖÆV@ÁUÁÖ;[~] ÁB&••ÁÖ[á^Áç áÁä ä Á ç Á^Á^} ç ÁÚYÁ ÁÇæ ÁEVÁ ^ÁÇ @} Á@Áç áÁä ä Á]!••^áÁÇ] Áç ^Áç] ^ÁÇ ÁÇUŠŠUY ÁÖÜÈ	FÍ	T æÁÍ Áä ä	È
ÖPÁV/Q ÖÁÇ ÖÖYÆZÖæ Þ æVÁ ^áÁç ^Áç ÁÇá^ÇÈ	FÍ	FÈÇ[]^	}[]^
ŠÖÜÁ/Q ÖÁÇ ÖÖYÆZÖÜÁç ^Áç ÁÇá^ÇÈ	FÍ	FÈÇ[]^	}[]^
ÞÇÈ ÖÆY @} ÁÇÁ^ç ç æç } Áç @ Áç * È@ Áç ^ÁÇ áä] ç áÁç } Áç Áç * ç * Áçæç } ÇŠÖÈ	FÍ	T æÁÍ Áä ä	È
ÇÈÚŠYÁÚVÞÆV@ÁÇ] ÁÚ ç } Áç Á^Áç] ä áÁ æç ä ä * Áç Áç æç È	FJ	ÈÇ } FKÜçæç } GÖUÁç ^ HÖæç ^	ÈÇ

VÜÇÈÙÈÛÖT ÁÍ G	ÓVP	ÜÇÈÖÒ	ÖÒØÇVŠV
ÖÇÚŠYÁÚVÞÆV@ÁÇ] ÁÚ ç } Áç Á^Áç] ä áÁ æç ä ä * Áç Áç æç È	F	U) È~	U~
ÚÜÖVÁUÞXÈÖÖVÆZÖÁ^ç ÁÚ ÞÈ@Áçæç } ÁÇÖÁ Á] áæ áÁ ç Á@Áç áÁä ä Á @} Áç ç * Á ^••æ^Áç Á^ç áÁ] { Á@ÁYÁ æç Áçæç * È	G	U) È~	U~

Voice Network

Þ^ç [\ | ÁÇæ æÁÇæ ç ÁÇVÜÇÈÙÈÛÖT ÁÇÈÇÁ Á^Áçæç Á } Áç ^ Á ÇÈÍ F

VÜÇÈÙÈÛÖT ÁÍ ÇÈ	ÓVP	ÜÇÈÖÒ	ÖÒØÇVŠV
ÞÖVÁÞÇÈÖŠÖÆV@Áç æ Á Á^ç Áçæç * Áçæç } Á^Á^} ç Áç Á çæç ä ÁÚ • ç { Á^ç ^} Á Ç ÖYÁÚ Á^ ç { • ÈÖÞÇÈÖÁç } ç æ áÁç @ Á çæç ä Á ç ç Á Çæç } • Áç ç Áç æ áÁ } Áç Á * ç { ç * È	F	ÈU~ FKU}	U~
ÞÖVÁÞÇÈÖŠÖÆV@Áç æ Á Á^ç Áçæç * Áçæç } Á^Á^} ç Áç Á çæç ä ÁÚ • ç { Á^ç ^} Á Ç ÖYÁÚ Á^ ç { • ÈÖÞÇÈÖÁç } ç æ áÁç @ Á çæç ä Á ç ç Á Çæç } • Áç ç Áç æ áÁ } Áç Á * ç { ç * È	G	ÈU~ FKU}	U)

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET CONP ENABLE -- Reserved for future usage.	3	0:Off 1:On	Off
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0:UUS 1:FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Network Numbering Plan (TRANS/PGM 321) ... see details on [page A-142](#)

TRANS/PGM 321	BTN	RANGE	DEFAULT
NUMBER TYPE -- Select Number Type	1	0: Net 1: Transit	Net
NUM PLAN CODE -- 'X' means any digits can be inserted between 0-9. (Select 'MUTE" button to input X).	2	8 digits	-
CO GROUP NO -- CO Group Number	3	01-72	-
AND DIGIT -- AND (Automatic Network Dialing) Digit	4	10 digits	-
DIGIT REPEAT -- Determine if AND digit is included in the SETUP message or not.	5	0: Off 1: On	Off
DIGIT SENDING -- Select digit sending mode (Overlap or Enblock)	6	0: Overlap 1: Enblock	Overlap

ADMIN PROGRAMMING*Voice Network*

Network Basic Attribute (TRANS/PGM 320 - FLEX 6-10) ... see details on [page A-142](#)

TRANS/PGM 320	BTN	RANGE	DEFAULT
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-999 9	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-999 9	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Application

BLF Manager Software

DECT Mobility

When one DECT is registered to more than two networked systems at the same time and the user of DECT moves to another networked system, the incoming call to DECT will be routed to the appropriate networked system automatically.

CONDITIONS

- DECT mobility information is sent through the LAN port of MPB.
- The physical port number of the DECT should be same as on whole systems.
- DECT must be registered to more than two systems for this functionality to work (refer to the Vertical DECT Installation Manual).

OPERATION

DECT Mobility is automatic.

ADMIN PROGRAMMING

Voice Network

Network Basic Attribute (TRANS/PGM 320 - FLEX 6-10)

TRANS/PGM 320	BTN	RANGE	DEFAULT
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-999 9	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-999 9	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with other systems for Voce Networking (Reserved).	10	-	0.0.0.0

Network Numbering Plan Table (TRANS/PGM 321 - FLEX 8)

TRANS/PGM 321	BTN	RANGE	DEFAULT
BLF SYSTEM IP -- IP Address of BLF Server used only when MBX IP is configured with other systems for Voice Networking	8	-	0.0.0.0

Traffic Analysis

```
V@ÁÜ•ç{ Á [] ä |•Éä |•Áä äÁ |ä ääæ |Á |Á [] Á~••ç~ d~ •Áçäq~ •Áæ-æÁ çæ ç•Á
& ç^|ä * ÁÜ•ç{ Á•[~ |&•ÉÄV@Á~ d~ ç^|{ Áç@ÁÜ•ç{ Áæ |Á^Á•^áÄ |Á
```

- " T [] ä |Áä äÁçäæ æ^Á•ç{ Á |•ç |{ ç &^Á
- " Uä•^|ç^Á•æ^Á^} ä•Áä äÁ&| { { ^} äÁ [••ä |Á& |!^&ç^Áæç} •ÉÄ
- " Ö^ç{| ä^Á [••ä |Á^} \ Á |! à |^ •ÁççÉÄ [| & ä * Áç^|Á | Áç @Éä ä |!Á
- " Ü^&| { { ^} äÁÜ•ç{ Á } *!æ^•É

```
V@Á |æ-æÁ | [ |Á^ |&ç^ äÁ^ Áç@ÁÜç} ää ç |Á^Á~ d~ ç^| |^Á [] Á~••ç~ É(Ö^ Á^) ç |Áç@Á
ä^ç^ äÁÜ•ç{ ÁÜÉHG |ÁÖÚÁ |!ÉÄ
```

- Ü•ç{ Á•[~ |&•Á | ç^| äÁ^ Á |æ-æÁÜ | | | •Á^ |Á
- " V^} ç |Öç |ÁÜ { { æ^ ÁÜ^ | |Öç |~ | |^ DÁ
- " Öç |Á^ |^ ÁÜ { { æ^ ÁÜ^ | |Öç |~ | |^ DÁ
- " ÖUÁÖ | |~ | ÁÜ { { æ^ ÁÜ^ | |Öç |~ | |^ DÁ

CONDITIONS

```
ÉÄ Viæ-æÁÜ | | | •Á | ä ç * Áæ |Á^ |æ^ÁÜç} ää ç |Öç |ÁÜ { { æ^ Áä äÖUÉÜÁÜ { { æ^ Á
Viæ-æÁÜ | | •ÉÄ
```

OPERATION

System Attendant

To print a Tenant Traffic Report:

- FÈ Ü |••Áç@ÁÜç |ÜÜÖT ä~ ç |} ÉÄ
- GÈ Öä |Éç |Á^} ç |Viæ-æÁÜ | | | ç | ä^ÉÄ
- HÈ Ü |^ |&Á^} ç | ç^| { à |ÁççÉÄ |ÁÉÜDÁ
- I È Ü |^ |&Öæ |ç | |{ çæ } |ç |Á^•ç | äæ É |Á | äæ DÁ
- Í È Ü |••Áç@ÁÜç |ÜÜÖT ä~ ç |} ÉÄ

To print a Call Type Traffic Report:

- FÈ Ü |••Áç@ÁÜç |ÜÜÖT ä~ ç |} ÉÄ
- GÈ Öä |Éç |Á^ |^ Á |æ-æÁÜ | | | ç | ä^ÉÄ
- HÈ Ü |^ |&Öæ |ç | |{ çæ } |ç |Á^•ç | äæ É |Á | äæ DÁ
- I È Ü |••Áç@ÁÜç |ÜÜÖT ä~ ç |} È

To print a CO Group Traffic Report:

1. Press the [TRANS/PGM] button.
2. Dial 023 {CO Group Traffic Report code}.
3. Select Day Information (0: Yesterday, 1: Today)
4. Press the [HOLD/SAVE] button.

ADMIN PROGRAMMING

System Data

RS-232 Port Settings (TRANS/PGM 230) ... see details on [page A-89](#)

TRANS/PGM 230	BTN	RANGE	DEFAULT
BAUD RATE -- Establishes the BAUD rate for the RS-232 serial port.	1	1: 9600 2: 19200 3: 38400 4: 57600 5: 115200	5:115200
PAGE BREAK -- The system can send a page break command over the serial port at the end of each page.	2	0:Off 1:On	0:Off
LINE PER PAGE -- Determines Page length, the number of lines the system will send before sending a Page break.	3	001-199	66
XON/XOFF -- Enables XON/XOFF protocol.	4	0:XOff 1:XOn	0:XOff

Serial Port Function Selections (TRANS/PGM 231) ... see details on [page A-90](#)

TRANS/PGM 231	BTN	RANGE	DEFAULT
ON LINE SMDR -- Defines the serial port or TCP channel used for the On-line SMDR.	1	0-5	COM
OFF LINE SMDR -- Defines the serial port or TCP channel used for Off-line SMDR.	2	0-5	COM
SMDI -- Defines the serial port or TCP channel used for the SMDI output.	3	0-5	COM1
CALL INFO -- Defines the serial port or TCP channel used to receive Call Information output.	4	0-5	COM

ADMIN PROGRAMMING

Table Data

System Time Table (TRANS/PGM 253) ... see details on [page A-107](#)

TRANS/PGM 253	BTN	RANGE	DEFAULT
TIME ZONE COMMENT-- defines the comment of the Time Table.	1	32 characters	none
SYSTEM TIME ZONE -- defines the Time Zone of the Time Table	2	0-73	0: Sys Time
DAYLIGHT SAVINGS -- defines Daylight Saving Time of Time Table.	3	On/Off	Off
RING MODE -- defines the ring mode of Time Table.	4	0: Day 1: Night 2: Timed	0:Day
AUTO RING MODE -- defines the Auto Ring mode of the Time Table.	5	On/Off	Off

Weekly Time Table (TRANS/PGM 254) ... see details on [page A-108](#)

TRANS/PGM 254	BTN	RANGE	DEFAULT
Monday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	1	0000-2359	Day: 9:00 Nite: 18:00 TDS: _-_ TDE: _-_
Tuesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	2	0000-2359	Day: 9:00 Nite: 18:00 TDS: _-_ TDE: _-_
Wednesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	3	0000-2359	Day: 9:00 Nite: 18:00 TDS: _-_ TDE: _-_
Thursday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	4	0000-2359	Day: 9:00 Nite: 18:00 TDS: _-_ TDE: _-_

VÜÇÈÙÈÛÖT ÁÍ I	ÓVÞ	ÜÇÈÖÒ	ÖÒØÈŠV
Ø ãæ ÁÖÏÞÐÖPVENQ ÖÖÁã * Á [á^Á çæÁã ^•Áã áÁVQ ÖÖÁ [á^Á ^} áÁã ^•È	í	€€€€€GHÍ J	Öæ ÍÁÍ€€ Þ æ ÍÁÍ€€ VÖUÍÁ È VÖÖÍÁ È
Üæ !áæ ÁÖÏÞÐÖPVENQ ÖÖÁã * Á [á^Á çæÁã ^•Áã áÁVQ ÖÖÁ { [á^Á} áÁã ^•È	î	€€€€€GHÍ J	Öæ ÍÁÍ€€ Þ æ ÍÁÍ€€ VÖUÍÁ È VÖÖÍÁ È
Û } áæ ÁÖÏÞÐÖPVENQ ÖÖÁã * Á [á^Á çæÁã ^•Áã áÁVQ ÖÖÁ [á^Á ^} áÁã ^•È	ï	€€€€€GHÍ J	Öæ ÍÁÍ€€ Þ æ ÍÁÍ€€ VÖUÍÁ È VÖÖÍÁ È

ŠÖÜÁã ^Áæ|ÁVÜÇÈÙÈÛÖT ÁÍ I DŠ Á^Áã çæ Á } Á æ ^ ÖÈFÉJ

VÜÇÈÙÈÛÖT ÁÍ I	ÓVÞ	ÜÇÈÖÒ	ÖÒØÈŠV
ÖÏÝÁZÞÁÉVQ !ÁæÖÁæ Á Á@Á ^\ ÈÖÖæ ÁZ [] ^ÁFÁ Á DŠ Á æ•ã } ^áÉV@Áæç^Öæ ÁZ [] ^Á Á@ÁZ [] ^Áæ•ã } ^áÁ Á@Á : ^} Öá áæ Á Á@Á ^\ ÁZ^cÁ ç } ÁÈ È	F	ØŠÖYÁÈ Á ÉÁÈH	Z [] ^ÁFÁÁæ•Á [Á@Á ^\
ÖÏÝÁZUPÖÁÉV@Á } d^ Á^á ^•Á@Áã ^Á [] ^Á Áæ Á [] ^ÁÁ , @ } Öæ ÁZ [] ^Á Á@Áç^È	G	€€€€	€€€€
ÖÏÝÁZUPÖÁÉV@Á } d^ Á^á ^•Á@Áã ^Á [] ^Á Áæ Á [] ^ÁÁ , @ } Öæ ÁZ [] ^Á Á@Áç^È	H	€€€€	È
ÖÏÝÁZUPÖÁÉV@Á } d^ Á^á ^•Á@Áã ^Á [] ^Á Áæ Á [] ^ÁÁ , @ } Öæ ÁZ [] ^Á Á@Áç^È	I	€€€€	È

P [|ãæ Áã ^Áæ|ÁVÜÇÈÙÈÛÖT ÁÍ I DŠ Á^Áã çæ Á } Á æ ^ ÖÈFÉÍ

VÜÇÈÙÈÛÖT ÁÍ I	ÓVÞ	ÜÇÈÖÒ	ÖÒØÈŠV
ÖÖŠÖÞÖÖÉJÁYÜÖÁÉÖ^ã ^•Öç^} áæÁV^ ÁÁ !ÁP [ãæ Áæ ÁÈ	F	Š^} æÈÖ^* [!ãæ	Ö!^* [!ãæ
PÜŠÖÖÝÁÖÖVÁÉÖ^ã ^•ÁP [ãæ Öæ ÁÁ !ÁP [ãæ Áæ ÁÈ	G	T T ÈÖ	P [] ^

System Database Backup To USB

The complete system database can be downloaded to a USB memory drive automatically. This can be scheduled to run once a week.

ADMIN PROGRAMMING

System Data

DB Auto Download, Weekly (TRANS/PGM 223 - FLEX 9) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
DB AUTO DOWNLOAD(WEEK) -- Determines when system database downloads to USB automatically,	9	1-7 represent: Mon-Sun	0: Off

DB Download Time (TRANS/PGM 223 - FLEX 10) ... see details on [page A-85](#)

TRANS/PGM 223	BTN	RANGE	DEFAULT
DB DOWNLOAD (TIME) -- Sets the time for system database download to USB automatically.	10	00-23	00

HARDWARE

USB Interface

Tenant Group

One System can be divided into several systems; each Station and Co line is assigned to a specific Tenant Group. Stations in a group are allowed or denied the ability to place intercom calls to Stations in other groups on a Group-by-Group basis.

Each Tenant Group has an Attendant Group. If a user dials 0 {Attendant Call Feature Code}, the call is routed to the assigned Attendant Group. Additionally, the assigned Attendant member can control the Day/Night Ring mode for Stations in the group switching from Day to Night mode. Each Group is assigned a separate Auto Ring Mode Table for changing the Ring and COS mode automatically during the Day and Night service mode (as applicable).

CONDITIONS

ËÄ ÇÄÜcæä } Á^ } a^á&æ&••Á ä|Á^c ! } Áæ ÄÖ!:[!Ä } ^Á @ } Áæc{] cä * ÄÄ Ä æ ^Áæ&æ|Ä ÁæÄ] æææ |æÁ^ } æ cÖ:[~] ËÄ

ËÄ V) æ cÖ:[^•Á [Áæ^&ó@ÄÜcæä } Á^ { à^!ä *Á|æ } Ä Ä@Á^•c{ LÄÄÄcæä } •Ä Ä@Á Ü•c{ Ä ~•c@æ^Áä^!^ } cÜcæä } Á^ { à^!•Áç^ } ÁÄ@^ Áæ^Áæ•ä } ^áÄÄ Áä^!^ } cÄ V) æ & Ä!:[~] •ËÄ

ËÄ Y @ } Á@ÄÜcä } äæ cÖ:[ÁæÁ^ } æ cÖ:[~] Á^•ÖæÐ ä @DVä ^áÄ [à^ÉÄÄ ä|Áæ^&ó] | Á c@Áæ•ä } ^áÁ^ } æ cÖ:[~] ËÄ

OPERATION

System

U] ^!æä } Ä Á^ } æ cÖ:[~] • Áæ æ ç { ææÄ @ } Ä!:[*!æ { ^áËÄ

ADMIN PROGRAMMING

Tenant Data

V) æ cÖ:cæÄÜcä * • ÄÜÜcæÜÜÖT ÄÍ €ÉÜÉDö Á^Á^cæä } Ä } Ä æ ^ ÖÉFH Ä@ ~ * cÄ] æ ^ ÖÉFH

Station Data

Ücæä } Á^ } æ cÖ:[ÉÜÜcæÜÜÖT ÄÍ €ÉÜÖYÁDö Á^Á^cæä } Ä } Ä æ ^ ÖÉF

VÜÜcæÜÜÖT ÄÍF	ÓVP	ÜÜcæÖÖ	ÖÖÜÜVŠV
VÖÜÜcæÜÜÖT ÄÍF } ^á^ Á^ } æ cÖ:[~] Ä!:[Ácæä } É	G	FÉÄT ÖYÄÜÉÉD FÉÄT ÖYÄÜÉÉD	F

CO Line Data

ÖÜÁ^ } æ cÖ:[ÄÜÜcæÜÜÖT ÄÍ €ÉÜÖYÁDö Á^Á^cæä } Ä } Ä æ ^ ÖÉÍ

VÜÜcæÜÜÖT ÄÍ€	ÓVP	ÜÜcæÖÖ	ÖÖÜÜVŠV
VÖÜÜcæÜÜÖT ÄÍ€ } Á^ { à^!Ä Äæ } Ä ÖÜÄæ^•É	Í	FÉÄT ÖYÄÜÉÉD FÉÄT ÖYÄÜÉÉD	F

Universal Answer (UA)

UA allows a user to be alerted via an external loud bell and answer defined CO/IP calls by dialing a UA code. While primarily intended for alternate answering, UA will also function in other modes providing UA in all service modes. Calls will appear on the {CO}/{IP} appearance or a {DN} button. An External Control Contact can be assigned to activate an external Loud Bell to alert users of incoming calls. Digital Phones may program a Flex button as a {UA} button.

CONDITIONS

- System will search a CO line for UA from first accessible CO line.

OPERATION

Digital Phone

To assign a Flex button as a {UA} button:

Press [TRANS/PGM] + {FLEX} + Button Feature Type (1) + {UA Feature Code} + [HOLD/SAVE]

To access an incoming UA call:

1. Lift the handset or press the [SPEAKER] button.
 2. Dial {UA Feature Code}; the UA call is connected.
- OR
3. Lift the handset or press the [SPEAKER] button.
 4. Press the {UA} button; the UA call is connected.

Single Line Phone

To access an incoming UA call:

1. Lift the handset.
2. Dial {UA Feature Code}.

ADMIN PROGRAMMING

Numbering Plan

Universal Answer Code (TRANS/PGM 113) ... see details on [page A-20](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
85	Universal Answer	587

CO Line Data

W) q^!•a^A^•, ^!ÁVÜCEÜBÜÖT ÁÍÎ ÁZSOYÄ D6 Á^^Á^a^A^ Á a^ ^ ÖE €

VÜCEÜBÜÖT ÁÍÎ	ÓVP	ÜCEÖÖ	ÖÖÖEVSV
WPQÖÜÜCESÜPÜY ÖÜÁEÁ@ Á^a^!^Á Á^Á ÁÜPÉa^ Á •a^} Á Á•, ^!Áa^A^ Á@ÁÜÁ Á^ Á^ Áa^ Á@ÁV) q^!•a^A^ CE•, ^!Á^a^!^Á a^É	ï	EAU~ FIAU)	U~

RELATED FEATURES

Š[~ áÁÖ||ÁÖ] d[|ÁSOÖD6 Á^^Á^a^A^ Á a^ ^ HÉFÍ

VMIB Integrated Auto Attd/Voice Mail

VMIB

V@Á[a^A^••a^A^c^!a^ÁÖ| a^ÁÖXT 040 & ^•Á| |&••a^* Áa^ áÁ ^{ [|^Á|Á@ÁÜ^•c^ Á
 a^c^!ae^a^CE d ÉCE} a^a^ dÁ[a^A^ a^Áa^ ÁÜ^•c^ { Áa^ } [~] &{ ^ } c^ ÉCE Áa^ } •ÉAV@Á ^{ [|^Á
 a^Á] [|^ÁÁ Á d|^ÁCE d ÉCE} a^a^ c^ } [~] &{ ^ } c^ É[a^A^ a^ÁÁ^••a^•Éa^ áÁ
 a^a^ •Á^•c^ Á| [[] c^ ÉAV@ÁÜ^•c^ Á| [[] c^ ÁÁ ^Éa^ ÉÁÖÉÁ^Á [|^ÁÁ Á@Á
 CE d ÉCE} a^a^ c^ a^Á[a^A^ a^Áa^] |a^a^ } •Áa^ Á^|Áa^ Á@Á^•c^ { Á^a^!^•ÉÁ

VMIB-Auto Attendant

Y @| Áa^A^Á { ^•Á Á Á@ÁÜ^•c^ Á@ [~ * c^ ÁÖT Á@ÉÁÖÖÁ|ÁÖÜÜCEÁ Á@Áa^ Á a^ÁÁ
 !| ~ c^ÁÁ Á ^Á Á ÉÁV^!ÉÁ &| á^áÁKT 040 } [~] &{ ^ } c^ ÉCE Áa^ } [~] &{ ^ } c^ Áa^•á^ÁÁ
 Üc^} ÁÖ| [~] Áa^ } [~] &{ ^ } c^ ÁÁÁÁ CE d ÉCE} a^a^ c^ } [~] &{ ^ } c^ ÁÖÖÁ|^ÁÖ] d[|^ÁÁ
 Ü| ~ c^ * ÁÖÜÜÁÜc^} ÁÖ| [~] Áa^ } [~] &{ ^ } c^ Áa^Á| a^ÁÁ @| Áa^A^Á Á| ~ c^ÁÁ Á@Á| [~] Á
 a^a^ÁÁ| Á^•á a^} •Á Üc^} ÁÖ| [~] ÁÖÁ c^ ÉÁ

Q | ÁÁ CE d ÉCE} a^a^ c^ } [~] &{ ^ } c^ Á@ÁÜ^•c^ { Á a^|Á| a^Á@Áa^ } [~] &{ ^ } c^ Áa^ áÁ [] a^| Á| Á
 áá a^ Á| { Á@Á & } ^&c^ áÁ c^!} a^| a^c^ ÉÁÖÖÜÁa^| Á^•á^• Áa^ a^ÁÁ a^ÁÁ ÁÁÁ ÁÁÁ a^ÁÁ Á
 a^Á•á} a^ÁÁ| ~ c^ÁÁ a^c^ a^a^ a^ÁÁ a^ÁÁ ÁÁ||^•[] áÁ a^ÁÁ| ~ c^ÁÁ

- " Üc^}
- " Üc^} ÁÖ| [~]
- " ÖÜÁÖ| [~] ÁÖ&••ÁÖ| á^
- " Qc^!} a^ÁÜa^ ÁZ[] ^
- " X| a^A^ a^ÁÖ&••ÁÖ| á^
- " ÖÖÜÁÖ&••ÁÖ| á^ÁÁKT 040 } [~] &{ ^ } c
- " ÖÖÜÁÖ&••Áa^ áÁÖ| [] ÁÖ| á^ÁÁKT 040 } [~] &{ ^ } c^

- Conference Room
- Net number
- Company directory
- Re-record VMIB announcement
- Direct VM transfer
- VM access

In addition, the System will monitor digits for a Station number; if the User dials a Station number, the Auto-Attendant will complete an unsupervised call transfer to the station.

CONDITIONS

- There are no individual time limits on Auto-Attendant announcements.
- The external caller may experience a Ring-Back tone before playback of a VMIB announcement.
- The Attendant Station must “Save” a recording before returning to the on-hook state, otherwise the existing recording is used and new recording will be lost.
- To record or delete an Auto-Attendant message, all of the VMIB channels must be in the idle state.
- The external caller may dial at any time during an Auto Attendant announcement and must dial prior to the expiration of the CCR Analysis timer.
- If the external caller dials an invalid selection or station, the System will present the Invalid Entry prompt and initiate a re-entry according to the DISA Retry Counter.
- If the external caller dials more than a single digit, the call is routed based on the System Numbering Plan.
- Calls answered by an Auto-Attendant (CCR) Announcement are interactive DISA calls and are subject to conditions of a DISA call.
- A CCR Announcement may be programmed to disconnect the call after playing.
- The Auto-Attendant Announcement feature is supported for DISA and DID calls.
- To allow back-tracking in call routing, assign one of the CCR destinations of a current step as the CCR announcement number for the previous step.
- The remote Caller’s voice mailbox access can be supported by assigning the {VMIB Access Code} to a CCR destination.

OPERATION

System Attendant

To record an Auto-Attendant Announcement:

FÈ Ú!^••Á@ÄÜÜÖPÜÜÖT Å~ ¼ } È
 GÈ ÖæÁÉ GÄ@Á^••æ^ÄÜ^& !â& å^È
 HÈ ÖæÁ@ÁKT 04[[0^ { à!ÈÄ
 I È ÖæÁ@ÁÉ } [~ } & { ^ } 0^ { à!ÁÉFÈ ÉÈ
 Í È Ò) c!Á@Áæ * æ^Á^ { à!ÁFÈÈÄ^ } [[!câDÁ@Áæ } [~ } & { ^ } ÁÚ!^••Á@ÄÄ^ Á Á
 !^& !âÈÁ å!Á^Á!^••} câÈÖ@!^Á æ^æ^ Áæ^& !ââÁ^ ••æ^Á@Á^ { à!Á
 åæ^âÈ@& !!^• } [] åå * Á^ ••æ^Á å!Á^Á |æ^âÈÄ
 Î È ÖæÁÄÄ
 Ï È Öc!Á@Á^] È } ^È& !âÁ^ ••æ^È
 Ì È Ú!^••Á@ÄPÜÖÜÖÖÖÅ~ ¼ } Á Á d] Á^& !âå * Áæ^âÁæ^Á@Á^ ••æ^È

To delete a recording:

FÈ Ú!^••Á@ÄÜÜÖPÜÜÖT Å~ ¼ } È
 GÈ ÖæÁÉ GÄT^••æ^ÄÜ^& !â& å^È
 HÈ ÖæÁ@ÁKT 04[[0^ { à!ÈÄ
 I È ÖæÁ@ÁÉ } [~ } & { ^ } 0^ { à!ÁÉFÈ ÉÈ
 Í È Ò) c!Á@Áæ * æ^Á^ { à!ÁFÈÈÄ^ } [[!câDÁ@Áæ } [~ } & { ^ } ÁÚ!^••Á@ÄÄ^ Á Á
 !^& !âÈÁ å!Á^Á@æâÈÖ@!^Á æ^æ^ Áæ^& !ââÁ^ ••æ^Á@Á^ { à!Áæ^âÈ
 @& !!^• } [] åå * Á^ ••æ^Á å!Á^Á |æ^âÈ
 Î È Ú!^••Á@ÄÜÜÖÖÖÅ~ ¼ } Á^ !å * Á |æ^â& Á Á |æ^Á^ ••æ^ÁÜ^•c{ Á] ^!æå } Á Á
 ÖÖÜÁÉ åå Á^c^Áæ!^• Áæ^âÁÉ d ÈÖc } åæ^Áæ^ d { ææÈÄ

ADMIN PROGRAMMING

Tables

ÖÖÜÁæ!^•ÁVÜÜÖPÜÜÖT ÁÉ ÉDÁ Á^Á^Áæ^ Á } Á æ^ ÖÉFG

VÜÜPÜÜÖT ÁÉ €	ÓVP	ÜÜPÖÖ	ÖÖÜÖVŠV
ÖÖÜÁÖÖÖÖÖÖ@Á^•cå æå } Á -ÖÖÜÁ] ~ Åæ^ å!Á@Á^•cå æå } Á &æ^ Á^Á^Áæ^ } Á^ { à!ÈÜææ } Á!] ^ } { à!Á!Á^æ^!^Á& å^ÈÄ PÜVÖKÁ !Á^æ^!^Á& å^ ÈÄ^!Á Á@Á^ { à!å * ÁÚ!Á Á!Á@Á æå } æ^!^Á& å^•È	FÉFG	T æ^Á Áæ^ æ	È

HARDWARE

XT 0

VMIB Voice Mail

Message Storage

When a station activates Call Forward to the {VMIB Access Feature Code}, the call is transferred to a VMIB mailbox or a transferred call recalls to the VMIB, the call is handled by the System's Voice Mail application. The caller can connect with the called Station User Greeting followed by a beep tone.

A remote Caller can record a message and hang-up or dial * for further options. When disconnected, the VM application will store the message in the Called User Voice Mailbox and activates the Message Waiting Indication (MWI) at the User Station. If VM back-up is assigned at the back-up station, Phontage or UCS Client is also notified.

CONDITIONS

- Two timers are provided to control voice message length:
 - VMIB-Message Minimum Record Timer: establishes the minimum voice message length; voice messages shorter than this timer are not stored.
 - VMIB-Message Maximum Record Timer: establishes the maximum voice message length; when the VMIB-Message Maximum Record Timer expires while a voice message is being recorded, a confirmation tone is heard and the message is saved for the destination station.
- If all VMIB channels are in use, a Ring-Back tone is provided until a VMIB channel is available.
- All active Stations including SLTs can leave and receive voice messages.
- Individual User Greetings and Voice Mails are protected from loss of AC power.

OPERATION

Remote Caller

To leave a voice message:

1. After receiving the Greeting and beep on an attempted call, record the desired message.
2. Hang up to quit recording or dial * for further options.

TRANS/PGM 145	BTN	RANGE	DEFAULT
TWO-WAY RECORD DEVICE -- Determines the save location of Two-Way recorded wav files: VM Boards, or Phontage. When Phontage is selected, recorded wav files are saved on the hard disk of the Phontage program-installed PC.	5	-	VM Boards
REC-MSG BACKUP STA -- When station has new voice mail saved on the VM internal boards, this information is reported to the assigned Phontage number. Phontage user can backup saved voice mail from VM internal boards to the hard disk of the Phontage program-installed PC.	6	-	-
BACKUP MSG DELETE -- When enabled, Phontage user can delete all voice mail in VM internal boards.	7	0: Disable 1: Enable	Disable
VMIB MSG TYPE -- Messages stored in the VMIB may be retrieved in either a FIFO (first-in-first-out) or LIFO (last-in-first-out) order based on this entry.	8	0: LIFO 1: FIFO	LIFO
VMIB NEW MSG NO -- Display the number of new messages.	9	-	-
VMIB SAVE MSG NO -- Display the number of saved messages.	10	-	-

HARDWARE

VMIB

Message Retrieval

A user can access their Mailbox locally from a Digital Phone by dialing the {VIMB Access Feature Code}, by pressing the [MSG/CALLBK] button, or by pressing a pre-assigned {VMAILBOX} Flex button when Off-Hook receiving Intercom dial tone. Prompts are presented to guide the User in the Voice Mailbox operation. The User must enter a Mailbox number (Station number), and a corresponding password in response to the Request for Mailbox number ("Please enter your Mailbox number.") and Request for Password ("Please enter your password code.") prompts. Additional prompts and mailbox operation is described in Operation, or refer to your Phone or Voice Mail User Guide.

CONDITIONS

- If no new/old messages are available, pressing 1 or 2, is an invalid operation and the User receives the "Invalid Entry" prompt or "No Message" prompt.
- If the dialed number is not recognized, the "Invalid Entry" prompt is played; after the second invalid entry, the User is disconnected.

To attach a memo to the current voice message:

1. After message playback, dial 7 during or after message option prompt.
2. Following the beep, record the desired memo.
3. Press * key to stop recording and store the memo.
4. During or after the New/Old Option Prompt, dial to forward the message and memo.

Single Line Phone

To retrieve Voice Mail locally:

1. Lift the handset.
2. Dial the {VMIB Access Feature Code}; the Mailbox & Password will be presented sequentially.
3. Enter the Mailbox number (Station number) and corresponding password; if entry is valid, the Number of Messages prompt will be presented.
4. Dial desired option code,
 - 1: Play New Messages
 - 2: Play Saved Messages
 - 8: Set Greeting or Password
 - #: Disconnect
 - 0: Operator
 - 9: Replay Prompt
5. Following selection, additional prompts will be presented.
6. At completion of session, hang-up to return to idle.

To attach a memo to the current voice message:

1. After Message Playback, dial 7 during or after Message Option Prompt.
2. Following the beep, record the desired memo.
3. Dial * to stop recording and store the memo.
4. During or after the New/Old Option Prompt, dial 4 to forward the message and memo.

RELATED FEATURES

Message Retrieval Options ... see details on [page 3-269](#)

Remote Message Retrieval ... see details on [page 3-267](#)

Multiple Voice Mailbox Support ... see details on [page 3-122](#)

HARDWARE

VMIB

Remote Message Retrieval

The System permits remote Users access to their Mailbox. After accessing the VMIB Voice Mail, operation follows the local procedures.

CONDITIONS

- The conditions associated with Message Retrieval and Message Retrieval Options apply.
- The conditions associated with DISA/DID apply.

OPERATION

Remote Caller

To access Voice Mailbox from a remote location:

1. Lift the handset.
2. Dial the telephone number of a DISA assigned CO Line assigned for answer by a VMIB Auto-Attendant.
OR
3. Dial a Station Group number assigned for answer by a VIMB Auto-Attendant.
4. Upon answer, dial {VIMB Access Feature Code}; the Request for Mail Box Number prompt will be presented.
5. Follow local access procedures.
OR
6. Dial a number and reach your VM greeting.
7. At your VM greeting press *.

RELATED FEATURES

Message Retrieval Options ... see [page 3-269](#)

VMIB - Auto Attendant ... see [page 3-258](#)

Message Retrieval ... see [page 3-263](#)

HARDWARE

VMIB

Message Retrieval Options

The user may dial the digit 9 to receive the VM Long Options prompt while in the Voice Mailbox, including during or after a Voice Message or System Prompt except when an option has been selected that requires user dialing. The VM Long Options prompt is:

"To play New Messages, press 1. To play Saved Messages, press 2. To set Station Forwarding, press 7 (available only for remote access). To set Greeting or Password, press 8. To Disconnect, press #. Press 0 for the Operator. Press 9 to hear this message again."

The VMIB Voice Mail will respond to incoming digits as shown in the following table.

VMIB Voice Mail Input

Digit	Function	Prompt
1	Play New Msg	--
2	Play Saved Msg	--
7	Set Cancel/Fwd	--
8	Mail Box Setting	Mailbox Settings (greeting/password)
9	VM Long Options	VM Long Options
#	Drop	Goodbye
0	Attendant Group Call	Call to System Attendant

When the user responds by dialing 1, the first New Message is played. At the end of message playback, the New Message option prompt is presented:

"To Replay Message, press 1. To listen to the next Message, press 2. To Delete Message, press 3. To Forward Message, press 4. To Call the Sender, press 5. To Skip Message, press 6. To return to Main Menu, press 9."

This process is repeated until the last new message is played and the No Message prompt ("No Messages") is played.

ADMIN PROGRAMMING

Station

Station VMIB Attributes (TRANS/PGM 145) ... [page A-40](#)

TRANS/PGM 145	BTN	RANGE	DEFAULT
VMIB ACCESS -- Permits station access to VMIB.	1	0: Disable 1: Enable	Disable
PROMPT LANGUAGE INDEX -- Selected language type prompt is played to the user when accessing the VMIB.	2	1-3	1
AUTO-RECORD SERVICE -- Determines if user can record a conversation with another user (internal/external). It can be used without two-way record button.	3	0: Disable 1: Enable	Disable
TWO WAY RECORD ACCESS -- When allowed, the station can activate the Two-way record feature to record a conversation.	4	0:Disable 1:Enable	Disable
TWO-WAY RECORD DEVICE -- Determines the save location of Two-Way recorded wav files: VM Boards, or Phontage. When Phontage is selected, recorded wav files are saved on the hard disk of the Phontage program-installed PC.	5	-	VM Boards
REC-MSG BACKUP STA -- When station has new voice mail saved on the VM internal boards, this information is reported to the assigned Phontage number. Phontage user can backup saved voice mail from VM internal boards to the hard disk of the Phontage program-installed PC.	6	-	-
BACKUP MSG DELETE -- When enabled, Phontage user can delete all voice mail in VM internal boards.	7	0: Disable 1: Enable	Disable
VMIB MSG TYPE -- Messages stored in the VMIB may be retrieved in either a FIFO (first-in-first-out) or LIFO (last-in-first-out) order based on this entry.	8	0: LIFO 1: FIFO	LIFO
VMIB NEW MSG NO -- Display the number of new messages.	9	-	-
VMIB SAVE MSG NO -- Display the number of saved messages.	10	-	-

Numbering Plan

VMIB Access Code (TRANS/PGM 113) ... [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
39	VMIB Access	523

ADMIN PROGRAMMING

Pre-Programmed Data

Station VMIB Attribute (TRANS/PGM 108) ... [page A-14](#)

TRANS/PGM 108	BTN	RANGE	REMARK
IP ADDR -- Public IP Address required for remote user and Web-admin. IPv4 format.	1	-	10.10.10..1
SUBNET MASK -- Used to register a Phonatg to the System, by entering its User ID and Password.	2	-	255.255.0.0
ROUTER IP ADDR -- IP Address of router for external network (WAN/IP) access. Required for shared voice and data LAN and remote Web access.	3	-	10.10.10.254
FIREWALL IP ADDR -- When the system is installed behind a NAPT server, the fixed IP Address provided by the NAPT server must be assigned in this field. Also, use this IP address for the MFIM address in remote devices.	4	-	0.0.0.0
DNS IP ADDR -- IP Address of Domain Name Server, which MBX IP will use to resolve URLs to an IP address. The DNS provides the resolution after receiving the name from MBX IP.	5	-	0.0.0.0
H.323 PORT -- H.323 UDP Port.	6	-	1720
SIP PORT -- SIP UDP Port.	7	-	5060
DHCP USAGE -- If this field is set to 'ON', the system gets the IP-address from the DHCP Server when it is booting.	8	-	Off
DIFFSERV -- Diff-Serv pretag value.	9	-	04

Station Data

Station VMIB Attribute (TRANS/PGM145) ... [page A-40](#)

TRANS/PGM 145	BTN	RANGE	DEFAULT
VMIB ACCESS -- Permits station access to VMIB.	1	0: Disable 1: Enable	Disable
PROMPT LANGUAGE INDEX -- Selected language type prompt is played to the user when accessing the VMIB.	2	1-3	1
AUTO-RECORD SERVICE -- Determines if user can record a conversation with another user (internal/external). It can be used without two-way record button.	3	0: Disable 1: Enable	Disable

Voice Mailbox Settings

The User can program personal Mailbox settings including a security password and a greeting. When a user presses 8 while retrieving messages, the Mailbox Setting prompt, ("To edit your greeting, press 1. To edit your password, press 2. To return to Main Menu, press 9.") is played.

CONDITIONS

- If the User is external (remote), the User must begin dialing within the CCR Analysis time, if not the call is released.
- If the dialed number is not recognized, the Invalid Entry prompt is played.
- The User must assign a password (Authentication Code= up to 12 digits) before access to the mailbox will be allowed.

NOTE: NOTE: Greeting does not need to be recorded.

OPERATION

To program Mailbox settings while using the Voice Mailbox:

Press 8 (Mailbox settings), the Mailbox Setting prompt is presented.

To modify the Password:

1. Dial 2, the Password Entry prompt will be presented ("Please enter your new password and press # when finished.").
2. Enter desired new password and then press the # key; the Reenter Password prompt will be presented ("Please re-enter your password to confirm and press # when finished.").
3. Enter the new password again, then press the # key; the Password Confirmation prompt is presented ("Your password is saved.").

To modify the Greeting:

1. Dial 1, the Greeting Option prompt will be presented ("To listen to your current Greeting, press 5. To Record a new Greeting, press 7. To return to the Main Menu, press 9.").
2. Dial 5, to hear your Greeting.
OR
3. Dial 7, the Record Greeting prompt is presented ("At the tone, record your new greeting, press # when done.").
4. After the beep, record Greeting speaking in a normal voice.
5. When finished, press the # key, the Greeting Confirmation prompt is presented ("Your greeting is saved.").

To modify Mailbox Settings:

ÖæÁÉ@ÁT æáÁ[cÁ^cá * Á|[] óÁ !^·^} c^áÁM ÁááÁ[~ !Á !^·cá * ÉÍ !^··ÁÉÁ ÁááÁ
^ [~ Áæ· , [!áÉ !^··ÁÉÁ ÁÁc !} Á Á æ Á ^} ~ ÉÍ !^··Á+ÉÁ

RELATED FEATURES

- T^··æ^ÁÚq !æ^Á Á^Á æ^ HÉÍ F
- T^··æ^ÁÚ^dāçæÁ Á^Á æ^ HÉÍ H
- Ü^ [cÁT^··æ^ÁÚ^dāçæÁ Á^Á æ^ HÉÍ Í
- T^··æ^ÁÚ^dāçæÁ] c} ·Á Á^Á æ^ HÉÍ J

HARDWARE

XT 040

Call Forward from VMIB

Òc!} æÁ^··Á &æ Áæçæ Á !Á^æçæ ÁÓæÁ[, æáÁ !Á@áÁæá } ÉÁ !^··á * Á Á @Á
!^dāçæ * Á ^··æ^··Á qÁÁc !} Á@ÁT æá[cÁ^cá !, æáÁ|[] ÉÁ

CONDITIONS

- ÉÁ G@Á^··Á !Á c!} æÁ [c É@Á^··Á !Á ~ ·ó^* á Áæá * Á æ@ Á@ÁÓÜÁæ æ·á Á
cÁ ^æ áÁæá ~ á^··^} óá æ Á æ@ Á@ÁT 040 c !Éá áÁÁ ^ !Á [c@ÁæÁ Á
!^æ^áÉ
- ÉÁ T æá[cÁ^cá !, æáÁ Á] ^ Áæçæ Á !Á c!} æÁ^··Á ÉÁ

OPERATION

To activate Call Forward while using the VM:

- FÉ Ú!^··Á Á ÁT æá[cÁ^cá !, æáÉ@Á[!^··] [] áá * Á |[] óÁ Á & æ^áÉÁ
- GÉ ÖæÁÉ@Áæ· , [!áÁ } d^ Á |[] óÁ Á !^·^} c^áÁÚ^æ^Á} c!Á@Á { à!Á Á Á !, æáÁ
q ÁÉÁ
- HÉ ÖæÁ@Á^··Á áÁÚæá } Á { à!Á Á Á [] , ·KÉÁ Á[!, æáÁ Á [c@ÁÚæá } ÉáæÁ@Á
Úæá } Á { à!Á áÁ !^··Á@Á^··Á Á[!, æáÁ@Á -É^··Á@ÁÚÁ^áÁ { à!Á
æ áÁæÁ @ } Á { à!Á !^··Á@Á^··Á

To deactivate Call Forward:

- FÉ Ú!^··Á Á ÁT æá[cÁ^cá !, æáÉ@Á[!^··] [] áá * Á |[] óÁ Á & æ^áÉÁ
- GÉ ÖæÁ@ÁÚæá } Á[!, æáá * Áæ & Á |[] óÁ Á !^·^} c^áÁM ÁÁc !} Á Á@ÁT æá
{ ^} ~ ÁÉ@ÁÉ@ÁT æá[cÁ^cá * Á |[] ÉÁ

ADMIN PROGRAMMING

Station Data

Station VMIB Attributes (TRANS/PGM 145) ... [page A-40](#)

TRANS/PGM 145	BTN	RANGE	DEFAULT
VMIB ACCESS -- Permits station access to VMIB.	1	0: Disable 1: Enable	Disable
PROMPT LANGUAGE INDEX -- Selected language type prompt is played to the user when accessing the VMIB.	2	1-3	1
AUTO-RECORD SERVICE -- Determines if user can record a conversation with another user (internal/external). It can be used without two-way record button.	3	0: Disable 1: Enable	Disable
TWO WAY RECORD ACCESS -- When allowed, the station can activate the Two-way record feature to record a conversation.	4	0:Disable 1:Enable	Disable
TWO-WAY RECORD DEVICE -- Determines the save location of Two-Way recorded wav files: VM Boards, or Phontage. When Phontage is selected, recorded wav files are saved on the hard disk of the Phontage program-installed PC.	5	-	VM Boards
REC-MSG BACKUP STA -- When station has new voice mail saved on the VM internal boards, this information is reported to the assigned Phontage number. Phontage user can backup saved voice mail from VM internal boards to the hard disk of the Phontage program-installed PC.	6	-	-
BACKUP MSG DELETE -- When enabled, Phontage user can delete all voice mail in VM internal boards.	7	0: Disable 1: Enable	Disable
VMIB MSG TYPE -- Messages stored in the VMIB may be retrieved in either a FIFO (first-in-first-out) or LIFO (last-in-first-out) order based on this entry.	8	0: LIFO 1: FIFO	LIFO
VMIB NEW MSG NO -- Display the number of new messages.	9	-	-
VMIB SAVE MSG NO -- Display the number of saved messages.	10	-	-

Numbering Plan

VMIB Access Code (TRANS/PGM 113) ... [page A-19](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
39	VMIB Access	523

RELATED FEATURES

- T ^••æ^ÁÚq !æ^Áó Á^^Á æ^ HÉÛ F
- T ^••æ^ÁÚ^dâçæó Á^^Á æ^ HÉÛ H
- Ü^ { [e^Á ^••æ^ÁÚ^dâçæó Á^^Á æ^ HÉÛ Ì
- T ^••æ^ÁÚ^dâçæÁÚ] q } •ó Á^^Á æ^ HÉÛ J

HARDWARE

XT 04AA

Delete All VM Messages

04AA^!ÁXT Á ^••æ^Áó Á^^Á^e^âÁ •q * Á@ÁÖ^!e^Á 04AA ÁÖ^!e^Áæ !^Á& á^ÉÁ

OPERATION

To delete all a user's VM Messages:

- FÈ Öæ^ÁÖ^!e^Á 04AA ÁÖ^!e^Áæ !^Á& á^ÉÁ
- GÈ Ò) e^Á^!e^Á q ÁE q |ã æá } Á& á^ÉÁ
- HÈ Öæ^ÁÖ^!e^Á 04AA

ADMIN PROGRAMMING

System Data

Ö^!e^Á 04AA Á ^••æ^ÁÖ [á^ÁVÜÖE ÜEÜÖT ÁFHÖ Á^^Áæ^Á } Á æ^ ÖÉÖE

ÖVP	ÖÖE/MÜÖÁVÜÖE ÜEÜÖT ÁFHÖ	ÜÖT ÖËS
ÌÌ	Ö^!e^Á 04AA Á ^••æ^	ÌÌF

Direct VM Transfer

Internal/External Calls can be directly transferred to a designated Station Voice Mail Box.

CONDITIONS

- VMIB Access option must be ON.
- If VMIB channel is all used, recalling is served to transferring station.

OPERATION

To activate Direct VM Transfer:

1. While on a CO/ICM Call.
2. Press [Trans] button and dial the {Direct VM Transfer} feature code.
3. Dial desired Station Number.
4. Go on-hook; VM Transfer will be completed.

ADMIN PROGRAMMING

System Data

Direct VM Transfer Code (TRANS/PGM 113) ... see details on [page A-20](#)

BTN	FEATURE (TRANS/PGM 113)	REMARK
89	Direct VM Transfer	683

NomadSP Message Backup and Delete

MBX IP Softphone (NomadSP or UCS Clients) can be notified of voice mail for a Registered Station on MIB boards. Softphone users can check their own voice mail and hear recorded voice mail of registered stations. Also, Softphone users can backup voice mail to their PC, and then can manage their voice mails. User can delete voice mail on VMIB boards, according to their assigned authority.

CONDITIONS

- Phontage backup will be operated when messages are saved at VMIB boards.
- If Backup Message Delete is executed, voice mails at target station will be deleted in VMIB boards.

OPERATION

Message Backup and Delete function is automatic (refer to Softphone User Guide for user operation).

ADMIN PROGRAMMING

Station Data

Ü^&|!âÁ^••æ^ÁÖæá~] ÁÚ@} æ^Á^~ { à^!ÁVÜCEÜBÜÖT ÁFÍ | ÁZÖSÖYÁ DÖ Á^Á^Á^æ^Á
[] Áæ^Á ÖH €

VÜCEÜBÜÖT ÁFÍ	ÓVP	ÜCEÖÖ	ÖÖÖEŠV
ÜÖÖÈ ÜÖÁÖÖÖSWÁVÖEY @) Áæá } ÁÖ Á^, Á[æ^Á æ^Áæ^Á [] Á@ÁT Á c!) æá[æá• ÁÖ Á { { æá } Á Á^ [c^á Á @ Á• á^á Ú@} æ^Á^~ { à^!ÁÚ@} æ^Á•^!ÁÖ Áæá~] Áæ^á[æ^Á æ^Á { Á XT Á c!) æá[æá• Á Á @ Áæá Á Á Á @ ÁÚ@} æ^Á] *!æ Á•æ^ÁÁÖÈ	î	È	È

Öæá~] Á^••æ^ÁÖ^c^ÁVÜCEÜBÜÖT FÍ | ÁZÖSÖYÁ DÖ Á^Á^Á^æ^Á } Áæ^Á ÖH €

VÜCEÜBÜÖT ÁFÍ	ÓVP	ÜCEÖÖ	ÖÖÖEŠV
ÖÖÖSWÁT ÜÖÖÖÖÖVÖEY @) Á) æá^áÁÚ@} æ^Á•^!ÁÖ Á^c^Á æá[æ^Á æá ÁT Á c!) æá[æá• È	î	ÈÖæá^ FÁÖ) æá^Á	Öæá^

System Voice Memo

V@Áæ^!Á^| çæ^Á^c^!æ^Á^!æ^Á[æ^Á^ { [•Á Á | çæ^Á@Á^•c^! Áá^ Áæ^ÁÖæ^Á
, ^|ÁÖ ÁÚæá } Á^~ { à^!ÁÖ) áÁ^æ^Á•Á c^!Á@ ÁÖ) æ^ÁÚ@} Á^] ^æ^!Á^!Á@ ÁÖ) á•á^! ÁÚŠV ÈÁ

CONDITIONS

ÈÁ Ø | ÁÚæá } ÁÚæá • ÈÁ { •Á { ÁÖ) c^áÁ^••æ^Á^Á ÁÖUÚÁ^Á á|Á^Á [c^ÁÁ } [~ } &^áÁ
áÁ [c^ÁÁ^ÈÁ

OPERATION

Digital Phone

To hear Date & Time Prompt:

FÈ Öæ^ÁÚ^•c^! { Á[æ^Á^ { [ÁÖ } [~ } &á * ÁÖæ^EÁ^ Á&| á^ÈÁ
GÈ Ö } [~ } &^ { ^ } c^! ÁÖæ^ÁÁÁ^ ÁÁ Á@æáÁÖæ^Á ÁT æ ÁG áÈÁÁ^ ÁÁ Ác^c^Á { ÈÁÁ

To hear Station Number Prompt:

FÈ Öæ^ÁÚ^•c^! { Á[æ^Á^ { [ÁÖ } [~ } &á * ÁÚæá } Á^~ { à^!Á&| á^ÈÁ
GÈ V@ÁÚæá } Á^~ { à^!Á } [~ } &^ { ^ } c^! ÁÚæá } ÁÁ@æáÁÖæ^Á ÁÁ Áæá } ÁFÍ ÈÁÁ

To hear Station Settings:

1. 1Dial {System Voice Memo Announcing Station Configuration code}.
2. Status for the Station is reported. Items reported are as follows:
 - Station IP Address
 - Station Mac Address
 - Station ICM Mode (Handsfree/Tone/Privacy)
 - Listed message x (x: number of all messages waiting)
 - Wake-Up Time (hh:mm)
 - Do not disturb - COS x

Single Line Phone*To hear Date & Time Prompt:*

1. Lift the handset.
2. Dial {System Voice Memo Announcing Date/Time code}.
3. Announcement for Time is heard, "Date is May 2nd.Time is xx:xx pm."

To hear Station Number Prompt:

1. Lift the handset.
2. Dial {System Voice Memo Announcing Station Number code}.
3. Announcement for Station is heard, "This is station 150."

To hear Station Settings:

1. Lift the handset.
2. Dial {System Voice Memo Announcing Station Configuration code}.
3. Status for Station is reported. Items that will be reported are as follows:
 - Station number
 - Station IP Address
 - Station Mac Address
 - Station ICM Mode Handsfree/Tone/Privacy)
 - Listed message x (the number of all messages waiting)
 - Wake-Up Time (hh:mm)
 - Do Not Disturb
 - Queued CO/IP xx
 - Locked (temporary COS change)
 - COS x

Wake-up Alarm

This feature allows a User or Attendant to set a Wake-Up time or desired time to be alerted. When the time is reached, the System will signal with an audible and visual notification.

CONDITIONS

- When receiving a Wake-Up signal, lifting the handset will return Wake-Up Answer Tone.
- The Wake-Up alarm ring signal follows the Ring Table.
- If the User does not answer the Wake-Up Alarm ring, it is repeated according to the Wake-Up Retry Counter with the interval of Wake-Up Retry Timer.

NOTE: The value 'N' of the Wake-Up Retry Counter means that 'N' repetition of Wake-Up Retry can occur after the first Wake-Up Alarm ring occurs.

The wake-up alarm ring will recur according to the Wake-up Retry Time and continues during Wake-Up Alarm Ring Timer.

If no action is taken by the User until the end of the Wake-Up Retry Counter, the ring signal is presented at the Attendant Station with a display designating the Station number that did not respond to Wake-Up Alarm.

- Time (hh:mm) must be entered in the Military format (24-hour).
- The Daily Alarm will reset and repeat each day until erased (cancelled), however, One-Time Alarm will reset and cancel automatically.
- When registering Wake-up Time, if user dials 1, then the One-Time Alarm will be set or if User dials 2, then the Daily Alarm will be set.

OPERATION

System Attendant

To register a Wake-Up Alarm:

1. Press the [TRANS/PGM] button.
2. Dial 045 {Attendant Station Program code}.
3. Dial the desired Station range; for a single station, enter the same Station Number twice.
4. Enter Time for Alarm (hh:mm).
5. For a Daily reminder (Repeating Alarm), dial #. 6. Press [HOLD/SAVE] button.

To erase Wake-Up Alarm:

FÈ Ú!^••Á@ÄÜÜÇEÜBÜÖT áá~ æ } ÈÁ
 GÈ ÖãÁ@ÁU! [*!æ Á [á^dÁ [} -á { æ } Á } ^/Á @ æ á ÈÁ
 HÈ ÖãÁ@Á • á^ÁUÇæ } Áæ *^LÁ [Áæ á *^Á Çæ } ÈÁ } ç!Á@Áæ ^Á Çæ } Á } { à^Á
 ç æ È
 Í È Ú!^••ÄPUSÖBÜÇXÒáá~ æ } È

Digital Phone

To register Wake-Up Alarm:

FÈ Ú!^••Á@ÄÜÜÇEÜBÜÖT áá~ æ } È
 GÈ ÖãÁFHÁU^ÁY æ ^È] Á [á^dÁ
 HÈ ÖãÁVá ^Á [Á Çæ { Á Çæ { ÈÁ
 Í È Ç [Á Çæ ÁU^ ^æ * Á Çæ { ÈÁ æ Á ÈÁ
 Í È Ú!^••ÄPUSÖBÜÇXÒáá~ æ } ÈÁ

To stop the Alarm when alerting:

ŠãÁ@Áæ á^Á Ç [Á!^••ÄÜÜÇEÜBÜÖT ÈÁ

To erase Wake-Up:

FÈ Ú!^••Á@ÄÜÜÇEÜBÜÖT áá~ æ } ÈÁ
 GÈ ÖãÁFI ÁÒ:æ^ÁY æ ^È] Á [á^dÁ
 HÈ Ú!^••ÄPUSÖBÜÇXÒáá~ æ } ÈÁ

Single Line Phone

To register Wake-Up:

FÈ ŠãÁ@Áæ á^dÁ
 GÈ ÖãÁ@ÁU! [*!æ Á [á^dÁ &••Á [á^dÁ [} -á { æ } Á } ^/Á @ æ á ÈÁ
 HÈ ÖãÁFHÁU^ÁY æ ^È] Á [á^dÁ
 Í È ÖãÁVá ^Á [Á Çæ { Á Çæ { ÈÁ
 Í È Ç [Á Çæ ÁU^ ^æ * Á Çæ { ÈÁ æ Á ÈÁ
 Í È Ú!^••ÄP [[Èæ Çæ á [} { { æ } Á } ^/Á Á [çæ^á ÈÁ

To stop the Alarm when alerting:

ŠãÁ@Áæ á^dÁ

To erase Wake-Up Alarm:

1. Lift the handset.
2. Dial the {Program Mode Access} code; confirmation tone is heard.
3. Dial 14 {Erase Wake-up code}.
4. Press Hook-flash, and a conformation tone is provided.

ADMIN PROGRAMMING

Station Data

Wake-Up Time (TRANS/PGM 134 - FLEX 8) ... [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
WAKE UP SET -- sets wake-up time.	8	HH:MM	-

Repeat Wake-up (TRANS/PGM 134 - FLEX 9) ... [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
WAKEUP REPEAT -- enables daily repeating alarm.	9	0:Off 1:On	Off

Table Data

Wake Up Answer Tone ... use Web Admin (TRANS/PGM 290 - FLEX 65) ... [page A-138](#)

INDEX	TONE NAME	DESCRIPTION
65	Wake-up Answer Tone	This is provided when station answers wake-up ring.

Wake-Up Indication Ring ... use Web Admin (TRANS/PGM 265 - FLEX 10) ... [page A-115](#)

INDEX	RING NAME	REMARK
10	Wakeup Indication Ring	-

Tenant Data

Y æ ^ È M Ä Ü ^ d ^ Á Ö [~ } ò V Ü Ö P Ù B J Ö T Á G € È Ö S Ö Y Ä D S Ä æ ^ Ö È G

VÜ Ö P Ù B J Ö T Á G €	Ó V P	Ü Ö P Ö Ö	Ö Ö Ö Ö V Š V
Y Ö S Ö Ä M Ü Ä Ü Ö V Ü Y Ä Ö U W P V Ä È ^ ç ! { ä ^ • Á @ Ä æ ^ Ä M Ä d ^ Ä [~ } ç È	Í	€ È	H

Y æ ^ È M Ä Ü ^ d ^ Á ä ^ Ä V Ü Ö P Ù B J Ö T Á G € È Ö S Ö Y Ä D S Ä æ ^ Ö È G

VÜ Ö P Ù B J Ö T Á G €	Ó V P	Ü Ö P Ö Ö	Ö Ö Ö Ö V Š V
Y Ö S Ö Ä M Ü Ä Ü Ö V Ü Y Ä Ö Ö È ^ ç ! { ä ^ • Á @ Ä æ ^ Ä M Ä d ^ Ä ä ^ Ä ä [ð È	Í	€ È Ö È	€ F

THIS PAGE INTENTIONALLY LEFT BLANK.

*Chapter 4***Intercom**

This chapter provides detailed information covering description and operation of the Intercom features available in the MBX IP System Software.

Direct Station Select/Busy Lamp Field (DSS/BLF)

When a Flex button on a Digital Phone or DSS Console is assigned as a {DSS} button, it also serves as a Busy Lamp Field (BLF). The LED indicates the status of the associated Station or System facility.

{DSS} button indicates the following conditions:

- In use at Station
- In use by another Station
- DND
- Receive Incoming Call
- Hold
- Call Forward
- Conference at Station
- Conference by another Station
- Conference Initiator
- Lifted handset
- Leave pre-selected (custom) message

CONDITIONS

- A Station receiving an ICM call is considered Busy, and associated station LEDs will flash at all other stations.
- A Station receiving an ICM call will receive visual LED Flex button indication (flashing) associated with the Calling Station.
- The LED Flash Rate can be adjusted by Admin. Programming.

OPERATION

Digital Phone

To assign a {DSS} button to a Flex button on a Digital Phone or a DSS Console:

U i ^ . • . A V U C E U B U O T A E A O S O Y A E A O c i } A O a e i ^ A r] ^ C F D E A U c a a } A r { a i ^ A E A U C E O a A O U U B O S O A] ^ i a a } A A e c { a a A i | A e . a } ^ a A | ^ c A ~ c i } . E A

PROGRAMMING

Station Data

U c a a } A O a c a | ^ A O c i } A O . a } { ^ } A V U C E U B U O T A G I D S A ^ A A c a A } A a e ^ O E G J

System Data

S O O A O [| | E a e O U a e A V U C E U B U O T A G I D S A ^ A A c a A } A a e ^ O E I J

RELATED FEATURES

Q c' i & { A O a | A O T A O a | D S A ^ A A | _

Intercom Call (ICM Call)

O A [] E a [& a * A O T A A e c a a | ^ A A c a U c a a } . A A O A U . c { E A V ^ i . A a e A | a e A e A Q c' i & { A e A A c A O A U c a a } . A A O A U . c { A ^ A a a a * A a } | a e a | ^ A a a A e A ^ a A A O A U . c { A r { a i a * A U a E

CONDITIONS

E A Q c' i & { A O a A i } ^ A a | A a ^ E ~ o A e c a } A A [o a a } A a e A O a E] ^ A V a ^ A | A A O A c a ^ A A c ^ A } A a a A c A a A A O A Q c' i E a a A V a ^ i A O i | | A i } ^ A A i ^ A ^ c a A } @ A c a ^ E ~ o A & i . D A

E A O T A O a A i } ^ A A A [c a A e e | A a a a * A O A a . o a a a A

E A Q a O a | ^ a U c a a } A A O . ^ E Q c' i & { A O . ^ A i } ^ A A i | c a a ^ a A i | A O A O . ^ A i } ^ A a ^ A i A . ^ a } a . D A @ } A O A i | | A i } ^ A A A ^ o A A O A U . c { L a O A e A i A e A a a } } ^ A o A i A a e c a e A A a e i ^ A ~ & O a A T . o . a e ^ A Y a e D a | a e A i a i A i A O A a ^ E ~ d A

E A Q i A O a a e A U Q } ^ A . A i . E A } . ^ & c a ^ A Q c' i & { A e A A e A A A | a e A a A a Q ~ o A A ^ A A i A i ^ * a a A O T A A e A i } ^ A A c ^ A } A e A A Q [A ^ a A i A e a * E] D A @ A . A i A a] | ^ A i . o . A a } [c a | A O U U a c i } E A

E A Q A Q c' i & { A e A A i A e U c a a } A A O A i } ^ A i A i [a A O E] [~] & A i [a ^ A V A i A U Q c' i & { A U a } a a ^ A T [a ^ D A A i O A i } . a e A i A a e . ^ i A a A } | . o . A O a | ^ a A V ^ i A a A O A e a ^ A O [i A i ^ . o . A A O A U O C S O U a c i } A c [^ A - E Q [\ D A

Operation

Digital Phone

To place an Intercom call:

1. Lift the handset or press the [SPEAKER] button to receive the ICM dial tone.
2. Dial Station number or press the {DSS} button.
3. For Ring-Back tone, await answer.
OR
4. For Intercom splash-tone, speak and await answer.

SLT

To place an intercom call:

1. Lift the handset to receive ICM dial tone.
2. Dial Station number.
3. For Ring-Back tone, await answer.
OR
4. For Intercom splash-tone, speak and await answer.

PROGRAMMING

Numbering Data

Flexible Station Number (TRANS/PGM 112) ... see details on [page A-16](#)

TRANS/PGM 112	BTN	RANGE	REMARK
STATION NUMBER (edit by range)	1	Start station number & End station number	Delete all station numbers and update entered station number range only.
SINGLE STATION NUMBER (edit)	2	One station number	Bin 001-324 (MBX IP 300), bin 001-128 (MBX IP 100): 1 number per one station port (My-DNs for each stations). Bin 325-648 (MBX IP 300), bin 129-256 (MBX IP 100): Free station numbers for MADN type or extra SADN type numbers (Sub-DNs).

Feature Numbering Plan (TRANS/PGM 113) ... see details on [page A-17](#)

3. Replace the handset.

To retrieve the held ICM call:

Lift the handset; station is connected with the Held party.

PROGRAMMING

Numbering Data

Feature Numbering Plan ([TRANS/PGM] 113) ... see details on [page A-17](#)

RELATED FEATURES

Music-On-Hold (MOH) ... see [page 3-123](#)

Intercom Call (ICM Call) ... see [page 4-2](#)

Hold ... see [page 3-101](#)

Hold Recall ... see [page 3-102](#)

Intercom Caller Controlled ICM Signaling

A User can change the Signaling mode of an ICM call from Tone ring to Voice announce.

CONDITIONS

- The ICM Signal mode cannot be changed if the Called Station number is {MADN}.
- If the Signaling mode is changed, the Call is not subject to Call Forward, No Answer.
- The Signaling mode for a specific Intercom call can only be changed once and cannot be changed back to the original Signaling mode.
- Changing the Signaling mode does not affect privacy at the Called Station.

OPERATION

To change the ICM Signaling mode:

1. Dial {Force HF Calling Code}.
2. Place intercom call,
OR
1. Place intercom call.
2. Dial #

PROGRAMMING*Station Data*

Howler Tone ([TRANS/PGM] 121 - FLEX 7)... see details on [page A-24](#)

[TRANS/PGM] 121	BTN	RANGE	DEFAULT
HOWLING TONE -- sets Anonymous Call Restrict service.	7	0: Off 1: On	On

Tenant Data

Dial Tone ... use *Web Admin* ([TRANS/PGM] 290 - FLEX 1-2)

Intercom Step Call

When the Busy Tone is received on a dialed Intercom call, the User may place a call to another Station by dialing the last digit of the Station number. The System replaces the last digit of the previously dialed Busy Station with the dialed digit and places an Intercom call to the new Station number.

CONDITIONS

- If the user dials the last digit of the Busy Station, Camp-On will be activated.
- After receiving a Busy tone, if the user takes no action for the Busy Tone Timer (7sec.), the System will start the Intercom Lockout procedure.
- If programmed, Step call is supported.

OPERATION**Digital Phone**

To activate Step call:

1. While receiving Busy notification on a dialed ICM call, dial a digit other than the last digit of the busy Station intercom number.
2. The System will attempt an ICM call to the new Station.

PROGRAMMING*Tenant Data*

Internal Busy Tone ... use *Web Admin* ([TRANS/PGM] 290 - FLEX 8)

While on an Intercom call, to perform an Unscreened call transfer:

1. Press the [TRANS] button.
 2. Dial the Station to receive the call.
 3. Hang-up, and return to Idle.
- OR
1. Press the {DSS/BLF} button for the desired Station.
 2. Hang-up, and return to Idle.

SLT

To perform a Screened transfer of an active Intercom call:

1. Press the Hook-switch.
2. Dial the Station to receive the call.
3. When answered, or on Splash tone, announce the call.
4. Hang-up, and return to Idle.

While on an Intercom call, to perform an Unscreened call transfer:

1. Press the Hook-switch.
2. Dial the Station to receive the call.
3. Hang-up, and return to Idle.

RELATED FEATURES

Hold Recall ... see [page 3-102](#)

Do Not Disturb (DND) ... see [page 3-77](#)

Call Transfer ... see [page 3-30](#)

INTRUSION

QÁÚcæá } Á^ ^ | &æ } ÁQ d´ á^ Á] [} Áæ } Á&æ } ÁÚcæá } Á[] ç^ | • æá } ÈQÁæ • ä } ^ á ÈÁ @ } Á@ ÁÚcæá } Á
Qd´ á^ • Áæ } ÁQ d´ • ä } Á[] ^ Á Á [] ç á^ á ÈÁæ } á Áæ } ^ | ^ } & ^ Á Á • æá | ä @ á Áæ [] * Á@ ÁQ d´ • ä } Á
Úcæá } ÈÁæ } á Á@ ÁÚcæá } Áæ } á ÁÓUÈWÁ æc ÈÁ

CONDITIONS

- " QÁÚcæá } Á´ • Á^ Á } æá | á Á | ÁQ d´ • ä } Á^ æ } ^ Á Á [] \ ÈÁ
- " QÁ@ ÁQ d´ á^ ÁÚcæá } Áæ } Á@ ÁÈ ç Á | ä æ } Á [] ç } Á^ á Á ÁÚP Á@ } Á@ Áæ | &æ } [Á^ ÁQ d´ á^ ÁÁ] [] ÈÁ

OPERATION

To perform an Intrusion:

- FÈ ŠáoP æ } á • á^ | Á | ^ • ÁÚ] ^ á^ | á ÈÁæ } á Á | æ } Áæ | Áæ } Á@ Á [] { æÁ æ } ^ | ÈÁ
- GÈ Y @ } ÁQ´ • Áæ } ^ Á Á@ æ á ÈÁ | ^ • ÁÚÜÇÈ ÒÚÁæ } ç } Áæ } á Áæ } Á@ ÁQ d´ á^ ÁÚ^ * ä ç | Á
Ø æ } ^ ÁQ [á^ ÈÁ
- HÈ Y @ } Áá ä @ á Á æ } ÁQ d´ • ä } Áæ | ÈP æ } ÈM Áæ } á Á^ ç | } Áæ } ÁÚ | ÈÁ

PROGRAMMING

Station Data

Qd´ • ä } ÁQ & Á • ÁÚÜÇÈ ÒÚÁÖT áFHG ÈÁÖŠÓYÁ DŠ Á^ Á^ Á^ æá } Á } Áæ ^ ÇÈHÁ

ŽÜÇÈÒÚÁÖT áFHG	ÓVP	ÜÇÈÒÒ	ÒÒÈÇÈŠV
QVÜWÜQÞ ÁÈÒÒÜÈÁæ } æá ^ Á d´ • ä } Á Áæ } Á&æ Áæ } Áæ } ÁÚcæá Á &æ È	Í	ÈÁQá æá FÁQ } æá	Öá æá

ÇÈ ç Á | ä æ } ÁÚÜÇÈ ÒÚÁÖT áFHI ÈÁÖŠÓYÁ F DŠ Á^ Á^ Á^ æá } Á } Áæ ^ ÇÈH

ŽÜÇÈÒÚÁÖT áFHI	ÓVP	ÜÇÈÒÒ	ÒÒÈÇÈŠV
ÇÈWUÁÚÜÇÈÖYÁ ÈÁQ } æá ^ Á ç } Á ä æ } Á^ æ } ^ ÁQ Á^ d } Á@ Á ä d´ • ä } Áæ Èæ } æá Èæ } È } ÈUPXÇÈ Á^ • Á^ æá } DÁ	FF	ÈÁÚ ~ FÁÚ }	U ~

RELATED FEATURES

U } ^ ÁQá æ Á^ | ç æ } Á^ Á^ Á^ æá } Á^ Á^ Á^ æá } HÈG

Message Wait/Call Back

Station Message Wait/Call Back

When a Called Station does not answer or is in DND, a Station User can activate a Message Wait Indication (MWI) to request a Call Back. A Station may receive a MWI from any number of other Stations in the System. The Station receiving the MWIs can return the calls using the [MSG/CALLBK] button.

When a Busy Station is called, the Calling User may request to be placed in a queue to receive a Call Back. When the Called Station returns to Idle, the System notifies the Initiating Station with Call Back ring. When the User answers, the previously Busy Station is called.

When a Message is waiting, the [MSG/CALLBK] button LED will flash; when MWI is received at a SLT, the MW lamp will flash.

CONDITIONS

- A Message Wait/Call Back Return Call will always ring at the Receiving Station overriding the Intercom Signaling mode selected.
- A Station can leave only one Call Back request.
- The [MSG/CALLBK] button LED will continue to flash until all MWIs and Call Back Requests, have been serviced (including Voicemails).
- If a Station is attempting to leave a message and the System MWI queue is full, the oldest MWI will be deleted.
- A MWI Reminder Tone can be enabled to remind the user of MWIs.
- A Station in Call Forward can leave a MWI.
- A MWI is left at the Originally Called Station even if the call is Forwarded.
- A Digital Phone with LCD may Call Back to Stations that left messages in any desired order, or the normal ("oldest first") order.
- Placing an Intercom call to a Station will cancel any existing MWI from that Station.
- A Station can support up to 99 VMS messages.
- If a Station requests a Call Back at a Busy Station, a Call Back Request Station will check the Busy Station's status every 5 sec., and receives Call Back Ring when the Status Check Timer is expired (after the Busy Station returns to Idle). For this reason, Call Back ring may be delayed after a Busy Station returns to Idle, and when several Stations request a Call Back at a Busy Station, the Call Back Ring may not be provided sequentially. Operation

SLT

To leave a MWI:

1. While receiving a Ring Back tone or No Answer on a Call Announce (H or P mode), press the Hook-Switch.
2. Dial the {Message Wait/Call Back code}.
3. Hang-up, the MWI is activated.

To leave a MWI:

1. While receiving a DND tone, press the Hook-Switch.
2. Dial the {Message Wait/Call Back code}.
3. Hang-Up, the MWI is activated.

To retrieve a Station Message Wait:

Dial the {Message Wait/Call Back Answer code}.

To leave a Call Back (queue for a station):

1. While receiving a Busy Signal, press the hook switch.
2. Dial the {Message Wait/Call Back code}.
3. Hang up, and return to Idle.

To respond to a Call Back Recall:

1. When the Busy Station returns to Idle, the System initiates a Call Back.
2. Lift the handset, or press the [Speaker] button.
3. The previously Busy Station is called.

PROGRAMMING

System Data

Message Reminder Tone Timer ([TRANS/PGM] 222 - FLEX 2) ... see details on [page A-84](#)

[TRANS/PGM] 222	BTN	RANGE	DEFAULT
MSG WIT ALERT TONE TMR -- A phone user will receive periodic reminder tones of a message waiting at intervals based on this timer.	2	00-60 (minutes)	00

Message Wait Reminder Tone

QÁæáæá } Á Á@ÁT ÜÖÖÖSSÓŠÁ~ d } ŠÖÖÈ@Öä äæÁ@ } ^•Áæ Á^Á^ } óæÁ } ^Áæ Áæ
] ^á äæÁ^ { ä á^Á Á@Á•Á^Á ÁY QÁ Á^ ^ÁV@ Á } ^Á Á^ } óæ Á@Áææ } Á } | ^Á @^Á
QÁ Áæ á Á@æáÁ ç^Á@Á] ^æ^ÁÈ

CONDITIONS

- ÈÁ V@Á ç^Áç^Áç^Á } Á } ^•Áæ Á^Á^ÈÁ Á ÈÁ ä ~ ç^Á@ÁÈÁ^çá * Á ç^Áæ æ^Á@Á
TY Á^ { ä á^Á } ^ÁÈ
- ÈÁ V@Á^ { ä á^Á } ^Á ç^Á } ç^Á^Á] ^æá * Á [çáæá } Á } ç^ÁÁ ^••æ^Áç^Á^Á } Á
!^çáç^ÁÈ
- ÈÁ ÖÖ•^Áææ } Á!Áææ } Á ÖÖÖÁ ç^Á [óÁ&ç^Á@ÁY Á^ { ä á^Á } ^ÁÈ
- ÈÁ ÜÜÁ@ } ^Áæ áÖÖÖVÁ [Á [ó^] [!ó@ÁY Á^ { ä á^Á } ^Áæ | ^ÁÈ

OPERATION

System

Y @ } Á | * !æ { ^ÁÈ@ÁY Á^ { ä á^Á } ^Á Áæ d { æáæ | ^Á } óæ Áææ } • Á Á^Á
æ] [] !æ ÈÁ

PROGRAMMING

System Data

T^••æ^Á^ { ä á^Á } ^Áá ^Á^ÜÖÖÜÖÖT áGGÈÖŠÖYÁÖŠ Á^Á^æ^Á } Á
] æ^ ÈÁ

ŽÜÖÖÜÖÖT áGG	ÓV	ÜÖÖÖ	ÖÖÖVŠ
TÜÖÁ QÁŠÖÜVÁVÖÖÁVÜÁÈÖÁ @ } ^Á•Á^Á ç^Á&ç^Á^Á^á äæÁ !^ { ä á^Á } ^Á Á^Á ^••æ^Á æá * Á ç^Áç^Áç^Á Á@Á Á^È	G	ÈÈ ÈÁ ç ä ~ ç•D	ÈÈ

HARDWARE

Öä äæÁ@ } ^Á

Paging

Internal/External & All Call Page

A Station that is set-up for using the Page features, can connect and transmit voice announcements to any or all of the System Internal/External Page Zones. Stations are grouped into “Zones” to receive Pages directed at each Zone. Stations not assigned to any Zone will not receive a Page including All Call Pages.

A Page Ring will be provided to the Page Zone(s) prior to the Audio Connection. The User is allowed to continue the Page for the specified Page Time-out Timer after which the User is disconnected and the Page Zone(s) is returned to idle.

The default Page Zone Dial codes are:

Paging Dial Codes

Page Type	MBX IP 100	MBX IP 300
Internal Page Zones	543 + Group Number	543 + Group Number
Internal All Call Page	543 = 00	543 + 00
External Page Zone	548	548
All Call Page	549	549

Flexible buttons of a Digital Phone may be assigned to access a Page Zone as a {PAGE ZONE} button.

CONDITIONS

- Stations that are not enabled to Page, will receive an Error tone when any Page Access code is dialed.
- Stations in DND or Busy will not receive Page announcements.
- A Station accessing a Page Zone is considered Busy.
- Stations, that are not included in any Internal Page Zone, will not receive any page, including All Call.
- For External Paging, an External Amplifier and Speaker(s) are required.
- The System External Control Contacts may be assigned to activate when External Page is accessed.

OPERATION

Digital Phone

To assign a Flex button as a {PAGE ZONE} button:

Ú!^••ĂŸÜÇÈÙÈÛÖT áÉÁÖŠÖÝÉÁÖ ç} ÁÖæ!^Ár]^ÇÉÁÚæ ã * ÁÖ[á^ÉĂŸÜÇÈÙÈĂ

To initiate a Page:

FÈ Šäó@Áç ä^dĂ
GÈ ÖãÁ@Á^•ã^áÚæ ã * ÁŸ á^Á!Á!^•ĂĂŸÜÇÈÙÈÛÖÖŠ ç} ĚĂ
HÈ ÖãÁÚæ^ÁÖ! [~] Á { à!ĚĂ
I È Çæ•ã }^áĚæ!Á@ÁÚæ^ÁŸ * ĚĂ æ^Á@Á^•ã^áĂ } [~] &{ ^ } ĊĂ
Í È Y @} ÁŸ ä @áĚĂ] æ^Á@Áç ä^dĂ [ÁŸ] Ě [\ ĚĂ

SLT

To initiate a Page:

FÈ Šäó@Áç ä^dĂ
GÈ ÖãÁ@Á^•ã^áÚæ ã * ÁŸ á^ĚĂ
HÈ ÖãÁÚæ^ÁÖ! [~] Á { à!ĚĂ
I È Çæ•ã }^áĚæ!Á@ÁÚæ^ÁŸ * ĚĂ æ^Á@Á^•ã^áĂ } [~] &{ ^ } ĊĂ
Í È Ü^] æ^Á@Áç ä^dĂ [ÁŸ] Ě [\ ĚĂ

PROGRAMMING

Station Data

Úæ^ÁÖ! [~] ÁÇ&••ĂŸÜÇÈÙÈÛÖT áÉÍ FÁŠ Á^Á^Á^çæ•Á } Áæ^ ÇĚ H

Station Group Data

Úæ^ÁÖ! [~] ĂŸÜÇÈÙÈÛÖT áÇÉÍ ÁŠ Á^Á^Á^çæ•Á } Áæ^ ÇĚ F

ŽŸÜÇÈÙÈÛÖT áÇÉÍ	ÓVP	ÛÇÈÙÈÛÖ	ÖÖÇÈVŠV
ÚÇÈÙÈÛÖT ÒT ÓÖÜÁŸÜÇÈÙÈĂæ•ã } Á çæ } •Ă Á ^{ à!•Á ŸĂÚæ^Á *! [~] È	È	È	È

Tenant Data

Úæ^ÁŸ]^ÁŠ Á^ÁWeb AdminĂŸÜÇÈÙÈÛÖT áÇÉÍĂÖŠÖÝÁHDĂŸÜÇÈÙÈÛÖT á

System Data

Paging Time-out Timer [TRANS/PGM] 220 - FLEX 4 ... see details on [page A-83](#)

[TRANS/PGM] 220	BTN	RANGE	DEFAULT
PAGE TIME OUT TMR -- Determines the maximum duration of a page after which the caller and Page Zone are released.	4	000-300 secs	15

Numbering Plan

Internal Page Calling Answer Code [TRANS/PGM] 113 ... see details on [page A-18](#)

BTN	FEATURE [TRANS/PGM] 113	REMARK
15	Internal Page Answer (Meet-Me Page)	547

Page Auto Answer (TRANS/PGM] 115 - FLEX 69 ... see details on [page A-22](#)

RELATED FEATURES

Meet Me Page Answer ... see [page 4-17](#)

HARDWARE

External Amplifier & Speakers

Meet Me Page Answer

Any station may respond to a Meet Me Page request over an Internal or External Page Zone. The user answers the page from any Station and is connected to the Paging Party. The Paging Party can answer the page by pressing the [HOLD/SAVE] fixed button and other users can answer by dialing the {Page Auto Answer Feature Code} or {Internal Page Answer Feature Code}.

Page Answer Dial Codes

Page Type	MBX IP 100	MBX IP 300
Page Auto Answer	546	546
Internal Page Answer	547	547

1. Lift the handset or press the [SPEAKER] button.
2. Dial the {Auto Page Answer code} from a Station; after the system locates the appropriate Station Group, the call it will be connected to the Paging Station.

PROGRAMMING

System Data

Paging Timeout Timer [TRANS/PGM] 220 - FLEX 4)... see details on [page A-83](#)

TRANS/PGM 220	BTN	RANGE	DEFAULT
PAGE TIME OUT TMR -- Determines the maximum duration of a page after which the caller and Page Zone are released.	4	000-300 secs	15

Station Data

Meet-Me Access [TRANS/PGM] 134 - FLEX 3 ... see details on [page A-34](#)

TRANS/PGM 134	BTN	RANGE	DEFAULT
MEET ME ACCESS -- enables 'meet me' feature when there is a page.	3	0: Disable 1: Enable	Enable

Numbering Plan

Int Page Answer Code [TRANS/PGM] 113 - FLEX 15 ... see details on [page A-18](#)

BTN	FEATURE (TRANS/PGM] 113)	REMARK
15	Internal Page Answer (Meet-Me Page)	547

Page Auto Answer [TRANS/PGM] 113 - FLEX 14 ... see details on [page A-18](#)

BTN	FEATURE [TRANS/PGM] 113	REMARK
14	Page Auto Answer	546

RELATED FEATURES

Internal/External & All Call Page ... see [page 4-15](#)

1. Lift the handset.
2. Dial the desired paging code or press a {ANNOUNCEMENT PAGE FOR ATTENDANT} button.
3. Dial page group number.
4. Dial desired Announcement number.
5. If assigned, after the Page Ring, VM message will be played.
6. Replace the handset, go on-hook

SLT

To make a page:

1. Lift the handset.
2. Dial the appropriate paging code.
3. Dial page group number.
4. If assigned, after the Page Ring, make announcement, or hear VM message.
5. Replace the handset, go on-hook.

PROGRAMMING*Station Data*

Internal Page Group Access [TRANS/PGM] 151... see details on [page A-43](#)

Station Group Data

Page Group [TRANS/PGM] 205 ... see details on [page A-71](#)

Tenant Data

Page Tone ...use *Web Admin* [TRANS/PGM] 290 - FLEX 33 ... see [page A-43](#)

System Data

Paging Timeout Timer [TRANS/PGM] 220 - FLEX 4 ... see [page A-83](#)

TRANS/PGM 220	BTN	RANGE	DEFAULT
PAGE TIME OUT TMR -- Determines the maximum duration of a page after which the caller and Page Zone are released.	4	000-300 secs	15

Push-To-Talk Paging

Digital Phone can be assigned as a member of one of the System's Push-To-Talk (PTT) Page Groups. The Digital Phone User may log-in or log-out of any one or all PTT Groups it is a member of. Once logged in, the User may place or receive One-Way Page announcements to/from other Users who are logged-in to the same PTT group. To place a PTT Page announcement, the User must press and hold the {PTT} Flex button.

An Attendant may log-in/-out other Stations to/from PTT groups.

CONDITIONS

- Conditions associated with Internal/External & All Call Page apply to PTT Paging.
- To access PTT Paging, the Station must be permitted access to System Paging.
- If allowed access to all PTT Groups, a Station may log-into all Groups (PTT Group 0) to place announcements to all Groups simultaneously and receive announcements from any group.
- A Station can only Log-In to PTT groups to which it is assigned as a member.
- The Station must have a {PTT} button to place or receive PTT announcements; by default, the WLAN phone is assigned a PTT button.
- The Station may be assigned and Logged-In to the default active PTT group in the System database.

OPERATION

Digital Phone

To assign a {PTT} Flex button:

Press [TRANS/PGM] + {FLEX} + Button Feature Type (1)+ {PTT} + [SAVE]

To Log-In to a PTT group:

1. Dial the {PTT Log-in/-out code}.
2. Dial the desired PTT Group Number.

To Log-Out of the PTT group(s):

1. Dial the {PTT Log-in/-out code}.
2. Dial '*'.

To place a Page to the active PTT Group:

1. Press and hold the {PTT} Flex button.
2. Make the desired Page announcement after hearing confirmation tone.

PROGRAMMING

Numbering Data

ÚVVÁ [* È] ÚVÜ Æ Á æ ^ Ç È J

ÓVP	Ø Ø Æ W Ü Ö Á V Ü Æ Ü Æ J Ö T Á F F H S Á ^ Á æ ^ Ç È J	Ü Ö T Ö Æ S
I I	ÚVVÁ [~] Á Æ & • •	I G Á È Á V V Á [~] Á V Ü Æ Ü Æ J Ö T Á F F H S [* Á ~ Ø

Station Group Data

ÚVVÁ [~] Á V Ü Æ Ü Æ J Ö T Á G Í D S Á ^ Á æ ^ Ç È H

V Ü Æ Ü Æ J Ö T Á G Í	ÓVP	Ü Ö Æ Ö Ö	Ø Ø Ø Æ V S V
ÚVVÁ Ö T Ö Ö Ü Á È Ö Á È Ö Á } d * Á æ • ä } • Á ç æ } • Á æ Á ^ { à ! • Á Á Á ÚVVÁ [~] È	F	È	È

Station Data

Ø æ á Á V V Á ^ Ç Á Ö Ç { Á Æ • ä } { ^ } Á V Ü Æ Ü Æ J Ö T Á G Í D S Á ^ Á æ ^ Ç È J

RELATED FEATURES

Ú æ ä * Á Á ^ Á æ ^ I È Í

HARDWARE

Ö ä æ Á @ } ^ Á

Ú @ } æ ^ Á

W Ö Ü Ö | a } Á

Chapter 5

CO/IP

This chapter provides detailed information covering description and operation of the CO/IP features available in the MBX IP System Software.

Alternative Route Selection

This feature is enabled if there are several paths in order to connect toward a destination System. If a selected path is not available for some reason (All Busy, Line Fault, etc), Alternative Route Selection (ARS) will connect calls using another designated path.

CONDITIONS

- ARS is optional and must be programmed to be operational.
- Up to 2 ARS pats can be assigned for each CO Group Access code.
- ARS digits should be contained in the CO Group Access Code, and will be applied when feature is initiated.
- ARS can be used in coordination with Last Number Redial, Station Speed Dial, and System Speed Dial.
- If ARS is operated with Digit Conversion Table, Dialed or Converted Digit will be provided to CO line after ARS service.

OPERATION

If set, Alternative Route Selection operation is automatic.

PROGRAMMING

Numbering Plan

CO Group Access Code (PGM 114) ... see [page A-21](#)

PGM 114	BTN	RANGE	REMARK
CO GRP ACCESS CODE (Edit By Range)	1	Start CO Grp Access Code & End CO Grp Access Code	-
CO GRP ACCESS CODE (Edit)	2	CO Grp Access Code	-

PROGRAMMING*Numbering Plan*

CO Group Access Code (PGM 114) ... see [page A-21](#)

PGM 114	BTN	RANGE	REMARK
CO GRP ACCESS CODE (Edit By Range)	1	Start CO Grp Access Code & End CO Grp Access Code	-
CO GRP ACCESS CODE (Edit)	2	CO Grp Access Code	-

CO Line Data

CO Group Access Code AND Digit (PGM 180 - FLEX 4) ... see [page A-61](#)

PGM 180	BTN	RANGE	DEFAULT
AND DGT -- Automatic Network Dialing (AND) digit is sent after CO line seized. This feature allows user to initiate CO calls only by dialing CO Group Access Code.	4	Max 10 digits	-

CO Group Access Code

The CO Group Access code can be set dynamically for each Outgoing CO Group. One Outgoing CO Group can have several access codes. Additionally, there are various kinds of services for each access code:

- Access Code Name – Access code name can be displayed when a user seizes a CO line with CO Group Access code.
- CO Line Choice – There are 3 ways to seize a CO line (Round / First / Last).
- Outgoing CO Group – When a user dials a CO Group Access code, the System will seize a CO Line with the Outgoing CO Group.
- AND – When using CO Group Access code, it can add max. 10 digits to be able to send towards PX automatically.
- ARS Service – When a selected path is not available for some reasons(all busy, line fault, etc), this feature connects a call using another path which is preset automatically

CONDITIONS

- This feature can be set for each Outgoing CO Group.

PGM 180	BTN	RANGE	DEFAULT
ARS SERVICE -- If Alternate Route Selection (ARS) is set, ARS digit is dialed instead of CO Group Access code when there is no available path.	5	0: Off 1: On	Off
ARS DGT 1 -- Alternate CO Group Access code to be used when original CO Group Access code failed to find available CO line.	6	Max 8 digits	-
ARS 1 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	7	0: Off 1: On	Off
ARS DGT 2 -- Second alternate CO Group Access code to be used when original CO Group Access code and first ARS code failed to find available CO line.	8	Max 8 digits	-
ARS 2 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	9	0: Off 1: On	Off

CO Line Flash

Analog CO Lines recognize a brief open or ground connection (Flash), as a request for a new dial tone. When used behind a PBX, a CO Line Flash is often used to activate a PBX feature or Call Transfer.

CONDITIONS

- Stations may Flash on a CO Line defined for PABX operation and will experience COS dialing restrictions if a PABX Trunk access code is dialed.
- During Flash, the LED for the CO Line button will remain lit.
- A Flash may be stored as a part of a Station or System Speed Dial number.
- While connected to an Internal Call or Dial Tone, pressing the {CO Flash} button will re-access the ICM Dial tone.
- Flash function is not available on Digital CO Lines like ISDN, VoIP and R2.

OPERATION

Digital Phone

While connected to an Analog CO line:

RELATED FEATURES

Station Speed Dial ... see [page 3-147](#)

CO/IP Line Groups

All CO Lines are included on one Outgoing CO Group and one Incoming CO Group individually. One CO Line cannot be a member of several CO Groups at the same time.

The CO/IP Lines in the System can be placed together into Groups for assigning access by Stations and common Access Dial codes (up to 24 Groups on MBX IP 100, and 72 Groups on MBX IP 300).

CONDITIONS

- Outgoing CO Line Groups and Incoming CO Line Groups are separated.
- CO/IP Lines in each CO Group can also be accessed individually by dialing the {CO Line Access Feature Code} and the CO/IP Line number.
- The System will select a CO/IP Line from a group based on the Round Robin, First Choice or Last Choice determined by database assignments.
- Multiple {CO Group Access Code} can be assigned to a CO Group.
- If a CO Line is not included in an outgoing CO line group, this line has to be seized using a Flex button or System feature code.

PROGRAMMING

System Data

CO Group Access Code (PGM 114) ... see details on [page A-21](#)

PGM 114	BTN	RANGE	REMARK
CO GRP ACCESS CODE (Edit By Range)	1	Start CO Grp Access Code & End CO Grp Access Code	-
CO GRP ACCESS CODE (Edit)	2	CO Grp Access Code	-

CO Data

PGM 180	BTN	RANGE	DEFAULT
ARS SERVICE -- If Alternate Route Selection (ARS) is set, ARS digit is dialed instead of CO Group Access code when there is no available path.	5	0: Off 1: On	Off
ARS DGT 1 -- Alternate CO Group Access code to be used when original CO Group Access code failed to find available CO line.	6	Max 8 digits	-
ARS 1 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	7	0: Off 1: On	Off
ARS DGT 2 -- Second alternate CO Group Access code to be used when original CO Group Access code and first ARS code failed to find available CO line.	8	Max 8 digits	-
ARS 2 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	9	0: Off 1: On	Off

CO Line Service

The System can set Service attributes and several options according to each CO Line.

Incoming CO Line Option

There are some options to support the Incoming CO line:

- Progress Indicator (Send)
- CID Prefix Code – Add to prefix code before CLI.
- Own Code Add to Transit CID – Own code can be added to incoming CLI when external User places an outgoing call through CO Line in the System.
- Provide Dial Tone – Dial Tone can be provided to a Station if PX is not given the dial tone.
- CPT Detect – System can release the CO Line by detecting the External User's disconnection.
- Own Code – Own code is added before the Station number when CLI information is available.

PGM 160	BTN	RANGE	DEFAULT
INC/OUT MODE -- Each CO lines can be set to only incoming call is allowed or outgoing is allowed only.	9	0: Incoming Only 1: Outgoing Only 2: Allow Both	Both
DIALING TYPE -- Signal type can be selected; DTMF, Pulse, R2MFC.	10	0: DTMF 1: PULSE 2: R2	DTMF
CHARGE MODE -- If 'FREE', the external call though CO line is not printed/saved to SMDR even though SMDR is enabled. If 'REPORT', the external call though CO, line is included to SMDR according to the SMDR Attributes.	11	0: Free 1: Report	Report
METERING TYPE -- According to PSTN service type, metering type can be selected among 00-12 to manage call charge. 01-06 can be applied to LCO lines, 07-12 can be applied to ISDN lines.	12	00: None 01: 12KHz 02: 16KHz 03: 50KHz 04: SPR 05: PPR 06: NPR 07: AOC 0(Standard) 08: AOC 1 (Italy & Spain) 09: AOC 2 (Finland) 10: AOC 3 (Australia) 11: AOC 4 (Belgium) 12: AOC 5 (Netherlands)	None

Incoming CO Attributes (PGM 165-166) ... see details on [page A-48](#)

PGM 165	BTN	RANGE	DEFAULT
NAME -- incoming CO line name can be assigned.	1	Max 16 chars	-
SCREEN INDICATOR -- determines if screen indicator will be inserted in ISDN messages.	2	0: Off (user-provided, not screened) 1: On (user-provided, verified and passed)	Off

PGM 165	BTN	RANGE	DEFAULT
CLI CONV TABLE -- CLI Conversion Table index.	15	1-9	1
HOLIDAY RING INDEX -- if ring mode is holiday and this is assigned, an incoming call is routed to the destination of holiday alternative ring index.	16	01-80, Not Asg	none

PGM 166	BTN	RANGE	DEFAULT
PROVIDE DIAL TONE -- If this feature is set to ON, dial tone is provided to networking CO.	1	0: Off 1: On	Off
BLF USAGE -- If this feature is set to ON, flex button LED will be flashing when CO line is programmed on the button.	2	0: Off 1: On	On
UNSUP CONF ENTEND -- If this feature is set to ON, unsupervised conference timer can be extended by dial feature code after warning tone is heard.	3	0:Disable 1:Enable	Disable
BLOCK IN CLRFRWD TMR -- If this feature is set to ON, CO line is blocked after clear forward waiting time.	4	0: Off 1: On	Off
CPT DETECT -- If this feature is set to ON, Call processing tone is detected to disconnect LCO line.	5	0: Off 1: On	On
ANSWER WAITING CALL -- If this feature is set to ON, system sends answer when call is waited.	6	0: Off 1: On	Off
UNIVERSAL ANSWER -- If this feature is set to ON, any station to answer a call on the CO Line by dialing the Universal Answer feature code.	7	0: Off 1: On	Off
RLS GUARD TIME -- If CO release signaling is not completed successfully, CO line is disconnected when timer expires.	8	00-15 (sec)	01
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after timer expires. The warning tone is heard before the line is disconnected.	9	000-255 (min)	000
WAIT CLRFRWD TIME -- Clear Forward Waiting Time.	10	001-300 (sec)	300
MAX RING TIME -- Max. Ring Time for when incoming CO calls are transferred/recalled.	11	015-300 (sec)	120
DISA SUPERVISION TMR -- DISA Supervision Timer.	12	1-9 (sec)	2
VMIB PLAY DELAY TMR -- Determines the amount of time paused before playing VMIB announcement.	13	0-9 (sec)	0

OPERATION

If set, Outgoing CO Line operation is automatic.

PROGRAMMING*CO Data*

CO Line Data (PGM 160) ... see details on [page A-45](#)

PGM 160	BTN	RANGE	DEFAULT
CO TYPE -- Displays physical line type of selected CO line.	1	Display Only	-
SVC TYPE -- Set CO line type as DID or Normal.	2	0:Normal 1:DID	Normal
OUTGOING GRP NO -- Set CO Group Number to apply to outgoing calls.	3	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
INCOMING GRP NO -- Set CO Group Number to apply to incoming calls.	4	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
TENANT NO -- Set Tenant group number to apply to CO lines.	5	1-9 (MBX IP-300) 1-3 (MBX IP-100)	1
DGT CONVERT TBL -- Set Digit Conversion Table index.	6	1-9	2
SIGNAL TYPE -- Set Answer Signal Type.	7	0: No Signal 1: Send Wink (IC) 2: Wait Seize Ack (OG) 3: Send Wink & Wait Sz Ack 4: Send & Wait Sans 5: Send Wink & Send Answer (IC) 6: Wait Ack & Send Answer (OG) 7: Send All & Wait All	No Signal
RLS TIMING -- If Release Timing is set to first release, CO line is released when one party release the call. If Caller or Called Release is set, CO line is released when caller or called party released the call.	8	0: First Release 1: Caller Release 2: Called Release	First RLS
INC/OUT MODE -- Each CO lines can be set to only incoming call is allowed or outgoing is allowed only.	9	0: Incoming Only 1: Outgoing Only 2: Allow Both	Both

PGM 170	BTN	RANGE	DEFAULT
CALLING NUM PLAN -- Select Calling number plan of ISDN SETUP message.	4	0: Unknown 1: I SDN/Telephony 2: Data 3: Telex 4: National 5: Private	Unknown
CALLED NUM PLAN ID -- Select Called number plan of ISDN SETUP message.	5	0: Unknown 1: I SDN/Telephony 2: Data 3: Telex 4: National 5: Private	Unknown
BEARER CAPABILITY - Select Bearer Capability of ISDN SETUP message.	6	0: Speech 1: Unrestricted 2: Restricted 3: 3.1KHz Audio 4: 7KHz 5: Video	Speech
ISDN LINE TYPE -- The system will encode voice using the A-law or u-law PCM format and should be set to match the ISDN Back bone type.	7	0:A-law 1:U-law	A-law
SENDING COMPLETE IE -- If set, will send 'Sending Complete' IE to ISDN SETUP message.	8	0: Off 1: On	Off
MAKE TRANSIT CLI -- When no CLI is sent with a transit call, system will initiate a CLI to CO direct transit call.	9	0: Off 1: On	Off
OWN CODE TO TRANSIT CLI -- If this feature is set to ON and same feature of incoming CO attribute is also set to ON, then Own code of outgoing CO line is inserted to the CLI of transit CO call.	10	0: Off 1: On	Off
USE REPRESENTATIVE CLI -- If this feature is set to ON, representative CLI is used to every outgoing call of selected CO line.	11	0: Off 1: On	Off
REPRESENTATIVE CLI -- When 'Use Represent CID'(PGM170-F10) is set to ON, representative CLI is sent when making outgoing call regardless of other CLI attribute.	12	Max 16 digits	-

PGM 171	BTN	RANGE	DEFAULT
MAX TRANSFER RING TIMER -- Max. Ring Time when outgoing CO is transferred/recalled.	7	001-300 (sec)	120
OUTGOING TIME TABLE -- The time Table index to be applied to outgoing CO Calls	8	1-9, none	none

Alternate Incoming CO Service

If the system cannot answer for an incoming CO call, a programmed service can be provided or it can be routed into a programmed destination. This feature is applied by incoming CO Group base Administrator to select the Routing Destination for the Incoming CO line on a case-by-case basis as follows:

- **Busy** – When calling a Busy User, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring Table, Tone, or Pilot Hunt.
- **No Answer** – When an Incoming Call goes unanswered, it can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring Table, Tone, or Pilot Hunt.
- **Transfer No Answer** – When an Incoming Call goes unanswered after an unscreened transfer, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring Table, Tone, Pilot Hunt, or Transfer Station.
- **Recall No Answer** – When an Incoming Call goes unanswered after a recall on a CO call, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring Table, Tone, or Pilot Hunt.
- **Vacant** – If dialing analysis determines an Incoming CO Call is to a vacant number, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, or Tone.
- **DND** – If an Incoming CO call is attempted to a DND User, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, Tone, or Pilot Hunt.
- **Handset Lifted** – If an Incoming CO Call is received at a Station where the handset is lifted (Off-Hook), the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, Tone, or Pilot Hunt.
- **Blocking** – If an Incoming Call is placed to a Blocked User, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, Tone, or Pilot Hunt.

CONDITIONS

- This feature can be set for each incoming CO Group.
- The destination is set differently according to Day, Night, and Time modes.

PGM 160	BTN	RANGE	DEFAULT
INC/OUT MODE -- Each CO lines can be set to only incoming call is allowed or outgoing is allowed only.	9	0: Incoming Only 1: Outgoing Only 2: Allow Both	Both
DIALING TYPE -- Signal type can be selected; DTMF, Pulse, R2MFC.	10	0: DTMF 1: PULSE 2: R2	DTMF
CHARGE MODE -- If 'FREE', the external call though CO line is not printed/saved to SMDR even though SMDR is enabled. If 'REPORT', the external call though CO, line is included to SMDR according to the SMDR Attributes.	11	0: Free 1: Report	Report
METERING TYPE -- According to PSTN service type, metering type can be selected among 00-12 to manage call charge. 01-06 can be applied to LCO lines, 07-12 can be applied to ISDN lines.	12	00: None 01: 12KHz 02: 16KHz 03: 50KHz 04: SPR 05: PPR 06: NPR 07: AOC 0(Standard) 08: AOC 1 (Italy & Spain) 09: AOC 2 (Finland) 10: AOC 3 (Australia) 11: AOC 4 (Belgium) 12: AOC 5 (Netherlands)	None

Incoming CO Line Attributes (PGM 165-166) ... see details on [page A-48](#)

PGM 165	BTN	RANGE	DEFAULT
NAME -- incoming CO line name can be assigned.	1	Max 16 chars	-
SCREEN INDICATOR -- determines if screen indicator will be inserted in ISDN messages.	2	0: Off (user-provided, not screened) 1: On (user-provided, verified and passed)	Off

PGM 165	BTN	RANGE	DEFAULT
CLI CONV TABLE -- CLI Conversion Table index.	15	1-9	1
HOLIDAY RING INDEX -- if ring mode is holiday and this is assigned, an incoming call is routed to the destination of holiday alternative ring index.	16	01-80, Not Asg	none

PGM 166	BTN	RANGE	DEFAULT
PROVIDE DIAL TONE -- If this feature is set to ON, dial tone is provided to networking CO.	1	0: Off 1: On	Off
BLF USAGE -- If this feature is set to ON, flex button LED will be flashing when CO line is programmed on the button.	2	0: Off 1: On	On
UNSUP CONF ENTEND -- If this feature is set to ON, unsupervised conference timer can be extended by dial feature code after warning tone is heard.	3	0:Disable 1:Enable	Disable
BLOCK IN CLRFRWD TMR -- If this feature is set to ON, CO line is blocked after clear forward waiting time.	4	0: Off 1: On	Off
CPT DETECT -- If this feature is set to ON, Call processing tone is detected to disconnect LCO line.	5	0: Off 1: On	On
ANSWER WAITING CALL -- If this feature is set to ON, system sends answer when call is waited.	6	0: Off 1: On	Off
UNIVERSAL ANSWER -- If this feature is set to ON, any station to answer a call on the CO Line by dialing the Universal Answer feature code.	7	0: Off 1: On	Off
RLS GUARD TIME -- If CO release signaling is not completed successfully, CO line is disconnected when timer expires.	8	00-15 (sec)	01
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after timer expires. The warning tone is heard before the line is disconnected.	9	000-255 (min)	000
WAIT CLRFRWD TIME -- Clear Forward Waiting Time.	10	001-300 (sec)	300
MAX RING TIME -- Max. Ring Time for when incoming CO calls are transferred/recalled.	11	015-300 (sec)	120
DISA SUPERVISION TMR -- DISA Supervision Timer.	12	1-9 (sec)	2
VMIB PLAY DELAY TMR -- Determines the amount of time paused before playing VMIB announcement.	13	0-9 (sec)	0

PGM 181	BTN	RANGE	DEFAULT
FEATURE CODE -- If set to Feature Code and valid feature code is assigned, then assigned feature is activated when there is an incoming call. NOTE: Feature Code is not applied to rerouted calls.	3	Valid Feature Code (Refer to PGM115)	-
FEATURE DELAY -- If Service type is set to Feature code, it can be delayed.	4	00-30 (secs)	00

Alternate Outgoing CO Service

A User can place an outgoing CO call and then can Hold or Transfer the Call to another User. If the System cannot answer for an external Outgoing Call, a programmed service can be provided or it can be routed into a programmed destination. This feature is applied by CO Line Group by the Administrator.

- Recall No Answer – Station does not answer the Hold Recall, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, Tone, or Pilot Hunt.
- Transfer No Answer – Transferred call goes unanswered, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, Tone, Pilot Hunt, or Transfer Station.
- No Answer – If an incoming call goes unanswered, the call can be set for routing destination, Disconnect, ATD, CO Ring Assign, Alt Ring table, Tone, or Pilot Hunt. Operation If set, Alternate Outgoing CO Service is automatic.

CONDITIONS

- This feature can be set for each CO line.
- If attendant is not assigned and it calls an incoming CO call, it plays error tone.
- If there is no voice mail resource or all voice mail channels are busy, it plays error tone.
- The destination is set differently according to Day, Night and Timed modes.
- If the destination is a ring table, all features of ring table can be applied.

PROGRAMMING

CO Line Data

PGM 160	BTN	RANGE	DEFAULT
CHARGE MODE -- If 'FREE', the external call though CO line is not printed/saved to SMDR even though SMDR is enabled. If 'REPORT', the external call though CO, line is included to SMDR according to the SMDR Attributes.	11	0: Free 1: Report	Report
METERING TYPE -- According to PSTN service type, metering type can be selected among 00-12 to manage call charge. 01-06 can be applied to LCO lines, 07-12 can be applied to ISDN lines.	12	00: None 01: 12KHz 02: 16KHz 03: 50KHz 04: SPR 05: PPR 06: NPR 07: AOC 0(Standard) 08: AOC 1 (Italy & Spain) 09: AOC 2 (Finland) 10: AOC 3 (Australia) 11: AOC 4 (Belgium) 12: AOC 5 (Netherlands)	None

Outgoing CO Alternative Attribute (PGM 173) ... see details on [page A-57](#)

PGM 173	BTN	RANGE	DEFAULT
DAY ALT DEST -- Abnormal case can be selected as error type.	-	F1: Recall No Answer F2: Transfer No Answer F3: No Answer	-
NO ANSWER DISCONNECT-- The CO call is disconnected. Every destination is set to 'Disconnect' by default.	1	-	-
NO ANSWER ATTENDANT -- The CO call is routed to Attendant.	2	-	-
NO ANSWER CO RING ASSIGN -- The CO call is routed according to Ring Assign Table. (see PGM 167)	3	-	-
NO ANSWER ALT RING TBL -- If destination is set to Alt Ring Table and the Table index is assigned, the CO call is routed according to Alt Ring Table. (See PGM 181)	4	01-80	-

CO COS Assign (PGM 177) ... see details on [page A-60](#)

PGM 177	BTN	RANGE	DEFAULT
DAY COS -- CO COS in Day mode.	1	00-15	0
DAY COS -- CO COS in Night mode.	2	00-15	0
DAY COS -- CO COS in Timed mode.	3	00-15	0

DID Name Service

When there's DID call, if name is programmed in Digit Conversion Table and dialed digit is matched, the name is displayed on ringing Station's LCD.

OPERATION

If programmed, did name is displayed to DID destination station's LCD.

PROGRAMMING

Table Data

DID Name (PGM 251) ... see details on [page A-104](#)

PGM 251	BTN	RANGE	DEFAULT
APPLY T-TYPE -- The Apply time type to be applied when the dialed digit is dialed.	1	0:Unconditional 1:Follow DNT 2: Follow LCR	Unconditional
DIALED DIGITS -- The dialed digits.	2	Max 16 digits	-
UNCOND CHANGED -- The CO Group Access Code and digits to be sent to PX when the dialed digit is pressed if Apply time type is 'unconditional'.	3	Max 16 digits	-
DAY CHANGED -- The CO Group Access Code and digits to be sent to PX in Day when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	4	Max 16 digits	-
NIGHT CHANGED -- The CO Group Access Code and digits to be sent to PX in Night when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'	5	Max 16 digits	-
TIMED CHANGED -- The CO Group Access Code and digits to be sent to PX in Timed when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	6	Max 16 digits	-

Incoming CO Line Holiday Service

When Ring Mode is Holiday mode, incoming CO call can be routed to Alternative Ring destination by a programmed holiday ring table index.

The destination of alternative ring table can be station or feature code.

OPERATION

If set, CO Line Holiday Service operation is automatic.

PROGRAMMING

CO Line Data

Incoming CO Line Attributes (PGM 165-166) ... see details on [page A-48](#)

PGM 165	BTN	RANGE	DEFAULT
NAME -- incoming CO line name can be assigned.	1	Max 16 chars	-
SCREEN INDICATOR -- determines if screen indicator will be inserted in ISDN messages.	2	0: Off (user-provided, not screened) 1: On (user-provided, verified and passed)	Off
CALLING TYPE -- for Incoming calls on the ISDN Line, this parameter defines the "Type of Number Plan" provided in Connected Party Information Element of the ISDN call CONNECT message.	3	0: Unknown 1: International 2: National 3: Subscriber 4: Not Used	Subscriber
CALLING NUM PLAN -- select connected number plan of ISDN CONNECT message.	4	0: Unknown 1: I SDN/Telephony 2: Data 3: Telex 4: National 5: Private	Unknown
SEND PROGRESS IND -- if this feature is set to ALL, Progress Indicator is sent to the ISDN PSTN about All Message. If this feature is set to ALERTING, Progress Indicator is sent to the ISDN PSTN about Alerting Message.	5	0 : NO 1: ALL 2: ALERTING	NO
R2 ANI SVC REQ -- if this feature is set to ON to R2 line, system request ANI digits (CLI data) to the calling party.	6	0: Off 1: On	Off

PGM 166	BTN	RANGE	DEFAULT
ANSWER WAITING CALL -- If this feature is set to ON, system sends answer when call is waited.	6	0: Off 1: On	Off
UNIVERSAL ANSWER -- If this feature is set to ON, any station to answer a call on the CO Line by dialing the Universal Answer feature code.	7	0: Off 1: On	Off
RLS GUARD TIME -- If CO release signaling is not completed successfully, CO line is disconnected when timer expires.	8	00-15 (sec)	01
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after timer expires. The warning tone is heard before the line is disconnected.	9	000-255 (min)	000
WAIT CLRFRWD TIME -- Clear Forward Waiting Time.	10	001-300 (sec)	300
MAX RING TIME -- Max. Ring Time for when incoming CO calls are transferred/recalled.	11	015-300 (sec)	120
DISA SUPERVISION TMR -- DISA Supervision Timer.	12	1-9 (sec)	2
VMIB PLAY DELAY TMR -- Determines the amount of time paused before playing VMIB announcement.	13	0-9 (sec)	0
INCOMING TIME TABLE -- The time Table index to be applied to incoming CO Call.	14	1-9, none	none
CO DELAY ANSWER TMR -- For Incoming calls on the ISDN Line, this parameter defines the delay time between Alerting and Connect Message.	15	0-100 (100msec)	0
OFFNET FWD USAGE -- ISDN lines can be set to use Call Deflection/Call Rerouting service if PSTN supports these feature.	16	0:Join 1:Call Deflection 2:Call Rerouting	Join

Alternative CO Ring Table (PGM 181) ... see details on [page A-63](#)

PGM 181	BTN	RANGE	DEFAULT
SERVICE TYPE -- If set as 0-2, ring option is applied to ring assigned stations. Otherwise, if set to 3, feature code is activated for incoming calls.	1	0: All Ring 1: First Idle 2: Circular 3: Feature Code	All Ring
CO RING ASSIGN -- Destination stations can be edited using a range or one by one. If press Flex 1-4 and then dial station range (up to 30 stations) or edit one station number.	2	(00-30) or one station number	-

ÚÔT ÁI F	ÓVP	ÜÇËÒÒ	ÖÒØËVŠV
ØØËWUÖÁÖUÖÖÄËGÁ^oÁ Á^æ ^ÁÖ[á^Áæ] á^çããÁ^æ ^Á & á^Á^æ • ä }^áÄ@) Áæ • ä }^áÁ^æ ^Á Áæçãæ^áÄ @} Á @ ^Á^Áæ & { ä * Áæ É ÞUVÖÁ^æ ^ÁÖ[á^Á^Á[çã] á^Á^ Á^ ~ ç^á^æ É	H	XçãÁ^æ ^Á Ö[á^Á^çã^Á^ Á ÚÔT FFI D	È
ØØËWUÖÁÖÖÖÇËËGÁ^içã^Á^ Á^Á^oÁ Á^æ ^Á& á^Á^Á &çã Á^Á^æ^áÉ	I	€È€Ç^& D	€€

DID/DISA Restriction

ÖÖÁ|^ÖÖÜÇã^Á^ Á[{ ^Á^æ } • Áæ] Á^Á^ • dæç^á^æ&| |áä * Á^ Á^ { ä Ú| | * |æ È
 GÁ[{ ^Á^æ } Á^ { á|^Á^Á^oÁ Á^ÖÖÜÇã^ • dæç } È@ &| { | { çã } Á^ Á^ã] |æ^á^Á } Á@ Á
 • çã } ÇŠÖÖÈ

CONDITIONS

- ÈÄ Y @) Á@ Á^çã^Á^ Á^æ^á^Á@ Á^æ } ÇÖÖÁ|^ÖÖÜÇã^ { á|^È@ Á^çã^Á^Á^ • dæç^á^È
- ÈÄ U@|^Á^çã^ Á^çã * Áæ • ä }^á^ÁÖU^Á^ Á^| Á^|, çá^á^Á^ Á^çã • Á|^Á^Á^ Á^çã ÈÄ &D^Á^ [ç
|^ • dæç^á^È
- ÈÄ V@ Á^æ |^Á^ Á^ [çã] |á^Á^ Á^ÜÖÁ @} Á^ • È

OPERATION

GÁ|^ | * |æ { ^á^ÖÖÜÇã^Á^ • dæç } Á^æ • Á^ Á^ã] |æ^á^Á^ Á^æ } ÇŠÖÖÈ

To change DID/DISA restriction status from each station terminal(toggle):

ÖçãÁ@ Á^ÖÖÜÇã^Á^ • dæç } Á^æ |^ÁÖ[á^Á^È

PROGRAMMING

Station Data

ÖÖÜÇã^Á^ • dæç } ÚÔT ÁHI ÄÖÖÖY^FGD^ Á^Á^Á^æ^Á^ } Á^æ^ ÇÈH

ÚÔT ÁHI	ÓVP	ÜÇËÒÒ	ÖÒØËVŠV
ÖÖÜÇã^Á^ ÖUVÜÖVÖV^ÄGÁ^oÁ Á^ÞÈ & { ä * ÖÖÁ ^ÖÖÜÇã^ * Á ç Á^Þ^Á^Á^ • dæç^á^È	FG	€U~ FKU} Á	U~

Numbering Plan

DID/DISA Restriction (PGM 113 - FLEX 108) ... see details on [page A-21](#)

BTN	FEATURE (PGM 113)	REMARK
108	DID/DISA Restriction	685

CO/IP LINE PRESET FORWARD

Each CO/IP Line can be assigned a Ring-No-Answer Preset Forward destination. An incoming call on the CO/IP line will be routed to the designed Ring Destination, following expiration of the CO/IP Line Preset No Answer Forward Timer. Preset Forward destination, determined according to the Ring Assignment Table.

CONDITIONS

- This feature can be set for each Normal-type CO Line, not DID-type CO Lines.
- CO/IP Line Preset Forward is available only when Incoming CO Ring Group destination is DN; not activated when destination is a Station Group or CCR.
- CO/IP Line Preset Forward will override Call Forward No-Answer at a Station.
- If Destination Station has an External No Answer Preset Call Forward destination set and the timer is same as CO Preset Forward Timer, CO Preset Call Forward will take priority. Otherwise the timer that expires first will be applied and Forward Destination will be applied according to the expired timer.
- CO/IP line Preset Forward is disabled if the Preset Forward Timer is set to 0.
- CO/IP line Preset Forward destination cannot be a VM Group.
- CO/IP line Preset Forward is not applied to the DID line.

OPERATION

System

If set, CO/IP Line Preset Forward is automatic.

PROGRAMMING

CO Line Data

CO Service Type (PGM 160 – FLEX 2) ... see details on [page A-45](#)

PGM 160	BTN	RANGE	DEFAULT
SVC TYPE -- Set CO line type as DID or Normal.	2	0: Normal 1: DID	Normal

makes an Outgoing CO Call. The CO Own Code is sent adding ahead of station number or received CLI.

CONDITIONS

- This feature can be set for each outgoing/incoming CO line.
- The outgoing CO own code and the incoming CO own code are independent.
- The maximum own code length is 16.

PROGRAMMING

CO Line Data

Outgoing CO Own Code (PGM 170 - FLEX 12) ... see details on [page A-54](#)

PGM 170	BTN	RANGE	DEFAULT
REPRESENTATIVE CLI -- When 'Use Represent CID'(PGM170-F10) is set to ON, representative CLI is sent when making outgoing call regardless of other CLI attribute.	12	Max 16 digits	-

Incoming CO Own Code (PGM 165 - FLEX 9) ... see details on [page A-48](#)

PGM 165	BTN	RANGE	DEFAULT
OWN CODE -- Own Code.	9	Max 16 digits	-

CO/IP Ring Assignment

Each station in the system can be programmed to provide an audible signal when the system detects an incoming call on specified CO/IP lines. Separate ring assignments are made for Day, Night and Timed Ring operation mode. In addition, the audible signal at the station can be delayed by 1 to 30 ring cycles allowing other stations to answer the call first.

CONDITIONS

- Separate assignments are made for Stations to ring in the Day, Night and/or Timed Ring mode.
- Audible Alerting for an Incoming VoIP call is based only on the derived IP Address.
- A Busy Station receives Muted Ring or Call Waiting tones as appropriate for the Station's Off-hook Ring Assignment.
- The system Ring mode can be selected manually or automatically,

ËÄ Automatic mode Öæ Ð ä @ ^ | ^ & ç | Á Á ^ c | { ä ^ á ä æ ^ á } Á @ Á Ç ç { æ Û Ü ä * Á T [á ^ Á ^ | ^ & ç | Á æ | ËÄ

ËÄ Manual mode Á @ Á Ç ç } ä æ ö æ Á æ ~ æ & | d [| Á ç ^ | Á @ Ü ä * Á [á ^ Á ^ | ^ & ç | ËÄ

ËÄ V @ Á Ö Ö Á Á @ Á Ç ç } ä æ ö Ü ç æ } Á ä | Á ä | æ Á ä @ Á ä Á ä ^ á Ü ä * Á T [á ^ ËÄ

ËÄ ÖÙÛÜÿ * Á Á •ã } ^ á Á Á } | Á } ^ Á Ü ç æ } Á ä á Á @ Á Ü ç æ } Á •ã } • Á Ç ç | Á | , æ á ËÄ c @ Á Ü Û Ü Ç ç | ä | Á ^ Á | ~ c ^ á Á & | ä ä * Á Á Ç ç | Á | , æ á Á ^ ç æ * • ËÄ

OPERATION

System

U] ^ | ç æ } Á Á @ Á Á æ ^ | ^ Á Á ç ç { æ Û Ü ËÄ

PROGRAMMING

CO Line Data

ÔÙÛÜÿ * Á Á ^ | Á Ü Ö T Á í ï D ö Á ^ Á Á ç æ Á } Á ä æ ^ Ö Ë F

Ü Ö T Á í ï	Ö V P	Ü Ç È Ö Ö	Ö Ö Ç È Á Š V
Ü Ö Ü X Ö Ö Á Y Ü Ö Á Á ç á Á Á } ^ Á Á ^ ç æ Á Á ËÄ Á ä * Á] ç Á Á ä } ä á Á Á ä * Á •ã } ^ á Á ç æ } • É U ç , á ^ Á Á ^ ^ & ç Á Á ^ c { ä ^ á ä æ ^ á } Á @ Á Ç ç { æ Û Ü ä * Á T [á ^ Á ^ ^ & ç Á æ ËÄ	F	€ Á Ü ä * Á Á • ç Á Ö á & æ Á Á ç æ ^ Á Á á	ç Ü ä *
Ö Ö Ç È Á Ü Ö Ö Á Á ç á Á Á } ^ Á Á ^ c Á Á ç æ Á Á ç æ ^ Á Á á ^ Á Á ä * } ^ á Á @ } Á •ã } ^ á Á ç æ ^ Á Á Á ç æ ^ á Á , @ } Á @ ^ Á Á ä ä { ä * Á ç æ É Á Ü Ö T Á í ï D	G	X ç á Á ç æ ^ Á Á á Á Á Ç ^ Á Á Á Ü Ö T Á í ï D	Ë
Ö Ö Ç È Á Ü Ö Ö Á Á ç á Á Á } ^ Á Á ^ c Á Á ç æ Á Á ç æ ^ Á Á á ^ Á Á ä * } ^ á Á @ } Á •ã } ^ á Á ç æ ^ Á Á Á ç æ ^ á Á , @ } Á @ ^ Á Á ä ä { ä * Á ç æ É	H	€ € È €	€ €
F € € Ç È Á Á •ã } ^ á Á ç æ } Á ä á Á æ Á ç ^ Á Á ç Á á Á ä } æ ^ á Á ç æ ^ Á Á ç , } Á ^ Á Á Á ^ á Á Á • & Á ç æ É	I	Ë	Ë

PGM 167	BTN	RANGE	DEFAULT
MEMBER ASSIGN -- To change station's ring assign status, enter desired station range. (Max 30 stations can be assigned)	5	Start Station & End Station	-
DELAY -- Enter delay value; if delay is 0, station will start to ring immediately. If delay value is deleted, the station will not ring. Otherwise if delay is 1-9, the station will start to ring after delay time(3 times of delay value)	5-1	0-9	Sta 100 (Port 0):delay 0 Others: not assigned

Table Data

System Time Table (PGM 253) ... see details on [page A-107](#)

PGM 253	BTN	RANGE	DEFAULT
TIME ZONE COMMENT-- defines the comment of the Time Table.	1	32 characters	none
SYSTEM TIME ZONE -- defines the Time Zone of the Time Table	2	0-73	0: Sys Time
DAYLIGHT SAVINGS -- defines Daylight Saving Time of Time Table.	3	On/Off	Off
RING MODE -- defines the ring mode of Time Table.	4	0: Day 1: Night 2: Timed	0:Day
AUTO RING MODE -- defines the Auto Ring mode of the Time Table.	5	On/Off	Off

Weekly Time Table (PGM 254) ... see details on [page A-108](#)

PGM 254	BTN	RANGE	DEFAULT
Monday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	1	0000-2359	Day: 9:00 Nite: 18:00 TDS: _-_ TDE: _-_-
Tuesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	2	0000-2359	Day: 9:00 Nite: 18:00 TDS: _-_ TDE: _-_-

CO Line Release Guard Time

To assure that the PSTN switching equipment has sufficient time to restore to the Idle condition, the System will hold CO Lines in a Busy State to Users after release of a CO Line by a Station. The time between Station disconnect and when the System changes the CO Line status from Busy to Idle is the CO Line Release Guard Time. If CO receives 'Release Ack' signal from PSTN before Release Guard Timer expired, then the CO line is released instantly.

OPERATION

System

Operation of this feature is automatic.

PROGRAMMING

CO Line Data

Incoming CO Release Guard Timer (PGM 166 - FLEX 8) ... see details on [page A-50](#)

PGM 166	BTN	RANGE	DEFAULT
RLS GUARD TIME -- If CO release signaling is not completed successfully, CO line is disconnected when timer expires.	8	00-15 (sec)	01

Outgoing CO Release Guard Timer (PGM 171 - FLEX 5) ... see details on [page A-57](#)

PGM 171	BTN	RANGE	DEFAULT
RLS GUARD TIMER -- If CO release signaling is not completed successfully, CO line is disconnected when the timer expires.	5	00-15	02

System Data

LCO Release Guard Timer (PGM 221 - FLEX 6) ... see details on [page A-84](#)

PGM 221	BTN	RANGE	DEFAULT
LCO RLS GUARD TMR -- when an analog CO Line is returned to idle, the system will deny access for this time to assure the PSTN returns the CO circuitry to idle.	6	00-60 (minutes)	010

CONDITIONS

- The CO transit service can be set through Admin. programming of optional permissions.
- The System provides an inter-working feature for all CO Lines.
- For a R2 CO to R2 CO call, set for link-by-link or end-to-end transit.
- For a PRI CO to PRI CO call, all messages are Forwarded transparently.

OPERATION

If set, CO Transit Service operation is automatic.

PROGRAMMING

CO Line Data

CO to CO Attributes (PGM 179) ... see details on [page A-60](#)

PGM 179	BTN	RANGE	DEFAULT
STATION OUTGOING CALL TRANSFER -- while stations are connected to outgoing CO call of first CO Group, the station can transfer the call to second CO group.	1	0: Off 1: On	On
OUTGOING CALL TRANSFER -- while ATD is connected to outgoing CO call of first CO Group, the ATD can transfer the call to second CO group.	2	0: Off 1: On	On
OUTGOING CALL TRANSFER RELEASE TYPE -- if outgoing CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	3	0: None 1: Release after Release Timer	None
OUTGOING CALL TRANSFER RELEASE TIME -- if an outgoing CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'RIs after RIs Time'. Before disconnecting, a warning tone is provided.	4	000-300 (sec)	060
INCOMING CALL TRANSFER DIRECTLY -- if this feature is set to ON, CO incoming call can be transferred directly without any stations or ATD to transfer the call.	5	0: Off 1: On	Off
STATION INCOMING CALL TRANSFER -- while stations are connected to incoming CO call of first CO Group, the station can transfer the call to second CO group.	6	0: Off 1: On	On

Pulse Dial Break Ratio (PGM 223 - FLEX 2) ... see details on [page A-85](#)

PGM 223	BTN	RANGE	DEFAULT
PULSE DIAL BREAK RATIO -- The break/make ratio for pulse dialing through analog CO line.	2	0: 60/40 1: 66/33 2: 50/50	1: 66/33

RELATED FEATURES

Dial Pulse to Tone Switchover ... see [page 3-62](#)

Direct Inward Dial (DID)

A Carrier Service, known as Direct Inward Dial (DID), sends digits to the System so that the call may be routed directly to a Specific Station or System Facility. DID service is available over digital and packet networks. ISDN lines can provide two-way, incoming DID and normal Outgoing Service, and requires no special signaling.

After collecting the digits from the Carrier, the System routes the Call to the Destination:

- Incoming DID number is compared with Digit Conversion Table. If matched, received DID number is converted according to the Table. Separate Digit Conversion can be applied according to DAY/Night/Timed Ring Mode.
- DID Destination is decided with the converted DID number.
- Destination can be Station, Station Group, Outgoing CO Call, Voice Mail, Net Station, Paging, or Conference Room.

CONDITIONS

- If ICLID routing is assigned for the CO/IP Line, the received Caller ID is first compared to the ICLID Table for routing. If Caller ID does not match an entry in the ICLID Table, the normal DID call processes are used.
- DID calls that encounter a Busy signal, are not answered in the DID/DISA No-Answer Timer, or are received at a Vacant or Invalid number can be routed to the Attendant, Tone, Station Group, or VMIB announcement. When the Attendant receives such calls, the call is appropriately identified by the Attendant Digital Phone Display.
- For a Station that is part of a non-pilot Station Hunt group, DID calls will follow the Group Hunt process if the Station is Busy or does not answer the call.
- DID calls are subject to Group Call Pick-up and Directed Call Pick-up.

PGM 160	BTN	RANGE	DEFAULT
INC/OUT MODE -- Each CO lines can be set to only incoming call is allowed or outgoing is allowed only.	9	0: Incoming Only 1: Outgoing Only 2: Allow Both	Both
DIALING TYPE -- Signal type can be selected; DTMF, Pulse, R2MFC.	10	0: DTMF 1: PULSE 2: R2	DTMF
CHARGE MODE -- If 'FREE', the external call though CO line is not printed/saved to SMDR even though SMDR is enabled. If 'REPORT', the external call though CO, line is included to SMDR according to the SMDR Attributes.	11	0: Free 1: Report	Report
METERING TYPE -- According to PSTN service type, metering type can be selected among 00-12 to manage call charge. 01-06 can be applied to LCO lines, 07-12 can be applied to ISDN lines.	12	00: None 01: 12KHz 02: 16KHz 03: 50KHz 04: SPR 05: PPR 06: NPR 07: AOC 0(Standard) 08: AOC 1 (Italy & Spain) 09: AOC 2 (Finland) 10: AOC 3 (Australia) 11: AOC 4 (Belgium) 12: AOC 5 (Netherlands)	None

PGM 251	BTN	RANGE	DEFAULT
TIMED CHANGED -- The CO Group Access Code and digits to be sent to PX in Timed when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	6	Max 16 digits	-
D1/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	7	Max 16 digits	-
D1/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	8	Max 16 digits	-
D1/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	9	Max 16 digits	-
D2/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	10	Max 16 digits	-
D2/T2 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	11	Max 16 digits	-
D2/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 2/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	12	Max 16 digits	-
D3/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	13	Max 16 digits	-
D3/T2 CHANGED -- The digits to be dialed in 'Day 3/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	14	Max 16 digits	-
D3/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	15	Max 16 digits	-
DNT TIME INDEX -- Day/Night/Timed Time Table Index.	16	1-9, none	none
LCR TIME INDEX -- LCR Time Table Index.	17	1-9, none	none

- DISA callers are subject to COS dialing restrictions. If Authorization Codes are required and the code matches a Station Authorization Code, the Station COS will apply.
- The System will disconnect an Outgoing DISA call if the Unsupervised Conference timer expires or Disconnect Supervision is received; a Disconnect Warning tone is provided 15 seconds prior to disconnect.
- If a DISA caller encounters a System All Lines Busy, Busy tone is received for 5 seconds before ICM Dial tone is presented again and the DISA caller may try another call.
- LEDs associated with the DISA CO Line appearance will provide normal status indications at all Stations except Attendants; the LED for the line at an Attendant Station will flutter at 240 ipm when Busy.
- If a DISA Caller accesses a CO/IP Line, the Transit option is applied (CO to CO Attribute); this function can make a call recovered after conversation during an assigned time.

OPERATION

System

Incoming calls enabled for DISA service:

- The System will recognize the Incoming call.
- The System will answer the call and connect the caller to the Intercom Dial tone or AA announcement.
- The Call will be processed based on the entered digits/programming.

DISA Caller

To remotely access System resources:

1. Place call to the System DISA facility.
2. On receipt of the Intercom Dial tone/AA Announcement, dial as desired.

PROGRAMMING

Numbering Plan

Feature Numbering Plan, DISA Tone Service (PGM 113)

CO Line Data

ÓUÁÓUÙÁÜÖT ÁÍ Ì D& Á^^Á^æ• Á} Áæ^ ÖĤ €

ÚÖT ÁÍ Ì	ÓVP	ÜÖÖÖÖ	ÖÖÖÖÖSV
ÖÖYÁÓUÙÁÜÖT ÁÍ Ì D& Á^^Á^æ• Á} Áæ^ ÖĤ €	F	€€Í	€
ÖÖYÁÓUÙÁÜÖT ÁÍ Ì D& Á^^Á^æ• Á} Áæ^ ÖĤ €	G	€€Í	€
ÖÖYÁÓUÙÁÜÖT ÁÍ Ì D& Á^^Á^æ• Á} Áæ^ ÖĤ €	H	€€Í	€

ÓUÁ&••ÁÜ{ ÁÖÜÖÁÜÖT ÁÍ Ì ÁÖÖÖYÁD& Á^^Á^æ• Á} Áæ^ ÖĤ G

ÚÖT ÁÍ Ì	ÓVP	ÜÖÖÖÖ	ÖÖÖÖÖSV
ÓUÁ&••ÁÜ{ ÁÖÜÖÁÜÖT ÁÍ Ì ÁÖÖÖYÁD& Á^^Á^æ• Á} Áæ^ ÖĤ G	F	€ÁÜ~ FÁÜ}	U~

ÖÖÖÁ&~} ÖÖ[á^ÁÜÖT ÁÍ Ì ÁÖÖÖYÁD& Á^^Á^æ• Á} Áæ^ ÖĤ G

ÚÖT ÁÍ Ì	ÓVP	ÜÖÖÖÖ	ÖÖÖÖÖSV
ÖÖÖÁ&~} ÖÖ[á^ÁÜÖT ÁÍ Ì ÁÖÖÖYÁD& Á^^Á^æ• Á} Áæ^ ÖĤ G	G	€ÁÜ~ FÁÜ}	U~

ÖÖÖÁÜ^d^ÁÜ[~} ÖÖÜÖT ÁÍ Ì ÁÖÖÖYÁD& Á^^Á^æ• Á} Áæ^ ÖĤ G

ÚÖT ÁÍ Ì	ÓVP	ÜÖÖÖÖ	ÖÖÖÖÖSV
ÖÖÖÁÜ^d^ÁÜ[~} ÖÖÜÖT ÁÍ Ì ÁÖÖÖYÁD& Á^^Á^æ• Á} Áæ^ ÖĤ G	H	FĖ	H

ÓUÁÁ ÓUÁÜÖT ÁÍ J D& Á^^Á^æ• Á} Áæ^ ÖĤ €

ÚÖT ÁÍ J	ÓVP	ÜÖÖÖÖ	ÖÖÖÖÖSV
ÓUÁÁ ÓUÁÜÖT ÁÍ J D& Á^^Á^æ• Á} Áæ^ ÖĤ €	F	€ÁÜ~ FÁÜ}	U}
ÓUÁÁ ÓUÁÜÖT ÁÍ J D& Á^^Á^æ• Á} Áæ^ ÖĤ €	G	€ÁÜ~ FÁÜ}	U}

PGM 179	BTN	RANGE	DEFAULT
OUTGOING CALL TRANSFER RELEASE TYPE -- if outgoing CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	3	0: None 1: Release after Release Timer	None
OUTGOING CALL TRANSFER RELEASE TIME -- if an outgoing CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'RIs after RIs Time'. Before disconnecting, a warning tone is provided.	4	000-300 (sec)	060
INCOMING CALL TRANSFER DIRECTLY -- if this feature is set to ON, CO incoming call can be transferred directly without any stations or ATD to transfer the call.	5	0: Off 1: On	Off
STATION INCOMING CALL TRANSFER -- while stations are connected to incoming CO call of first CO Group, the station can transfer the call to second CO group.	6	0: Off 1: On	On
ATD INCOMING CALL TRANSFER -- while ATD is connected to incoming CO call of first CO Group, the ATD can transfer the call to second CO group.	7	0: Off 1: On	On
INCOMING CALL TRANSFER RELEASE TYPE -- If incoming CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	8	0: None 1: Release after Release Timer	None
INCOMING CALL TRANSFER RELEASE TIME -- If an incoming CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'RIs after RIs Time'. Before disconnected, warning tone is provided.	9	000-300 (sec)	060

RELATED FEATURES

- VMIB-Auto Attendant ... see [page 7-37](#)
- Day/Night/Timed Ring Mode ... see [page 7-37](#)
- Dialing Restrictions ... see [page 3-63](#)
- Authorization Codes (Password) ... see [page 3-5](#)
- Unsupervised Conference ... see [page 3-53](#)
- VMIB Integrated Auto Attd/Voice Mail ... see [page 3-258](#)
- Auto Service Mode Control ... see [page 3-10](#)

Dual Tone Multi-Frequency (DTMF) Signal Sending

CO Lines can be assigned for Dual Tone Multi-Frequency (DTMF) signaling.

CONDITIONS

- The System will mute the User's voice transmission to reduce interference while sending DTMF tones.

OPERATION

System

Operation of this feature is automatic when programmed.

PROGRAMMING

CO Line Data

CO COS (PGM 177)

Outgoing CO Line Inter-Digit Timer (PGM 174)

H.323 Multi Route Service

The system can set-up several destination IPs for one prefix. The destination IP is selected circularly when user tries to make a H.323 call.

CONDITIONS

- This feature is for only VoIP (H.323).

OPERATION

Operation of this feature is automatic when programmed.

PROGRAMMING

H.323

PÈGHÀU[~ cÁUcã ~ cÁUJÖT ÁÍ €DŠ Á^^Á^cã• Á } Á æ ^ ÖËI î

ÚÖT ÁÍ €	ÓVP	ÜÖP ÖÖ	ÖÖÖÖVŠV
ÖÖÖVÁFDËÁ^• çã } Á { à!• Áe• [&æ^áÁ ä@ç@P ÈGHÀ[~ ç * Á •^•c{ È	F	T æ Á Á ä æ	È
ÖÖÜVÁUÖÖÜÁÁ^• çã } ÁUÁáá!•• Áe• [&æ^áÁ ä@ç@P ÈGHÀ ! ~ ç * Á^•c{ È	G	È	ÈÈÈÈÈ

PÈGHÀUÖÁUcã ~ cÁUJÖT ÁÍ FDŠ Á^^Á^cã• Á } Á æ ^ ÖËI î

ÚÖT ÁÍ F	ÓVP	ÜÖP ÖÖ	ÖÖÖÖVŠV
ÜÖVWÚÁ UÖÖÁÁP ÈGHÀUÁçã• Áe Á^Á^dÉ] Á• ç * Á@P ÈGHÀ P[! çã! Áe ÁUcãç [à^È	F	ÈP[! çã FKçã ÇÁ [à^	Öæ ÇÁ [à^
VWPÖÖŠÁ UÖÖÁÁP ÈGHÀUÁçã• Áe Á^Á^dÉ] Á• ç * Á@P ÈG Í Á Ö) çã • çã } ÁV } } ^ ç * È	G	ÈU ~ FKU }	U }
ÖVT ÖÁÜPÖÁ UÖÖÁÁÁ! ç * Áe [] ^ & ç } ÈÖVT ÖÁä æ Áe Á^Á •^} ç Öæ ä Á! ÁU ~ ç Áe ä ÁP ÈG Í È	H	ÈQ çã ä FKÜÖG HH GU^ c	Q çã ä
ÖÖÖÁÜÖXÁÖÖÁ^! ç Á! ^ Èæ * ç * Á! Á[ç Á ç Á^dÉ PUVÖNÁ ç ç ^ Á ç Áe • Á Ç ç ç Á^ ç ä ç ä Á^ ç ^ È	I	ÈÈ H	I
ÖË FFOÖÖUÖÖÖÁÁ • æ ^ Á - ÖË FFOÖÖ [à^ & Á^] ^ È	í	ÈP[ÁV^ FKV^	P[ÁV^
ÖË FFWÖÖUÖÖÖÁÁ • æ ^ Á - ÖË FFWÖÖ [à^ & Á^] ^ È	î	ÈP[ÁV^ FKV^	P[ÁV^
ÖË GJÁÖUÖÖÖÁÁ • æ ^ Á - ÖË GJÁÖ [à^ & Á^] ^ È	ï	ÈP[ÁV^ FKV^	P[ÁV^
ÖË GHÁÖUÖÖÖÁÁ • æ ^ Á - ÖË GHÁÖ [à^ & Á^] ^ È	ì	ÈP[ÁV^ FKV^	P[ÁV^
ÖSÁUÖÖÖÁÁ • æ ^ Á Á^c{ ç ^ Á Öæ \ \ ^] ^! ç ç Á Á^ Á^ ä È	J	ÈU ~ FKU }	U ~

H.323 Incoming Attributes (PGM 362) ... see details on [page A-147](#)

PGM 362	BTN	RANGE	DEFAULT
FROM IP-- IP address associated with H,323 incoming calls.	1	-	0.0.0.0
INCOMING CO GRP NUM -- CO group number associated with H.323 incoming calls.	2	01-72	-

Incoming Calling Line ID (ICLID) Call Routing

The system can employ Incoming Calling Line ID (ICLID) to determine the routing of Incoming external calls. Each CO/IP Line, including DID Lines, may be assigned to employ ICLID routing. The System will compare the received ICLID to entries in the ICLID Routing Table. If a match is found, the call will be routed to the destination defined in the ICLID Ring Assignment Table. Destinations can be the VMIB, an external Voice Mail, a Station or a Station Group.

CONDITIONS

- If the received ICLID does not match an entry in the ICLID Route Table, the call is routed according to CO Ring Assign Table.
- For analog CO Lines, the System will await receipt of a valid ICLID for the ICLID Ring Timer. At expiration of the timer, if ICLID is not received, the call is routed based on the type and other programming (Ring assignments, etc.) CO/IP Line.
- The ICLID received from the CO/IP Line must be a telephone number to match an ICLID Route Table entry.
- If ICLID routing is enabled for a DID line, DID Call Wait is disabled.
- Beside the System ICLID Table, each station can have up to 10 individual ICLID numbers.

OPERATION

System

The System will implement routing automatically based on database entries and the received ICLID.

PROGRAMMING

CO Line Data

PGM 167	BTN	RANGE	DEFAULT
100 (0) -- Assigned station and delay value can be displayed. Volume Up/Down key is used to scroll data.	4	-	-
MEMBER ASSIGN -- To change station's ring assign status, enter desired station range. (Max 30 stations can be assigned)	5	Start Station & End Station	-
DELAY -- Enter delay value; if delay is 0, station will start to ring immediately. If delay value is deleted, the station will not ring. Otherwise if delay is 1-9, the station will start to ring after delay time (3 times of delay value).	5-1	0-9	Sta 100 (Port 0):delay 0 Others: not assigned

Table

ICLID Table (PGM 262) ... see details on [page A-113](#)

PGM 262	BTN	RANGE	DEFAULT
ICLID NUMBER -- ICLID used to match the index.	1	24 digits	None
ICLID NAME -- ICLID name that is sent by the System to the destination for the ICLID routed call.	2	16 characters	-
INC CO GROUP NO -- The CO Group Number to apply ICLID route; if not assigned, ICLID is applied to all CO Groups.	3	1-72	-
DAY RING INDEX -- The index to be routed in Day; the Alternative Ring Index (PGM 181).	4	1-80	-
NIGHT RING INDEX -- The index to be routed in Night; the Alternative Ring Index (PGM 181).	5	1-80	-
TIMED RING INDEX -- The index to be routed in Timed; the Alternative Ring Index (PGM 181).	6	1-80	-
TENANT NO -- The tenant number to be applied the ICLID.	7	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

IP Trunking

H.323 v4 Service

When assigned to support H.323 protocol, VoIP channels provide protocol conversion between H.323 v4 and SIP. This permits the VoIP channel to connect to external H.323 networks or

PGM 361	BTN	RANGE	DEFAULT
G.711A CODEC -- usage of G.711A Codec Type.	5	0:Not Use 1:Use	Not Use
G.711U CODEC -- usage of G.711U Codec Type.	6	0:Not Use 1:Use	Not Use
G.729 CODEC -- usage of G.729 Codec Type.	7	0:Not Use 1:Use	Not Use
G.723 CODEC -- usage of G.723.1 Codec Type.	8	0:Not Use 1:Use	Not Use
GK USED -- used to determine if Gatekeeper will be used.	9	0:Off 1:On	Off

SIP

SIP User ID Data ...use *Web Admin* (PGM 370)

SIP CO Service ...use *Web Admin* (PGM 371)

RELATED FEATURES

System Networking ... see [page 3-200](#)

HARDWARE

VOIB

Session Initiation Protocol (SIP) Service

When assigned to support Session Initiation Protocol (SIP), VoIP channels provide protocol conversion between SIP and H.323. This permits the VoIP channel to connect to external SIP Networks for call services. In addition, to the IETF RFC-3261 SIP draft standard, System's VoIP channels support other SIP related RFCs including:

- RFC-2617 – HTTP Authentication, Basic & Digest
- RFC-3515 – Refer Method
- RFC-3264 – Offer/Answer Model
- RFC-3265 – SIP Basic Call Flow Examples
- RFC-3891 – SIP “Replaces” Header

Using the SIP database assignments, the System will register and authenticate with the SIP Proxy Server permitting the System to interoperate employing SIP to establish, manage and terminate real-time voice sessions with external parties.

H.323 Routing Attributes (PGM 360) ... see details on [page A-146](#)

PGM 360	BTN	RANGE	DEFAULT
DIGIT (1) -- destination numbers associated with the H.323 routing system.	1	Max 8 digits	-
DEST IP ADDR -- destination IP address associated with the H.323 routing system.	2	-	0.0.0.0

H.323 Call Setup (PGM 361) ... see details on [page A-146](#)

PGM 361	BTN	RANGE	DEFAULT
SETUP MODE -- H.323 IP calls can be set-up using the H.323 Normal or Fast Start mode.	1	0:Normal 1:Fash Mode	Fash Mode
TUNNEL MODE -- H.323 IP calls can be set-up using the H.245 Encapsulation (Tunneling).	2	0:Off 1:On	On
DTMF SEND MODE -- during a connection, DTMF digits can be sent In-band or Out of band (H.245).	3	0:Inband 1:RFC2833 2:Out	Inband
DIFF SERV -- Diffserv pre-tagging for Voice packet. NOTE: High values may cause high packet discard levels.	4	0-63	4
G.711A CODEC -- usage of G.711A Codec Type.	5	0:Not Use 1:Use	Not Use
G.711U CODEC -- usage of G.711U Codec Type.	6	0:Not Use 1:Use	Not Use
G.729 CODEC -- usage of G.729 Codec Type.	7	0:Not Use 1:Use	Not Use
G.723 CODEC -- usage of G.723.1 Codec Type.	8	0:Not Use 1:Use	Not Use
GK USED -- used to determine if Gatekeeper will be used.	9	0:Off 1:On	Off

SMDR Attributes (PGM 232) ... see details on [page A-91](#)

PGM 232	BTN	RANGE	DEFAULT
SMDR SERVICE -- SMDR Service Option. On-Line / Off-Line SMDR / SMDR-Interface / Email Service .can be enabled	1	0: Not Use 1: On-Line 2: Off-Line 3: On-Line/Off-Line 4: SMDR-Interface 5: SMDR E-Mail 6: Off-Line & E-Mail 7: On/Off-Line & E-Mail 8: Interface & E-Mail	0:Not Use
OUTGOING REPORT -- Outgoing Call Report Option for SMDR Service. If this option is set, outgoing call will be included at SMDR data	2	0:Off 1:On	0:Off
INCOMING REPORT -- Incoming Call Report Option for SMDR Service. If this option is set, incoming call will be included at SMDR data	3	0:Off 1:On	0:Off
ICM REPORT -- Internal Call Report Option for SMDR Service.If this option is set, internal call will be included at SMDR data	4	0:Off 1:On	0:Off
LOST CALL REPORT -- Outgoing or Incoming Lost Call Report Option for SMDR Service. If this option is set, CO lost call will be included at SMDR data	5	0:Off 1:On	0:Off
RECORD TYPE -- If set to on, LD calls are identified by the LONG DIST CALL DGT Counter; the system can record all outgoing calls or only long distance calls.	6	0:All Call 1:LD	0:All Call
LONG DIST CALL DGT CNT -- Dialed numbers, which exceed the assigned LD Digit count, are considered long distance calls for SMDR.	7	07-15	07
CURRENCY UNIT -- The unit of currency used for call cost can be identified with 3 alpha characters for easy reference.	8	Max 3 characters	-

ÚÓŦ ÁHG	ÓVP	ÜœÖÖ	ÖÖZÖŠV
ÓUÚVÁÓÜÁVŠUÖÁĚY @) Ā Ā^c!ā * Ā Ā! çā^áÁ à Ā@ ÁUUVB Ē@ Ā •c! Ā Ā^c!ā * Ā~ •ĀœĀ Ā^Á æ•ā}^áĒ	J	Ī Āā ā	€€€€€€
ÚŦ ÖÜÁÜÖŦVŦPĚÖ^c! ā Ā•Ā@Ā •āā } Ā Ā c@ Ā^&ā āĀ Ā@ÁÖ •c! Ā!ÁÜ •ĀĒ cœĀ * Ā! { Ā c@Áā @Ē •c!āā āĒ	F€	€Ē	€
PŦÖÖPĚÖŠÖÖÖŦVĚÖ^c! ā Ā•Ā@Ā { à!Á [Āāā^áāā ā Ā ĀāĀĀ!Ā^&!ā Ā~!] [•Ā•Ēā] áÁ !^ āā^áÁ ā@ĚĚÖ^c! ĀĒĒĒ , Ā^ā Ā•Á , @c@!Ā^āā * Ā!Āāā * Āā ā Ā^ĀāĀ^ ĒĚĚ āāāā} Ē@Ā cœĀ } Ā~ •c!Ā•ā}^áĀ!ĀŦ ÖÜÁ PŦÖÖŦŦÖŦĚĚĚ^c! Ā Ē	FF	€Ŧ	€
PŦÖÖPĚÖŦVÁUÚŦVŦPĚY @) ĀPŦÖÖPĚÁ ÖŦŠÖÖÖŦŦVĚĚĚ} āĀ^áĒ^c! ĀĒĒĒ ç^Ē@Ā ā áĀ^c! { ā Ā•ĀĀāā * Ā!Āāā * Āā ā Ā^Á ĒāĀ} Ē	FG	€Ē^c FĚĚ @	FĚĚ @
VÜœÜZÖÜÖPœÜÖÖĀŦ ÜÖÖĚĚ FĚÖ ÖÖŦŦŦŦŦŦŦ @) ĀœĀ/Ā Āā •Ā! ĀĀĀ Ā ā c@!Ā cœĀ } Ē@Āāā •Ā! ĀĀœĀ/Ā &œ^áĀ Ā ç [Ā cœĀ] •Ā•Ā^ĀœĀ Ē ĚÖÜÖŦŦVŦVŦŦŦŦŦŦŦ @) ĀœĀ/Ā Ā dā •Ā! ĀĀĀ Ā c@!Ā cœĀ } Ē@ĀœĀ/Ā &œ^áĀ ç Ā@Āāā •Ā! ā * Ā cœĀ } Ē ĚÖÜÖŦŦVŦVŦŦŦŦŦŦŦ @) ĀœĀ/Ā Ā dā •Ā! ĀĀĀ Ā c@!Ā cœĀ } Ē@ĀœĀ/Ā &œ^áĀ ç Ā@Āāā •Ā! ĀĀ cœĀ } Ē	FH	€Qāāā~ ā FĚc*!æ^Á^!ā * GQc*!æ^Á^!ā	€Qāāā~ ā
VÜœÜZÖÜÖPœÜÖÖĚĚ FĚÜŦŦ ŦŦŦŦŦŦŦŦŦŦŦ @) ĀŦŦ} āā ŦĚ ā^Á [^c [ā * ĀœĀ/Ā āĀāā •Ā!•ĀœĀ/Ā Ā c@!Ā •cœĀ } Ē@Āāā •Ā! ĀĀ āĀĀ , Ā@ĀĀāā •Ā!Ā Öœ^ĀĀ [āĒ ĚĚŦŦŦŦŦŦŦŦŦŦŦŦŦŦŦ @) ĀŦŦ} āā ŦĚ ā^Á [^c [ā * ĀœĀ/Ā āĀāā •Ā!•ĀœĀ/Ā Ā c@!Ā •cœĀ } Ē@ĀœĀ/Ā &œ^áĀ Ā@ĀŦŦ} āā Ē ĚĚŦŦŦŦŦŦŦŦŦŦŦŦŦŦŦ @) ĀŦŦ} āā ŦĚ ā^Á [^c [ā * ĀœĀ/Ā āĀāā •Ā!•ĀœĀ/Ā Ā c@!Ā •cœĀ } Ē@ĀœĀ/Ā &œ^áĀ Ā@Āāā •Ā! ĀĀ •cœĀ } Ē	FI	€P { āĀœ^ā * FĚĚĚĚĚĚĚĚĚĚ * GĚ^!ĀĀĚĚĚĚĚ *	€P { āĀœ^ā *

PGM 232	BTN	RANGE	DEFAULT
WARNING TONE SVC -- if this option is enabled and SMDR service type is off-line, the system check free records space. And if free space is less than 1000, warning tone will be served as alarm to Attendant.	15	0:Off 1:On	0:Off
SMDR CONN TYPE -- This assigns port to be used for SMDR Interface. SMDR Interface is served through LAN or SIO.	16	0:SIO 1:LAN	0:SIO
- SMTP MAIL SERVER ADDRESS -- SMTP Mail Server IP Address.	Web Only	-	-
- SMTP MAIL SERVER PORT -- SMTP Mail Server Port Number		-	-
- SMDR REPORTED MAIL ADDRESS -- SMDR User Mail Address.		Max 64 characters	-
- SMDR SMTP MAIL SERVER ID -- SMTP Mail Server User ID		-	-
- SMDR SMTP MAIL SERVER PASSWORD -- SMTP Mail Server User Password		-	-
- SMDR SMTP SENDER ADD -- Sender Address of Reported SMDR E-Mail		Max 64 characters	-
- SMDR SMTP SEND WEEKLY SET -- Select SMDR Mail Send Day		N/A (Monday- Sunday)	N/A
- SMDR MAIL SEND DAILY SET -- Sets time-of-day for SMDR data to be sent on a daily basis (00 for no daily records, 01-23 for hour of the day).		00-23	00
- SMDR MAIL AUTO SEND MODE -- If the SMDR buffer is full, the system can automatically send a notification by e-mail.	Web Only	0:Off 1:On	1:On
- SMDR MAIL AUTO DELETE MODE -- Deletes SMDR records after sending e-mail.		0:Off 1:On	1:On

CO/IP Line Data

- CCCCCCCC – Called Station
- DD...D – Speed Dial Name
- EEE – Speed Dial Bin Number (3 or 4)
- FFFFFFFF – Answering Station

The System will also compare the identification to the Speed Dial bins. If a match exists, the Name of the Speed Dial bin may be displayed in place of the number, CO/IP Name Display.

The System will send calling and answering party identification in the appropriate messages to the ISDN based on the database. Identification messages may be restricted, and not reported to the far-end user. Calling Line Identification Restriction and Connected Line Identification Restriction may be enabled in the System database.

CONDITIONS

- This feature may not be available in the specific ISDN service area or may be a subscription service.

OPERATION

Operation of this feature is automatic.

PROGRAMMING

System Data

CLI Print (PGM 223 - FLEX 6) ... see details on [page A-85](#)

PGM 223	BTN	RANGE	DEFAULT
CLI PRINT -- If set to ON, CLI information is printed.	6	0: Off 1: On	0: Off

Keypad Facility

The ISDN Keypad Facility Information Element (IE) may enable the User to activate certain ISDN services (ex., Off-Net Forward). To access this facility, the Station must be enabled and have a Flex button programmed for {KEYPAD FACILITY}. When activated, the digits dialed by a User are sent in the Keypad Facility IE instead of the Called Party Number IE.

CONDITIONS

- This feature can be activated or deactivated only after a CO Line (ISDN) is seized.
- Once activated, the system will continue to send dialed digits as Keypad Facility IE messages regardless of ISDN messages; in the connected mode, DTMF tones are not sent to the connected party, only the keypad message is sent.

ËÄ V@Áæ^!^Á æÁ [ç^Áæççç^Á Á@Á] ^ä&ÄÜÖPÁ!Á æÁ^Áæ^ à•&ä ç } Á
 •^iç&^ËÄ

ËÄ V@Á^•ç { &ç Áçç ä^Á } | Áä ä * | ^Öç|Á^•^!^ } &^Á^iç&^ Áçç^~ ä^Áçç ä|ä * Á-Á
 ç [Áä ~ |çç ^ [•Öç|Á^•^!^ } &•Ëçç } [ç^Á^] [|çäËÄ

OPERATION

Digital Phone

To program a {KEYPAD FACILITY} button:

Ú!^••ÄÜÖT æÁçSÖY^ÉÓ^ ç } Á^æ^!^Á] ^ÄFDEÁS^] æÁçççç ç^æ^!^Á ä^ÁËÄ
 ŽÜÇÖÁÄ

To activate the keypad facility after seizing an ISDN line:

FÈ ŠäP çç ä^Ä!Á!^••ÄÜ] ^æ^!^á~ ç } ËÄ
 GÈ Ú!^••Á@ÁSÖYÜÇÖÄÜÖSÖY^ä~ ç } ËÄ
 HÈ Öäç^• ä^áä ä ä ËÄ ç | Áçç } •Á ä|Áä çç^Á@^S^] æÁçççç Áæ^!^ËÄ

PROGRAMMING

Numbering Plan

S^] æÁçççç ÄÜ [ä^ÄÜÖT ÄFHDS Á^Á^çç^Á } Áæ^ ÖËÇE

ÖVP	ÜÇE/MÜÖÄÜÖT ÄFHD	ÜÖT ÖËS
ÌH	S^] æÁçççç	ÄÄE

Station Data

Ö^ç^Ó^ ç } ÄÇ•ä { ^ } çÜÖT ÄFG DS Á^Á^çç^Á } Áæ^ ÖËGJ
 S^] æÁçççç Á•æ^ ÄÜÖT ÄFHÄSÖYÄFGDS Á^Á^çç^Á } Áæ^ ÖËHH

ÜÖT ÄFH	ÖVP	ÜÇE ÖÖ	ÖÖÇEVS
SÖYÜÇÖÄÜÖSÖYÄMÜÖÖÄËÄ] æ^Á^] æÁçççç È	FG	€^Öä çç^ FHÖ) çç^	Öä çç^

RELATED FEATURES

Üççç } ÄÜ] ^ä^Öäçç^ Á^Á^ Áæ^ HÈI Ì

HARDWARE

Öä ääÜ@ } ^

PRIB

Multiple Subscriber Number (MSN)

The Multiple Subscriber Number (MSN) feature enables multiple stations to receive ISDN incoming calls at a specific destination. Additionally, it enables a station to place an outgoing call using a specific CLI.

CONDITIONS

- If a CO line uses Representative CLI, that information is sent before other CLI options.

OPERATION

If set, MSN operation is automatic.

PROGRAMMING

Station Data

Station DN Type (PGM 130 – FLEX 1) ... see details on [page A-31](#)

Station CLI Number (PGM 135 – FLEX 6) ... see details on [page A-35](#)

PGM 135	BTN	RANGE	DEFAULT
CLI NUMBER -- When not restricted (FLEX 4 & 5 above), this entry is added to the number sent in the ISDN call SETUP or CONNECT message in place of the station number.	6	24 digits	-

Station Flex Button Assign (PGM 126) ... see details on [page A-29](#)

CO Line Data

CO Digit Conv. Table Index (PGM 160 – FLEX 6) ... see details on [page A-45](#)

PGM 160	BTN	RANGE	DEFAULT
DGT CONVERT TBL -- Set Digit Conversion Table index.	6	1-9	2

System Data

PGM 251	BTN	RANGE	DEFAULT
D3/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	13	Max 16 digits	-
D3/T2 CHANGED -- The digits to be dialed in 'Day 3/Time 2' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	14	Max 16 digits	-
D3/T3 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 3/Time 3' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	15	Max 16 digits	-
DNT TIME INDEX -- Day/Night/Timed Time Table Index.	16	1-9, none	none
LCR TIME INDEX -- LCR Time Table Index.	17	1-9, none	none
NAME -- When DID destination starts to ring, the name is displayed on the ringing station's LCD.	18	Max 16 digits	-
APPLY OPTION -- The Apply Option can be applied according to the caller.	19	0:All 1:Station 2:CO Line 3:Diable	0:All

HARDWARE

PRIB

ISDN CLI

When programmed, the ISDN will send CLI information on incoming and outgoing Calls. On Incoming Calls, CLI information is delivered to the Calling Party System. On Outgoing Calls, CLI information is delivered to the Called Party System, and also from the Called Party System to the MBX IP.

CONDITIONS

- If a CO line is using Representative CLI, that information is sent before other CLI options.
- If a Station that places or answers the CO call has a CLI number programmed, only the CLI number of the station is sent as CLI information (similar to Long CLI option of ipLDK system).
- If a CO line is not using Representative CLI and the Station is not using a programmed CLI number, then the {CO Own Code} + {Station number} is used as CLI information.

PGM 135	BTN	RANGE	DEFAULT
COLR WHEN ANSWER -- COLR (Connected Line Id Restriction) an ISDN service, removes connected party ID sent from the PSTN to the calling party with a RESTRICT instruction in the CONNECT message. If enabled here, the system will send the restrict instruction to the PSTN when the station answers an ISDN call.	5	0: Off 1: On	Off
CLI NUMBER -- When not restricted (FLEX 4 & 5 above), this entry is added to the number sent in the ISDN call SETUP or CONNECT message in place of the station number.	6	24 digits	-
CFWD CLI/REDIRECT -- When an incoming ISDN call is forwarded by the ISDN, the call SETUP message will contain an original and redirected CLI. This selection determines if the Digital Phone will display the original or redirected number.	7	0: CLI 1: Redirect	CLI
IGNORE CALLER CLIR -- When receive a call with CLIR option, ignore the option and display CID.	8	0: Off 1: On	Off
MOBILE EXTENSION CLI -- When mobile extension makes a call, CLI is determined by this option. (0:Caller No, 1:Mobile Station No, 2:Caller No + Mobile Staton No).	9	0: Caller No 1: Mobile Sta No 2: Caller + Mobile Sta	Caller No
LONG CLI 1 -- If CLI type of outgoing CO line is set to 1, Long CLI 1 is sent.	10	24 digits	-
LONG CLI 2 -- If CLI type of outgoing CO line is set to 2, Long CLI 2 is sent.	11	24 digits	-
LONG CLI 3 -- If CLI type of outgoing CO line is set to 3, Long CLI 3 is sent.	12	24 digits	-
CLI NAME DISPLAY -- If this is set to ON, Name matched with CLI will be displayed This selection determines if the Digital Phone will display CLI name with CLI.	13	0:Off 1:On	Off
STA NO HIDDEN -- If this is set to ON, station number is not displayed at calling or called party LCD. This selection determines if the Digital Phone will display Station number	14	0:Off 1:On	Off
CALL TRANSFER CLI -- When a STA makes transfer call, call SETUP message will contain an transferor or transferred CLI	15	0:Transferor 1:Transferred	Transferor

CONDITIONS

- The ISDN must support Call Deflection Supplementary Service as defined by the ETS300-202/206/207 Standard protocol.
- ISDN lines that support Call Deflection must be assigned in the System database.

OPERATION**Digital Phone**

To activate ISDN Call Deflection for an External Phone Number:

1. Lift the handset or press the [SPEAKER] button to receive dial tone.
2. Press the [FWD] button.
3. Dial Forward condition (1-4, or #)
4. Dial CO Access Code and desired External Phone Number.
5. Replace the handset, and return to idle.

To deactivate ISDN Call Deflection:

Press flashing [FWD] button, Call Forward will deactivate and the [FWD] button LED will be extinguished.

PROGRAMMING*CO Line Data*

ISDN CD (PGM 161 - FLEX 9) ... see details on [page A-46](#)

PGM 161	BTN	RANGE	DEFAULT
GAIN TABLE IDX -- Determines Gain Table for CO line.	9	1-3	1

HARDWARE

- ISDN Line
- Digital Phone

Representative CLI Service

If a user makes a CO Call, the System can send Representative CLI instead of Individual CLI.

CONDITIONS

- This feature can be set for each CO Line.

Chapter 6

Digital Phone

The following Digital phones and Optional Boards are available for use with the MBX IP 100 and 300 Systems.

Digital Phones

- Edge 8012/8024 IP phones
- Edge 700 8 & 24 button digital phones
- 30xx Vodavi digital phones
- STS digital phones
- 90/Tr90 infintie/Triad digital phones
- Comdial 80xx/83xx/E100 digital phones

Optional Boards

- BTU (IP-8000 Series)
- MU/FU/MFU/BTU/USB (LDP-7000 Series)

DSS

- DSS/LSS (IP-8000 Series: IP-8012DSS, IP-8012LSS)
- Digital-48DSS
- LDP-7048DSS

Door Phone

- LDP-DPB

PROGRAMMING*System Data*

ACNR Pause Timer (PGM 220 - FLEX 3) ... see details on [page A-83](#)

PGM 220	BTN	RANGE	DEFAULT
ACNR PAUSE TMR -- This timer establishes the time between ACNR attempts.	3	005-300 secs	030

Tenant Data

ACNR Retry Counter (PGM 280 - FLEX 4) ... see details on [page A-128](#)

PGM 280	BTN	RANGE	DEFAULT
ACNR RETRY COUNT -- Determines the ACNR retry count.	4	0-5	3

Station Data

ACNR Access (PGM 133 - FLEX 5) ... see details on [page A-33](#)

PGM 133	BTN	RANGE	DEFAULT
ACNR ACCESS -- enable ACNR feature.	5	0: Disable 1: Enable	Disable

RELATED FEATURES

Last Number Redial (LNR) ... see [page 3-110](#)

Speakerphone ... see [page 6-19](#)

Mute ... see [page 6-13](#)

HARDWARE

Digital Phone

CONDITIONS

- This feature does not apply to Digital Phones not equipped/assigned with Speakerphone; the User must lift the Handset.
- Paging while on the Speakerphone may cause feedback from Paging Equipment; if Auto Speaker is enabled and a {PAGE ZONE} button is pressed, the display will show "LIFT THE HANDSET". To complete the page, User must lift the Handset within the predefined 5-second period or the phone will return to Idle.

PROGRAMMING*Station Data*

Auto Speaker Selection (PGM 121 - FLEX 1) ... see details on [page A-24](#)

PGM 121	BTN	RANGE	DEFAULT
AUTO SPKR -- enables [SPEAKER] activation when a CO/IP, DSS or other feature button is pressed (handsfree).	1	0:Off 1:On	On

HARDWARE

Digital Phone

Background Music (BGM)

A Digital Phone can receive audio (generally music), from an Internal or External Source while it is Idle. Music from the source is received over the Speaker and will be disabled during Ringing, Paging, or when the Station is Off-Hook.

CONDITIONS

- Speaker volume can be adjustable at the Station using the [VOL UP]/[VOL DOWN] keys on the Digital Phone.
- Silence is provided if no BGM Source is assigned.

OPERATION

Digital Phone

To listen to Background Music:

FÈ Ú|·^•• Á@ ÄÜÖT áá~ ç[} Áæ ä ÄÖæÄG ĚÄ
 GÈ Ù|^&ó@ Á^• ä^áÄÖÖT ÁÚ[~ |&•ĚÄ
 HÈ Ú|·^•• ÄÜÖXÖáá~ ç[} ĚÄÄ

RELATED FEATURES

T~•æĚ} Ě[|áÄT UPDš Á^^Á æ^ ĚĚGH
 Qç[} æDç[} æBÄŲ|Äæ|Áæ^š Á^^Á æ^ | ĚÍ

HARDWARE

ÖÖT Á[~ |&Á| : [] ^| ^& } } ^&ç^áÄ Á@Ä ÚÖÄÇ^~^|Ä ÄPæá, æ^ÁBÄQ•ç[ææ] } ÄÖ~ ä^DÄÄ

Call Log Display

W^|^|·Á -Ää äæÁQ } ^•Á äÖU| -Ä^• Áæ Äç, ÁæÖæ||Š[* Á -ÄQç[{ ä * ĚÜ~ ç[ä * Áæ äÄ ä^•áÄ
 Öæ|·Á } Á@ÁÚQ } ^ŠÖÖÄÇ @|^Áæ } |ææ|^ĚÄ

CONDITIONS

ĚÄ U } ^Á çæ[} Áæ Äç^Á] Ä Ä ÄĚÄ[**^á/æç|·ĚÄ
 ĚÄ Öæ||Š[* Á Áä] |æ^á/æ Ä } ^Á -Ä@^^Ä] ^•Á -Áæ|·KÜ^&ä^á/Öæ||ĚÖæ^á/Öæ||æ äŠ[·Ä
 Öæ|ĚÄ
 ĚÄ V@ÄÖæ||Š[* Á Äç|^á/Ä Ä[|æ^Á ^{ [|^ÄšÄ Ä[ç[|: ç&ç^á/Ä Áæ^Á -Ä[, ^|Áæ|^ĚÄ

OPERATION

Digital Phone

To access the Call Log menu:

1. Press the {LOG} Soft button on the Digital Phone; a similar display will be presented.

>01 -> 107			
02 M 106			
SEND	SELECT	EXIT	

Symbol	Description
→	Outgoing (Dialed) Call
←	Incoming Answered (Received) Call
M	Missed (Lost) Call

2. Press the [VOL UP]/[VOL DOWN] buttons to select the Call Log to display.

>01 -> 107			
02 M 106			
SEND	SELECT	EXIT	

3. Press the {SEND} button to make a call, press {SELECT} to check the detailed information, or press {EXIT} to return to Main Menu selections.

HARDWARE

Digital Phones with 3 Soft keys

One Time DND

While a Station is ringing or receiving an Off-Hook Muted Ring, the User can press the [DND] button, to reject the call and terminate Ringing. When the Station returns to the Idle status, DND is automatically cancelled and the [DND] LED is extinguished. If the DND button is pressed while on a call, any ringing to the Station regardless of destination DN, will be rejected and will not ring.

CONDITIONS

- If the [DND] button is pressed while on an active call, subsequent calls will not be received for the duration of that call.
- One Time DND operates regardless of DND Access privilege.
- If the [DND] button is pressed when Delayed Ring Service is enabled, the Station will continue to receive Incoming Call Ringing.
- CO/IP recalls will override One Time DND.

OPERATION

Digital Phone

To activate One Time DND while on a call

Press the [DND] button, the [DND] LED lights, station goes to DND state.

System

Deactivation

When the Station returns to Idle, DND automatically is cancelled and the [DND] LED will extinguish.

PROGRAMMING

Station Data

DND Access (PGM 132 - FLEX 4) ... see details on [page A-33](#)

PGM 132	BTN	RANGE	DEFAULT
DND ACCESS -- enables DND to be activated by the station.	4	0: Disable 1: Enable	Enable

RELATED FEATURES

Do Not Disturb (DND) ... see [page 3-77](#)

HARDWARE

Digital Phone

HARDWARE

Digital Phone

Intercom Signaling Mode

Each Digital Phone can select the applicable signaling mode used for incoming ICM calls while the station is Idle; there are three signaling modes available:

- Call Announce with Hands free Answer-Back (H) – When an ICM call is received, the User receives a splash tone followed by the ICM caller's voice. The user may respond to the Caller without the need to Lift the Handset or press the [SPEAKER] button.
- Call Announce with Privacy (P) – When an ICM call is received, the User will receive a Splash tone followed by the ICM Caller's voice; the User must lift the Handset or press the [SPEAKER] button to connect the call.
- Tone Ring (T) – An ICM call will cause the Digital Phone to provide an audible ICM ring tone; the user must lift the handset or press [SPEAKER] to answer.

NOTE: Digital Phones use Tone Ring Mode as a default, and SLTs always function in the Tone Ring Mode.

CONDITIONS

- Callback and Call Forward will ring in the tone mode, regardless of ICM Signaling Mode selected by the User.
- The ICM Signaling Mode Selection does not affect Page announcements.
- By default, the ICM Signaling Mode is Tone ring, and is stored in battery-protected memory.

OPERATION

Digital Phone

To change ICM Signaling Mode:

1. Press the [PGM] button; the [SPEAKER] button LED will light steady.
2. Dial 11 {Station User Program code}, and a confirmation tone is received.
3. Dial the desired ICM Signaling Mode code (1=H, 2=T, or 3=IP).
4. Press the [SAVE] button

~~AAAAAA~~ [AMP] [VOLUME] [MUTE] [SPEAKER] [H] [P] [T] [IP] [K]

Select the HTP switch or button to select the desired mode.

PROGRAMMING

Tenant

Qc!& { ÁÜ} æq * Á [á^ Öä æÁÜçæÁÜÖT ÁGHI Ds Á^^Á^æq Á } Á æ ^ ÖËF

ÜÖT ÁGHI	ÓVP	ÜÖÖÒ	ÖÖÖÖSV	
ÜVÖÚÖÖSSÄÄ^c! { q ^• ÁÜc } ÁÖæ/Á Á) æ ÁÁ! Áæ æ ÁÊ	F	€ÁÖä æ Á FÁÖ) æ Á	Öä æ Á	
ÖÖQÁÄÄ @ } Áæ&•q * Áæ~•^ Á } ^ÉV^Á Á æ ÁæÁ Á } ^Á ~ c@Á } ^É } &@Áçæ^É	G	€ÁÖE FÁÖæ Éæ GÁÖæ] Á } HÁÖæ Á æ I ÁÜ [æÁÜç! Í ÁÜ d~•q } Î ÁÜ } c	€ÁÖE	
ÖÖQÁGÄ	H			
ÖÖQÁHÄ	I			
ÖÖQÁÄÄ	Í			
ÖÖQÁÄÄ	Î			
ÖÖQÁÄÄ	J			
ÖÖQÁÄÄ	F€			
ÖÖQÁÄÄ	FF			
ÖÖQÁÄÄ	FG			Öæ Á æ
ÖÖQÁÄÄ	FH			X [æÁÜç!

RELATED FEATURES

Qc!& { ÁÜ} æq * Á [á^ Öä æÁÜçæÁÜÖT ÁGHI Ds Á^^Á^æq Á } Á æ ^ I ËG
 Üæ q * Á Á^^Á^æq Á } Á æ ^ I ËF

HARDWARE

Öä æÁÜç } ^Á

Mute

A Digital Phone can turn off audio transmission from the Handset, Speakerphone or Headset Microphone (Mic Mute).

CONDITIONS

- Changing from Speakerphone to Handset or vice versa while the phone is Muted will re-activate the phone microphone, transmitting audio.
- Returning to Idle or placing another CO/IP or Intercom call will cancel Mute, and re-establish audio transmission from the phone.

OPERATION

Digital Phone

To Mute the Microphone:

While on a call, press the [MUTE] button; the [MUTE] button LED will illuminate and the microphone (Handset, Speakerphone, Headset) will be muted, disabling audio transmission to the other party.

To activate the Microphone:

Press the illuminated [MUTE] button; the [MUTE] button LED will be extinguished, and the microphone is activated, transmitting audio to the connected party.

PROGRAMMING

Station Data

Headset Ring (PGM 121 - FLEX 3) ... see details on [page A-24](#)

PGM 121	BTN	RANGE	DEFAULT
HEADSET RING -- in Headset mode, this item selects device to receive incoming ring signals. - Speaker, Headset or Both.	3	0:Speaker 1:Headset 2:Both	Speaker

RELATED FEATURES

Speakerphone ... see [page 6-19](#)

Group Listening ... see [page 6-10](#)

HARDWARE

Digital Phone

On-Hook Dialing

Digital Phones equipped with a Speakerphone can allow Users to place as well as receive calls while the Handset is On-Hook. Once the User activates the Speakerphone by pressing the [SPEAKER] button or Automatic Speaker Select, Dial tone is received and the User may dial the desired number.

CONDITIONS

- If the Outgoing call is not Answered, the User must press the illuminated [SPEAKER] button to return to Idle.
- When the Speakerphone is used, the Microphone is active unless the [MUTE] button is pressed, and the [MUTE] button LED is On.

OPERATION

Digital Phone

To activate On-Hook Dialing:

1. Press the [SPEAKER] button, and Dial tone is received; the [SPEAKER] button LED will illuminate.
2. Dial the desired number (ICM number, or select CO/IP path and dial).

PROGRAMMING

Station Data

Auto Speaker Selection (PGM 121 - FLEX 1) ... see details on [page A-24](#)

PGM 121	BTN	RANGE	DEFAULT
AUTO SPKR -- enables [SPEAKER] activation when a CO/IP, DSS or other feature button is pressed (handsfree).	1	0:Off 1:On	On

RELATED FEATURES

- Mute ... see [page 6-13](#)
 Speakerphone see [page 6-19](#)
 Automatic Speaker Select see [page 6-4](#)

PROGRAMMING*Station Data*

Auto Dial Digit (PGM 138 - FLEX 1) ... see details on [page A-38](#)

PGM 138	BTN	RANGE	DEFAULT
AUTO DIAL DGT -- Digits will be dialed automatically.	1	Max 16 digits	-

Auto Dial Pause Time (PGM 138 - FLEX 2) ... see details on [page A-38](#)

PGM 138	BTN	RANGE	DEFAULT
AUTO DIAL PAUSE TIME -- Auto dial pause time.	2	00-30	0

RELATED FEATURES

Speakerphone ... see [page 6-19](#)

Intercom Call (ICM Call) ... see [page 4-2](#)

Station Flexible Buttons ... see [page 6-21](#)

Differential Ring

The User can select one of 14 Ring tones so that the MBX IP Phone ring can be distinguished from other nearby phones. Up to 8 Ring tones can be stored in the MBX IP Phone permanent memory; the first 4 tones are fixed, and the other Ring tones can be downloaded from a library of 10 Ring tones stored in the System protected memory.

After downloading a tone from System memory, it can be selected as the Differential Ring Tone.

CONDITIONS

- The downloadable Ring tone files are stored in System memory as *.wav files with a maximum length of 4 seconds. These files can be replaced as desired using the Web Upload function.
- Ring tone download is only supported at LIP-series terminals.

OPERATION**MBX IP Phone**

To download a Ring Tone from System memory:

OPERATION

Digital Phone

To save a Dialed number, while on a CO/IP Call:

After dialing, but before hanging up, press the [SPEED] button twice; the dialed number will be stored in the SNR buffer.

To dial a Saved number:

1. Lift the handset or press the [SPEAKER] button.
2. Press the [SPEED] button.
3. Dial #.

RELATED FEATURES

Station Speed Dial ... see [page 3-147](#)

System Speed Dial ... see [page 3-150](#)

Last Number Redial (LNR) ... see [page 3-110](#)

HARDWARE

Digital Phone

Speakerphone

Digital Phones equipped with a Speakerphone can use the telephone hands-free in two-way conversations.

CONDITIONS

- If Automatic Speaker Select is enabled at the Station, pressing a DSS, DN, CO Line Access Code or Speed Dial button will automatically activate the Speakerphone.
- The [MUTE] button LED indicates the status of the Microphone, when lit the Microphone is inactive.
- When Group Listen is enabled, pressing the [SPEAKER] button while using the handset will send audio to both the Handset and Speaker. However, only the Handset microphone will be active; in order to activate the Speakerphone Microphone, the Handset must be On-Hook.
- Each Digital Phone equipped with Speakerphone is allowed/denied Speakerphone operation based on System Database Admin. Programming.
- When Headset operation is assigned for the Station, the Speakerphone is disabled and the [SPEAKER] button activates the Headset audio path instead of the Speaker.

OPERATION

Digital Phone

To activate the Speakerphone:

Y @ ^ Á } Á Ó æ | Á ! Á } @ } Á | æ æ * Á Ó æ | È | ^ • • Á @ Á Ú Ó Ç S Ò Ù Á Á ~ æ } L @ Á S Ò Ö Á } Á Á
á | { á æ È Á

To switch from Handset to Speakerphone:

F È Y @ ^ Á } Á Ó æ | È | ^ • • Á @ Á Ú Ó Ç S Ò Ù Á Á ~ æ } L @ Á S Ò Ö Á } Á Á | { á æ È Á
G È Ú ^] | æ Á P æ á • ^ Æ @ Á Ú] ^ æ ^ !] @ } ^ Á Á Á Ó æ | æ á È Á Á

To terminate a Speakerphone call:

Y @ ^ Á } Á Ó æ | Á • á * Á @ Á Ú] ^ æ ^ !] @ } ^ Á È | ^ • • Á @ Á Ú Ó Ç S Ò Ù Á Á ~ æ } L @ Á S Ò Ö Á } Á Á
^ ç á * ~ á È Á

PROGRAMMING

Station Data

P ^ æ • ^ ç Á * Á Ú Ó T Á G F Á Ó S Ò Y Á Ç Á Á Á Á Á æ ^ È È G

Ú Ó T Á G F	Ó V P	Ü Ç È Ö Ò	Ö Ò Ç È V Š V
P Ó Ç Ö Ù Ó V Á Ú Ç Ö Á È Á P ^ æ • ^ ç Á [á È Á Ç Á Á { Á • ^ ^ & • Á ^ ç Á Á Á Á & á ^ Á & & { á * Á á * Á á } æ È Á Ú] ^ æ ^ !] È P ^ æ • ^ ç Á ! Á Ú] Ç È	H	È Ú] ^ æ ^ ! F K P ^ æ • ^ ç Á G Ó [Ç È	Ú] ^ æ ^ !

P ^ æ • ^ ç Á [á È Á Ú Ó T Á G F Á Ó S Ò Y Á Ç Á Á Á Á Á æ ^ È È G

Ú Ó T Á G F	Ó V P	Ü Ç È Ö Ò	Ö Ò Ç È V Š V
P Ó Ç Ö Ù Ó V Á Ú Ó Ç È Á ^ ^ & • Á Ú] ^ æ ^ !] @ } ^ Á [á È Á P ^ æ • ^ ç Á [á È Á ! Á Ç Á Á Á Á [á È	G	È Ú] ^ æ ^ ! F K P ^ æ • ^ ç Á G Ó È È	Ú] ^ æ ^ !

RELATED FEATURES

- T ~ ç Á Á Á Á Á æ ^ Í È H
- Ö [~] Á Ó ç Á } á * Á Á Á Á Á æ ^ Í È €
- Ç È ç { æ Á Ú] ^ æ ^ ! Á Ú] ^ & ç Á Á Á Á Á æ ^ Í È
- Ö ! ^ Á } Á Ú] , ^ Á Ú æ Á Á Á Á Á Á æ ^ H È J

Station Flexible Buttons

The Digital Phone incorporates a field of Flex buttons as well as the Fixed Feature buttons. The Flex buttons are assigned in the System database to access features, functions and resources of the System. Specifically, Flex buttons can be assigned as:

- Empty button – No system database assignment.
- {DSS} button – used to place One-touch ICM calls to a designated Station and display Station status.
- A Flex Numbering Plan, button activates the feature associated with the assigned digits from the Flexible Numbering Plan.
- A DN Flex button accesses and dials the assigned number.
- An External Telephone Number including CO Access Code to make external call.
- A CO Line Appearance button provides access to the individual CO Line assigned to the Flex button. The CO Line button LED provides the status of the CO Line.
- Fixed button activates the feature associated with the fixed button

With the exception of CO Line buttons, Flex buttons can be assigned at the station by the end-user. If allowed in the database, the user can also assign or reassign CO Line buttons.

CONDITIONS

- Fixed button programming is supported when the Phone does not already have the same Fixed button.
- If a Fixed button or Dial Number button is set to not allow User modification according to Admin. Programming, the User cannot change the button.
- DN button can be assigned or changed by Admin. Programming. The station can only change the ring option of DN button.

OPERATION

Digital Phone

To assign a Flex button at the station:

1. Press the [PGM] button.
2. Press the desired Flex button.
3. Select the type. - 1: Telephone number or Feature code. - 2: Fixed Button. - 0: Delete.
4. Select the desired button type using the [VOL UP]/[VOL DOWN] key to assign a Fixed button,
OR
5. Dial the desired number to create the Telephone number button.

PROGRAMMING

System Data

LED Data (PGM 234) ... see details on [page A-95](#)

Station Data

Station Flexible Button (PGM 126) ... see details on [page A-29](#)

HARDWARE

Digital Phone

Station ICLID Call Routing

The Station can employ Incoming Calling Line ID (ICLID) to determine appropriate routing for Incoming External Calls.

CONDITIONS

- If the received ICLID does not match an entry in the Station ICLID List, the Station will receive CO/IP Line Ringing.
- This feature applies to all digital and analog CO Lines.
- The ICLID received from the CO/IP Line must be a telephone number to match a station ICLID List.
- Each Station can have 10 ICLID numbers individually.

OPERATION

Digital Phone

To assign ICLID at the Station:

1. Press [PGM] button and Dial 71, then the empty ICLID bin automatically will be allocated.
2. Enter ICLID and press [SAVE] button.
3. Enter the Routing Destination, and press the [SAVE] button.

NOTE: Routing Destination can be a Station number, Hunt Group number or VMIB Forward code.

To view the assigned ICLID at the Station:

1. Press [PGM] button and dial 72; ICLID information is displayed.
2. Press [VOLUMN UP/DOWN] to view the ICLID List.

To delete the assigned ICLID on the Station:

FÈ Ú!^••ÁÚÓT áá~ æ} Áá á/ÖáÁ GLÁÓŠÖÁ {!| æá } Á Áá] |æ^áÁ
 GÈ Ù^!^&á@ ÁÓŠÖÁá Á á@ÁXUSÁMÚÁÁXUSÁÓUY Þáá~ æ} •Áá áÁ!^••ÁÚÖXÒÁÁ
 HÈ Ú!^••ÁÚÓÒÖáá~ æ} L& } -á{ æá } Á } ^Á á/Á^Á!^•^} ¢áÁÁ
 I È ÖáÁÁÁÖ^!^•ÁÁ

Station User Programming & Codes

W^!^•Áá Á![*!æ Áá Áá!æ Á -Á } &á } •Áá á/Á^æ!^•Áá á/Ö&^•ÁÚæ•Á {!| æá } ÁÁ
 V@ÁÚcæá } ÁV^!ÁÚ![*!æ ÁÖ[á^•Á^•áÁ! Á@^Á~!][••Áá^Áá^Áá Áá ¢áÁÁ^!|, ÁÁ

User Program Code Chart

USER PGM CODE	DESCRIPTION	REMARK
11	Intercom Answer Mode	1:H, 2:T, 3:P
12 + Name	User name creation	2 digits for each character
13 + Time	Set wake-up alarm time	HH/mm, 24-hour clock
14	Cancel Wake-up Alarm	-
15	Set language for the display	00-14
16	LCD Date Mode Change	DD/MM/YY or MMDDYY
17	LCD Time Mode Change	12 Hour/24 Hour
18	Set Backlight	0-3
21	ICM Ring Type	-
22	TRK Ring Type	-
23	Ring Download	LIP-Series Only
24	Back Ground Music	-
31	Temporary COS	Auth. Code required
32	Retrieve COS	Auth. Code required
33	COS Override (Walking COS)	Auth. Code required
34	Register Password	-
35	Call Log Protect	-
36	SMS Message Protect	LIP-Series/LDP6000-Series
41 + MSG number [xx]	Set Pre-defined Message.	0-9, MSG *: User Custom # Deactivation
42	Create a Station User Message	-
43	Send SMS Message	LIP Series/LDP6000 Series
44	Receive SMS Message	LIP Series/LDP6000 Series
51 + x	Activate a mobile phone	X =1-2
52 + x	Register the mobile number	X =1-2

USER PGM CODE	DESCRIPTION	REMARK
Í HÉÁ	Ü^* ä c!Á@Á [äq^ÖŠÄ ~ { à^!Á	ÝMFÉÁ
Í I ÉÁ { ÁÁE cÖ! á^Á	ÚcæáÖ! } -ÁÚ [[{ Á	È
Í I ÉÁ { ÁÁE cÖ! á^Á	Ö! [•^ÁÖ! } -ÁÚ [[{ Á	È
Î FÁ	Ú] ^æ^!P^æ•^cÁ [á^Á	Ú] ^æP^æ•^cÁÈÈÈ ÖÁ
Î GÁ	P^æ•^cÁq * Á [á^Á	Ú] ^æ^!P^æ•^cÁÈÈÈ cÖÁ
Ï FÁ	Ü^* ä c!ÁÚcæá } ÁÖŠÖÁ	È
Ï GÁ	Xa, ÁÚcæá } ÁÖŠÖÁ	È
ì FÁ	Xa, ÁÖÁEá!^••Á	ÖÁÚ@ } ^ÈÖVQ ÈŠVT Á
ì GÁ	Xa, ÁÖÁEá!^••Á	ÖÁÚ@ } ^ÈÖVQ ÈŠVT Á
ì HÁ	Xa, ÖÁÚ@ } ^Á^!•q } Á	È
ì ÉÁ	P^c [!Á^cæ * Á	ŠÖÁ^!a•Á
JFÁ	Ü^* c! Á^!•q } Á	È
JGÁ	Ü^* c! ÁÖÁEá!^••Á	È

DECT Program Code Chart

USER PGM CODE	DESCRIPTION	REMARK
FGÉÁæ ^Á	V^!Áæ ^Á^æ } Á	Gáá á! ÁæÖcææc!Á
FHÉÁæ ^Á	Ü^cæ È] Áæ { Áæ ^Á	PPÈ { ÈÇ Èq ~ !ÁÚ & Á
FI Á	Öæ &^ÁY æ^È] Áæ { Á	È
FÍ Á	Ü^cæq * ^ Á! ÁcÁæ] æÁ	ÈÈFI Á
HFÁ	V{] [!æ^ ÁOUÁ	CE cÖ! á^Á
HGÁ	Ü^dæc^ ÁOUÁ	CE cÖ! á^Á
HHÁ	ÖUÁÚc^! ä^ÁY æq * ÁOUÁ	CE cÖ! á^Á
H Á	Ü^* ä c!ÁÚæ•, [!áÁ	È
I FÉÁ ÜÖÁ ~ { à^!Ácá	Ü^Á!ÁE^q á^ÁÁ^••æ^Á	ÈÈÈ ÜÖÁÁV^!ÁÖ^•q { ÁÁ Ö^æcææ } Á
I GÁ	Ö! ^æ^ÁÚcæá } ÁV^!Á^••æ^Á	È
Í FÉÁ	Öcææ^Á [äq^Á @ } ^Á	cMFÁ GÁ
Í GÉÁ	Ü^* ä c!Á@Á [äq^Á ~ { à^!Á	cMFÁ GÁ

USER PGM CODE	DESCRIPTION	REMARK
53 + x	Register the mobile CLI number	X = 1-2
54 + Rm & Auth Code	Start a Conf Room	-
55 + Rm & Auth Code	Close a Conf Room	-
71	Register Station ICLID	-
72	View Station ICLID	-
91	System Version	-
92	System IP Address	-

Additionally, a Station User Program Menu display is provided on the Phone display to assist the User in setting the Station User Program Code Features and Functions. The [VOL UP]/[VOL DOWN] buttons are used to scroll through the Menu items and the Dial Pad is used to enter a selection.

OPERATION

Digital Phone

To activate a Station User Program Code Feature or Function:

1. Press the [PGM] button, the Station User Program Menu is displayed.
 2. Use the [VOL UP]/[VOL DOWN] to display the desired menu item.
- OR
3. Dial the desired Station User Program Code and additional entries as required

Two-Way Record

A Digital Phone User can record any active conversation to the Station User's Internal/External Mailbox or to a Phontage Hard Disk drive or UCS Client (where applicable). A {RECORD} button must be assigned to access this feature and record Normal Incoming/Outgoing Calls.

CONDITIONS

- The {RECORD} button LED will flash at 120 ipm while recording.
- Two-Way Recording feature is a manual recording, while the feature Call Recording is an automatic recording method.
- This feature is available when using the VMIB, Feature Server, or an external AA/VM, using SMDI communications mode. When an external AA/VM system uses in-band (DTMF) mode, Two-Way Record is not available.

Two-way Record Access (PGM 145 - Btn 4) ... see details on [page A-40](#)

PGM 145	BTN	RANGE	DEFAULT
TWO WAY RECORD ACCESS -- when allowed, the station can activate the Two-way record feature to record a conversation.	4	0:Disable 1:Enable	Disable

Two-way Record Device (PGM 145 - Btn 5) ... see details on [page A-40](#)

PGM 145	BTN	RANGE	DEFAULT
TWO-WAY RECORD DEVICE -- determines the save location of Two-Way recorded wav files: VM Boards, or Phontage. When Phontage is selected, recorded wav files are saved on the hard disk of the Phontage program-installed PC.	5	-	VM Boards

System

Tone Table (PGM 290) ... see details on [page A-133](#)

PGM 290	BTN	RANGE	DEFAULT
TONE TYPE -- Designates the Tone type.	1	01: Normal Tone 02: VMIB Prompt 03: VMIB Announcement 04: Internal MOH 05: External MOH 06-09: VMIB MOH 1/2/3/4 10-14: SLT MOH 1-5	01: Normal Tone
TONE TIME -- Determines the amount of time tone is provided.	2	1-600	10
TONE PORT -- Tone port index of PGM 264. The cadence of tone port may be changed by using Web-Admin.	3	1-19	-
PROMPT/ANNC NO -- The VMIB Prompt or Announcement number when tone type is VMIB Prompt or announcement.	4	1-255	-

To assign Speaker Hearing Mode:

- Press the {AME} button. 2. Press 2 (Speaker Hearing Mode)

To Delete AME Feature:

- 1. Press the {AME} button.
- 2. Press 0 (Disable)

To Answer a call in LED Blinking Mode:

- 1. When a call has been forwarded to VMIB, the {AME} Button will blink.
- 2. Press {AME} button to go to Speaker Hearing mode.
- 3. Press {AME} button to communicate without saving conversation,
OR
- 4. Press {Mute} Button to communicate with saving conversation

To Answer a call in Speaker Hearing Mode:

- 1. When a call is forwarded to VMIB, press the {AME} button to communicate without saving conversation,
OR
- 2. Press {Mute} Button to communicate while saving the conversation.

PROGRAMMING

Station

VMIB Access (PGM 145 - FLEX 1) ... see details on [page A-40](#)

PGM 145	BTN	RANGE	DEFAULT
VMIB ACCESS -- Permits station access to VMIB.	1	0: Disable 1: Enable	Disable

HARDWARE

- Digital Phone
- VMIB, Feature Server or External SMDI based AA/VM system
- Phontage or UCS Client

System Data

Intercom Busy One-Digit Service (PGM 237) ... see details on [page A-101](#)

PGM 237	BTN	RANGE	DEFAULT
STEP CALL -- determines if Step Call is enabled or disabled.	1	0: Disable 1: Enable	Disable
DIGIT 1 -- when accessing a busy tone, User may dial for one of the one-touch services.	2	0: N/A 1: Call-Back 2: Camp On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	0: N/A
DIGIT 2 --	3		
DIGIT 3 --	4		
DIGIT 4 --	5		
DIGIT 5 --	6		
DIGIT 6 --	7		
DIGIT 7 --	8		
DIGIT 8 --	9		
DIGIT 9 --	10		
DIGIT 0 --	11		
DIGIT * --	12		
DIGIT # --	13	Voice-Over	

HARDWARE

Digital Phone

Chapter 7

Attendants

Attendant Group

The System can have an Attendant Group (up to 5 Attendants) per Tenant. Each Attendant position must be equipped with a multi-button Phone and may include multiple DSS Consoles.

There are 2 different destinations to cover Attendant duties in a Tenant as follows:

- Night Attendant Group – Can be assigned as Hunt Group and covers Attendant Calls when all Attendants in a Tenant are in {DND}.status or the System is in Night Ring mode.
- Forward Destination – This can be assigned as Station/Hunt Group/Telephone Number and it covers Attendant Call according to the Forward type of the Attendant group.

CONDITION

- The first Attendant (System Attendant) is assigned as Station 100 (default), and others are not assigned.
- Attendant Calls (using the Attendant Call Code) is routed to first available Attendant according to Attendant Group Type (Terminal/Circular/Ring/Longest idle).
- A member in Attendant Group can use all DN features.
- If a member in the Attendant Group sets DND/FWD/Preselected Msg., Attendant Call will not be received.
- LIP/Digital/LDP series set for SADN-type can be assigned as the member of an Attendant Group.
- The Tenant of an Attendant member should be the same as Attendant Group.

OPERATION

If set, Attendant Group operation is automatic.

PROGRAMMING

Tenant Data

PGM 271	BTN	RANGE	DEFAULT
GREETING RPT DELAY -- Determines the length of time the timer will pause before the greeting is repeated.	6	000-100 (seconds)	0
QUEUING TYPE -- Determines the type of Queuing Tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
QUEUING TIMER -- Determines the Greeting/Queuing Timeout Timer.	8	010-300 (sec)	030
QUEUING TONE NO -- Determines the Queuing Tone number used when Queuing Type is set to Normal.	9	01-19	00
QUEUING PROMPT ANNC -- Determines the Queuing Prompt/ Announce Number when the Queuing Type is set to Prompt or Announce.	10	001-255	Not Asg
QUEUING REPEAT NO -- determines the Queuing Repeat number.	11	000-100	3
GREETING RPT DELAY -- Determines the Pause Timer before Queuing is repeated.	12	000-100 (seconds)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0

PGM 272	BTN	RANGE	DEFAULT
FORWARD TYPE -- Determines the Forward type to use. 0: Not used 1: Unconditional - call is routed to a forward destination unconditionally. 2: Queuing overflow - call is routed to a forward destination when a queue overflows. 3: Queuing timeout - call is routed to a forward destination when queuing time expires. 4: Queuing all - call is routed to a forward destination when a queue overflows or queuing time expires.	3	0: Not Used 1: Uncond 2: Q Overflow 3: Time out 4: All	0: Not Used
APPLY TIME TYPE -- Determines the time setting for applying the Forward type.	4	0: All 1: Day 2: Night 3: Timed	0: All
FWD DESTINATION -- Determines the forward destination (trunk access code should be included).	5	Max 16 digits	-
WRAP UP TMR -- Determines the Wrap-up Timer; a member is available when this timer expires after a member goes to idle.	6	000-600 (100ms)	5
MEMBER NO ANS TMR -- Determines the No Answer timer; if this timer expires, a call is routed to the next attendant	7	05-60 (seconds)	15
ATD CALL BY STA NO -- This entry defines attendant call by dialing attendant member. 0 : the call for attendant follows normal call. 1: the call for attendant follows attendant group call	8	-	Off
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer expires, a call is routed to the forward destination according to forward type.	9	0-180 (seconds)	0
PROVIDE ANNC-- This entry defines if system answer the call when a greeting or queuing announcement is provided.	10	0: With Answer 1: W/O Answer	0: With Answer

pā @Öcc) åæ öö: [~] Öc•ā } { ^ } ÖÜÖT ĀĬ İ Đö Á^Ā^Ācā Ā } Ā æ ^ ÖĒGH

ÜÖT ĀĬ İ	ÓVP	ÜÖÖÖ	ÖÖÖÖSV
PÖPVÁÖS/VÖÖÜÁYÜÖĀÖc) åæ öö: [~] Ę	F	€Ā^! { ā æ FĪÖā& æ GĀŪā * HĪÖ } *^öā ^	€Ā^! { ā æ
PÖPVÁÖS/VÖÖÜÁÖĀÖĀÖc) åæ öö: [~] Ę	G	T æĀĪ	Ę
PÖPVÁ ÖT ÖÖÜĀÖĀÖĀÖc) åæ öö: [~] Ę	H	Ę	Ę

pā @Öcc) åæ öö: [~] Öö!^Ā * Ę^~ Ā * Ā } ^ ÖÜÖT ĀĬ İ Đö Á^Ā^Ācā Ā } Ā æ ^ ÖĒGH

ÜÖT ĀĬ İ	ÓVP	ÜÖÖÖ	ÖÖÖÖSV
ÖÜÖÖVÖÖÖÁYÜÖĀÖĀÖc) åæ öö: [~] Öö!^Ā * Ā } ^ Ā đ Ā^Ā^ĀĘ	F	FĪÖ! { { ā Ā GĀŪ! { } c HĪÖ } & I KÖVĀ UP Í KÖYVĀ UP Ī KĀT ÖĀ UPF Ï KĀT ÖĀ UPG Ì KĀT ÖĀ UPH J KĀT ÖĀ UPI FĒÜŠVĀ UPF FFÜŠVĀ UPG FGÜŠVĀ UPH FHÜŠVĀ UPI FI KÜŠVĀ UPÍ	FĪÖ! { { ā Ā
ÖÜÖÖVÖÖÖÁYÜÖĀÖĀÖc) åæ öö: [~] Öö!^Ā * Ā } ^ Ā ~^ĀĘ	F	€Ā [{ { ā Ā FĪŪ! { } c GĪÖ } & HĪÖ VĀ UP I KÖYVĀ UP	€Ā [{ { ā Ā
ÖÜÖÖVÖÖÖÁÜÖĀÖĀÖc) åæ öö: [~] Öö!^Ā * Ā } Ā Ā Ę	G	€€€Ī €Ā^&Đ	€€€
ÖÜÖÖVÖÖÖÁÜÖĀÖĀÖc) åæ öö: [~] Öö!^Ā * Ā } ^ Ā { Ā!Ā @ } Ā!^Ā * Ā } ^ Ā Ā Ā Ā } { { ā Ā	H	€ĒĒJ	€

PGM 276	BTN	RANGE	DEFAULT
GREETING PROMPT/ANNC -- Determines the Greeting Prompt/ Announce Number when Greeting Type is set to Prompt or Announce.	4	001-255	Not Asg
GREETING REPEAT NO -- Determines the number of times the Greeting will repeat.	5	000-100	3
GREETING RPT DELAY -- Determines the length of time the timer will pause before the greeting is repeated.	6	000-100 (seconds)	0
QUEUING TYPE -- Determines the type of Queuing Tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
QUEUING TIMER -- Determines the Greeting/Queuing Timeout Timer.	8	010-300 (sec)	030
QUEUING TONE NO -- Determines the Queuing Tone number used when Queuing Type is set to Normal.	9	01-19	00
QUEUING PROMPT ANNC -- Determines the Queuing Prompt/ Announce Number when the Queuing Type is set to Prompt or Announce.	10	001-255	Not Asg
QUEUING REPEAT NO -- determines the Queuing Repeat number.	11	000-100	3
GREETING RPT DELAY -- Determines the Pause Timer before Queuing is repeated.	12	000-100 (seconds)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0

PGM 277	BTN	RANGE	DEFAULT
FORWARD TYPE -- Determines the Forward type to use. 0: Not used 1: Unconditional - call is routed to a forward destination unconditionally. 2: Queuing overflow - call is routed to a forward destination when a queue overflows. 3: Queuing timeout - call is routed to a forward destination when queuing time expires. 4: Queuing all - call is routed to a forward destination when a queue overflows or queuing time expires.	3	0: Not Used 1: Uncond 2: Q Overflow 3: Time out 4: All	0: Not Used
APPLY TIME TYPE -- Determines the time setting for applying the Forward type.	4	0: All 1: Day 2: Night 3: Timed	0: All
FWD DESTINATION -- Determines the forward destination (trunk access code should be included).	5	Max 16 digits	-
WRAP UP TMR -- Determines the Wrap-up Timer; a member is available when this timer expires after a member goes to idle.	6	000-600 (100ms)	5
MEMBER NO ANS TMR -- Determines the No Answer timer; if this timer expires, a call is routed to the next attendant	7	05-60 (seconds)	15
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer expires, a call is routed to the forward destination according to forward type.	8	0-180 (seconds)	0
PROVIDE ANNC-- This entry defines if system answer the call when a greeting or queuing announcement is provided.	9	0: With Answer 1: W/O Answer	0: With Answer

Numbering Plan

Feature Numbering Plan, Attendant Call (PGM 113) ... see details on [page A-17](#)

BTN	FEATURE (PGM 113)	REMARK
1	Attendant Call	0

HARDWARE

Digital Phone

Night Attendant Group Greeting/Queuing Tone (PGM 276) ... see details on [page A-123](#)

PGM 276	BTN	RANGE	DEFAULT
GREETING TYPE -- Determines the type of Greeting Tone to be used.	1	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	1: Normal
GREETING TYPE -- Determines the type of Greeting Tone used.	1	0: Normal 1: Prompt 2: Annc 3: INT MOH 4: EXT MOH	0: Normal
GREETING PLAY -- Determines the Greeting Play time.	2	000-180 (sec)	000
GREETING TONE NO --- Determines the Greeting Tone number when greeting type is set to Normal.	3	01-19	04
GREETING PROMPT/ANNC -- Determines the Greeting Prompt/ Announce Number when Greeting Type is set to Prompt or Announce.	4	001-255	Not Asg
GREETING REPEAT NO -- Determines the number of times the Greeting will repeat.	5	000-100	3
GREETING RPT DELAY -- Determines the length of time the timer will pause before the greeting is repeated.	6	000-100 (seconds)	0

PGM 276	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	14	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4: INT MOH
SECOND Q. TIMER -- This entry defines the timer for forward destination.	15	000-300 (seconds)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	16	01-19	Not Asg
SECOND PRT ANNCThis entry defines second queuing prompt / annc.Number in case queuing type is PROMPT/ANNC.	17	001-255	Not Asg
SECOND REPEAT NO -- This entry defines second queuing repeat number.	18	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	19	000-100 (seconds)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	20	0-1	0

Night Attendant Group Attribute (PGM 277) ... see details on [page A-126](#)

PGM 277	BTN	RANGE	DEFAULT
CALL IN GREETING -- Determines if call is routed to the Attendant when Greeting Tone is played.	1	0: After Greeting 1: In Greeting	1: In Greeting
MAX QUEUE COUNT -- Determines the Queue count.	2	00-99	05


- INT MOH
- EXT MOH
- VMIB MOH (1-4 for MBX IP-300, 1-3 for MBX IP-100)
- SLT MOH (1-5)

CONDITIONS

- If Greeting Play timer is expired, RBT is provided.
- During Announcement delay time, MOH or RBT can be provided by PGM.
- If queuing announcement forward timer is expired, second queuing announcement can be provided.
- If Second queuing announcement forward timer is not assigned, a call is routed to the forward destination after first queuing announcement forward timer is expired.

OPERATION

If set, Greeting/Queuing Tone Service operation is automatic.



PROGRAMMING

Tenant Data

PGM 271	BTN	RANGE	DEFAULT
QUEUING TYPE -- Determines the type of Queuing Tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
QUEUING TIMER -- Determines the Greeting/Queuing Timeout Timer.	8	010-300 (sec)	030
QUEUING TONE NO -- Determines the Queuing Tone number used when Queuing Type is set to Normal.	9	01-19	00
QUEUING PROMPT ANNC -- Determines the Queuing Prompt/ Announce Number when the Queuing Type is set to Prompt or Announce.	10	001-255	Not Asg
QUEUING REPEAT NO -- determines the Queuing Repeat number.	11	000-100	3
GREETING RPT DELAY -- Determines the Pause Timer before Queuing is repeated.	12	000-100 (seconds)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0

PGM 272	BTN	RANGE	DEFAULT
FORWARD TYPE -- Determines the Forward type to use. 0: Not used 1: Unconditional - call is routed to a forward destination unconditionally. 2: Queuing overflow - call is routed to a forward destination when a queue overflows. 3: Queuing timeout - call is routed to a forward destination when queuing time expires. 4: Queuing all - call is routed to a forward destination when a queue overflows or queuing time expires.	3	0: Not Used 1: Uncond 2: Q Overflow 3: Time out 4: All	0: Not Used
APPLY TIME TYPE -- Determines the time setting for applying the Forward type.	4	0: All 1: Day 2: Night 3: Timed	0: All
FWD DESTINATION -- Determines the forward destination (trunk access code should be included).	5	Max 16 digits	-
WRAP UP TMR -- Determines the Wrap-up Timer; a member is available when this timer expires after a member goes to idle.	6	000-600 (100ms)	5
MEMBER NO ANS TMR -- Determines the No Answer timer; if this timer expires, a call is routed to the next attendant	7	05-60 (seconds)	15
ATD CALL BY STA NO -- This entry defines attendant call by dialing attendant member. 0 : the call for attendant follows normal call. 1: the call for attendant follows attendant group call	8	-	Off
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer expires, a call is routed to the forward destination according to forward type.	9	0-180 (seconds)	0
PROVIDE ANNC-- This entry defines if system answer the call when a greeting or queuing announcement is provided.	10	0: With Answer 1: W/O Answer	0: With Answer

Table Data

Tone Frequency/Cadence (PGM 264) ... see details on [page A-114](#)

CCR Service for Attendant Queuing Announcement

The System can provide CCR Service during queuing announcement according to the CCR option.

Station Group Attribute (PGM 201-202) ... see details on [page A-65](#)

PGM 201	BTN	RANGE	DEFAULT
GREETING TYPE -- this entry defines the type of greeting tone.	1	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10: SLT MOH1 11: SLT MOH2 12: SLT MOH3 13: SLT MOH4 14: SLT MOH5	1
GREETING PLAY -- this entry defines greeting play time.	2	000-180 (secs)	000
GREETING TONE NO -- This entry defines greeting tone number in case greeting type is normal.	3	01-19	Not Assigned
GREETING PRT/ANNC -- This entry defines greeting prompt / annc. Number in case greeting type is PROMPT/ANNC.	4	001-255	Not Assigned
GREETING REPEAT NO -- This entry defines greeting repeat number.	5	000-100	3
GREETING RPT DELAY -- This entry defines the pause timer before greeting repeat.	6	000-100 (secs)	0

PGM 201	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	15	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
SECOND Q. TIMER -- This entry defines the timer for forward destination.	16	000-300 (secs)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	17	01-19	Not Assigned
SECOND PRT/ANNC -- This entry defines second queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	18	001-255	Not Assigned
SECOND REPEAT NO -- This entry defines second queuing repeat number.	19	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	20	000-100 (secs)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	21	0-1	0
MOH FOR ANNC, -- This entry defines MOH option during second queuing annc. Pause time.	22	01-12	none

PGM 202	BTN	RANGE	DEFAULT
CALL IN GREETING -- This entry defines if a call is routed to a destination during greeting tone is played.	1	0: After Greeting 1. In Greeting	After Greeting
MAX QUEUE COUNT -- This entry defines queue count.	2	00-99	00

CCR Table (PGM260) ... see details on [page A-112](#)

PGM 260	BTN	RANGE	DEFAULT
CCR TABLE -- The destination of CCR input digit; the destination can be a Station number, Station group number or Feature code. NOTE: For Feature codes, refer to the Numbering Plan for the applicable codes.	1-12	Max 8 digits	-

Forward Destination, Overflow Service

This can be assigned as Station/Hunt Group/Telephone Number, covering Attendant Call according to the Forward type of the Attendant Group. There are 4 kinds of Forward type in an Attendant Group:

- Unconditional
- Queuing Overflow
- Queuing Timeout
- Queuing Overflow or Queuing Timeout

The Overflow Destination can be programmed as Station/Station Group/External number/NET Destination.

OPERATION

To use the Unconditional Forward Overflow Destination:

1. Dial the {Attendant Call code}.
2. The Call is Routed to the Forward Destination.

To use the Queuing Overflow Forward Destination:

1. Dial the {Attendant call code}.
2. The Call is Queued when all Member Stations are in Busy mode.

NOTE: The Call will be Routed to the Forward Destination when max. queue has been Overflowed.

To use Queuing Timeout Forward Destination:

1. Dial the {Attendant Call code}.
2. The call is Queued when all Member Stations are in Busy mode.

NOTE: Calls will be Routed to the Forward Destination when Queuing Time has expired.

To use Queuing Overflow or Timeout as Forward Destination:

FÈ ÖæÁ@ÄÖç) åæ öÖæ|Æ| å^æÄ

GÈ V@Öæ|Æ| Á^ ^ ^åÄ @} Åç|Ä ^{ à^!Áçææ } • Åæ^Å ÄÖ^ • Ä [à^ÈÙVÒKÁ@Öæ|Ä ç|Ä
 à^Á [^ ç^ÁÄ Ä@Ä |, æåÄ^•ç ææ } Å @} Á^ ^ ç * ÁÄ ^Äç| ä^•Ä|Ä æÈÙ^ ^ ^Å Ä
 [ç^!-|, ^åÈÄ

PROGRAMMING

Tenant Data

Öç) åæ öÖ| [^] Áçæ æ ç^ÁÜÖT ÄÛ ÈÛ ÇÄ Å^Å^Å^æ^ Ä } Ä æ ^ ÖÈÈÏ

ÜÖT ÄÛ F	ÓVP	ÜÖÈÖÖ	ÖÖÖæVŠV
ÖÜÖÖVÖÖÖÄYÜÖÈÈÖ^ç { ç^•Å@Ä^ ^Ä -Ö!^ç * Ä } ^Ä ç Å^Å^•åÈ	F	FkP[!{ æÄ GÁU![{]c HkQ } & I kP VÄT UP Í kÖYVÄT UP Î kÄT ÖÄT UPF Ï kÄT ÖÄT UPG Ì kÄT ÖÄT UPH J kÄT ÖÄT UPI FkÜŠVÄT UPF FkÜŠVÄT UPG FkÜŠVÄT UPH FkÜŠVÄT UPI FÍ kÜŠVÄT UPÍ	FkP[!{ æ
ÖÜÖÖVÖÖÖÄÜSÖYÈÖ^ç { ç^•Å@Ö!^ç * Ä æ Ä Å È	G	ÈÈÈÏ ÈÄ^&D	ÈÈÈ
ÖÜÖÖVÖÖÖÖÄUÖÖÄUÈÈÖ^ç { ç^•Å@Ö!^ç * Ä } ^Ä } ^{ à^!Ä @} Ä!^ç * Å] ^Å Å^ç Ä Ä !{ æÈ	H	ÈÈÈJ	È
ÖÜÖÖVÖÖÖÖÄÜÜT ÜVÈÈÖÖÄÈÖ^ç { ç^•Å@Ö!^ç * Ä Ü![{] çæ } [^] & Ä ^ { à^!Ä @} Ö!^ç * Ä] ^Å Å^ç Ä Ü![{] ç!Ä } [^] & È	I	ÈÈÈÏ Í	P [çæ *
ÖÜÖÖVÖÖÖÖÄÜÖÜÖÖÄUÈÈÖ^ç { ç^•Å@Ä^ { à^!Ä -Ä Å^•Ä @Ö!^ç * Ä ç Ä } ^æÈ	Í	ÈÈÈÈÈÈ	H
ÖÜÖÖVÖÖÖÖÄÜÜVÖÖÖSÖYÈÖ^ç { ç^•Å@Ä^ } * çÄ -Ä Å^Å@Ä ç^!Ä ç Ä æ^•Å^!^Å@Ä!^ç * ÅÄ } ^æ^åÈ	Ï	ÈÈÈÈÈÈÄ^& } å^D	È

PGM 271	BTN	RANGE	DEFAULT
QUEUING TYPE -- Determines the type of Queuing Tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6. VMIB MOH1 7. VMIB MOH2 8. VMIB MOH3 9. VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
QUEUING TIMER -- Determines the Greeting/Queuing Timeout Timer.	8	010-300 (sec)	030
QUEUING TONE NO -- Determines the Queuing Tone number used when Queuing Type is set to Normal.	9	01-19	00
QUEUING PROMPT ANNC -- Determines the Queuing Prompt/ Announce Number when the Queuing Type is set to Prompt or Announce.	10	001-255	Not Asg
QUEUING REPEAT NO -- determines the Queuing Repeat number.	11	000-100	3
GREETING RPT DELAY -- Determines the Pause Timer before Queuing is repeated.	12	000-100 (seconds)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0

PGM 272	BTN	RANGE	DEFAULT
FORWARD TYPE -- Determines the Forward type to use. 0: Not used 1: Unconditional - call is routed to a forward destination unconditionally. 2: Queuing overflow - call is routed to a forward destination when a queue overflows. 3: Queuing timeout - call is routed to a forward destination when queuing time expires. 4: Queuing all - call is routed to a forward destination when a queue overflows or queuing time expires.	3	0: Not Used 1: Uncond 2: Q Overflow 3: Time out 4: All	0: Not Used
APPLY TIME TYPE -- Determines the time setting for applying the Forward type.	4	0: All 1: Day 2: Night 3: Timed	0: All
FWD DESTINATION -- Determines the forward destination (trunk access code should be included).	5	Max 16 digits	-
WRAP UP TMR -- Determines the Wrap-up Timer; a member is available when this timer expires after a member goes to idle.	6	000-600 (100ms)	5
MEMBER NO ANS TMR -- Determines the No Answer timer; if this timer expires, a call is routed to the next attendant	7	05-60 (seconds)	15
ATD CALL BY STA NO -- This entry defines attendant call by dialing attendant member. 0 : the call for attendant follows normal call. 1: the call for attendant follows attendant group call	8	-	Off
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer expires, a call is routed to the forward destination according to forward type.	9	0-180 (seconds)	0
PROVIDE ANNC-- This entry defines if system answer the call when a greeting or queuing announcement is provided.	10	0: With Answer 1: W/O Answer	0: With Answer

Attendant Recall

Unanswered or Abandoned CO/IP Calls that remain unanswered for the Hold or Transfer Hold Timer (as applicable), will Recall at the Station that placed the Call on Hold. If the Call remains unanswered for the assigned Recall Time, the first available Attendant will also receive the Recall. The Attendant and Station will simultaneously receive the recall signal for the Attendant Recall Timer period after which the System will disconnect the Call and return the CO/IP Line to Idle.

OPERATION

System

Öcc^} äæ} öÜ^&æ|Ä] ^!ææ| } Ä Äæ ç { ææÄÄ

PROGRAMMING

CO Line Data

Q&| { ä * ÄOUÄcc^!} æÄÜÖT Äİ JDÄ Ä ^^Ä^ææ* Ä } Ä æ ^ Öİİ H

ÜÖT Äİ J	ÓVP	ÜÖPÖÖ	ÖÖÖÖVŠV
Q& { ä * ÄOUÄcc^!} ææÄ^ ÖÖYÄÄÄ	F	ØFÄÖ • ^ ØGÄ [ÄÖ • ^! ØHÄ çæä	Öä & } } ^&c FÄ ^&
PÖPVÄÄÄ	G	ØHÄ çæä ØI ÄV!æ • ^!Ä [ÄÖ • ^! ØI ÄU^&æ Ä [ÄÖ • ^!	Öä & } } ^&c FÄ ^&
VQ ÖÖÄÄÄ	H	ØI ÄÖPÖ ØI ÄU^ ÖUÄU^ çæÄ ØI ÄÖ! FÄÖä & } } ^&c GÄÖcc^} äæ} c HÄOUÄÜä * I ÄÖÄÜä * ÄVæ Ä I ÄÄ } ^ I ÄÄ çP^ } öI: [^]	Öä & } } ^&c FÄ ^&

U^ ç [ä * ÄOUÄcc^!} æÄÜÖT Äİ HDÄ Ä ^^Ä^ææ* Ä } Ä æ ^ Öİİ

ÜÖT Äİ H	ÓVP	ÜÖPÖÖ	ÖÖÖÖVŠV
ÖÖYÄÖVÄÖÖVÄÄÄÄ) [ç ææ^&æ ÄÄÄ^&c äÄÄ Ä Ä! Ä } ^É	È	ØFÄU^&æ Ä [ÄÖ • ^! ØGÄV!æ • ^!Ä [ÄÖ • ^! ØHÄ [ÄÖ • ^!	È
PÜÄÖÜY ÖÜÄÖÜÜPÖÖVÄÄV@ÄOUÄcc^ Ä Ä ää & } } ^&c äÄÖç^!^ Ä^ ç ææ } Ä Ä^ÄÄ ÄÖä & } } ^&cÄ ä^ Ä^æ É	F	È	È
PÜÄÖÜY ÖÜÄÖVÖPÖÖVÄÄV@ÄOUÄcc^ Ä [^ çÄÄ Ä Ä Öcc^} äæ} É	G	È	È
PÜÄÖÜY ÖÜÄÖÜÜPÖÖVÄÄV@ÄOUÄcc^ Ä Ä ! ^ çÄÄæ& ää * Ä ÄÜä * ÄÖ • ä } ÄVæ ÄÄÄÄÜÖT Äİ D	H	È	È

PGM 173	BTN	RANGE	DEFAULT
NO ANSWER ALT RING TBL -- If destination is set to Alt Ring Table and the Table index is assigned, the CO call is routed according to Alt Ring Table. (See PGM 181)	4	01-80	-
NO ANSWER TONE -- If destination is set to Tone, the Error / Busy tone is heard.	5	-	-
NO ANSWER PILOT HUNT GROUP -- The CO call is routed to Pilot Hunt Group of the original destination.	6	-	-
NO ANSWER RING -- The call is routed to the same destination again.	7	-	-
NO ANSWERThe CO call is routed to the transferred station again. Only possible for 'Transfer No Answer' case.	8	-	-

Tenant Data

Attendant Group Assign (PGM 270) ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

RELATED FEATURES

Hold ... see [page 3-101](#)

Call Transfer ... see [page 3-30](#)

Example of User Program Code Chart

User PGM Code	Item Description	Remark
01 SMDR		
011	PRINT STATION SMDR	Station Range
012	DELETE STATION SMDR	Station Range
013	PRINT FAILED CALL SMDR	
014	DELETE FAILED CALL SMDR	
015	DELETE ALL SMDR	
016	ABORT PRINTING	
02 TRAFFIC		
021	PRINT TRAFFIC (TENANT)	
022	PRINT TRAFFIC (CALL TYPE)	
023	PRINT TRAFFIC (CO GRP)	
03 COS / PASSWORD		
031	TEMPORARY COS MODE	Station Range
032	RETRIEVE COS	Station Range
033	REGISTER PASSWORD	Station Range
034	CALL LOG PROTECT	Station Range
04 DATE / TIME		
041	SET SYSTEM DATE	
042	SET SYSTEM TIME	
043	LCD DATE MODE	Station Range
044	LCD TIME MODE	Station Range
045	SET WAKE UP	Station Range
046	RESET WAKE UP	Station Range
05 MULTI MESSAGE		
051	PRESELECTED MESSAGE	Station Range, MSG No
052	SET USER MESSAGE	Station Range

1. Press the [PGM] button, the Attendant Station Program Menu is displayed.
2. Dial 0 to access the Attendant Station Program codes (Display Menu).
3. Enter the desired code. OR
4. Use the [VOL UP]/[VOL DOWN] or [NAVI UP]/[NAVI DOWN] button to display the desired menu item and enter the desired code.
5. Enter any additional inputs, if required.

PROGRAMMING

Tenant Data

Attendant Group Assign (PGM 270) ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

RELATED FEATURES

Station Message Detail Recording (SMDR) ... see [page 3-187](#)

Traffic Analysis ... see [page 3-250](#)

Temporary Station COS/Lock ... see [page 3-68](#)

Authorization Codes (Password) ... see [page 3-5](#)

System Clock Set ... see [page 7-42](#)

VMIB Integrated Auto Attd/Voice Mail ... see [page 3-258](#)

Auto Service Mode Control ... see [page 3-10](#)

HARDWARE

Digital Phone

Day/Night/Timed Ring Mode

The System Clock automatically controls Ring Mode; Ring assignments are applied based on the Time of Day and Day of Week. Three modes of ring (Ring Assignments) are provided: Day, Night and Timed.

The Attendant controls the System Ring Service mode changing from Auto Service Mode to Day, Night or Timed Service mode. Based on the Service Mode selected, different Ring Assignments, COS and Answering Privileges are invoked for System Users.

CONDITIONS

- Only Attendants can change Day/Timed/Night Ring Mode for the System manually and program the Auto Ring Mode Selection Table.
- A Station can receive Incoming Calls for CO Lines based on the Database assignments and the System mode (Day/Night/Timed) when the Call arrives.
- When the Auto Ring Selection Table is programmed, Ringing, COS and CO/IP Access mode are changed automatically based on Times assigned in the Table.
- The Attendant always has manual control of System mode by Enabling/Disabling the Auto Service Mode Control.

OPERATION

Attendant

To modify Day/Timed/Night Ring Mode manually (Attendant Only):

1. Press the [PGM] button.
 2. Dial 0 8 1 {Day/Night Program code}.
 3. Select Tenant Number (0=All, or 1-9).
 4. Select Ring mode (0=AUTO, 1=DAY, 2=NIGHT, 3=TIMED).
- OR
1. Dial the {Day/Night Program Feature Code}.
 2. Select Tenant Number (0=All, or 1-9).
 3. Select Ring mode (0=AUTO, 1=DAY, 2=NIGHT, 3=TIMED).

To set Day/Timed/Night Ring Mode automatically (Auto Service Mode Control):

1. Press the [PGM] button.
2. Dial 0 8 1 {Day/Night Program code}.
3. Select Tenant Number (0=All, or 1-9).
4. Select Auto Ring mode (0=AUTO).

OR

FÈ Öæ Ðã @Vã ^ãÁã * Á [â

GÈ Ù^|&Á^} æ ó { à^|ÁEMOËÄ | ÁÈÈÈ

HÈ Ù^|&ÁÈ ç Áã * Á [â^|ÁEMOEWUÈ

PROGRAMMING

Numbering Plan

Öæ | ^ Á { à^|ã * Á | æ ÁÜÖT ÁFHÖ Á^Á^Á^æ Á } Á æ ^ ÖÈÈ

Table Data

Ù • ç { ÁVã ^ÁVã | ÁÜÖT ÁG HÈ | DÖ Á^Á^Á^æ Á } Á æ ^ ÖÈÈ

ÚÖT ÁG H	ÓVÞ	ÜÖÞ ÖÒ	ÖÒÖVŠV
VQ ÖZUPÖÓUT T ÖPVEÄ^ã ^• Á@Á [{ { ^ } ç Á@ÁVã ^Á Væ ^È	F	HG&@æ&^!•	} [] ^
ÜYÜVÖT ÁQ ÖZUPÖÖÄ^ã ^• Á@ÁVã ^Á [] ^ Á Á@ÁVã ^ÁVã ^Á	G	ÈÈ H	ÈÁ • ÁVã ^
ÖÖYŠÖP VÁÜÖXÖ ÖÜÈÄ^ã ^• Öæ æ @ÁVã * ÁVã ^ Á ÁVã ^Á Væ ^È	H	U} BU~	U~
ÜÖÖÁ UÖÖÄÄ^ã ^• Á@Áã * Á [â^ Á ÁVã ^ÁVã ^È	I	ÈÖæ FÁã @ GÁVã ^á	ÈÖæ
EWUÁÜÖÖÁ UÖÖÄÄ^ã ^• Á@ÁÈ ç Áã * Á [â^ Á ÁVã ^Á Væ ^È	Í	U} BU-Á	U~

ÚÖT ÁG I	ÓVÞ	ÜÖÞ ÖÒ	ÖÒÖVŠV
T [] áæ ÖÖYŠÖP VÁÜÖXÖ ÖÖÁã * Á [â^ Á ç ÁVã ^• ÁVã áVQ ÖÖÁ [â^ Á ^} áVã ^• È	F	ÈÈÈÈGHI J	Öæ ÁVã ÈÈ P æ ÁVã ÈÈ VÖÜÁ ÈÈ VÖÖÁ ÈÈ
V ^• áæ ÖÖYŠÖP VÁÜÖXÖ ÖÖÁã * Á [â^ Á ç ÁVã ^• ÁVã áVQ ÖÖÁ { [â^ Á } áVã ^• È	G	ÈÈÈÈGHI J	Öæ ÁVã ÈÈ P æ ÁVã ÈÈ VÖÜÁ ÈÈ VÖÖÁ ÈÈ

PGM 254	BTN	RANGE	DEFAULT
Wednesday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	3	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Thursday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	4	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Friday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	5	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Saturday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	6	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Sunday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	7	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __

Tenant Data

Attendant Group Assign (PGM 270) ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

V} æ áVā ^Áaa| ^Q ā^cÁJÖT ÁG €Đ Á^^Á^æp Á} Á æ ^ ÖĜ

ÚÖT ÁG €	ÓVP	ÜÖPÖÖ	ÖÖÖÖVŠV
VÖPÖP VÁPÖT ÖĜÖ^c { ā^•Á@Áæ ^Á^Á^} æ dĚ	F	T æÁG	Ě
VÖPÖP VÁPÖT ÖÖÜŠÖYĜÖ^c { ā^•Á@Á^} æ dĚ æ ^Á^ Áā æ Ě	G	ĚÁ~ FÁJ}	ĚÁ~
VQ ÖÁÖŠÖÁÖ ÖÖYĜÖ^c { ā^•ÁVā ^Áaa ^Q ā^cÁ^ Á^} æ dĚ! [] Ě	H	FĚ	F
ÖPÜÁÖÜYÁÖUWPVĜÖ^c { ā^•Á@ÖPÜÁ^d^ ÁĚ } dĚ	I	ĚĚ	H
Y ÖSÖMÜÁÖÜYÁÖUWPVĜÖ^c { ā^•Á@ÁY æ^ÁM Á^d^ ÁĚ } dĚ	í	ĚĚ	H
Y ÖSÖMÜÁÖÜYÁVQ ÖĜÖ^c { ā^•Á@ÁY æ^ÁM Á^d^ ÁĚ ^ÁĚ ā Ě	î	ĚĚÖĚ	ĚF
ÖWPÁÖÜYÁÖUWPVĜÖ^c { ā^•Á@ÖWPÁ^d^ ÁĚ } dĚ Ĝ^•Á^ç^âD	ï	ĚĚ	H
T VŠÖÖÖŠÖÁÖÜY ÖĜÖÁÖXÖÁÖUWPVĜÖ^c { ā^•Á@Á^~ dĚæĚÁ f!, æāÁĚ } dĚ	ì	ĚĚĚ	Ěí

RELATED FEATURES

- Ů•c|{ ÁÖ| & Á^æ Á^^Á æ ^ İ Ğ G
- Š~ áÁÖ||ÁÖ| } d| |ÁŠÖÖĐ Á^^Á æ ^ ĤĤĤ
- Öæā * Á^•dæā } •ö Á^^Á æ ^ ĤĤ H
- ÖĚ Ě Á^çæÁ^ [áÁÖ|] d| |Áö Á^^Á æ ^ ĤĤ€

DSS/DLS Consoles

V@ÁŮ•c|{ ÁĚ| , Áæ Á} |ā æāÁ~ { à^Á^ -ÖÜÛËŠÙÁÔ[]•[|^•Á^ Á^Á^•æp á^Á^ Á@ÁŮ•c|{ ĚÁ
W| Á^ Á^ÖÜÛËŠÙÁÔ[]•[|^•Á^ æ Á^Á^• [&æ^áÁ^ á@ÖÁ^æĚ } ÁĚ } ^&c^áÁ^ Á@ÁŮ•c|{ ĚÁÖæ@
à^ Ě } Á} Á@ÁÖ[]•[|^Áæ Á^Á^•ā } ^áÁ^ ÖÜÁŠā ĚÖc|& { ĚÁ|Á^æ |^Á^ĚÁ
V@ÁŮ^Á|Á|ÁĚ{ ā ā dæĚ |Á æ Á@} Á@æ *^Á āāā æÁ^cÁ^ Ě } •Áæ Á^• āāĚÁ |æĚ } Á^
c@ÖÜÛËŠÙÁÔ[]•[|^Á^cÁ^ Ě } •Á@Á@Á æ Á^ Á^cÁ^ Ě } •Á} Á@Öā āāÁ@ } ^Ě

CONDITIONS

- ĚÁ Öæ@ÖÜÛËŠÙÁÔ[]•[|^Á^ Á^•ā } ^áÁ^ Á^ |æ^Á^ Á^ } ^&cĚ } Á^ á@ÖÁ^ ^&āÁ^æĚ } Ě
- ĚÁ V@!^Á^ Á| ÁĚ āÁ^ Á@Á^ { à^Á^ -ÖÜÛËŠÙÁÔ[]•[|^•Á^ Á^Á^•æp á^Á^ Á^ } |á@Á^æ āÁ
Ů•c|{ Áæā æāā •ĚÁ

PROGRAMMING*Station Data*

Station Type (PGM 120) ... see details on [page A-23](#)

Tenant Data

Attendant Group Assign (PGM 270) ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

RELATED FEATURES

Station Flexible Buttons ... see [page 6-21](#)

DSS/BLF... see [page 4-1](#)

EZ-Attendant

The ez-Attendant is a Windows-based PC application that provides a visualization of the Attendant functionality to simplify Attendant control of Features and Functions including Call Display, and User and System status. ez-Attendant operates in conjunction with the Attendant Digital Phone to simplify overall operation (refer to ez-Attendant Installation and User Guide).

OPERATION*Attendant*

Operation of the ez-Attendant is described in detail in the ez-Attendant Installation and User Guide.

CONDITIONS

- ez-Attendant requires installation of a System Lock-key.

PROGRAMMING

Tenant Data

Öc^} åæ öÖ|{~} ÁÖ•ã} ÁÜÖT ÁĜ €DÖ Á^^Á^cæ} Á} Áæ^ ÖĖFİ

ÜÖT ÁĜ €	ÓVP	ÜÖP ÖÖ	ÖÖÖÖVŠV
ÖVÖÖÜÁYÜÖĖÖ^ã^•Á@ÁĜ] ^Á-Öc^} åæ öÖ {~} È	F	€Á^ { åæ FĶÖ&~ æ GÁÜã* HŠ } *^•öÁ ^	€
ÖVÖÖÜÁÖĖ ÖĖÖÖ^ã^•Á@Áæ ^Á-Ác^} åæ öÖ {~} È	G	TæÁĬ	È
ÖÜÁÖÖÁWT ÖÖÜĖÖÖ^ã^•Ác^} åæ öÖ {~} { à^!ÁĬ!ÁÖÜÁã^È	H	TæÁ	È
T ÖT ÖÖÜÖÜÖĖÖÖ•ã}•Ácæ}•ÁöÁ ^{ à^!•Á-Áö Öc^} åæ öÖ {~} È	I	È	Öö•Ücæ}

System Clock Set

V@Öc^} åæ öÖ|{~} Á^ö@ÁÜ•c{ Áã ^Ėæ ĖÁ

OPERATION

Attendant

To set the System Date:

FÈ Ú!^••Á@ÁÜÖT áã~ cĬ} ÈÁ
 GÈ ÖãÁĬ FÁÖc^} åæ öÖcæ} ÁÜ|{~!æ ÁĬ á^ĖÁ
 HÈ Ö} c!Á@ÁÖæ ÁT T ĖÖĖYĖÁ
 I È Ú!^••Á@ÁÜÖÖÖáã~ cĬ} ÈÁĬ} -ã{ æĬ} ÁĬ} ^Á@æáĖÁ

To set the System Time:

FÈ Ú!^••Á@ÁÜÖT áã~ cĬ} È
 GÈ ÖãÁĬ GÁÖc^} åæ öÖcæ} ÁÜ|{~!æ ÁĬ á^ĖÁ
 HÈ Ö} c!Á@Áã ^ÁPPE T ĖÁ
 I È Ú!^••Á@ÁÜÖÖÖáã~ cĬ} ÈÁĬ} -ã{ æĬ} ÁĬ} ^Á@æáĖÁ

PROGRAMMING

Tenant Data

Attendant Group Assign (PGM 270) System Data ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

System Date & Time (PGM233) ... see details on [page A-94](#)

PGM 233	BTN	RANGE	DEFAULT
SET SYSTEM TIME/DATE -- Sets the system time.	1	HH:MM	-
SET SYSTEM TIME/DATE -- Sets the system date.	2	MMDDYY	-
DST ENABLE MODE -- Enables DST feature for System Time.	3	0:Off 1:On	0:Off
- DST START TIME -- The DST start time.	Web Only	See DST Table	2nd Sunday of March at 2:00 AM
- DST END TIME -- The DST end time.		See DST Table	1st Sunday in Nov., at 2:00 AM

RELATED FEATURES

Least Cost Routing (LCR) ... see [page 3-112](#)

Station Message Detail Recording (SMDR) ... see [page 3-187](#)

Auto Service Mode Control ... see [page 3-10](#)

Day/Night/Timed Ring Mode ... see [page 7-37](#)

USB Upgrade

The Attendant can upgrade the System via USB memory. USB upgrade could be executed using the Attendant Keyset. Before upgrading, a User must save the System ROM file (GS55(56)MXXXXX.rom) in USB memory.

OPERATION

Attendant

To upgrade the System using the Attendant Keyset:

FÈ Üæ^ÁÛ•c{ ÄÜT ÄÄÄÜÍ Í Ç Í D YYYÉ{ { DÄ ÄWÜÓÄ ^{ [!^Ä
GÈ Q•^!ó@ÄWÜÓÄ ^{ [!^Ä Ä@ÄWÜÓÄ [!ó Ä@ÄT ÜÓÄ [æäÄ
HÈ Ü!^••Ä@ÄÜÖT ä~ ç } Ä
I È ÖäÄÄFÄCÄ) ää cÄæä } ÄÜ [!æ Ä Ä^Ä

MOUNT USB MEMORY
PLEASE WAIT...

İ È Þ { ä^!Ä ÄÛ•c{ ÄÜT ÄÄÄÄWÜÓÄ ^{ [!^Ä Ää } ä^äÈ

ROM FILE NUM : TOTAL 2
PRESS 0-1 TO VIEW FILE

İ È ÖäÄÄÄ { ä^!Ä ÄÛ•c{ ÄÜT ÄÄÄÄä } ä Ä@Ää } [!] : äÄ ÄÛ•c{ ÄÜT ÄÄÄ
} ä ^È

0 : GS56MA0Aa.rom
PRESS [HOLD] TO UPGRADE

İ È Ü!^••Ä@ÄPUSÖä~ ç } Ä ÄM *!æ^Ä@ÄÛ•c{ È

0 : GS56MA0Aa.rom
PRESS [HOLD] TO UPGRADE

İ È Ç [! , ä * ÄM *!æ^ÄÛ•c{ ÄÄä } ä ä^ää ä@Ä^•^Ä äÄÄc ! } Ä Ä@ÄÄÄÄÈ

SOFTWARE UPGRADE
USB UPGRADE SUCCESS

JÈ Ü•cÄÄ@ÄÛ•c{ ÄÄ

CONDITIONS

ÄÄ WÜÓAM *!æ^ÄÄÄ) ää cÄ^•^ÄÄÄ Ä~] [!Ä] Ä ÄÄÜT Ä ä^ÄÄÄÄÄ

PROGRAMMING

Tenant Data

Attendant Group Assign (PGM 270) ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

USB DB Up/Download From/To USB

The Attendant can upload/download the System database via USB memory. USB upload/download can be executed from the Attendant Station.

OPERATION

Attendant

To download the System Database using the Attendant Keypad:

1. Insert the USB memory to the USB port in MPB board.
2. Press the [PGM] button.
3. Dial 092 {Attendant Station Program code}; the display will be as shown.

DB DOWNLOAD TO USB
PRESS OK/SAVE KEY

4. Press the [HOLD] / [OK] button to download the database.

DB DOWNLOAD TO USB
PLEASE WAIT...

5. Following download, the result is displayed and Keypad will return to Idle.

DB DOWNLOAD TO USB
DOWNLOAD SUCCESS

Attendant Group Assign (PGM 270) ... see details on [page A-118](#)

PGM 270	BTN	RANGE	DEFAULT
ATTD GR TYPE -- Defines the type of Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0
ATTD GR NAME -- Defines the name of attendant group.	2	Max 16	-
CO ATD NUMBER -- Defines attendant call number for CO line.	3	Max 4	-
MEMBER ASG -- Assigns stations as members of an Attendant group.	4	-	First Station

Chapter 8

Single Line Telephone

Broker Call

Broker Call allows an SLT User to engage in 2 Calls, alternating between the two Parties, so that the conversation with each Party is private.

There are two types of Broker Call:

- Transfer Broker Call – 2nd Call is originated by the SLT user.
- Call-Wait (Camp-On) Broker Call – 2nd Call is delivered to the SLT through a Call-Wait.

CONDITIONS

- After a Hook-Switch (Flash), if the Call results in an Error, Busy, No Answer or an Abnormal State, the SLT User may shortly press Hook-Switch to retrieve the Held Call.
- During a Transfer Broker Call, if the SLT User goes On-Hook, the Broker Call Parties are connected (Call Transfer).
- During a Transfer Broker Call, if the active caller disconnects from the SLT User, the Held Party, if another Station, is connected to the SLT.
- During a Call-Wait Broker Call, if the SLT User goes On-Hook, the Active Call is disconnected and the Held Call will Recall to the SLT.
- During a Call-Wait Broker Call, if the Active Party disconnects from the SLT, the SLT User receives an Error tone; after the SLT User goes On-Hook a Recall will be received.
- If after a Hook-Switch (Flash), the User takes no action for duration of the Dial Tone Timer, the SLT will receive an Error tone; once the SLT goes On-Hook, the SLT will receive a Recall automatically.

OPERATION

SLT

To activate a Transfer Broker Call:

FÈ Y @^Á) Áæ Á&ç^ ÓæÈÈ |^•• Á@Á[[\È, æ&@Á Á^&á^Á@ÁQ^!& { ÁÓáÁ } ^Á@Á
æ&ç^ ÁÓáÁ Á |æ&áÁ } ÁQ&^ • á^Á[[áÈ

GÈ Ú|æ^ Á^Á^& } áÁÓáÈÈ

HÈ V[Áç^ } æ^Á^ç ^) Á&ç^ ÈÈ @!q^ Á|^•• Á@Á[[\È, æ&@Á

To activate a Call Wait Broker Call:

FÈ Y @^Á) Áæ Á&ç^ ÓæÈÈ |ááÁ Q& { á * ÁÓáÈÈ æ^Á^&á^ÁÈ|^•• Á@Á[[\È, æ&@Á
ç Áæ •, ^!Á@Á & { á * ÁÓáÈÈ

GÈ V[Áç^ } æ^Á^ç ^) ÁÓáÈÈ @!q^ Á|^•• Á@Á[[\È, æ&@Á

PROGRAMMING

Station Data

P[[\Á]æ @ [ç] } Á @ } Áæ • ^!Á]ÖT ÁG ÁSÖYÁ DÈ Á^Á^æ^ Á } Á æ ^ ÖÈÈ

ÚÖT ÁG	ÓVP	ÜÇP ÖÒ	ÖÒZÖVŠV
PUUSÁÖSÇEUPÁ PÖPÁVÜÇEÜZÖUÁÈÖ^ç! { á^Á@Á [] ^!ææ } Á @ } Á^Á ^•• Á@[[\Èæ @^ ç] } Á @^Á çæ • ^!á * Á&çÈ ÈÖæ & ^Áæ • ^!ÁÁ! [] Á^ !!^) ç&ç^ áÁ& ç^!Á] ^çá ~ • ç&ç^ ÈÈ [\ ^! ÁQ á& !!^) ç&ç^ áÁ& ç^!Á] ^çá ~ • Á@ á&ç^ ÖÖ [] ^!^) &^Á^ çæ á @ÈÈ æ Á & } ^!^) &^Á&ç^ ÈÈ [\ ^! ÈÈ [] - ÁU] ^!æ áÁ [\ ^! Á æ áÁ [] ^!^) &^Á @ } Áæ • ^! ÁQ [\ Áæ @ Á æ ç Á^Á&	Í	ÈÁÖæ & ^Á!æ • ^! FÁÖ [\ ^! GÁÖ [] ^!^) & HÁÖ [\ ^! ÈÈ [] ~	Öæ & ^Á!æ • ^!

RELATED FEATURE

Öæ|Á!æ • ^!Á Á^Á æ ^ ÈÈÈ

Hook-Flash Mode

- V[Á! [@áá^ Á^!çæ Áæ^ÁR[[\È]æ @ÁSVÁR[[\È]æ @çæ Á^Ááæ æ^ÁáÈ! [] ^áÈ! Á } [] ^áÈÈ
- " Öá æ|^ÁT [á^Á ÁY @ } ÁR[[\È]æ @Á^ç&ç^áÈ@Á |^çá ~ • Áá^Á ç|Á^Á& } ç ~ ^áÈæ áÁ
@Áá^Á Á [ÖÖ []] ^áÈ
- " Çæ @Ö [] Á ÁY @ } ÁR[[\È]æ @Çæ @Á^ç&ç^áÈ |^çá ~ • Á } ç^! • ææ } Á ç|Á^Á
áá & } } ^ç&áÈÈ
- " Çæ @Ö [] ^!Á ÁR[[\È]æ @Á Á } [] ^áÈÈ

- Hold Release – During the conversation when a SLT user hook-flashes, the previous line is placed on hold; if the SLT user hangs-up without being transferred, the previous line will be disconnected automatically.

PROGRAMMING

Station Data

Hook Flash Mode (PGM 132 FLEX 7) ... see [page A-33](#)

PGM 124	BTN	RANGE	DEFAULT
HOOK FLASH MODE -- determine the operation when SLT user press hook-flash button during conversation. 0. FLASH NORMAL: Hook Flash can be detected. In addition, it will be operated normal case flow. 1. FLASH IGNORE: Hook Flash cannot be detected. All of hook flash will be ignored at any time. 2. FLASH DROP: When Hook Flash is detected, the line will be disconnected. 3. HOLD RELEASE: Drop the holding line if system detects Hook Flash and then On-Hook during dialing state.	7	0: Flash Normal 1: Flash Ignore 2: Flash Drop 3: Hold Release	Flash Normal

HARDWARE

SLT

Howler Tone

When an SLT station goes Off-Hook and does not initiate dialing for the duration of the Dial Tone Timer, delays dialing between digits in excess of the Inter-Digit Timer, or stays Off-Hook at the completion of activating a Feature or Program, the Station will present the Howler tone as an Error indication and the Call attempt will be abandoned. In order to complete the Call, the User must return to On-Hook and restart the Call.

CONDITIONS

- Howler Tone is sent after Error tone.
- Lock-out occurs when Howler tone starts.

OPERATION

System

The System will deliver a Howler tone automatically, as required.

SLT Name Registration

A SLT user has the capability to program the User Name so that a Calling Station with an LCD can see the associated Name instead of the Station number.

OPERATION

SLT

To register a name at the SLT:

1. Lift the handset.
2. Dial {Name Register Feature Code}.
3. Enter name (refer to Alphanumeric Chart on [page C-1](#)).
4. Press the Hook-Switch; the confirmation tone will be heard.

To delete the Name at the SLT:

1. Lift the handset.
2. Dial {Name Register Feature Code}.
3. Press the Hook-Switch; confirmation tone will be heard.

RELATED FEATURES

Dial-by-Name ... see [page 3-60](#)

Station Speed Dial ... see [page 3-147](#)

Chapter 9

SIP Phone

SIP Terminal Registration

The System supports the SIP-based videophone, LVP-2000, as well as other third party SIP phones. Compatible SIP phones support the Internet Engineering Technical Committee standard RFC3261 for real-time communications over the Internet. Once registered, the System will deliver services to the SIP Phone. Operation of the SIP Phone generally follows the steps outlined for an SLT.

CONDITIONS

- The SIP Phone not supporting standard SIP protocol is not supported.
- Support for 3rd-party SIP phones requires a license.
- The 3rd-party applications supporting standard SIP protocol can be registered.
- The System checks the SIP status periodically; if the System does not receive the 'REGISTER' message from the SIP Phone in Registration Time, the SIP Phone registration attempt is cancelled.
- A VOIB channel is needed for the SIP Phone to Place or Receive Calls.

OPERATION

Web Admin

To register a SIP Phone:

1. Select IP Phone Registration Table.
2. Enter the Auth ID, Password, and User ID of SIP Phone.
3. Click the Save button.

SIP Phone

1. Configure SIP Phone settings (ex. IP address, Subnet mask, Gateway, Telephone number, Proxy Address, Expiration Timer, etc.); the Telephone is the Station number to be assigned to Phone by System and the Proxy Address is the System MPB IP address.
2. Boot the SIP Phone, which will activate registration with the System.

To place an External Call:

1. Dial the {CO Access Code} and telephone number.
2. Press the [OUTGOING] button on SIP Phone

SIP Call Pick-Up

The SIP phone can Pick-Up Intercom or Incoming CO Line Calls for other Stations.

CONDITIONS

- For SIP Phone Features (ex., Receive Calls, etc.) to work, the phone must be enabled with those features and be able to place a call using its own function.

OPERATION

To answer an Incoming call:

When Ringing is received and caller number is displayed, lift handset or press [ANSWER] button on SIP Phone.

SIP Hold Call

The SIP Phone can place an Active Call on Hold.

CONDITIONS

- If the SIP phone has a Call Hold Function, it will not operate correctly if the Hold message is not compatible between the SIP Phone and the System.

OPERATION

To place an Exclusive Hold:

While on an Active Call, press the [HOLD] button; the Call will be placed on Exclusive Hold, and will not be able to be accessed by other Stations.

SIP Transfer Call

The SIP phone can Transfer an Active Call.

SIP 3-Party Conference

The SIP phone can make a 3-party conference.

CONDITIONS

- If the SIP phone has a Conference Function, it will not operate correctly if the Conference message is not compatible between the SIP Phone and the System.

OPERATION

Refer to the Phone User Guide to set up a Conference.

SIP Call Wait/Broker Call

The SIP phone can initiate Broker Call when the SIP Phone User receives Call Wait indication.

CONDITIONS

- If the SIP phone has a Call Wait/Broker Call Function, it will not operate correctly if the Call Wait/Broker Call message is not compatible between the SIP Phone and the System.

OPERATION

Refer to the Phone User Guide to initiate Broker Call.

SIP SMS

The SIP phone can Send and Receive SMS messages with other Stations.

CONDITIONS

- If the SIP phone has a SMS Function, it will not operate correctly if the SMS message is not compatible between the SIP Phone and the System.

OPERATION

Refer to the Phone User Guide for SMS.

Chapter 10

ACD (Automatic Call Distribution)

ACD (Automatic Call Distribution) feature provides the service to distribute calls to agents in an efficient way. Each agent can set or change own specific state and get ready to receive the ACD calls. And supervisor can be assigned to each group and they can change the ACD group status.

Items	MBX IP 100	MBX IP 300
Number of ACD Group	20	50
Number of Supervisor	1	1
Number of Sub-Supervisor	3	3
Number of Agents	50	50
Max Queue Count	99	99
Max Steps for Queue Announcement	5	5
ACD Agent Priority	20 (1-20)	20 (1-20)

ACD Basic Feature

ACD calls are analyzed first by the system to find an appropriate agent who will receive the call. System selects one of the free agents and then directs the ACD call to the agent selected.

Each agent registered in admin has to log in first to receive an ACD call. If all the agents are in busy status or in logout status, the next ACD calls will be queued. When one of the agents goes to ready state or idle state, the queued ACD call is routed to the agent in ready state. While an ACD call is being queued, queuing announcement will be served.

- ACD Group has 5 types of status: Normal / Forward / Overflow / Night / Holiday. Each status of ACD calls can be handled at the same time.
- Each ACD group can have one Supervisor and three Sub-Supervisors. A Supervisor or Sub-Supervisor can monitor the state of an agent and can also check the group's call traffic.
- Each ACD group can have a maximum of 50 agents. To answer the ACD call, agents have to log-in.

- If [Password Check When Agent Login] is set in admin [PGM214-Flex8], agent has to enter password on log-in. If password is correct and agent is in log-out state, agent enters into log-in state.

Agent Log-Out

- Dial {ACD Agent Log-In/Out} feature code.
OR
- Press flex button registered as {ACD Agent Log-In/Out} feature code.
- If agent is in log-in state, agent is put into log-out state.

ACD Call Operation

- If an ACD call arrives, system automatically finds an idle agent (not in DND and not in Work Mode).
- If there are more than one idle agents, system check the priority of each agent and then one of longest idle agents will be chosen from the highest priority group.
- If there is no available agent, the ACD call will be queued and ACD announcement service is started.

PROGRAMMING

Numbering Plan

Feature Numbering Plan (PGM113) ... see details on [page A-17](#)

ACD Numbering Plan (PGM118) ... see details on [page A-22](#)

PGM 118	BTN	RANGE	REMARK
ACD GROUP RANGE -- ACD Group Number edit by range.	1	Start ACD Group Number & End ACD Group Number	-
ACD GROUP NO -- ACD Group Number edit.	2	ACD Group Number	-

Station Port

Station Port Attribute (PGM124) ... see details on [page A-27](#)

PGM 124	BTN	RANGE	DEFAULT
MSG WAIT INDICATION -- this menu determines the way to notify a station to wait message.	1	01-48	MW Remind Tone
APPLY DIFF RING -- determine user's differential ring mode. Applying to all ring mode or normal ring mode.	2	1-9	All Ring
ICM DIFF RING ID -- set the intercom differential ring ID – usually 1-4 is valid.	3	000-254	On

ACD Group Assignment (PGM 212) ... see details on [page A-76](#)

PGM 212	BTN	RANGE	DEFAULT
GROUP NAME -- ACD Group Name.	1	Start ACD Group Number & End ACD Group Number	-
SERVICE MODE -- ACD Group Status.	2	0: Normal 1: Group Forward 2: Overflow 3: Night 4: Holiday 5: Not Service	Normal
TENANT NO -- ACD Tenant Number.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE INDEX -- ACD Group Time Table.	4	1-9	1
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

ACD Group Attribute1 (PGM 213) ... see details on [page A-77](#)

PGM 213	BTN	RANGE	DEFAULT
SUB-SUP ASSIGN -- This entry assigns Sub-Supervisor in ACD Group.	1	-	-
GROUP FWD DEST -- When ACD Group status is Group Forward Status, all of ACD call will be forwarded to this entry assigned destination.	2	-	-
NIGHT SERVICE -- -- This entry defines how to reroute ACD call when group status is Night Status.	3	0: Release 1: Announcement 2: Forward	Release
NIGHT FWD DEST -- When Night Service type is Forward, applied destination can be assigned.	4	-	-

PGM 213	BTN	RANGE	DEFAULT
AGENT NO-ANS OPTION -- This entry defines no-answer Agent No-Answer case about ACD-call. 1 Not use 2 Forward: call will be forwarded to defined destination 3 DND: Agent state will be changed automatically to DND state. 4 DND & Forward: Agent state will be change to DND state, and ACD call will be forwarded to defined destination	15	0: Not use 1: Forward 2: DND state 3: DND & Forward	Not use
AGENT NO-ANS DEST -- When Agent No-Answer option is Forward, applied destination can be assigned.	16	-	-

ACD Group Attribute2 (PGM 214) ... see details on [page A-79](#)

PGM 214	BTN	RANGE	DEFAULT
SUPERVISOR PSWD CHECK -- This entry defines check the supervisor password when supervisor change group status.	1	0:Off 1:On	0:Off
AGENT-AGENT CALL -- This entry defines agent to agent call restriction.	2	0:Allow 1:Direct call 2:Forward call	0:Allow
WORK MODE TIMER -- This entry defines wrap up timer of Agent Work State.	3	001-240	60
AUTO-WORK MODE OPTION -- This entry defines when change the agent work state. (It is applied, when only agent has auto-work option). 1 CALL: after conversation, agent state will be changed to work state. 2 CALL, RING: after conversation or after ringing, agent state will be changed to work state. 3 CALL, OG: after conversation or after make outgoing call, agent state will be changed to work state. 4 CALL, RING, OG: after conversation or after ringing or after make outgoing call, agent state will be changed to work state.	4	0:Call 1:Call, Ring 2:Call OG 3:Call, Ring, OG	0:Call
ANNOUNCEMENT USE -- This entry defines usage of Announcement when agent answer incoming ACD Call.	5	0:Off 1:On	0:Off

PGM 214	BTN	RANGE	DEFAULT
INFO PRINT INTERVAL -- This entry defines print interval seconds of Information Traffic data.	17	001-250	001 (10 sec)
INFO CLR AFTER PRT -- If this value is ON, after print Information traffic data, previous data will be deleted.	18	0:Off 1:On	0:Off

ACD Group Service Status

ACD group has 5 status settings (Normal / Forward / Overflow / Night / Holiday Status).

- 1 - Normal status is a general service status.
- 2 - Forward status, ACD call will be forcibly forwarded to registered destination.
- 3 - Overflow status will be changed automatically from Normal status when all agents are busy and also ACD queue is full. Administrator or Supervisor can make rule release, overflow announcement or forward.
- 4 & 5 - Night and Holiday status can be changed automatically by system time-table or can be changed manually by Supervisor. In each status Administrator or Supervisor can make rule how to handle the AC call. ACD calls can be released immediately, or can be served with Night or Holiday Announcement, or can be forwarded to the registered destination.

In case of Forward, Night, or Holiday status, these kinds of status can be set manually by a System Administrator or group Supervisor. And also in case of Night, or Holiday status, if [Auto service change] admin is set PGM 212 - Flex 5, group status can be changed automatically according to the system time table.

CONDITIONS

- Group status can be changed only by supervisor or administrator.
- Supervisor can change the rule for ACD group in its Station Web Program.
- If [Password Check When Service Mode Changed] is set in admin [PGM214-Flex9], supervisor has to enter the correct password when supervisor wants to change the group status (Group Forward / Night / Holiday Status).
- If [Auto Service Status Change] is set in admin [PGM212-Flex5], group status will be changed automatically from Normal to Night or Holiday status according to system time table.
- If [Auto Service Status Change] is set in admin [PGM212-Flex5] and the System-Time is in Timed mode, ACD will follow the settings for Night Service.
- If [Auto Service Status Change] is set as Manual Change [PGM212-Flex5], supervisor can change group status manually.

Station Port Attribute (PGM 124) ... see details on [page A-27](#)

PGM 124	BTN	RANGE	DEFAULT
MSG WAIT INDICATION -- this menu determines the way to notify a station to wait message.	1	01-48	MW Remind Tone
APPLY DIFF RING -- determine user's differential ring mode. Applying to all ring mode or normal ring mode.	2	1-9	All Ring
ICM DIFF RING ID -- set the intercom differential ring ID -- usually 1-4 is valid.	3	000-254	On
CO DIFF RING ID -- set the CO line differential ring ID -- usually 1-4 is valid.	4	000-254	Off
COS APPLY OPTION -- determine whether the applied COS is the COS of SUB-DN or COS of MY-DN when station accesses SUB-DN.	5	0: SUB-DN 1: MY-DN	SUN-DN
HOOK FLASH WHEN TRANSFER -- Determine the operation when user press hook-flash button while transferring call. 0. Cancel transfer : drop current call and recover previous call 1. Broker : hold current call and recover previous held call 2. Conference: establish 3-way conference call. 3. Broker-Conf : Operated Broker and Conference when a user hook flash within 2 sec	6	0: Cancel Transfer 1: Broker 2: Conference 3: Broker-Conf	Cancel Transfer
OFF-HOOK ON PAGED -- when lifting handset while listening to paging message, user can make another call or continue to listen. 0: continue to listen to paging message 1: stop listening, seize a remaining DN, and hear dial-tone. User can make a another call.	7	0: Paged 1: Dial Tone	Paged
PLA -- Preferred Line Answer enables Ringing Line Preference for the station. Calls that ring the telephone are answered by going off-hook. (Reserved).	8	0: Off 1: On	On
PICKUP BY DSS BUTTON -- this value determines the method of pickup when pressing DSS button.	9	0: Disable 1: Group Pickup 2: Direct Pickup	Direct Pickup
CLI IP ADDRESS -- CLI IP Address.	10	IP Address	0.0.0.0
ACD AGENT PRIORITY -- when a station is a member of an ACD Group, this value will be used for priority as agent.	11	01-20	10

PGM 213	BTN	RANGE	DEFAULT
HOLIDAY SERVICE -- This entry defines how to reroute ACD call when group status is Holiday Status.	5	0: Release 1: Announcement. 2: Forward	Release
HOLIDAY FWD DEST -- When Holiday Service type is Forward, applied destination can be assigned.	6	-	-
OVERFLOW SERVICE -- This entry defines how to reroute ACD call when group status is Overflow Status.	7	0: Release 1: Announcement 2: Forward	Release
OVERFLOW FWD DEST -- When Overflow Service type is Forward, applied destination can be assigned.	8	-	-
MAX QUEUING COUNT -- This entry defines MAX queuing call count. If queuing ACD Call count is over the max q-count, ACD group state will be changed to Overflow Status.	9	00-99	10
QUEUING ANNC STEP -- This entry defines queuing announcement play service step. One ACD Group can have max 5 announcements for queuing ACD Call.	10	1-5	1
REPEAT COUNT -- This entry defines total queuing announcement repeat service count. If this entry is defines as One or More Times service, Queuing Announcement will be played from 1st to defined Step. And then from Repeat Position Queuing Announcement will be restarted to defined step until Repeat Count.	11	0:No Repeat 1:One Time 2:Three Times 3:Five Times 4:Ten Times 5:Twenty Times	No Repeat
REPEAT POSITION -- This entry defines Repeat Announcement Start Position.	12	1-5	1
FWD AFTER QUEUING -- This entry defines reroute usage after queuing time over.	13	0: Off 1: On	Off
Q-FWD DEST -- Reroute destination after queuing time over.	14	-	-

PGM 214	BTN	RANGE	DEFAULT
GROUP Q-CNT DISPLAY -- This entry defines display of Queuing count of ACD call.	6	0:Off 1:On	0:Off
Q-CNT INTERVAL -- This entry defines display interval seconds of Queuing count of ACD call.	7	0:Real Time 1:10sec 2:20sec 3:30sec 4:40sec 5:50sec 6:60sec	0:Real Time
LOGIN PASSWD CHECK -- This entry defines check the password when agent log-in.	8	0:Off 1:On	0:Off
LOGIN AGENT STATE -- This entry defines usage of default Agent State option when agent log-in.	9	0:Ready state 1:DND state 2:Work state	0:Ready state
LOGIN AUTO ANSWER -- This entry defines usage of Agent Auto Answer option when agent log-in.	10	0:Off 1:On	0:Off
LOGIN AUTO WORK -- This entry defines usage of Agent Auto Work option when agent log-in.	11	0:Off 1:On	0:Off
LOGIN HANDSET -- This entry defines usage of Agent Headset option when agent log-in.	12	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode	1:Handset Mode
LOGOUT HANDSET -- This entry defines usage of Agent Headset option when agent log-out	13	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode 4:Logon Mode	1:Handset Mode
LOGOUT RESTRICTION -- This entry defines restriction of Logout State Agent.	14	0:Not use 1:CO outgoing 2:All call	0:Not use
CO ANSWER TIME -- This entry defines when the ACK message is sent to caller party.	15	0:Queued to group 1:Agent Answer	0:Queued to group
INFO DATA PRINT -- This entry defines usage of ACD Call Traffic Information data Print or Not. Information Traffic data will be printed at Information-Print Port.	16	0:Off 1:On	0:Off

ACD Group Assignment (PGM 212) ... see details on [page A-76](#)

PGM 212	BTN	RANGE	DEFAULT
GROUP NAME -- ACD Group Name.	1	Start ACD Group Number & End ACD Group Number	-
SERVICE MODE -- ACD Group Status.	2	0: Normal 1: Group Forward 2: Overflow 3: Night 4: Holiday 5: Not Service	Normal
TENANT NO -- ACD Tenant Number.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE INDEX -- ACD Group Time Table.	4	1-9	1
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

ACD Group Attribute1 (PGM 213) ... see details on [page A-77](#)

PGM 213	BTN	RANGE	DEFAULT
SUB-SUP ASSIGN -- This entry assigns Sub-Supervisor in ACD Group.	1	-	-
GROUP FWD DEST -- When ACD Group status is Group Forward Status, all of ACD call will be forwarded to this entry assigned destination.	2	-	-
NIGHT SERVICE -- -- This entry defines how to reroute ACD call when group status is Night Status.	3	0: Release 1: Announcement 2: Forward	Release
NIGHT FWD DEST -- When Night Service type is Forward, applied destination can be assigned.	4	-	-

PGM 213	BTN	RANGE	DEFAULT
AGENT NO-ANS OPTION -- This entry defines no-answer Agent No-Answer case about ACD-call. 1 Not use 2 Forward: call will be forwarded to defined destination 3 DND: Agent state will be changed automatically to DND state. 4 DND & Forward: Agent state will be change to DND state, and ACD call will be forwarded to defined destination	15	0: Not use 1: Forward 2: DND state 3: DND & Forward	Not use
AGENT NO-ANS DEST -- When Agent No-Answer option is Forward, applied destination can be assigned.	16	-	-

ACD Group Attribute2 (PGM 214) ... see details on [page A-79](#)

PGM 214	BTN	RANGE	DEFAULT
SUPERVISOR PSWD CHECK -- This entry defines check the supervisor password when supervisor change group status.	1	0:Off 1:On	0:Off
AGENT-AGENT CALL -- This entry defines agent to agent call restriction.	2	0:Allow 1:Direct call 2:Forward call	0:Allow
WORK MODE TIMER -- This entry defines wrap up timer of Agent Work State.	3	001-240	60
AUTO-WORK MODE OPTION -- This entry defines when change the agent work state. (It is applied, when only agent has auto-work option). 1 CALL: after conversation, agent state will be changed to work state. 2 CALL, RING: after conversation or after ringing, agent state will be changed to work state. 3 CALL, OG: after conversation or after make outgoing call, agent state will be changed to work state. 4 CALL, RING, OG: after conversation or after ringing or after make outgoing call, agent state will be changed to work state.	4	0:Call 1:Call, Ring 2:Call OG 3:Call, Ring, OG	0:Call
ANNOUNCEMENT USE -- This entry defines usage of Announcement when agent answer incoming ACD Call.	5	0:Off 1:On	0:Off

PGM 214	BTN	RANGE	DEFAULT
INFO PRINT INTERVAL -- This entry defines print interval seconds of Information Traffic data.	17	001-250	001 (10 sec)
INFO CLR AFTER PRT -- If this value is ON, after print Information traffic data, previous data will be deleted.	18	0:Off 1:On	0:Off

ACD Call Queuing Service

If all of agents are busy or all of agents are not log-in, next ACD call will be queued. Max queue count can be changed by Administrator or Supervisor. When ACD call is queued, system gives Queuing announcement. Each group can serve max 5 queuing announcements and can define how many announcements can be served [Queuing Announcement Service Step PGM 213 - Flex 7]. And also each group can have the rule how to handle the queued call after finish the Queuing Announcement. In that case ACD call can be released or forwarded to registered destination.

- If [queued count display option] admin is set [PGM 214 - Flex 8], queued count will be displayed to Supervisor and Sub-Supervisor and all of agent keyset.
- An Administrator can make time interval for Queued call count display [PGM 214 - Flex 9]
- If {ACD Supervisor Queued Call Answer} feature code is saved at Supervisor's or Sub-Supervisor's flex button, this button color will be steady-on when there are queued ACD call. At that time, Supervisor or Sub-Supervisor can answer the first queued ACD call or can forward to registered destination.
- Administrator can make Queuing Announcement Scenario with [Repeat Announcements Count] and [Repeat Announcements Start Position] in PGM 213 - Flex 9, 10. After [Queuing Announcement Service Step], if [Repeat Announcements Count] is set. queuing announcement will be restarted from [Repeat Announcements Start Position].

CONDITIONS

- Each Queuing Announcement playtime is max 600sec.
- If there is not registered forward destination, after queuing announcement, ACD call will be released.
- Supervisor, Sub-Supervisor and all of Agents can check and listen all of ACD Group Announcement with {ACD Announce Play} feature code.

OR

6. Press 2 is Forward queued call to some of destination.
7. If dial some of Tel-Number and then press hold or '#' button, first queued call will be rerouted.

PROGRAMMING

Numbering Plan

Feature Numbering Plan (PGM 113) ... see details on [page A-17](#)

Station Group

ACD Group Assignment (PGM 212) ... see details on [page A-76](#)

PGM 212	BTN	RANGE	DEFAULT
GROUP NAME -- ACD Group Name.	1	Start ACD Group Number & End ACD Group Number	-
SERVICE MODE -- ACD Group Status.	2	0: Normal 1: Group Forward 2: Overflow 3: Night 4: Holiday 5: Not Service	Normal
TENANT NO -- ACD Tenant Number.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE INDEX -- ACD Group Time Table.	4	1-9	1
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

PGM 213	BTN	RANGE	DEFAULT
FWD AFTER QUEUING -- This entry defines reroute usage after queuing time over.	13	0: Off 1: On	Off
Q-FWD DEST -- Reroute destination after queuing time over.	14	-	-
AGENT NO-ANS OPTION -- This entry defines no-answer Agent No-Answer case about ACD-call. 1 Not use 2 Forward: call will be forwarded to defined destination 3 DND: Agent state will be changed automatically to DND state. 4 DND & Forward: Agent state will be change to DND state, and ACD call will be forwarded to defined destination	15	0: Not use 1: Forward 2: DND state 3: DND & Forward	Not use
AGENT NO-ANS DEST -- When Agent No-Answer option is Forward, applied destination can be assigned.	16	-	-

ACD Group Attribute2 (PGM 214) ... see details on [page A-79](#)

PGM 214	BTN	RANGE	DEFAULT
SUPERVISOR PSWD CHECK -- This entry defines check the supervisor password when supervisor change group status.	1	0:Off 1:On	0:Off
AGENT-AGENT CALL -- This entry defines agent to agent call restriction.	2	0:Allow 1:Direct call 2:Forward call	0:Allow
WORK MODE TIMER -- This entry defines wrap up timer of Agent Work State.	3	001-240	60
AUTO-WORK MODE OPTION -- This entry defines when change the agent work state. (It is applied, when only agent has auto-work option). 1 CALL: after conversation, agent state will be changed to work state. 2 CALL, RING: after conversation or after ringing, agent state will be changed to work state. 3 CALL, OG: after conversation or after make outgoing call, agent state will be changed to work state. 4 CALL, RING, OG: after conversation or after ringing or after make outgoing call, agent state will be changed to work state.	4	0:Call 1:Call, Ring 2:Call OG 3:Call, Ring, OG	0:Call

PGM 214	BTN	RANGE	DEFAULT
INFO DATA PRINT -- This entry defines usage of ACD Call Traffic Information data Print or Not. Information Traffic data will be printed at Information-Print Port.	16	0:Off 1:On	0:Off
INFO PRINT INTERVAL -- This entry defines print interval seconds of Information Traffic data.	17	001-250	001 (10 sec)
INFO CLR AFTER PRT -- If this value is ON, after print Information traffic data, previous data will be deleted.	18	0:Off 1:On	0:Off

ACD Group Announcement (PGM 215) ... see details on [page A-81](#)

PGM 215	BTN	RANGE	DEFAULT
TONE TYPE -- designates the tone type.	1	01:Normal Tone 02:VMIB Prompt 03:VMIB Announcement 04:Internal MOH 05:External MOH 06-09:VMIB MOH 1/2/3/4 10-14:SLT MOH 1-5	01:Normal Tone
TONE TIME -- determines the amount of time tone is provided.	2	1-600	10
TONE PORT -- tone port index of PGM 264. The cadence of tone port may be changed by using Web Admin.	3	1-19	-
PROMPT ANNC NO -- The VMIB Prompt or Announcement number when tone type is VMIB Prompt or announcement.	4	1-255	-
PROMPT ANNC RPT -- The VMIB Prompt or Announcement Repeat number when tone type is VMIB Prompt or announcement.	5	0-100	1
PROMPT ANNC INTVL -- The VMIB Prompt or Announcement Repeat interval when VMIB Prompt or announcement. Repeat is assigned.	6	0-100	0
CCR USE -- This option is defined during announcement will be played, usage of CCR feature.	7	0:Off 1:On	0:Off

5. Defined rule will be operated.

PROGRAMMING

Station Group

ACD Group Assignment (PGM 212) ... see details on [page A-76](#)

PGM 212	BTN	RANGE	DEFAULT
GROUP NAME -- ACD Group Name.	1	Start ACD Group Number & End ACD Group Number	-
SERVICE MODE -- ACD Group Status.	2	0: Normal 1: Group Forward 2: Overflow 3: Night 4: Holiday 5: Not Service	Normal
TENANT NO -- ACD Tenant Number.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE INDEX -- ACD Group Time Table.	4	1-9	1
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

ACD Group Attribute1 (PGM 213) ... see details on [page A-77](#)

PGM 213	BTN	RANGE	DEFAULT
SUB-SUP ASSIGN -- This entry assigns Sub-Supervisor in ACD Group.	1	-	-
GROUP FWD DEST -- When ACD Group status is Group Forward Status, all of ACD call will be forwarded to this entry assigned destination.	2	-	-

ÚÓŦ ÁGFH	ÓVÞ	ÛœŦÖÒ	ÖÒœŦŦŠV
ÞŦŦVÄÛÖÛXŦŦŦŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ, ŦŦ ÄŦ!["Ŧ ÄÖÖÄË &Ŧ!Ä @) ÄŦ!["] Äœœ•ŦŦ ÄŦä @ÄÛœœ•Ë	H	€ÄÛ^Ŧ^æ^ FŦŦ}[`}&{ ^}c GÄŦ!, æä	Û^Ŧæ^
ÞŦŦVÄÛÖÛ ÖÄÖÛVŦŦV @) ÄŦä @ÄÛÿçæ^ÄÖ`!ä ÄŦ!, æäŦŦ äŦ! ä`äŦŦ•ç äŦŦ} /æŦ ŦŦŦ•ä}^äË	I	Ë	Ë
PÛŠŦŦŦÄÛÖÛXŦŦŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ, ŦŦ ÄŦ!["Ŧ ÄÖÖÄË &Ŧ!Ä @) ÄŦ!["] Äœœ•ŦŦ ÄŦ ŦæŦÄÛœœ•Ë	Í	€ÄÛ^Ŧ^æ^ FŦŦ}[`}&{ ^}dË GÄŦ!, æä	Û^Ŧæ^
PÛŠŦŦŦÄÛ ÖÄÖÛVŦŦV @) ÄŦ ŦæŦÄÛÿçæ^ÄÖ`!ä ÄŦ ÄŦ!, æäŦŦ ä`äŦŦ•ç äŦŦ} /æŦ ŦŦŦ•ä}^äË	î	Ë	Ë
ÛXÖÛŦŦŦÛY ÄÛÖÛXŦŦŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ, ŦŦ ÄŦ!["Ŧ Ä ÖÖÖÄË&Ŧ!Ä @) ÄŦ!["] Äœœ•ŦŦ ÄÛçŦ!- , ÄÛœœ•Ë	ï	€ÄÛ^Ŧ^æ^ FŦŦ}[`}&{ ^}c GÄŦ!, æä	Û^Ŧæ^
ÛXÖÛŦŦŦÛY ÄÛ ÖÄÖÛVŦŦV @) ÄÛçŦ!- , ÄÛÿçæ^ÄÖ`!ä ÄŦ ÄŦ!, æäŦŦ ä`äŦŦ•ç äŦŦ} /æŦ ŦŦŦ•ä}^äË	ì	Ë	Ë
ŦœŦÄÛWÖŦÖÖÛVŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ œŦÄ`^`ä`*Ä &ŦŦ}[`] dËÄ`^`ä`*ÄÖÖÄË&ŦŦ}[`] œŦÄçŦ!Ŧ@Ä äŦÄË}[`] dË ÖÖÖÄË!["] ÄœœÄ çŦŦŦ&œŦ`^äŦ ÄÛçŦ!- , ÄÛœœ•Ë	J	€€ÛJ	F€
ÛWÖŦÖÖœÞŦÖÛVŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ`^`ä`*Ä äŦ}[`}&{ ^}çŦ! æŦÄÿçæ^ÄœŦ} ÄÛÖÖÖ!["] /æŦ Äœœ^Ä {æŦÄ}][`}&{ ^}œŦ!Ä`^`ä`*ÄÖÖÄË&ŦŦ	F€	F€	F
ÛÖÛœœŦÖÛVŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ œŦÄ`^`ä`*Ä äŦ}[`}&{ ^}œŦ^æŦÄÿçæ^ÄŦ}[`] dËœŦÄ) d`ŦŦ-ä`^•ÄŦ ÄŦ^ÄŦ!ÄŦ! !ÄÄ`^•Äÿçæ^ÄÛ`^`ä`*ÄË}[`}&{ ^}çŦ! æŦ^äÄŦ! {Ŧ•œŦ ŦŦ-ä`^•ÄÄÛœŦ} ÄŦ! {ÄÛ^Ŧ^æŦ ÄÛœœ•ÄÛ`^`ä`*ÄË}[`}&{ ^}çŦ! æŦŦŦŦ•œœœŦŦŦŦ-ä`^•Ä•œŦÄ}çÄÛ^Ŧ^æŦ}[`]dË	FF	€Þ[ÄÛ^Ŧ^æ FŦŦ]^ÄÄ`^• GŦ@^ÄÄ`^• HœŦ^ÄÄ`^• IŦŦ]^ÄÄ`^• ÍŦŦ, ^}çÄÄ`^•	Þ[ÄÛ^Ŧ^æ
ÛÖÛœœŦÄÛÛÖŦÞŦŦV@Ä) d`ŦŦ-ä`^•ÄÛ^Ŧ^æŦœŦ}[`}&{ ^}œŦœœÄÛœœ•äŦ}Ë	FG	F€	F
ŦY ÖÄœŦVÖÛÄÛWÖŦÖÖŦŦV@Ä) d`ŦŦ-ä`^•ÄŦ!["Ŧ Äœœ^Ä äœœ!Ä`^`ä`*Ä ÄŦÄçŦ!Ë	FH	€ÄÛ~ FŦÄÛ}	U~
ÛŦY ÖÄÖÛVŦŦVÄÛ!["ŦŦŦŦ-ä`^•ÄŦ} /æŦ!Ä`^`ä`*Ä ÄŦÄçŦ!Ë	FI	Ë	Ë

PGM 213	BTN	RANGE	DEFAULT
AGENT NO-ANS OPTION -- This entry defines no-answer Agent No-Answer case about ACD-call. 1 Not use 2 Forward: call will be forwarded to defined destination 3 DND: Agent state will be changed automatically to DND state. 4 DND & Forward: Agent state will be change to DND state, and ACD call will be forwarded to defined destination	15	0: Not use 1: Forward 2: DND state 3: DND & Forward	Not use
AGENT NO-ANS DEST -- When Agent No-Answer option is Forward, applied destination can be assigned.	16	-	-

ACD Group Attribute2 (PGM 214) ... see details on [page A-79](#)

PGM 214	BTN	RANGE	DEFAULT
SUPERVISOR PSWD CHECK -- This entry defines check the supervisor password when supervisor change group status.	1	0:Off 1:On	0:Off
AGENT-AGENT CALL -- This entry defines agent to agent call restriction.	2	0:Allow 1:Direct call 2:Forward call	0:Allow
WORK MODE TIMER -- This entry defines wrap up timer of Agent Work State.	3	001-240	60
AUTO-WORK MODE OPTION -- This entry defines when change the agent work state. (It is applied, when only agent has auto-work option). 1 CALL: after conversation, agent state will be changed to work state. 2 CALL, RING: after conversation or after ringing, agent state will be changed to work state. 3 CALL, OG: after conversation or after make outgoing call, agent state will be changed to work state. 4 CALL, RING, OG: after conversation or after ringing or after make outgoing call, agent state will be changed to work state.	4	0:Call 1:Call, Ring 2:Call OG 3:Call, Ring, OG	0:Call
ANNOUNCEMENT USE -- This entry defines usage of Announcement when agent answer incoming ACD Call.	5	0:Off 1:On	0:Off

PGM 214	BTN	RANGE	DEFAULT
INFO PRINT INTERVAL -- This entry defines print interval seconds of Information Traffic data.	17	001-250	001 (10 sec)
INFO CLR AFTER PRT -- If this value is ON, after print Information traffic data, previous data will be deleted.	18	0:Off 1:On	0:Off

ACD Group Announcement (PGM 215) ... see details on [page A-81](#)

ACD Agent State

When administrator assigns the agents, all of agents are log-out state. If agents want to receive the ACD call, agents have to go to log-in state. Agents can go to log-in state with [ACD Agent Login/Logout] feature code. And also log-in agents can change their state from Ready state to DND state and Work state. So each agent can have 4 types of state (Log-Out / Log-In Ready / Log-In DND / Log-In Work).

- 1 - Log-Out State: Agent is only assigned for ACD member. Agents cannot receive ACD call. If [Call Restriction When Agent Logout] admin is set as All Call Restriction, agents cannot make call.
- 2 - Log-In Ready State: Agent is logged-in and ready to receive the ACD call.
- 3 - Log-In Work State: Agent is log-in state but agent can work without any ACD call during Work-Mode Expired Timer. Work-Mode Expired Timer can be changed at admin [PGM 214 - Flex 3]. After this timer agent's state is changed to ready state automatically.
 - 1) Agents can set own state to Work state with {ACD Agent Work Mode} feature code.
 - 2) If agent dial {ACD Agent Work Mode} feature code or press flex button registered as {ACD Agent Work Mode} feature code, agent state goes to Ready State.
 - 3) Also agents can set Auto Work State Changing Function with {ACD Agent Auto Work} feature code. If Auto Work State Changing Function is set, after conversation or after ringing or after outgoing call, agent state automatically changes to Work State. Changing condition can be set at Agent Auto Work Mode admin [PGM 214 - Flex 4]
4. - Log-In DND State: Agent is log-in but agent is set as DND. DND agent does not receive ACD call. DND is not changed automatically, agent has to change own state to Ready state or Work state. Supervisor or Sub-Supervisor can monitor DND agent and then can change their DND state to Ready or Work State.
 - 1) Agent can set own state to DND State with {ACD Agent DND} feature code.
 - 2) If agent dial {ACD Agent DND} feature code or press flex button registered as {ACD Agent DND} feature code, agent state goes to Ready State.

PROGRAMMING

Numbering Plan

Feature Numbering Plan (PGM 113) ... see details on [page A-17](#)

Station Group

ACD Group Assignment (PGM 212) ... see details on [page A-76](#)

PGM 212	BTN	RANGE	DEFAULT
GROUP NAME -- ACD Group Name.	1	Start ACD Group Number & End ACD Group Number	-
SERVICE MODE -- ACD Group Status.	2	0: Normal 1: Group Forward 2: Overflow 3: Night 4: Holiday 5: Not Service	Normal
TENANT NO -- ACD Tenant Number.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE INDEX -- ACD Group Time Table.	4	1-9	1
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

ACD Group Attribute1 (PGM 213) ... see details on [page A-77](#)

PGM 213	BTN	RANGE	DEFAULT
SUB-SUP ASSIGN -- This entry assigns Sub-Supervisor in ACD Group.	1	-	-
GROUP FWD DEST -- When ACD Group status is Group Forward Status, all of ACD call will be forwarded to this entry assigned destination.	2	-	-

PGM 213	BTN	RANGE	DEFAULT
AGENT NO-ANS OPTION -- This entry defines no-answer Agent No-Answer case about ACD-call. 1 Not use 2 Forward: call will be forwarded to defined destination 3 DND: Agent state will be changed automatically to DND state. 4 DND & Forward: Agent state will be change to DND state, and ACD call will be forwarded to defined destination	15	0: Not use 1: Forward 2: DND state 3: DND & Forward	Not use
AGENT NO-ANS DEST -- When Agent No-Answer option is Forward, applied destination can be assigned.	16	-	-

ACD Group Attribute2 (PGM 214) ... see details on [page A-79](#)

PGM 214	BTN	RANGE	DEFAULT
SUPERVISOR PSWD CHECK -- This entry defines check the supervisor password when supervisor change group status.	1	0:Off 1:On	0:Off
AGENT-AGENT CALL -- This entry defines agent to agent call restriction.	2	0:Allow 1:Direct call 2:Forward call	0:Allow
WORK MODE TIMER -- This entry defines wrap up timer of Agent Work State.	3	001-240	60
AUTO-WORK MODE OPTION -- This entry defines when change the agent work state. (It is applied, when only agent has auto-work option). 1 CALL: after conversation, agent state will be changed to work state. 2 CALL, RING: after conversation or after ringing, agent state will be changed to work state. 3 CALL, OG: after conversation or after make outgoing call, agent state will be changed to work state. 4 CALL, RING, OG: after conversation or after ringing or after make outgoing call, agent state will be changed to work state.	4	0:Call 1:Call, Ring 2:Call OG 3:Call, Ring, OG	0:Call
ANNOUNCEMENT USE -- This entry defines usage of Announcement when agent answer incoming ACD Call.	5	0:Off 1:On	0:Off

ÚÓŦ ÁFI	ÓVP	Üœ ÖÒ	ÖÖZœVŠV
ÖÜUWÁÜËÖP VÁÖÜÜSÖYÄV@Á} d^ Á^ q^ Á^ Á ää] æ Á^ Á^ Á^ q^ Á^ Á^ } Ö ÖÖÖ&æÉ	í	€K~ FKU}	€K~
ÛËÖP VÁÖ VÖÜXÖSÄV@Á} d^ Á^ q^ Á^ Á^ } æ Á q^ c! çæ Á^ Á^ } ä^ Á^ Á^ Á^ q^ Á^ Á^ } Ö ÖÖÖ&æÉ	ï	€K^æÁVq^ Á^ FK€^& GGE^& HKE^& IK€^& ÍK€^& îK€^&	€K^æÁVq^ Á^
ŠÜÖÖÁÜœÜY ÖÖPÖÖSÄV@Á} d^ Á^ q^ Á^ Á^ & @ & Á @ Á^ æ, [!á Á^ @} Á^ Á^ } Ö ÖÖÖ&æÉ	ì	€K~ FKU}	€K~
ŠÜÖÖÄËÖP VÁÜVÖÖÄV@Á} d^ Á^ q^ Á^ Á^ • æ^ Á^ Á^ á^ æ œ^ } ÖÜæ Á^ } ç } Á^ @} Á^ Á^ } Ö ÖÖÖ&æÉ	J	€K^æá^ Á^æ FÖPÖÁ^æ GY [! Á^æ	€K^æá^ Á^æ
ŠÜÖÖÄœWUÁÜP ÜY ÖÜÄV@Á} d^ Á^ q^ Á^ Á^ • æ^ Á^ Á^ [-œ^ } œ ç Äœ, ^! Á^ } ç } Á^ @} Á^ Á^ } Ö ÖÖÖ&æÉ	F€	€K~ FKU}	€K~
ŠÜÖÖÄœWUÁÜ ÜSÄV@Á} d^ Á^ q^ Á^ Á^ • æ^ Á^ Á^ œ^ } œ ç Á^ [! Á^ } ç } Á^ @} Á^ Á^ } Ö ÖÖÖ&æÉ	FF	€K~ FKU}	€K~
ŠÜÖÖÄœPœÖÜÖVÄV@Á} d^ Á^ q^ Á^ Á^ • æ^ Á^ Á^ œ^ } œ^ æ^ œ^ } ç } Á^ @} Á^ Á^ } Ö ÖÖÖ&æÉ	FG	€P^æá^ œ^ [á^ FIPæ á^ œ^ [á^ GÖæÉ æÁ [á^ HÖ^ ^ ç [œ^ [á^ Á^	FIPæ á^ œ^ [á^
ŠÜÖÜWÁPœÖÜÖVÄV@Á} d^ Á^ q^ Á^ Á^ • æ^ Á^ Á^ œ^ } œ^ æ^ œ^ } ç } Á^ @} Á^ Á^ } Ö ÖÖÖ&æÉ	FH	€P^æá^ œ^ [á^ FIPæ á^ œ^ [á^ GÖæÉ æÁ [á^ HÖ^ ^ ç [œ^ [á^ IKS^ * } Á^ [á^	FIPæ á^ œ^ [á^
ŠÜÖÜWÁÜÖVÜÖVÖPÄV@Á} d^ Á^ q^ Á^ Á^ !^ d æ ç } Á^ Á^ * [^ ÖÜæ œ^ } ç } Ö ÖÖÖ&æÉ	FI	€P [œ^ Á^ FÖUÁ^ ç [q^ * Gœ^ &æ	€P [œ^ Á^
ÖÜÄœÜY ÖÜÁÖ ÖÄV@Á} d^ Á^ q^ Á^ Á^ @} Á^ Á^ ÖÖSÁ^ Á^ • æ^ Á^ Á^ } Ö ÖÖÖ&æÉ	Fí	€K^ Á^ Á^ Á^ [^ } FICE^ } œœ, ^!	€K^ Á^ Á^ Á^ [^ }
ÖÜÄœÜY ÖÜÁÖ ÖÄV@Á} d^ Á^ q^ Á^ Á^ • æ^ Á^ Á^ ÖÖÖÖæÁ^ ç ç Q^ [! { æ } Á^ Á^ Á^ } Ö ÖÖÖ&æÉ Q^ [! { æ } Á^ ç ç Á^ Á^ } Á^ Á^ } ç ç Á^ Á^ Q^ [! { æ } ÖÜ: q ÖÜ [! ç	Fî	€K~ FKU}	€K~

PGM 214	BTN	RANGE	DEFAULT
INFO PRINT INTERVAL -- This entry defines print interval seconds of Information Traffic data.	17	001-250	001 (10 sec)
INFO CLR AFTER PRT -- If this value is ON, after print Information traffic data, previous data will be deleted.	18	0:Off 1:On	0:Off

ACD Agent Log-in / Log-out Default Setting

When agents go to log-in, some of default functions can be set according to admin values. And these kinds of values can be defined by an administrator:

- 1 - Administrator can define Auto-Answer mode when agent goes to log-in [PGM214-Flex12]. If [Auto Answer Use When Agent Login] option is set, when agent goes to log-in state, this agent's answer mode is set as Auto-Answer. So when this agent receives the ACD call, after first ring, agent keyset automatically answer the ACD call. Agent cans turn-on or turn-off Auto-Answer function with {ACD Agent Auto Answer} feature code.
- 2 - Administrator can define Auto-Work mode when agent goes to log-in [PGM214-Flex13]. If [Auto Work-Mode Use When Agent Login] option is set, when agent goes to log-in state, this agent's auto work-mode is set. Agent cans turn-on or turn-off Auto-Answer function with {ACD Agent Auto Work} feature code.
- 3 - Administrator can define log-in agent's headset mode when agent goes to log-in [PGM214-Flex14]. If [Handset Mode When Agent Login] admin is set as Headset or Handset or Ear-Mic, when agent goes to log-in state, this agent's headset mode is changed to defined value.
- 4 - Administrator can define log-out agent's headset mode when agent goes to log-out [PGM214-Flex15]. If [Handset Mode When Agent Logout] admin is set as Headset or Handset or Ear-Mic, when agent goes to log-out state, this agent's headset mode is changed to defined value
- 5 - Administrator can define log-out agent's call restriction [PGM214-Flex16]. Administrator can restrict all of call, and also only restrict outgoing call. If defined value is all of call, log-out agent cannot make any call.

PROGRAMMING

Numbering Plan

Feature Numbering Plan (PGM 113) ... see details on [page A-17](#)

Station Group

PGM 213	BTN	RANGE	DEFAULT
HOLIDAY SERVICE -- This entry defines how to reroute ACD call when group status is Holiday Status.	5	0: Release 1: Announcement. 2: Forward	Release
HOLIDAY FWD DEST -- When Holiday Service type is Forward, applied destination can be assigned.	6	-	-
OVERFLOW SERVICE -- This entry defines how to reroute ACD call when group status is Overflow Status.	7	0: Release 1: Announcement 2: Forward	Release
OVERFLOW FWD DEST -- When Overflow Service type is Forward, applied destination can be assigned.	8	-	-
MAX QUEUING COUNT -- This entry defines MAX queuing call count. If queuing ACD Call count is over the max q-count, ACD group state will be changed to Overflow Status.	9	00-99	10
QUEUING ANNC STEP -- This entry defines queuing announcement play service step. One ACD Group can have max 5 announcements for queuing ACD Call.	10	1-5	1
REPEAT COUNT -- This entry defines total queuing announcement repeat service count. If this entry is defines as One or More Times service, Queuing Announcement will be played from 1st to defined Step. And then from Repeat Position Queuing Announcement will be restarted to defined step until Repeat Count.	11	0:No Repeat 1:One Time 2:Three Times 3:Five Times 4:Ten Times 5:Twenty Times	No Repeat
REPEAT POSITION -- This entry defines Repeat Announcement Start Position.	12	1-5	1
FWD AFTER QUEUING -- This entry defines reroute usage after queuing time over.	13	0: Off 1: On	Off
Q-FWD DEST -- Reroute destination after queuing time over.	14	-	-

ÚÖT ÁGFH	ÓVP	ÜÖE ÖÖ	ÖÖÖEVSV
OEÖÖVÁPUEEÜÁUUVQPAEAV@Á} d^ Á^á^ Á [EÖ •, ^!Á OE ^} OÖ [EÖ •, ^!Áæ^Áæ [~ OÖÖEÖE FÁP [OÁ •^ GÖQ , æáÁÖEÄ } ÁÁ^Á! , æá^áÁ Á^á^ Á^Á^ ÖÖ } HÖPÖHÖE ^} OÁæ^Á } ÁÁ^ÁÖE } ^áÁæ q { æEÖ^ Á ÖPÖÁ •æE I ÖPÖBÁQ , æáÁÖE ^} OÁæ^Á } ÁÁ^ÁÖE } ^ÁÁ ÖPÖÁæEÄ æ } áÖÖÖEÖE } ÁÁ^Á! , æá^áÁ Á^á^ Á^Á^ ÖÖ }	FÍ	EÁP [OÁ •^ FKQ , æá GÖPÖÁæE HÖPÖBÁQ , æá	P [OÁ •^
OEÖÖVÁPUEEÜÖÖUVÁEY @} ÖE ^} OÖ [EÖ •, ^!Á } ÖÁ } ÁÁ Q , æáEÖ } áÁ^Á^ ÖÖ } ÁÖ Á^Á • } ^áE	FÍ	E	E

OEÖÖÁÖ [~] ÁÖæä ~ ÖGÖÖT ÁGFI ÖÖ Á^Á^ ÖÖ } Á } Áæ ^ ÖE J

ÚÖT ÁGFI	ÓVP	ÜÖE ÖÖ	ÖÖÖEVSV
ÜWÜÖUXQUUÁUUY ÖÖPÖÖÖÁEAV@Á} d^ Á^á^ Á^Á &@& Á@Á^ ^!ÖE [Áæ •, [ÁÁ @ } Á^] ^!ÖE [Á &ÖE } ^Á; [~] Áæ •E	F	EÜ~ FKU }	EÜ~
OEÖÖVÁEÖÖVÁÖÖÖÁEAV@Á} d^ Á^á^ Á^Á^ ÖE ^} OÁ Á æ ^} OÖEÁ^ • d ÖE } E	G	EÖE , FÖÖÁ^ ÖEÖE GQ , æáÁÖE	EÖE ,
Y UÜSÁ UÖÖÁV ÖÜÁEAV@Á} d^ Á^á^ Á^Á } ÖÁ } Á Ö ^!Á ÖE ^} OY [ÁÖæE	H	EEÖG €	Í €
ÖWUËY UÜSÁ UÖÖÁUUVQPAEAV@Á} d^ Á^á^ Á^Á , @} ÁÖE } ^Á@Á^ ^} OY [ÁæEÖEÖEÖE] áEÄ , @} Á } Á^ ^} OÖEÖE q E [Á } ÖE FÖÖÖÖÖEÖE!Á } Ö! • ÖE } EÖE ^} OÁæ^Á } ÁÁ^Á &ÖE } ^áÁÁ } [ÁæE GÖÖÖÖÖEÖEÖEÖE!Á } Ö! • ÖE } Á! ÁÖE! Áá * } EÄ æ ^} OÁæ^Á } ÁÁ^ÁÖE } ^áÁÁ } [ÁæE HÖÖÖÖÖEÖEÖEÖE!Á } Ö! • ÖE } Á! ÁÖE! Áæ ^Á [~ Ö [á * ÖEÖEÖE ^} OÁæ^Á } ÁÁ^ÁÖE } ^áÁÁ } [Á •æE I ÖÖÖÖÖEÖEÖEÖEÖEÖE!Á } Ö! • ÖE } Á! ÁÖE! Áá * } Á [ÁÖE! Áæ ^Á^ Ö [á * ÖEÖEÖE ^} OÁæ^Á } ÁÁ^Á &ÖE } ^áÁÁ } [ÁæE	I	EÖE FÖEÖEÜÖ * GÖEÖEÜÖ HÖEÖEÜÖ * EÜÖ	EÖE
ÖEPUWÖÖÖT ÖP VÁUÖÁEAV@Á} d^ Á^á^ Á^Á^ ÖE ^Á [ÁÖ } [~] &{ ^} OY @} Á^ ^} ÖE •, ^!ÁÖE { á * Á OEÖÖÁÖE	Í	EÜ~ FKU }	EÜ~

PGM 214	BTN	RANGE	DEFAULT
GROUP Q-CNT DISPLAY -- This entry defines display of Queuing count of ACD call.	6	0:Off 1:On	0:Off
Q-CNT INTERVAL -- This entry defines display interval seconds of Queuing count of ACD call.	7	0:Real Time 1:10sec 2:20sec 3:30sec 4:40sec 5:50sec 6:60sec	0:Real Time
LOGIN PASSWD CHECK -- This entry defines check the password when agent log-in.	8	0:Off 1:On	0:Off
LOGIN AGENT STATE -- This entry defines usage of default Agent State option when agent log-in.	9	0:Ready state 1:DND state 2:Work state	0:Ready state
LOGIN AUTO ANSWER -- This entry defines usage of Agent Auto Answer option when agent log-in.	10	0:Off 1:On	0:Off
LOGIN AUTO WORK -- This entry defines usage of Agent Auto Work option when agent log-in.	11	0:Off 1:On	0:Off
LOGIN HANDSET -- This entry defines usage of Agent Headset option when agent log-in.	12	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode	1:Handset Mode
LOGOUT HANDSET -- This entry defines usage of Agent Headset option when agent log-out	13	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode 4:Logon Mode	1:Handset Mode
LOGOUT RESTRICTION -- This entry defines restriction of Logout State Agent.	14	0:Not use 1:CO outgoing 2:All call	0:Not use
CO ANSWER TIME -- This entry defines when the ACK message is sent to caller party.	15	0:Queued to group 1:Agent Answer	0:Queued to group
INFO DATA PRINT -- This entry defines usage of ACD Call Traffic Information data Print or Not. Information Traffic data will be printed at Information-Print Port.	16	0:Off 1:On	0:Off

Station Port

Station Port Attribute (PGM 124) ... see details on [page A-27](#)

PGM 124	BTN	RANGE	DEFAULT
MSG WAIT INDICATION -- this menu determines the way to notify a station to wait message.	1	01-48	MW Remind Tone
APPLY DIFF RING -- determine user's differential ring mode. Applying to all ring mode or normal ring mode.	2	1-9	All Ring
ICM DIFF RING ID -- set the intercom differential ring ID – usually 1-4 is valid.	3	000-254	On
CO DIFF RING ID -- set the CO line differential ring ID – usually 1-4 is valid.	4	000-254	Off
COS APPLY OPTION -- determine whether the applied COS is the COS of SUB-DN or COS of MY-DN when station accesses SUB-DN.	5	0: SUB-DN 1: MY-DN	SUN-DN
HOOK FLASH WHEN TRANSFER -- Determine the operation when user press hook-flash button while transferring call. 0. Cancel transfer : drop current call and recover previous call 1. Broker : hold current call and recover previous held call 2. Conference: establish 3-way conference call. 3. Broker-Conf : Operated Broker and Conference when a user hook flash within 2 sec	6	0: Cancel Transfer 1: Broker 2: Conference 3: Broker-Conf	Cancel Transfer
OFF-HOOK ON PAGED -- when lifting handset while listening to paging message, user can make another call or continue to listen. 0: continue to listen to paging message 1: stop listening, seize a remaining DN, and hear dial-tone. User can make a another call.	7	0: Paged 1: Dial Tone	Paged
PLA -- Preferred Line Answer enables Ringing Line Preference for the station. Calls that ring the telephone are answered by going off-hook. (Reserved).	8	0: Off 1: On	On
PICKUP BY DSS BUTTON -- this value determines the method of pickup when pressing DSS button.	9	0: Disable 1: Group Pickup 2: Direct Pickup	Direct Pickup
CLI IP ADDRESS -- CLI IP Address.	10	IP Address	0.0.0.0
ACD AGENT PRIORITY -- when a station is a member of an ACD Group, this value will be used for priority as agent.	11	01-20	10

PGM 213	BTN	RANGE	DEFAULT
HOLIDAY SERVICE -- This entry defines how to reroute ACD call when group status is Holiday Status.	5	0: Release 1: Announcement. 2: Forward	Release
HOLIDAY FWD DEST -- When Holiday Service type is Forward, applied destination can be assigned.	6	-	-
OVERFLOW SERVICE -- This entry defines how to reroute ACD call when group status is Overflow Status.	7	0: Release 1: Announcement 2: Forward	Release
OVERFLOW FWD DEST -- When Overflow Service type is Forward, applied destination can be assigned.	8	-	-
MAX QUEUING COUNT -- This entry defines MAX queuing call count. If queuing ACD Call count is over the max q-count, ACD group state will be changed to Overflow Status.	9	00-99	10
QUEUING ANNC STEP -- This entry defines queuing announcement play service step. One ACD Group can have max 5 announcements for queuing ACD Call.	10	1-5	1
REPEAT COUNT -- This entry defines total queuing announcement repeat service count. If this entry is defines as One or More Times service, Queuing Announcement will be played from 1st to defined Step. And then from Repeat Position Queuing Announcement will be restarted to defined step until Repeat Count.	11	0:No Repeat 1:One Time 2:Three Times 3:Five Times 4:Ten Times 5:Twenty Times	No Repeat
REPEAT POSITION -- This entry defines Repeat Announcement Start Position.	12	1-5	1
FWD AFTER QUEUING -- This entry defines reroute usage after queuing time over.	13	0: Off 1: On	Off
Q-FWD DEST -- Reroute destination after queuing time over.	14	-	-

ÚÓT ÁGFH	ÓVP	ÜCE ÖÖ	ÖÖÖEVSV
OEÖÖVÁPUEEÜÁJUVQ PÁV@Á} d`Á^ã^Á [Eã •, ^!Á CE^ } óP [EÖ •, ^!Á & e^Áã [~ OEÖÖEãE FÁP [ó^•^ GQ , eãÁ & eãÁ q Á^Á! , eãÁ^Á Á^ã^Á^Á^• qãã } HÖPÖKCE^ } ó^•^Á q Á^Á&e } ^ÁÁe q { eãã^ Á ÖPÖÁ • eãE I ÖPÖBÁQ , eãÁCE^ } ó^•^Á q Á^Á&e } ^Á^ ÁÖPÖÁ eãE eãÁÖÖÖEã q Á^Á! , eãÁ^Á Á^ã^Á^Á^• qãã }	FÍ	€ÁP [ó^•^ FKQ , eãÁ GÁÖPÖÁ eã^ HÁÖPÖBÁQ , eãÁ	P [ó^•^
OEÖÖVÁPUEEÜÁÖÖUVÁV @ } ÁE^ } óP [EÖ •, ^!Á } qã } ÁÁ Q , eãÁEã } ãÁ^Á^• qãã } Áeã Á^Áe •ã } ^ÁE	FÍ	È	È

OEÖÖAÖ:[~] ÁÖedã ~ eGÁÚÓT ÁGFI DÖ Á^Á^Á^eã • Á } Á eã ^ ÖÈ J

ÚÓT ÁGFI	ÓVP	ÜCE ÖÖ	ÖÖÖEVSV
ÜWÜÖUXQUUÁJUY ÖÖPÖÖSÁV@Á} d`Á^ã^Á^•Á &@& Á@Á^ } ^!çã [!Á eã •, [!Á @ } Á^ } ^!çã [!Á &e } ^Á; [~] Á eã • E	F	€K~ FKU }	€K~
OEÖÖVÁEÖÖP VÁÖÖSÁV@Á} d`Á^ã^Á^•Á eã^ } óÁ Á eã^ } eãÁÁ^• dãã } È	G	€C , FIÖá^&eã GQ , eãÁ&eã	€C ,
Y UÜSÁ UÖÖÁQ ÖÜÁV@Á} d`Á^ã^Á^•Á !eãÁ } Á qã ^!Á ÁE^ } óY [!Á eãE	H	€€FEG €	î €
ÖWUËY UÜSÁ UÖÖÁJUVQ PÁV@Á} d`Á^ã^Á^•Á , @ } Á&e } ^Á@Áe^ } óY [!Á eãE ÁÖEÁ } ãÁE , @ } Á } ^Áe^ } ó^•^Áe q E [!Á] qã } E FÁÖÖSÁÁ^Á } ç^!•eã } Ee^ } ó^•^Á q Á^Á &e } ^ÁÁÁ Á [!Á eãE GÁÖÖSÁÁÖÖÁ^Á } ç^!•eã } Á!Áe^!Áã *ã *E eã^ } ó^•^Á q Á^Á&e } ^ÁÁÁ Á [!Á eãE HÁÖÖSÁÁÖÖÁ^Á } ç^!•eã } Á!Áe^!Á eãÁ [~ ç [q * ÁeãEe^ } ó^•^Á q Á^Á&e } ^ÁÁÁ Á [!Á • eãE I ÁÖÖSÁÁÖÖÁ^Á } ç^!•eã } Á!Áe^!Áã *ã *Á [!Áe^!Á eãÁ^ ç [q * ÁeãEe^ } ó^•^Á q Á^Á &e } ^ÁÁÁ Á [!Á eãE	I	€Öeã FIÖeãEÜã * GÖeãÁÜÖ HÖeãEÜã * EÜÖ	€Öeã
ÖEPUWPÖÖT ÖP VÁVÜÖÁV@Á} d`Á^ã^Á^•Á eãÁ [ÁE } [~] &{ ^ } óY @ } Áe^ } eã •, ^!Áeã { q * ÁÁ OEÖÖAÖE	Í	€K~ FKU }	€K~

PGM 214	BTN	RANGE	DEFAULT
GROUP Q-CNT DISPLAY -- This entry defines display of Queuing count of ACD call.	6	0:Off 1:On	0:Off
Q-CNT INTERVAL -- This entry defines display interval seconds of Queuing count of ACD call.	7	0:Real Time 1:10sec 2:20sec 3:30sec 4:40sec 5:50sec 6:60sec	0:Real Time
LOGIN PASSWD CHECK -- This entry defines check the password when agent log-in.	8	0:Off 1:On	0:Off
LOGIN AGENT STATE -- This entry defines usage of default Agent State option when agent log-in.	9	0:Ready state 1:DND state 2:Work state	0:Ready state
LOGIN AUTO ANSWER -- This entry defines usage of Agent Auto Answer option when agent log-in.	10	0:Off 1:On	0:Off
LOGIN AUTO WORK -- This entry defines usage of Agent Auto Work option when agent log-in.	11	0:Off 1:On	0:Off
LOGIN HANDSET -- This entry defines usage of Agent Headset option when agent log-in.	12	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode	1:Handset Mode
LOGOUT HANDSET -- This entry defines usage of Agent Headset option when agent log-out	13	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode 4:Logon Mode	1:Handset Mode
LOGOUT RESTRICTION -- This entry defines restriction of Logout State Agent.	14	0:Not use 1:CO outgoing 2:All call	0:Not use
CO ANSWER TIME -- This entry defines when the ACK message is sent to caller party.	15	0:Queued to group 1:Agent Answer	0:Queued to group
INFO DATA PRINT -- This entry defines usage of ACD Call Traffic Information data Print or Not. Information Traffic data will be printed at Information-Print Port.	16	0:Off 1:On	0:Off

- d) Supervisor can change max Queuing Count and also can change Queuing Service Announcement Step.
Supervisor also can make rule how to handle ACD call when all of queuing announcement service is over. And After Queuing Forward Destination can be changed.
2. Supervisor and Sub-Supervisor Answer the Queued ACD call.
Supervisor and Sub-Supervisor can find queued ACD call count on the LCD. And if {ACD Supervisor Queued Call Answer} feature code is saved at flex button, this flex button's color will be changed to steady-on.
 - 1) First Queued ACD call Answer by Supervisor
 - a) When there are queued ACD call, if Supervisor or Sub-Supervisor press {ACD Supervisor Queued Call Answer} feature codes, Total queued ACD call count and sub-menu will be displayed on LCD.
 - b) If supervisor choose Check First Queued Call menu, CLI of first Queued call will be display. At that time, if supervisor choose Answer option, queued ACD call will route to Supervisor.
 - 2) First Queued ACD call Reroute
 - a) When there are queued ACD call, if Supervisor or Sub-Supervisor press {ACD Supervisor Queued Call Answer} feature codes, Total queued ACD call count and sub-menu will be displayed on LCD.
 - b) If supervisor choose Check First Queued Call menu, CLI of first Queued call will be display. At that time, if supervisor choose Reroute option, current registered Forward Destination after Queuing Announcement will be displayed.
 - c) If press [HOLD] or "#" button, queued ACD call will be rerouted to registered destination.
OR
 - d) If dial other Tel-Number and then press [HOLD] or "#" button, queued ACD call will be rerouted to new dialed Tel-Number.
3. Supervisor and Sub-Supervisor Monitoring Agent.
Supervisor and Sub-Supervisor can check and monitor agent's status. And also Supervisor and Sub-Supervisor can overhear agent's conversation.
 - 1) Agent Status Monitor by Supervisor on Digital Phone
 - a) Supervisor can check agent's state with {ACD Supervisor Agent State Check} feature code. If supervisor dial or press flex button registered as {ACD Supervisor Agent State Check} feature code, first agent state will be displayed on LCD.

OPERATIONS

Group Forward / Night / Holiday Status Change by Supervisor

1. Dial {ACD Supervisor Group Forward / Night / Holiday Status} feature code.
OR
2. Press flex button registered as {ACD Supervisor Group Forward / Night / Holiday Status} feature code.
3. Group Status will be changed.

ACD Group Management or ACD Agent State Check With Web-Admin

1. Connect Web-Admin Page of MBX IP System
2. Choose Station Program Menu.
3. Enter Supervisor Number and Password.
4. ACD Group Management Menu will be displayed on the Left Menu List.
5. Supervisor can change each Group Status rules and Destination.
6. Supervisor and Sub-Supervisor can check Agent Log-In/Out, Ready, DND, Work State. And also Agent's Priority can be displayed.
7. Supervisor and Sub-Supervisor can change Agent's State and Priority.

ACD Group Call or Agent Traffic Check with Web-Admin

1. Connect Web-Admin Page of MBX IP System
2. Choose Station Program Menu.
3. Enter Supervisor Number and Password.
4. ACD Group Traffic Menu will be displayed on the Left Menu List.
5. Supervisor and Sub-Supervisor can check Group Call Traffic and Agent Traffic Data.
6. Supervisor and Sub-Supervisor can Clear Group Call Traffic and Agent Traffic Data.

First Queued Call Answer or Reroute by Supervisor

1. If there are queued calls, {ACD Supervisor Queued Call Answer} feature code is saved at flex button.
2. Flex button's color will be changed to steady-on.
3. Dial {ACD Supervisor Queued Call Answer} feature code.
OR
4. Press flex button registered as {ACD S Supervisor Queued Call Answer} feature code.
5. Choose sub-menu then First Queued Call CLI will be display
6. Press "1" then queued call will be routed to Supervisor.
OR

I È Ú!^••ACÁ) aÁÖãA^|È~ { à^!È
 I È Ú!^••AAÁ|PUSÖá~ c} È@) Á^~^áA&c|) q|A^A[~ c^áA ÁÖãA^|È~ { à^!È

Silent Monitor by Supervisor

FÈ ÖãAÁÖÖÁ~]^\cã[!Aq^ c^ [] q|!^Aæ!^A&| á^È
 OR
 GÈ Ú!^••Á^c^~ c} Á^* a c!^áA ÁÖÖÁ~]^\cã[!Aq^ c^ [] q|!^Aæ!^A&| á^È
 HÈ ÖãA^•á^Á^ c^} c^ { à^!È
 I È c^} c&[c^!•æ} Á q|A^A c^! @æÈ

CONDITIONS

- " GÁÖÖÁ~]^\cã[!A: [~] Aq|, æáA^P| |ãæ A^ã @A [á^Aæ!^A&| á^A Áæ^á^A Á^c^~ c} È @) Á! [~] Áææ •A Á [{ ^Áææ •È@ Á^c^~ c} c&| [! Á q|A^A&@) *^áA c^ Á c^æ^ È } È
- " Ö!q^* Á! [~] Áææ •A Áq|, æáA^P| |ãæ A^ã @Áææ •ÈÁ~]^\cã[!Aæ^ Á! Á!^••Á , ÖÖÁ~]^\cã[!A: [~] Aq|, æáA^P| |ãæ A^ã @A [á^Aæ!^A&| á^A c^} È@) Á *! [~] Áææ •Á q|A^A&@) *^áA Á! [! æÁææ •È

PROGRAMMING

Numbering Plan

Øæ!^A~ { à!q^* Á|æ) ÁÜÖT ÁFGD Á^A^æ^ Á) Áæ^ ÖEÍ

Station Group

00000:[~] Ác^•ã { ^} ÁÜÖT ÁFGD Á^A^æ^ Á) Áæ^ ÖEÍ

ÚÖT ÁFG	ÓVP	ÜÖEÖÖ	ÖÖÖEVS
ÖÜUWÁ^c^ ÖÁÖÖÖÁ: [~] Áæ^ Á^È	F	ÚæÖÖÖÖÁ: [~] Á~ { à^!Á BÁ) áÁÖÖÖÁ: [~] Á~ { à^!	È
ÜÖUXÖÖÁ UÖÖÁÖÖÖÁ: [~] Áææ •È	G	È^P [! { æ FÁÖ! [~] Aq , æáA GÁ c^!- , Á HÁã @ I HÁ ãæ Í HÁ [Á^!cã^	P [! { æ
ÁÖP^E VÁU ÁÖÖÖÁ^} æ^ Á~ { à^!È	H	FÈ Á^ ÖYÁÜÈÈÈÈ FÈ Á^ ÖYÁÜÈÈÈÈ	F
VÖ ÖÁÖÖÖÁ ÖÖY ÁÖÖÖÁ: [~] Áq^ Á^æ^ Á^È	I	FÈ	F

PGM 212	BTN	RANGE	DEFAULT
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

ACD Group Attribute1 (PGM 213) ... see details on [page A-77](#)

PGM 213	BTN	RANGE	DEFAULT
SUB-SUP ASSIGN -- This entry assigns Sub-Supervisor in ACD Group.	1	-	-
GROUP FWD DEST -- When ACD Group status is Group Forward Status, all of ACD call will be forwarded to this entry assigned destination.	2	-	-
NIGHT SERVICE -- -- This entry defines how to reroute ACD call when group status is Night Status.	3	0: Release 1: Announcement 2: Forward	Release
NIGHT FWD DEST -- When Night Service type is Forward, applied destination can be assigned.	4	-	-
HOLIDAY SERVICE -- This entry defines how to reroute ACD call when group status is Holiday Status.	5	0: Release 1: Announcement. 2: Forward	Release
HOLIDAY FWD DEST -- When Holiday Service type is Forward, applied destination can be assigned.	6	-	-
OVERFLOW SERVICE -- This entry defines how to reroute ACD call when group status is Overflow Status.	7	0: Release 1: Announcement 2: Forward	Release
OVERFLOW FWD DEST -- When Overflow Service type is Forward, applied destination can be assigned.	8	-	-
MAX QUEUING COUNT -- This entry defines MAX queuing call count. If queuing ACD Call count is over the max q-count, ACD group state will be changed to Overflow Status.	9	00-99	10

PGM 214	BTN	RANGE	DEFAULT
AUTO-WORK MODE OPTION -- This entry defines when change the agent work state. (It is applied, when only agent has auto-work option). 1 CALL: after conversation, agent state will be changed to work state. 2 CALL, RING: after conversation or after ringing, agent state will be changed to work state. 3 CALL, OG: after conversation or after make outgoing call, agent state will be changed to work state. 4 CALL, RING, OG: after conversation or after ringing or after make outgoing call, agent state will be changed to work state.	4	0:Call 1:Call, Ring 2:Call OG 3:Call, Ring, OG	0:Call
ANNOUNCEMENT USE -- This entry defines usage of Announcement when agent answer incoming ACD Call.	5	0:Off 1:On	0:Off
GROUP Q-CNT DISPLAY -- This entry defines display of Queuing count of ACD call.	6	0:Off 1:On	0:Off
Q-CNT INTERVAL -- This entry defines display interval seconds of Queuing count of ACD call.	7	0:Real Time 1:10sec 2:20sec 3:30sec 4:40sec 5:50sec 6:60sec	0:Real Time
LOGIN PASSWD CHECK -- This entry defines check the password when agent log-in.	8	0:Off 1:On	0:Off
LOGIN AGENT STATE -- This entry defines usage of default Agent State option when agent log-in.	9	0:Ready state 1:DND state 2:Work state	0:Ready state
LOGIN AUTO ANSWER -- This entry defines usage of Agent Auto Answer option when agent log-in.	10	0:Off 1:On	0:Off
LOGIN AUTO WORK -- This entry defines usage of Agent Auto Work option when agent log-in.	11	0:Off 1:On	0:Off

- a) Total Calls Count
- b) Unanswered Call Count
- c) Average Call Time 00:00 (minute: second)
- d) Average Ring Time 00:00 (minute: second)
- e) Busy Count and Time 00:00:00 (hour: minute: second)
- f) Number of calls count in Current Queue
- g) Average Queued Time 00:00 (minute: second) and Longest Queued Time 00:00 (minute: second)
 - Supervisor can check all of data with Volume Up/Down Key or Up / Down in Navigation Key.
 - During checking the Group Call Traffic information, Supervisor can clear all of Group Call Traffic with [SPEED] button. If Supervisor uses 3-soft keyset, Delete menu will be displayed at 3-soft menu.
 - Average Call time means average conversation time of all of agent ACD call.
 - Busy count means how many times all of agents are busy. And Busy time means total accrued Times of Agent's busy state.
 - Information about Queued data will be always computed when there are queued ACD calls in Queue

2) Agent Call Traffic

Agent's ACD call data will be saved and Traffic data format is just like bellow lists.

- a) Total Calls Count
- b) Unanswered Call Count
- c) Average Call Time 00:00 (minute: second)
- d) Average Ring Time 00:00 (minute: second)
- e) Last Log-In Time 00:00:00 (hour: minute: second)
 - When Supervisor enter Agent Call Traffic feature, first agent data will be displayed. And Supervisor can check all of agent data with Volume-Up/Down button or Up/Down in Navigation Key.
 - During checking the Group Call Traffic information, Supervisor can clear all of Group Call Traffic with [SPEED] button. If Supervisor uses 3-soft keyset, Delete menu will be displayed at 3-soft menu.
 - Average Call time means average conversation time.
 - In case of Last Log-In time, if check at ACD Group Call Traffic web page in Station Program of Web-Admin, Log-In date also can be checked.

2. ACD Group Call Traffic web page in Station Program

6	Average call service time (ex., 25=0 min 25 sec)
7	Total busy time (ex., 64=1 min 04 sec)
8	Number of current queued calls
9	Longest queued time
0	Average queued time
lf	Line Feed (0x0A)
cr	Carriage Return (0x0D)

Supervisor or Sub-Supervisor can print Group Call Traffic data at Information-Print port manually.

1. Press {ACD Supervisor Traffic Check} feature code.
2. Choose Group Traffic data.
3. Press [Hold/Save] button for printing data to Information-Print Port.

Supervisor or Sub-Supervisor can print Agent Call Traffic data at Information-Print port.

1. Press {ACD Supervisor Traffic Check} feature code.
2. Choose Agent Traffic data.
3. Find desired Agent number with "*" or "#" button, Left/Right in Navigation Key
4. Press [Hold/Save] button for printing data to Information-Print Port.

Agent Call Traffic Format

~ 1 = 2 = 3 = 4 = 5 cr lf

Field(s)	Description
~ (tilt)	Means start of ACD statistics and is always located at first column
= (equal)	Delimiter between each meaningful data
1	Each Agent number
2	Total call counter
3	Unanswered call counter
4	Average ringing time (ex., 96=1 min 36 sec)
5	Average service time (ex., 96=1 min 36 sec)
lf	Line Feed (0x0A)
cr	Carriage Return (0x0D)

ACD Group Attribute1 (PGM 213) ... see details on [page A-77](#)

PGM 213	BTN	RANGE	DEFAULT
SUB-SUP ASSIGN -- This entry assigns Sub-Supervisor in ACD Group.	1	-	-
GROUP FWD DEST -- When ACD Group status is Group Forward Status, all of ACD call will be forwarded to this entry assigned destination.	2	-	-
NIGHT SERVICE -- -- This entry defines how to reroute ACD call when group status is Night Status.	3	0: Release 1: Announcement 2: Forward	Release
NIGHT FWD DEST -- When Night Service type is Forward, applied destination can be assigned.	4	-	-
HOLIDAY SERVICE -- This entry defines how to reroute ACD call when group status is Holiday Status.	5	0: Release 1: Announcement. 2: Forward	Release
HOLIDAY FWD DEST -- When Holiday Service type is Forward, applied destination can be assigned.	6	-	-
OVERFLOW SERVICE -- This entry defines how to reroute ACD call when group status is Overflow Status.	7	0: Release 1: Announcement 2: Forward	Release
OVERFLOW FWD DEST -- When Overflow Service type is Forward, applied destination can be assigned.	8	-	-
MAX QUEUING COUNT -- This entry defines MAX queuing call count. If queuing ACD Call count is over the max q-count, ACD group state will be changed to Overflow Status.	9	00-99	10
QUEUING ANNC STEP -- This entry defines queuing announcement play service step. One ACD Group can have max 5 announcements for queuing ACD Call.	10	1-5	1
REPEAT COUNT -- This entry defines total queuing announcement repeat service count. If this entry is defines as One or More Times service, Queuing Announcement will be played from 1st to defined Step. And then from Repeat Position Queuing Announcement will be restarted to defined step until Repeat Count.	11	0:No Repeat 1:One Time 2:Three Times 3:Five Times 4:Ten Times 5:Twenty Times	No Repeat
REPEAT POSITION -- This entry defines Repeat Announcement Start Position.	12	1-5	1

PGM 214	BTN	RANGE	DEFAULT
ANNOUNCEMENT USE -- This entry defines usage of Announcement when agent answer incoming ACD Call.	5	0:Off 1:On	0:Off
GROUP Q-CNT DISPLAY -- This entry defines display of Queuing count of ACD call.	6	0:Off 1:On	0:Off
Q-CNT INTERVAL -- This entry defines display interval seconds of Queuing count of ACD call.	7	0:Real Time 1:10sec 2:20sec 3:30sec 4:40sec 5:50sec 6:60sec	0:Real Time
LOGIN PASSWD CHECK -- This entry defines check the password when agent log-in.	8	0:Off 1:On	0:Off
LOGIN AGENT STATE -- This entry defines usage of default Agent State option when agent log-in.	9	0:Ready state 1:DND state 2:Work state	0:Ready state
LOGIN AUTO ANSWER -- This entry defines usage of Agent Auto Answer option when agent log-in.	10	0:Off 1:On	0:Off
LOGIN AUTO WORK -- This entry defines usage of Agent Auto Work option when agent log-in.	11	0:Off 1:On	0:Off
LOGIN HANDSET -- This entry defines usage of Agent Headset option when agent log-in.	12	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode	1:Handset Mode
LOGOUT HANDSET -- This entry defines usage of Agent Headset option when agent log-out	13	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode 4:Logon Mode	1:Handset Mode
LOGOUT RESTRICTION -- This entry defines restriction of Logout State Agent.	14	0:Not use 1:CO outgoing 2:All call	0:Not use
CO ANSWER TIME -- This entry defines when the ACK message is sent to caller party.	15	0:Queued to group 1:Agent Answer	0:Queued to group

System Programming Tables

The MBX IP system can be programmed to meet each customer's individual needs. System programming may be accomplished by entering the "PROGRAM MODE" at an assigned Admin Station or using the Web Admin (refer to the "MBX IP Web Administration Guide"). This section provides general information.

Other sections include:

- Section 2 - provides a description for data entry using the Admin Station.

NOTE: Some parameters are available through Web Admin and not the Keyset Admin.

- Appendix B - provides an index to database entries, default value charts for the Flexible Numbering Plan, Fixed Function dial codes and the entire database. Indices and charts are helpful references when entering data into the system database.

Initialization

When power is applied to the system or the MPB Reset button is pressed, the system will initiate the "Power-up" routine. During the Power-Up routine the system will check the database default switch (1st position of the MPB DIP-switch), refer to the "MBX IP Hardware and Installation Guide".

If the switch is in the ON position:

the system will perform a simple Power-Up routine; clear all scratch-pad memory, load run-time programs, establish communications with each registered board and DTIM/SLTM gateway Module and MBX IP terminal, send RESTART commands and load appropriate settings to the Modules and terminals. If a Module or terminal does not respond after several attempts, the system places the device in an out-of-service mode but maintains the database settings. Once the Power-up routine is complete, the system will conduct normal operations.

If the database default switch is in the OFF position:

in place of the Power-Up routine, the system will perform the full Initialization procedure. The initialization procedure will set the system database except DECT registration data to default values, refer to Initialization section. Once initialization is complete, set the initialization switch to the ON position to protect the database.

Program Menu Structure

Öææææ^ÁÚa{ ä ä dææ } Á Á&&{ }|ä @äÁ^Á} c!ä * ÁÜÜÜÖÜcF ÁÜÜÖÜÁV[{ Á@ÁäÁ äÁ
 [ÁÁ @ } ^Á!Á^Á&cä * Áæ Á{ Á{ Á@Áæä ææ } Áæ ^Á Á@Á^ÁÚa{ ä Á^Á!Á Á ÖYÁÚÁ
 Y^ÁÚa{ ä ä!ææ } ÁÖ ä^ÁÁ

Öææææ{ • Á^Á! * ä ä^ÁÁ ÁÁ!~ } Á äÖÁV{ { } Áe^&cFÁ Áææ } Á^•c{ Á^ { à!ä * Á!æ } Á
 ^cFÁV{ • Á æ Á^Á!c@!Á!~ } ^áÁ!{ ä * ÁÁ |cææ^!áÁ } ^Ád~&c!^Á Á @, } Á Á@Á
 { ||, ä * Áæ!É

Administration Menu Table

Administration	Menu	
Ú!^É![*!æ { ^áÖæææ	Š{ &cææ } Á![*!æ	FEE
	Ú!{ cÖE•ä }{ ^}c	FEF
	Š{ * äæÁ! cÖE•ä }{ ^}c	FEH
	ÖÖÖVÖVÖVÖV Á Á! :c	FEl
	ÖÉÜ@ } ^Á^* ä dææ }	FÉl
	ÖVÖ ÖVÖV ÖVÖV Á^* ä dææ }	FÉl
	ÖÁÖá!^•Á!æ	FÉl È-EJ
p~ { à!ä * Á!æ	p~ { à!ä * Á!æ Á^ } ^	FFÉ
	U~•c{ Á^ { à!ä * Á!æ	FFF
	Ö^cá!^ÁÚææ } Á^ { à!	FFG
	Öæ!^Á^ { à!ä * Á!æ	FFH
	ÖÜÁÖ!~ } ÁÖ&••ÁÖ! á^	FFI
	Úææ } ÁÖ!~ } Á^ { à!	FFl
	ÖÖÖÁÖ!~ } Á^ { à!	FFl
Úææ } Á! :cÖæææ	Úææ } Á^ } ^	FGÉ
	Úææ } Á! :cÖcä~ c^	FGFÈ-G
	Úææ } Á^cá!^ÁÖ c{ }	FG
	Úææ } ÁÖVÖVÖVá!^••	ÈÈÈ
Úææ } Á^ { à!Öæææ	Úææ } ÁÖPÁE•ä }{ ^}c	FHE
	Úææ } ÁÖPÁE/VÜ	FHFÈ-H
	Úææ } ÁÜÜÁE•ä }{ ^}c	FHl
	Úææ } ÁE c ÖææÖcä~ c^	FHl
	Ú!^•^cÖæÁÖ! , æá	FI G
	ÖæÁÖ! , æá	FI H

Administration	Menu	
Station Number Data	Station VMIB Attribute	145
	Mobile Phone Attribute	146
	CO/IP Group Access	150
	Page Zone Access	151
	Command Group Access	152
CO Line Data	CO Line Attribute	160-163
	Incoming CO ATTR	165-166
	CO Ring Assignment	167
	Normal/DISA CO ATTR	168
	Incoming CO Alternative	169
	Outgoing CO ATTR	170-171
	Outgoing CO Alternative	173
	CO Inter-Digit Timer	174
	DTMF Send Interval	175
	CO COS Assignment	177
	CO-to-CO Attribute	179
	CO Group Access Code	180
	Alternative Ring Table	181
Station Group Data	Station Group Assign	200
	Station Group ATTR	201-202
	Voice Mail Group	203
	Call Pick-Up Group	204
	Page Group	205
	Command Conference Group	206
	PTT Group	208
	Interphone Group	209
	Pilot Hunt Group	210-211
	ACD Group Assignment	212
	ACD Group ATTR	213-214
	ACD Group Announcement	215
System Data	System Timer	222
	System Attribute	223
	System Password	226
	Alarm Attribute	227
	External Control Contact	228

Administration	Menu	
Ü•c{ Äää	T•äÄ ~!&	GGJ
	ÜÜEGHÄ ^cä*	GHÉ
	Ü^:äÄ {!Ä ^&cä}	GHF
	ÜT ÖÜ/Äcä~c	GHG
	Ü•c{ Äää/ÄVä ^	GHH
	SÖÖ/Äää @*Äää	GHI
	ÜÜÜ/Äcä~c	GHI
	T[ää^Äcä~c	GHI
	Qc!& { Ä•^Äää	GHI
	ÖäÄ } ^Äää/Äää ^	GÉ
	Öc^& cä^Ä ^&^cä^ Äc•ä }	GF
	Öc^& cä^Ä&&••	GG
	ÜÜVÜ/Äcä~c	HH
	Y^ä/Ä&&••/Äc @ ä ää }	HH
Vää ^Äää	V /Äc& ^ cä ^Äää ^	GÉ
	Öää/ÄÖ } cÄää ^	GÉGG
	Ü•c{ ÄVä ^Äää ^	GÉGI
	SÖÜVä ^Äää ^	GÍ
	P äää ÄVä ^Äää ^	GÍ
	Ü•c{ ÄJ ^Äää ^	GÍ
	Ö(^!*^) & Ä ä^Äää ^	GÍ
	Öä } [~] & { ^ } cÄää ^	GJ
	ÖÖÜVää ^	GÉ
	ÖSÖVää ^	GG
	ÖSÖ } c^!•ä } Äää ^	GH
	V } ^Ä ^~^) & Äää^) &	GÍ
	Üä*Äää ^	GÍ
	Üä*Ä ^~^) & Äää^) &	GÍ
X äÄÄ äÄ/ÄcÄ ^	GJ	
V^} ää cÄää	ÖV/ÖÄ [~] /Äc•ä } { ^ } c	GÉ
	ÖV/ÖÄ [~] /ÄcVÜ	GÉGG
	Pä @/ÖV/ÖÄ [~] /Äc•ä }	GÍ
	Pä @/ÖV/ÖÄ [~] /ÄcV	GÍÉI
	V^} ää cÄää~c	GÉGF
	V^} ää cÄ [~] /Ä&&••	GH

Administration	Menu	
Tenant Data	CO Call Restriction	284-285
	Local Call Prefix Table	286
	Long Call Prefix Table	287
	International Call Prefix	288
	Tone Table	290
Board Data	ISDN Board Attribute	300
	ISDN Clock Priority	301
	VOIB/VMIB Board Attr	305
	Reset Board	310
Voice Network	Networking Attr	320
	Networking Numbering	321
T-Net Data	T-Net Attribute	330
	CM Attribute	331
	ISDN Attribute	333
	T-Net Board Attribute	334
	IP-Phone T-Net Enable	335
H.324 Data	H.323 Routing Attribute	360
	H.323 VOIB Attribute	361
	H.323 Incoming Attr	362
	GK Attribute	363
SIP Data	SIP User ID Data	370
	SIP CO Service	371
	SIP Station Attribute	380
	SIP STA Service ATTR	381
Zone Data	Zone Attribute	395
	Zone RTP Relay Group	396
	Inter Zone Attribute	397
	Station Zone Attribute	399
SNMP Data	SNMP Data	---
DECT Data	DECT Registration	0#
	DECT Attribute	490
Green Mode	Green Mode Activation	---
	Green Mode Time Setting	---
Initialization	Initialization	499

S/W Upgrade

S/W Upgrade
Øá^ÁM]] æáÁ
ÓÉY ÁM] *!æá^
W] *!æá^Á: [&^••Áá,
XT ÓÁ: [{] ÓM] *!æá^
ÓÉWÁÚ•c{ Á: ^á * ÁM /BÁ [, }]] æá
ÓÉYÓÁM] *!æá^

System Management

System	Menu
Óææææ ^Á/Ó Áá•cÈ	Óææææ ^Á: [, }]] æá
	Óææææ ^ÁM]] æáÁ
ÚT ÓÚ	ÚT ÓÚ
V^cÓææææ ^	V^cÓææææ ^Á: [, }]] æá
	V^cÓææææ ^ÁM]] æá
Øá^ÁÚ•c{	Øá^Áá, /BÁ ^á
	Øá^ÁÚ•c{ Á: { } æá }
V!æá	Uá * Á•c
	T ÚÓÁ [* Áá,
	Ú•c{ Á [* Áá,
	ÓY /BÁ ^áá•Á [* Áá,
	Pc] Á [* Áá,
	Óá Á, á@Áæ•
	ÓU Áá ^Áæ•
	Úæá } Áæ•
	ÚS/VÁ ^Á [] á: !
	Ú•c{ /SÚWÁæ•
Óæá /BÁÓæá^} &^Á: [] d [VÓT /Óæá c €È È D
	ÓUU/Óæá c F I D
	ÚVÚ/Óæá c G È H cD
	ÚS/VÁá * /Óæá^} &^c €D
	ÓÉPÚÁ [] ^ÁÓæá^} &^c FD
Ó] áé &•Á: [] d [S [& /S^ Á: •æá]
ÓÓÓVÁæá á• Á: æ } ^	ÓÓÓVÁæá á•
X [á^Á áÁ ^á	X [á^Á áÁ ^á

Station Admin Programming

LCD & Button Functions

While in the PROGRAM MODE, the Liquid Crystal Display (LCD) and Flex button LEDs of an Admin Station are used to guide and indicate status of the feature. The **dial pad** is most often used to enter data after selecting a data item using the Flex buttons. In some cases, pressing a **Flex** button will toggle the entry with the Flex button LED indicating the status (ON/OFF).

For PROGRAM CODES with multiple Flex button selections, the **volume controls** ([VOL UP] and [VOL DOWN] buttons) may be used to select the next or previous item. The **[SPEED]** button is generally employed as a delete button to erase existing entries however, where noted, it may be used to confirm a range input. Pressing the **[CONF]** button will return the screen to the 1st step of the data entry procedure for the PROGRAM CODE without storing unsaved entries.

The **[SAVE]** button is used to store data after entry. If there are no conflicts in the entered data, a confirmation tone will be received and the data stored. If a conflict exists, an error tone is provided and newly entered data is not saved. Generally, corrected data may be entered and stored without restarting the entry procedure from the 1st step.

Alphanumeric Data Entries

In some cases, an alphanumeric entry is required. Two (2) dial pad digits represent each character of an alphanumeric entry, as shown in the table on [page C-1](#).

Use the table to determine the two digits that must be entered from the dial pad for each character.

Required Data Entries

During initialization a default database is established, refer to Initialization section on [page A-1](#) and Quick Reference tables in Appendix B.

However, there are several data entries, which **MUST** be completed to assure proper operation of the system. The system employs the Country Code (refer to TRANS/PGM 100 on [page A-8](#)), to establish tone and gain plans specific to the country. Also, the MPB IP address, sub-net mask and Default Gateway (Router) IP address (refer to TRANS/PGM 108 on [page A-14](#)), must be assigned for proper external IP call operation and WAN access as well as remote Web Admin access.

Data Entry Mode

All data entry is accomplished from an Admin Station or station assigned for data entry (Station Port Attributes I (TRANS/PGM CODE 121, Flex button 5). After DB initialization, Station 100

TRANS/PGM 100	BTN	RANGE	REMARK
NATION CODE -- enables [SPEAKER] activation when a CO/IP, DSS or other feature button is pressed (handsfree).	1	4 digits	1
SITE NAME -- selects Speakerphone mode, Headset mode or Ear Mic Mode.	2	24 characters	-

Nation Codes

NATION	CODE
Œ*^} œ æ	II
Œ • d œ æ	IF
Œ ^ ! à œ æ	JJI
Œ œ @ œ æ	JIH
Œ œ * œ æ ^ • @	II €
Œ ^ œ æ ^ •	HI
Œ ^ * ã {	HG
Œ [œ æ	I JF
Œ i œ æ	II
Œ ~ } ^ ã	IIH
Œ œ ^ [[]	GH
Œ @ ^	II
Œ @ œ æ Ü Ö D	II
Œ [[{ à œ æ	II
Œ [• œ æ Ü Ö	I €
Œ ^ ~ •	HI
Œ : ^ & @ Ü [ç œ D	IG
Œ ^ } { œ \	II
Œ & œ æ [I JH
Œ * ^ } c	GE
Œ Á œ ç œ æ [I €H
Œ œ [] œ æ	G F
Œ œ	II J
Œ œ æ á	HI
Œ œ & ^	HH
Œ œ æ [}	G F
Œ ^ [! * œ æ	JJI
Œ ^ { œ æ	I J
Œ @ œ æ	GH
Œ ! ^ & ^	HE
Œ ~ œ æ	II F
Œ ~ œ æ { œ æ	I €G
Œ ~ ^ œ æ	I JG
P œ æ á	I €J

NATION	CODE
P [] á ~ œ æ	I €
P [] * Á [] *	II G
Q á œ æ	JF
Q á [] ^ • œ æ	I G
Q œ æ	Ji
Q œ æ	JII
Q ^ œ æ á	HIH
Q i œ æ	JIG
Q œ æ ^	HJ
R œ æ œ æ	IF
R [á œ æ	JIG
S ^ } ^ œ æ	GI
S [! ^ œ æ	IG
S ~ , œ æ	JII
S ~ ! * ^ : • œ æ	JJI
Š œ æ ^ ! œ æ	GF
Š œ æ ^ œ æ	GF
S ~ œ æ { à [~ ! *	HIG
T œ æ œ • œ æ	I €
T [á ç œ æ	HIH
T œ æ œ æ	HI
T ^ œ æ []	IG
T [] œ æ []	HI
T [! [& []	GFG
T ^ œ æ { œ æ Ü Ö [] œ æ	Ji
P ^ œ @ ! œ æ á •	HF
P ^ , Á ^ œ œ æ á	II
P œ æ ^ ! œ æ	GH
P [! , œ æ	II
U { œ æ	JII
Ú œ æ œ œ æ	JG
Ú œ æ œ œ æ	I €
Ü Ö Ö	III
Ú œ æ œ ~ œ æ	I Ji

NATION	CODE
U ^ ~	IF
Ú [] œ æ [] á ^ •	I H
Ú [] œ æ á	II
Ú [! c * œ æ	HIF
Ú œ œ œ	JII
Ú ~ { œ æ œ æ	I €
Ú ~ • • œ æ	II
Ú œ á á œ œ œ œ œ	JII
Ú ^ } ^ * œ æ	GGF
Ú œ * œ æ [! ^	II
Ú [~ œ œ œ œ œ	G
Ú] œ æ	HI
Ú i œ œ \ œ æ	Ji
Ú , œ œ œ á	GI
Ú , ^ á ^ }	II
Ú , œ ^ œ æ á	IF
V œ æ á œ æ	JJG
V ^ [{	EG
V ^ d œ æ	EF
V @ œ æ á	II
V ~ } á œ æ	GF
V ~ ! ^ ^	JE
V ~ ! { ^ } á œ æ	JJH
W Ö Ö Ö	JIF
W ! œ æ ^	HI €
W , œ á á S á * á [{	II
W ~ * * œ æ	I Ji
W Ö Ö Ö	F
W : á ^ á œ æ	JJI
X ^ } ^ : ~ ^ œ æ	II
X œ ç œ æ	II
Y Ö Ö Ö Ö	JII
Default = 1 (U.S.A.)	

Slot Assignment (TRANS/PGM 101)

1. Press the [TRANS/PGM] button and dial 101.
2. Enter Slot number
3. To change board type, press the Flex button 1 and dial board. Refer to NOTE2 - Board Type Code.
4. To change device number, press the Flex button 2 and dial device.
5. To store the location data press the [SAVE] button.

Slot Assignment

TRANS/PGM 101	BTN	RANGE	REMARK
SLOT ASSIGNMENT-- refer to "Board Type Code" table below.	1	-	-
SLOT 02 -- enter device (port) number.	2	-	-

NOTE: If the DIP switch of the manual board detection (the 1st DIP Switch) is ON, system will detect the installed board type automatically. If the 1st DIP switch is OFF, the board type code must be entered at each slot. After manually setting Rack Slot assignment, the user should reset the system manually.

Board Type Code

STATION BOARD	CODE	CO LINE BOARD	CODE	VMIB BOARD	CODE
DSIB	11	VOIU	31	VMIB	51
DTIB12	12	VOIB8	32	AAIB	52
DTIB24	13	VOIB24	33	VSF	53
SLIB12	14	LCOB4	34		
SLIB24	15	LCOB8	35		
WTIB	16	LCOB12	36		
DTIM8	17	PRIB	37		
SLTM4/8	18				
SLTM32	19				

Logical Slot Assignment (TRANS/PGM 103)

1. Press the [TRANS/PGM] button and dial 103.
2. Press the Flex button (1-3) to change slot order.
3. Enter slot numbers.

TRANS/PGM 106	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register an IP Phone to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-1 .)	1	-	-
USER ID -- Used to register a Phontage to the System, by entering its User ID and Password.	2	-	-
USER PASSWORD -- Used to register a Phontage to the System, by entering its User ID and Password.	3	-	-
STA NUMBER (VIEW) -- Once a connection is made to the System, the current Station number will be displayed.	4	-	-
IP ADDRESS (VIEW) -- Displays the IP Address of the IP phone/Phontage.	5	-	-
F/W IP ADDRESS (VIEW) -- Displays the Firewall IP Address of the IP phone/Phontage.	6	-	-
RTP SECURITY -- Enable RTP Security.	7	-	-

DTIM/SLTM Registration Table (TRANS/PGM 107)

1. Press the [TRANS/PGM] button and dial 107.
2. Enter slot number to be assigned.
3. Press the Flex button (1-5) and enter the desired data
4. Press the [SAVE] button to store.

TRANS/PGM 107	BTN	RANGE	REMARK
MAC ADDRESS -- Used to register a DTIM to the System, by entering its MAC Address. (Refer to Alphanumeric Dial Pad entries on page C-1 .)	1	-	-
STA RANGE (VIEW) -- Once a connection is made to the System, the Station number assigned to DTIM/SLTM will be displayed.	2	-	-
IP ADDRESS -- Displays the IP Address of the IP phone/Phontage.	3	-	-
F/W IP ADDRESS -- Displays the Firewall IP Address of the IP phone/Phontage.	4	-	-
RTP SECURITY -- Enable RTP Security.	5	-	-

1. Press the [TRANS/PGM] button and dial 109.
2. Select the desired button 1-7.

TRANS/PGM 109	BTN	RANGE	REMARK
MAC ADDR -- The MAC Address of MPB.	1	-	-
PROTOCOL PORT -- UDP Port for communicating between MPB and Boards (or, IP Phone).	2	-	-
PRIVATE NET MASK	3	-	-
APP RLS VERSION -- System Version.	4	-	-
APP RLS DATE -- The released Date of System software.	5	-	-
BOOT VERSION -- System Boot Version.	6	-	-
BOOT RLS DATE -- The released Date of System Booting application.	7	-	-

NUMBERING PLAN DATA - TRANS/PGM Codes 110 to 116

Numbering Plan Type (TRANS/PGM 110)

The MBX IP system provides default Numbering plan set. One of any numbering plans can be installed or every numbering plan can be cleared.

If numbering plan type 7 is selected, all numbering codes are deleted. After deleting, the user should then assign the 'System Numbering Plan (TRANS/PGM 111)'. After configuring the System Numbering Plan, the user can assign the other numbering plan code. This is useful when the user wants to reconfigure all the numbering codes without default values.

1. Press the [TRANS/PGM] button and dial 110.
2. Press Flex Btn 1 and select one of the default numbering plans.

If numbering plan type 7 is selected, all numbering codes are deleted. After deleting, the user should first assign the prefix numbering plan. After configuring the prefix, the user can assign the others like station number, CO Group Access Code, Extra Numbering and Feature Code. This is useful when a user wants to reconfigure all numbering codes.

3. Press the [SAVE] button to update all numbering plan codes with selected default value.

System Numbering Plan (TRANS/PGM 111)

To assign a numbering plan code, the type should be matched with one of the System Numbering Plans provided, which consists of a Prefix and More digits.

Use the Volume Up / Down buttons for data of the next / previous index.

4. Enter station number to update.
5. Press the [SAVE] button to update changed data.

Check if newly entered number is available number according to Prefix Code plan (TRANS/PGM Code 111).

TRANS/PGM 112	BTN	RANGE	REMARK
STATION NUMBER (edit by range)	1	Start station number & End station number	Delete all station numbers and update entered station number range only.
SINGLE STATION NUMBER (edit)	2	One station number	Bin 001-324 (MBX IP 300), bin 001-128 (MBX IP 100): 1 number per one station port (My-DNs for each stations). Bin 325-648 (MBX IP 300), bin 129-256 (MBX IP 100): Free station numbers for MADN type or extra SADN type numbers (Sub-DNs).

FEATURE NUMBERING PLAN (TRANS/PGM 113)

Feature Numbering codes for the system can be assigned and edited in TRANS/PGM 113. Appendix B provides the default values for each of the eight base Numbering Plans. Select the default Numbering Plan in TRANS/PGM 110.

1. Press the [TRANS/PGM] button and dial 115:-
2. Select the desired index (01-108); refer to the following table.
3. Press the [SAVE] button to store the new Numbering Plan data.

Check if newly entered number is available according to Prefix Code plan (TRANS/PGM 111).

Feature Numbering Codes

BTN	FEATURE	REMARK
1	Attendant Call	0
2	Conference Room 1	571
3	Conference Room 2	572
4	Conference Room 3	573
5	Conference Room 4	574

BTN	FEATURE	REMARK
36	Call Parking Location	541 + xx (Parking Location 00-49)
37	TRANS/PGM Mode Access	521
38	Two-Way Record	522
39	VMIB Access	523
40	AME Access	524
41	CO Line Access	888 + CO Line # (001-200: MBX IP-300, 01-80: MBX IP-100)
42	VM MWI Enable	*8
43	VM MWI Cancel	*9
44	MCID Request	*0
45	Unsupervised Conf Extend	5##
46	PTT Group Access	524 + PTT Group # (0-9) + * (Log out)
47	Hot Desk Log In/Log Out	525
48	Name Register	526
49	Create Conf Room	527 + Conf. Room #
50	Delete Conf Room	528 + Conf. Room #
51	Wake Up Register	529 + HH:MM
52	Wake Up Cancel	530
53	Temporarily COS Down	531
54	Cancel Temp COS Down	532
55	Password Change	533
56	Inter-Phone Group Access	534
57	Call Wait Request	535
58	Preselected MSG TRANS/PGM	536
59	Forced Handsfree Call	537
60	Call Based CLIR	582
61	CLIR Access	583
62	COLR Access	584
63	Pilot Hunt Call	585
64	Command Call Oneway	581

BTN	FEATURE	REMARK
95	ACD Agent Auto Work	503
96	ACD Agent Auto Answer	504
97	ACD Call Indication	508
98	Non-ACD Call Indication	509
99	ACD Supervisor Group Forward	890
100	ACD Supervisor Night	891
101	ACD Supervisor Holiday	892
102	ACD Supervisor Queued Call Answer	893
103	ACD Supervisor Agent State Check	894
104	ACD Supervisor Silent Monitor	895
105	ACD Supervisor Call Traffic Check	896
106	ACD Announcement Play & Check	899
107	Day/Night/Timed Mode Change	513
108	DID/DISA Restriction	685

CO Group Access Code (TRANS/PGM 114)

MBX IP System provides CO Group Access Codes (73 in MBX IP-300/25 in MBX IP-100). Each code can be edited by Admin Programming. Each CO Group Access Code has its attributes (refer to TRANS/PGM Code 178).

1. Press the [TRANS/PGM] button and dial 114.
2. Press Flex button 1 to edit whole CO Grp access code by range.
3. Enter desired access code by range.

OR

4. Press Flex button 2 to edit one CO Grp access code.
Use the Volume up / down buttons to scroll to the next / previous index.
5. Enter desired access code.
6. Press the [SAVE] button to update changed data.

Check if newly entered number is available, refer to Prefix Code plan (TRANS/PGM Code 111).

OR

Press Flex button 2 to edit one ACD Group Number.

Use the Volume Up / Down buttons to scroll to the next / previous index.

4. Enter desired ACD Group number.
5. Press the [SAVE] button to update changed data. Check if newly entered number is available number according to Prefix Code plan (TRANS/PGM Code 111).

TRANS/PGM 118	BTN	RANGE	REMARK
ACD GROUP RANGE -- ACD Group Number edit by range.	1	Start ACD Group Number & End ACD Group Number	-
ACD GROUP NO -- ACD Group Number edit.	2	ACD Group Number	-

STATION DATA - TRANS/PGM Codes 120-152

Station Type (TRANS/PGM 120)

Each station has its own station type according to its terminal type. This station type is used by the system to recognize the station's capabilities. In addition, this station type defines DSS/BLF consoles, which can be connected to a station. Maximum 5 DSS/BLF consoles can be connected to a station. Especially, in IP-8000 Series, maximum 4 serial DSS/BLF consoles can be connected. For DSS/BLF consoles, the associated father station number is displayed.

To set the terminal type:

1. Press the [TRANS/PGM] button and dial 120.
2. Use the dial pad to enter a station number.
3. Select the desired Flex button:
 - FLEX 1: to display current station type or to set SLT station type (DTMF normal, DTMF MSG-wait, PULSE normal, PULSE MSG-wait)
 - FLEX 2: to connect DSS/BLF consoles to a station or to display father station number of a DSS/BLF console
 - FLEX 3: to restart IP-Phone
4. For Flex button 1 (TYPE), to view station type.
 - Only for SLT station, station's type can be modified. To modify SLT station type, use the dial pad button 1 to 4 (1: DTMF Normal, 2: DTMF Msg-wait, 3: Pulse Normal, 4: Pulse Msg-Wait).
 - Press the [SAVE] button to store the data entries.

TRANS/PGM 121	BTN	RANGE	DEFAULT
HEADSET RING -- in Headset mode, this item selects device to receive incoming ring signals. - Speaker, Headset or Both.	3	0:Speaker 1:Headset 2:Both	Speaker
GROUP LISTEN -- enables Group Listen feature, audio is sent to both the handset and speaker with the handset microphone active and speakerphone microphone OFF.	4	0:Off 1:On	Off
KEYSET ADMIN -- when an SLT extension attempts to transfer a CO call to a CO line it is blocked and the call is released.	5	0:Disable 1:Enable	Disable
NO TOUCH ANS -- permits station to receive pilot hunt ring.	6	0:Off 1:On	Off
HOWLING TONE -- sets Anonymous Call Restrict service.	7	0:Off 1:On	On
DUMMY TERMINAL -- this item defines whether a station is used for hot desk terminal. If you want to use a station as hot desk, this field must be set to 'ON'.	8	0: Off 1: On	Off
PORT BLOCK -- if this value is set to ON, Station is blocked so it is impossible to use that station.	9	0: Off 1: On	Off
GAIN TABLE IDX -- this feature allows 3 kinds of gain tables per station.	10	1-3	1
SLT LINE LENGTH -- this feature is used to distinguish the line length when the distance between SLT station and SLIB board is too variable. (Short:0km, Long:0-3km, Far:3-7.5km).	11	0: Short 1: Long 2: Far	Short
ALARM -- enable to receive system alarm signal.	12	0:Disable 1:Enable	Disable
DOOR OPEN -- enable to use door open feature.	13	0:Disable 1:Enable	Disable

Station Attributes II (TRANS/PGM 122)

LLCD LANGUAGE SELECTION

TRANS/PGM 122	BTN	RANGE	DEFAULT
LCD LANGUAGE -- sets the Language used in the Station's LCD.	1	(00-14)	00 (English)
LCD DATE MODE -- sets the Station's Date display as month/day or day/month.	2	0: DDMMYY 1: MMDDYY	DDMMYY

VÜÖE ÒÜBÏÖT ÁFG	ÓVÞ	ÜÖE ÒÒ	ÖÖÖEVSV
ŠÖÖÁ/Q ÖÁT UÖÖÁEÁ^¨• Á@Áq ^Áã} æÁ [á^Áe ÁFGÁ @~!Á!ÁG Èq~!Áq qãæ~DÁq ^È	H	€ÁFGP[~!ÁT[á^ FKG ÁP[~!ÁT[á^	FG@~!
ÖÖÖŠÖP VÁVÜÖÖÖÁEÁÁææ } ÁæÁ~]] :ŠÖÖÁ àæá ã @Á [~ ÁæÁ ^áæá ã @Á •æ^Á] ç } È	I	€ÁÖE æ•ÁU~ FKÓ•^ÁU } r Á GÁÖE æ•ÁU } HÁÖE ç Á I KÓ^ æ^áÁU~	Ö•^ÁU } r
ÖÈ €€ÁÜP VÁEÖÁ €€Á^!a•Á! { q æÁÖ•Á [Áq á•Á [-Á] áÁVá ^•Á^, ÁÚ [{ æ } ááÖ [çE V ç Á ^ } Á á^ç! { q ^•Á } @Á } çÁ Á•áÈ	í	€ÁVá ^•Á^, ÁÚ [{ FKÓ [çE	Vá ^•Á^, ÁÚ [{
ÖÈ €€ÁŠÖÖÖÜÖP VÞÖÜÜÁEÖÁ €€Á^!a•Á! { q æÁ &æ Áæb•öŠÖÖÁ!ã @ ^••Á! :Á•^!q Áq } ç^ } æ } &È	î	€FÈÍ	€í
ÖÜUWÁV WÖMÖÖÖÜSÖY ÁEÁç Á Á^ç ÁUÞEÁ^•ç { Á] : çã^•Áææ } Á [~] ÁU^ ^ ^ Áq } { ææ } Á Á! [~] Á { ^ { à^È	ï	€ÁU~ FKÁ } Á	U~

ÒP VÜY	ŠÖE ÖWÖÖÖ
€€	Ö) * ã @
€F	Öçãæ
€G	Öq } ä @
€H	Ö~ &Á
€I	Ü, ^ãã @

ÒP VÜY	ŠÖE ÖWÖÖÖ
€	Öæ ä @
€í	P [!, ^* ææ
€ï	P^à!^,
€ì	Ö^! { æ
€j	Ö^ } &@

ÒP VÜY	ŠÖE ÖWÖÖÖ
F€	Ú [!ç ** ^•^
FF	Ú] æ ä @
FG	S [!^æ
FH	Ö•ç { ææ
FI	Ü~ ••ææ

Station Attributes III (TRANS/PGM 123)

TRANS/PGM 123	BTN	RANGE	DEFAULT
PRIME NUMBER BTN -- among My-DN and several Sub-DNs which are assigned to station flex buttons, determines the first-seized DN when the user initiates a call. If prime button is not set or invalid, the system scans sequentially from flexible button 1 to flexible Button 48 and take the unused and valid flexible button as prime button NOTE: DN buttons of associated DSS box cannot be a prime number button.	1	01-48	01
ZONE NO -- this menu represents a station belonging to what zone.	2	1-9	1
AUTO HOLD -- enables Auto Hold for the station. With Auto Hold enabled, the system will place an active external call on hold if the user presses a CO/IP or DSS button.	3	0: Off 1: On	Off
ENBLOCK DIAL -- when On, the user-dialed digits are stored at the Digital Phone until explicitly sent by the user. When sent, all dialed digits are sent to the system in a block. Enblock mode is only available to Digital Phones with soft keys.	4	0: Off 1: On	Off
ICM ANSWER MODE -- selects Handsfree, Privacy or Tone ring ICM Signaling mode.	5	1: Handsfree 2: Tone 3: Privacy	Tone
DATA SECURITY -- disables override and camp-on tones to the station to avoid occurring error when sending data.	6	0: Off 1: On	Off
PROGRESS INDICATOR -- if this value is set to ON, Progress Indicator Information is included to Setup message (Origin is non-ISDN).	7	0: Off 1: On	Off
FAX MODE -- if this value is set to ON, Bearer Capability information with 3.1Khz is provided to PX.	8	0: Off 1: On	Off
DTMF WHEN REDIAL -- if this value is set to ON, DTMF tone is heard to the station user while redial. (Reserved) .	9	0: Off 1: On	On
MUTE RING SERVICE -- if this value is set to MUTE RING, system provides MUTE RING to user.	10	0: Mute Ring 1: No Ring	Mute Ring
AUTO IDLE SERVICE -- If this value is set to AUTO, system provides Auto Idle service.	11	0: Auto 1: Manual	Auto

Station Attributes IV (TRANS/PGM 124)

Station Flexible Button Assignment (TRANS/PGM 126)

Flex buttons for each Digital Phone and DSS Console can be assigned a function (Type) and an associated Value.

For assignments to a DSS Console, enter the DSS console station number and enter the desired button number. For Serial DSS, the button numbers are decided by the order of Serial DSS. The button number starts from 49 at the first Serial DSS, 97 at the 2nd Serial DSS, 48 is added to the button number when desired Serial DSS order is increased. Each console contains entries for up to 48 buttons even though the console may only have 12 buttons. In this case, assignments for buttons 13 to 48 are ignored.

1. Press the [TRANS/PGM] button and dial 126.
2. Use the dial pad to enter a station range (Ex. 100-110). For a single station, enter the same number twice.
3. Dial the desired Flex button number (001-240)
4. Press the desired Flex button (1-3).
 - Flex button 1: to configure button type
 - Flex button 2: to configure ring option
 - Flex button 3: to configure access mode

For Flex Button 1:

To configure button type, use the dial pad to select button type 1-3.

- Type 1: to assign Fixed type button to Flex button.
- Type 2: to assign Station Number(DN) to Flex button.
- Type 3: to assign "Dialed Number" to Flex button.

For Fixed Button:

Use the dial pad to select one of the following:

- | | |
|---------------|-------------|
| 1: redial | 6: button |
| 2: speed | 7: transfer |
| 3: conference | 8: recall |
| 4: mute | 9: PTT |
| 5: call back | |

Press the [SAVE] button to store the data entered.

If a station already has the same fixed type button, an error tone is heard and the data is not saved.

Station Number Information (TRANS/PGM 130)

In accordance with the station number's physical characteristics, the station number is divided into My-DN and Sub-DN.

- My-DN is only a role of SADN (Single-Assign Directory Number) and only one My-DN is assigned to a physical terminal. In MBX IP system, the scope of station number used for My-DN is predefined – station bin index from 1 to 324 for MBX IP-300, from 1 to 108 for MBX IP-100. Station number with station bin index greater than My-DN's bin index is Sub-DN.
- Sub-DN is used for MADN or SADN. MADN can have 10 different stations as its members but SADN has only 1 member. In addition to, Sub-DN, which is used for SADN, can be configured as a hot-desk agent number. If Sub-DN is used for hot-desk agent, station is not allocated explicitly for Sub-DN member. Only when a terminal login to hot desk with Sub-DN, Sub-DN has terminal's station number (My-DN) as its member.

To set the terminal type:

1. Press the [TRANS/PGM] button and dial 130.
2. Use the dial pad to enter the station number.
3. Press the desired Flex button (1-2):

Flex 1 -- to configure station number type:

Dial 1-3 to configure station number type.

- Type 1 : SADN-Normal
- Type 2 : MADN
- Type 3 : SADN-Hot Desk Agent

Press the [SAVE] button to store the data entries.

NOTE: Type cannot be changed for My-DN numbers.

Flex 2 -- to display station member view

Station Number Attributes - TRANS/PGM 131-135

Station Number Attributes define features and functions available to the station number. Generally, the entry will turn the feature ON (enable) or OFF (disable). Refer to the following tables for a description of the features and the input required.

1. Press the [TRANS/PGM] button and dial:
 - 131 for Station Number Attributes 1
 - 132 for Station Number Attributes 2
 - 133 for Station Number Attributes 3

FH Áq |ÁÜcæq } Áp { à^!ÁÖcã ã ¢•Á
 FH Áq |ÁÜcæq } Áp { à^!ÁÖÖÖcã ã ¢•
 GE W^!Á@Áãqãã Áq } ¢!Ácæq } Áq *^!ÁÖÖÉÉÉÉÉÉÉÉ!Áãq *^!Ácæq } ÉÁ } ¢!Á@Á
 •æ ^!Á { à^!Áq çÁÉ
 HE Ú!^••Á@Áãqãã ÁqãÁÖ!¢Áã ¢q } LÁ^!Áq Á@Áq ||| , q *ÁÜcæq } Áp { à^!ÁÖcã ã ¢•Áã|Á•É
 I É W^!Á@Áãqãã Áq } ¢!Áãããããããã!Á@Áãããã ¢!Á^cæq *ÉÁ^!Áq Á@Áq ||| , q *ÁÜcæq } Á
 Þ { à^!ÁÖcã ã ¢•Áã|Á•É
 Í É Ú!^••Á@ÁÜÖÖÖÖÁã ¢q } Áq Áq !^!Á@Áãããã } d^É

Station Number Attributes I (TRANS/PGM 131)

VÜÖEÜÜÖT ÁFHÉ	ÓVÞ	ÜÖÖÖ	ÖÖÖÖVŠV
ÜVÖEÜÞÁÞÖÉ ÖÁÉÁ } çã!^!Áã ç ^!Á } d^ÉV@Á ç ^!Á Á ãã } çã^!Á } Á@ÁÖÖÁ -ÖÁ çãÁÜq } ^	F	T çãÁq &çã•	É
VÖÞÖE VÖÜÜWÜÁÉÁ } ^çã Á } ç Á! [] Áq Ácæq } É	G	FÉÁq ÖYÁÜÁÉÉ FÉÁq ÖYÁÜÁÉÉ	F
ÖÖVÁÖÜÞXÖÜÜWÞÁVÖÖÖÖÁ } ^çã ÖÁ çã } ç!^•q } Áã Á { Ácæq } É	H	FÉ	F
ÜÖÜY ÜÖÖÁÉÁ } d çã ÖÜÖÖÁÜÖÖ!çã } Áq Ácæq } É	I	ÉÉGãã çã	É
ÖWÜYÁÜÖXÖÖÁÉÁ } @ } Áq ÁÜVÁçç } •q } Áçç { } Ö Áq Áq } ^!Á çÖÜÁçç!Á ÁçÖÜÁq ^!ÁÁ & ^!Áã çã@Áçç!Á Á^!Áçç^!ÁÉ	Í	ÉÖ^•Áq } ^ FÖç } É } GÖç!Á çã HÜq çP } c	Ö^•Áq } ^
ÖÞÖÜÖÖÁ ÜÖÖÁÉÁ } ^! { ç Ácæq } Áq Á^!ç^!Á q! ç@ } çã *É	î	ÉÖ^! FÜ^! } [ic	Ü^! } [ic
ÜT ÖÜÁÖÖÖÞÖÖVÁÉÁ } ^!ç } [] { [^•Öç!Á } d çã^!çãÉ	ï	ÉÖã çã! FÖ } çã!	Öã çã!
PUVÖÖÜSÁÖÖÞVÁWT ÖÖÜÁÉÁ } ^! çã^!É } Áq ^É	ì	ÉÁ~ FÁÜ } Á	U~
VÖ ÖÁVÖÖÖÖÖÖÖÖYÁÉÁ } çã!^•Áçç Á^ } ^çã *Áçç { É	J	FÉÁq [] ^	} [] ^

Station Number Attributes II (TRANS/PGM 132)

TRANS/PGM 132	BTN	RANGE	DEFAULT
FORCED HANDSFREE ACCESS -- when placing an intercom call, a user can change the ICM signaling mode, Tone Ring to Hands free answer mode or Hands free answer to Tone Ring mode.	1	0: Disable 1: Enable	Disable
FORWARD ACCESS -- enables Call Forward to be activated by the station.	2	0: Disable 1: Enable	Enable
OFFNET FORWARD ACCESS -- a station must be allowed Off Net Fwd to forward external incoming calls outside the system or otherwise establish a CO-to-CO connection.	3	0: Disable 1: Enable	Enable
DND ACCESS -- enables DND to be activated by the station.	4	0: Disable 1: Enable	Enable
INTRUSION ACCESS -- enables intrusion to gain access to an active call.	5	0: Disable 1: Enable	Disable
MOBILE EXT ACCESS -- enables mobile extension ability.	6	0: Disable 1: Enable	Enable
HOOK FLASH MODE -- determine the operation when SLT user press hook-flash button during conversation. 0. FLASH NORMAL: Hook Flash can be detected. In addition, it will be operated normal case flow. 1. FLASH IGNORE: Hook Flash cannot be detected. All of hook flash will be ignored at any time. 2. FLASH DROP: When Hook Flash is detected, the line will be disconnected. 3. HOLD RELEASE: Drop the holding line if system detects Hook Flash and then On-Hook during dialing state.	7	0: Flash Normal 1: Flash Ignore 2: Flash Drop 3: Hold Release	Flash Normal
AUTO PICKUP -- if a group member is ringing, another member of the Group can Pick-Up a call ringing at another member by simply going "Off-hook".	8	0: Disable 1: Enable	Disable

Station Number Attributes III (TRANS/PGM 133)

TRANS/PGM 133	BTN	RANGE	DEFAULT
CO QUEUE ACCESS -- enable CO Queuing.	1	0: Disable 1: Enable	Enable
CONFERENCE ACCESS -- enable Conference call.	2	0: Disable 1: Enable	Enable

VÜÖPÜÖJÖT ÁFH	ÓVP	ÜÖPÖÖ	ÖÖÖVŠV
Y ÖSÖÁWÜÖÖÖÜÜÄÄ } æè ^ÁY æ^È] ÁÖæ { Áææ !^È	H	€ÖÖæè ^ FÖÖ) æè ^	Ö) æè ^
ÜVP ÖÖŠŠÁÖÖSÁÖÖÖÜÜÄÄ } æè ^Á&æ ÁæÄ Áææ !^Á @ } Á æ&æ ^áÁ cæä } Á Á~ •^È	I	€ÖÖæè ^ FÖÖ) æè ^	Ö) æè ^
ÖÖPÜÁÖÖÖÜÜÄÄ } æè ^ÁÖÖPÜÁææ !^È	Í	€ÖÖæè ^ FÖÖ) æè ^	Öäæè ^
ÖÖÜÖPÖÖÁ UVÖÖÖÖÖÖÜÜÄÄ } æè ^ÁÖÖ•^ } &Á [ÖÖÁ ^ææ !^È	Ī	€ÖÖæè ^ FÖÖ) æè ^	Ö) æè ^
ÖÖŠŠÁ ÖVÁÖÖÖÜÜÄÄ } æè ^Á Áæ^Á&æ Á æè ^ @ } Á &æ ^áÁ cæä } Á [^•Á [ÖÖ , ^!Á Á ÖPÖÁ cææ È	İ	€ÖÖæè ^ FÖÖ) æè ^	Ö) æè ^
ÖÖF ÜÁPÖÖÖÖÜÜÄÄ } æè ^Á&æ] È } Áææ !^È	ì	€ÖÖæè ^ FÖÖ) æè ^	Ö) æè ^
XUÖÖÁXÖÜÖÖÖÖÜÜÄÄ } æè ^Á& [ÖÖÁ ç^!Áææ !^È	J	€ÖÖæè ^ FÖÖ) æè ^	Öäæè ^
XUÖÖÁXÖÜÖÖÖÖVWPÄÖÖ } æè ^Á•bç } Á& ç@!æ Áæ [~ ÖÁ ç [ÖÖÁ ç^!Áææ !^È	F€	€ÖÖæè ^ FÖÖ) æè ^	Öäæè ^
ÜÜÖÖÖÖÖÖŠŠÁÜÖÖÖÄÄ } æè ^Á! ^ } æè ^Á&È	FF	€ÖÖæè ^ FÖÖ) æè ^	Öäæè ^
SÖYÜÖÖÖÖÖÖVÁWÜÖÖÖÄÄ } æè ^Á^~] æè ^Á&æ È	FG	€ÖÖæè ^ FÖÖ) æè ^	Öäæè ^

Station Number Attributes IV (TRANS/PGM 134)

VÜÖPÜÖJÖT ÁFH	ÓVP	ÜÖPÖÖ	ÖÖÖVŠV
ÜÜÖÖÖÖÖÖÖÜÜÄÄ ä•Á cæä } Á] ^^áÁæ Áä •Á&&••æ ç@!æ È	F	€ÖÖæè ^ FÖÖ) æè ^Á	Ö) æè ^
ÜÖÖÖÖÖÖÖÖÜÜÄÄ ! { ä Á cæä } Á Á æ^Á æ^È	G	€ÖÖæè ^ FÖÖ) æè ^Á	Ö) æè ^
T ÖÖVÁ ÖÖÖÖÖÖÜÜÄÄ } æè ^Á •Á ^^ÖÁ ^ç^ææ !^Á @ } Á @ ^!Á Á] æ^È	H	€ÖÖæè ^ FÖÖ) æè ^Á	Ö) æè ^
ÖÖŠŠÖWÜÖVWPÄÜÖÜVÜÖVÄÄ •dæ •ÖÜ Öæ Ö !æä } Á Á cæä } È	I	€ÖÖæè ^ FÖÖ) æè ^Á	Öäæè ^
ÜŠV ÖÖSÜÖSÁÖÖS ÖÖŠŠÄÄ @ } Á ÖŠVÁ ç } •ä } Áææ [] ÖÁ Á dæ •^!Á ÖÜ Á&æ Á Á ÖÜ Áä ^Á Á & ^áÁ ä@ &æ Á Á^æ^áÈ	Í	€ÖÖæè ^ FÖÖ) æè ^Á	Öäæè ^

TRANS/PGM 134	BTN	RANGE	DEFAULT
PILOT HUNT RING -- permits station to receive pilot hunt ring.	6	0:Disable 1:Enable	Enable
ACR USER -- sets Anonymous Call Restrict service.	7	0:Off 1:On	Off
WAKE UP SET -- sets wake-up time.	8	HH:MM	-
WAKEUP REPEAT -- enables daily repeating alarm.	9	0:Off 1:On	Off
BRANCH/BRIDGE LINE -- set branch/bridge line feature. Branch: Conference call by pressing {DN} button in use. Bridge: Bridge call by pressing {DN} button in use. Bridge (Softphone): Auto bridge if Phontage/UC Client's IP bridge is enabled.	10	0:Off 1:On	Off
AUTO PRIVACY -- enables auto privacy feature (to restrict the intrusion/call-wait/camp-on/OHVA in busy station).	11	0:Off 1:On	Off
DID DISA RESTRICTION -- If set to ON, incoming DID or DISA ring to DN is restricted.	12	0:Off 1:On	Off

Station CLI Attributes (TRANS/PGM 135)

TRANS/PGM 135	BTN	RANGE	DEFAULT
CLIP DISPLAY -- Calling Line Identification Presentation (CLIP), an ISDN service, sends the number of the calling party to the system in the call SETUP message. If enabled, the number will be shown in the Digital phone LCD.	1	0:Off 1:On	On
COLP DISPLAY -- COLP (Connected Line Id Presentation), an ISDN service, sends the number of the answering party to the system in the call CONNECT message. If enabled, the number will be shown in the Digital Phone LCD.	2	0:Off 1:On	Off
CLI/REDIRECT -- When an incoming ISDN call is redirected, the call SETUP message will contain an original and redirected CLI. This selection determines if the Digital Phone will display the original or redirected CLI number.	3	0:CLI 1:Redirect	CLI

TRANS/PGM 135	BTN	RANGE	DEFAULT
STA NO HIDDEN -- If this is set to ON, station number is not displayed at calling or called party LCD. This selection determines if the Digital Phone will display Station number	14	0:Off 1:On	Off
CALL TRANSFER CLI -- When a STA makes transfer call, call SETUP message will contain an transferor or transferred CLI	15	0:Transferor 1:Transferred	Transferor

Station Class of Service (TRANS/PGM 137)

All stations are assigned a Class-of-Service (COS), which determines the ability of the user to dial certain types of calls. Separate COS assignments are made for Day, Night and Timed Mode system operation. Maximum level of COS privileges is 16 (0-15). These privileges are represented in Toll Exception Table (TRANS/PGM CODE 250). By default, all stations are assigned with a Station COS of 1, no restrictions for all three modes.

The station COS interacts with the CO Line COS to establish overall dialing or Toll restrictions.

1. Press the [TRANS/PGM] button and dial 137.
2. Use the dial pad to enter a station range (Ex. 100-110). For a single station, enter the same number twice.
3. Press desired Flex button number (1-3).
 - Flex button 1: Day COS
 - Flex button 2: Night COS
 - Flex button 3: Timed COS
4. Use the dial pad to enter desired data for the Station COS, refer to the Restrictions Table below for each COS service.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 137	BTN	RANGE	DEFAULT
DAY COS -- Station's COS in Day mode.	1	00-15	1
NIGHT COS -- Station's COS in Night mode.	2	00-15	1
TIMED COS -- Station's COS in Timed mode.	3	00-15	1

Station Preset Call Forward (TRANS/PGM 142)

This assignment allows an external or internal call to initially ring at a station and forward to a pre-determined destination. Preset Call Forward can be assigned separately for Internal Unconditional, Internal Busy, Internal No Answer, External Unconditional, External Busy, External No Answer preset forwarding to any Station, Hunt group or External Telephone No.

1. Press the [TRANS/PGM] button and dial 142.
2. Use the dial pad to enter a station range (Ex. 100-110). For a single station, enter the same number twice.
3. Press Flex button number (1-6) for the desired type of forward,
 - Flex 1: Internal Unconditional
 - Flex 2: Internal Busy
 - Flex 3: Internal No Answer
 - Flex 4: External Unconditional
 - Flex 5: External Busy
 - Flex 6: External No Answer
4. Use the dial pad to enter the preset forward destination
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 142	BTN	RANGE	DEFAULT
INTERNAL UNCOND -- The unconditional preset forward destination of internal(intercom) call .	1	Max 32 digits	-
INTERNAL BUSY -- The busy preset forward destination of internal(intercom) call.	2	Max 32 digits	-
INTERNAL NO-ANSWER -- The no-answer preset forward destination of internal(intercom) .	3	Max 32 digits	-
EXTERNAL UNCOND -- The unconditional preset forward destination of external call.	4	Max 32 digits	-
EXTERNAL BUSY -- The busy preset forward destination of external call.	5	Max 32 digits	-
EXTERNAL NO-ANSWER -- The no-answer preset forward destination of external call.	6	Max 32 digits	-

1. Press the [TRANS/PGM] button and dial 145.
2. Use the dial pad to enter a station range (Ex. 100-110). For a single station, enter the same number twice.
3. Press the desired Flex button; refer to the following Table.
4. Use the dial pad to enter desired data for the attribute setting, refer to Table.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 145	BTN	RANGE	DEFAULT
VMIB ACCESS -- Permits station access to VMIB.	1	0: Disable 1: Enable	Disable
PROMPT LANGUAGE INDEX -- Selected language type prompt is played to the user when accessing the VMIB.	2	1-3	1
AUTO-RECORD SERVICE -- Determines if user can record a conversation with another user (internal/external). It can be used without two-way record button.	3	0: Disable 1: Enable	Disable
TWO WAY RECORD ACCESS -- When allowed, the station can activate the Two-way record feature to record a conversation.	4	0:Disable 1:Enable	Disable
TWO-WAY RECORD DEVICE -- Determines the save location of Two-Way recorded wav files: VM Boards, or Phontage. When Phontage is selected, recorded wav files are saved on the hard disk of the Phontage program-installed PC.	5	-	VM Boards
REC-MSG BACKUP STA -- When station has new voice mail saved on the VM internal boards, this information is reported to the assigned Phontage number. Phontage user can backup saved voice mail from VM internal boards to the hard disk of the Phontage program-installed PC.	6	-	-
BACKUP MSG DELETE -- When enabled, Phontage user can delete all voice mail in VM internal boards.	7	0: Disable 1: Enable	Disable
VMIB MSG TYPE -- Messages stored in the VMIB may be retrieved in either a FIFO (first-in-first-out) or LIFO (last-in-first-out) order based on this entry.	8	0: LIFO 1: FIFO	LIFO
VMIB NEW MSG NO -- Display the number of new messages.	9	-	-
VMIB SAVE MSG NO -- Display the number of saved messages.	10	-	-

TRANS/PGM 146	BTN	RANGE	DEFAULT
MOBILE SERVICE CLI 4 -- CLI 4for Mobile Service.	11	Max 24 digits	-
MOBILE SERVICE CLI 5 -- CLI 5for Mobile Service.	12	Max 24 digits	-

CO/IP Group Access (TRANS/PGM 150)

Stations can be allowed or denied access to CO Lines and IP Channels by group, refer to CO Line Attributes, TRANS/PGM CODE 160, button 2/3. As a default, all stations are allowed access to CO/IP group 1.

1. Press the [TRANS/PGM] button and dial 150.
2. Use the dial pad to enter a station range (Ex. 100-110). For a single station, enter the same number twice.
3. Press desired Flex button number (1-3),
Flex 1: to access for CO line 1 to 24
Flex 2: to access for CO line 25 to 48
Flex 3: to access for CO line 49 to 72
4. Press the desired Flex button to toggle CO/IP Group access, LED on: group access allowed, LED off: group access not allowed.
5. Press the [SAVE] button to store the data entry.

Internal Page Group Access (TRANS/PGM 151)

Each Digital Phone can be enabled internal page group access, allowing Stations the ability to make announcements to each Internal Page Group.

1. Press the [TRANS/PGM] button and dial 151.
2. Use the dial pad to enter a station range (Ex. 100-110). For a single station, enter the same number twice.
3. Press desired Flex button number (1-2),
Flex 1: to access for page zone 1 to 24
Flex 2: to access for page zone 25 to 30
4. Press the desired Flex button to toggle Internal Page Zone assignments.
LED ON: station makes announcement.
LED OFF: station does not make announcement.
5. Press the [SAVE] button to store the Page Zone data.

CO Attributes I (TRANS/PGM 160)

TRANS/PGM 160	BTN	RANGE	DEFAULT
CO TYPE -- Displays physical line type of selected CO line.	1	Display Only	-
SVC TYPE -- Set CO line type as DID or Normal.	2	0: Normal 1: DID	Normal
OUTGOING GRP NO -- Set CO Group Number to apply to outgoing calls.	3	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
INCOMING GRP NO -- Set CO Group Number to apply to incoming calls.	4	01-72, none (MBX IP-300) 01-24, none (MBX IP-100)	01
TENANT NO -- Set Tenant group number to apply to CO lines.	5	1-9 (MBX IP-300) 1-3 (MBX IP-100)	1
DGT CONVERT TBL -- Set Digit Conversion Table index.	6	1-9	2
SIGNAL TYPE -- Set Answer Signal Type.	7	0: No Signal 1: Send Wink (IC) 2: Wait Seize Ack (OG) 3: Send Wink & Wait Sz Ack 4: Send & Wait Sans 5: Send Wink & Send Answer (IC) 6: Wait Ack & Send Answer (OG) 7: Send All & Wait All	No Signal
RLS TIMING -- If Release Timing is set to first release, CO line is released when one party release the call. If Caller or Called Release is set, CO line is released when caller or called party released the call.	8	0: First Release 1: Caller Release 2: Called Release	First RLS
INC/OUT MODE -- Each CO lines can be set to only incoming call is allowed or outgoing is allowed only.	9	0: Incoming Only 1: Outgoing Only 2: Allow Both	Both
DIALING TYPE -- Signal type can be selected; DTMF, Pulse, R2MFC.	10	0: DTMF 1: PULSE 2: R2	DTMF

TRANS/PGM 161	BTN	RANGE	DEFAULT
LINE LENGTH -- LCO line length.	6	0: 0km 1: 3km 2: 5km 3: 7km	0km
ZONE NO -- Zone number of CO lines.	7	1-9	1
PROMPT LANGUAGE -- VMIB Prompt Index.	8	1-3	1
GAIN TABLE IDX -- Determines Gain Table for CO line.	9	1-3	1

CO Attributes III (TRANS/PGM 162)

TRANS/PGM 162	BTN	RANGE	DEFAULT
CO ACCESS MODE -- CO lines can be set to blocked, or CO line or Dedicated line.	1	0: Blocked Line 1: Normal CO Line 2: Dedicated Line	Normal CO Line
DIGIT SENDING MODE -- CO lines can be set to send digit with overlap or enblock method.	2	0:Overlap 1:Enblock	Overlap
MAX DGT LEN -- Number of dialed digits can be limited.	3	00-32	32
OVERLAP MIN DGT LEN -- Number of minimum digits can be limited for overlap dialing.	4	00-32	00
CHECK PASSWORD -- Reserved for Password. Password can be requested when the CO line is seized.	5	0: Off 1: On	Off
R2 CONNECT MODE -- R2 line connection mode.	6	0: End-to End 1: Link-by-Link	End-to End
R2MFC BACKWARD VAL -- R2MFC Backward Value.	7	01-15	01
DUMMY DIAL TONE -- When CO line is seized, dummy dial tone can be provided for in case if PSTN does not provide it..	8	0: Off 1: On	Off
T1 NORMAL MODE -- Determines if Loop or Ground is selected for each T1 Digital lines.	9	0: Loop 1: Ground	Loop
T1 DID MODE -- Determines if IMM, Wink, Delay Wink is selected for each T1 DID lines	10	0: Immediate 1: Wink 2: Delay Wink	Wink

5. Press the [SAVE] button to store the changed data.

CO Incoming Attributes I (TRANS/PGM 165)

TRANS/PGM 165	BTN	RANGE	DEFAULT
NAME -- incoming CO line name can be assigned.	1	Max 16 chars	-
SCREEN INDICATOR -- determines if screen indicator will be inserted in ISDN messages.	2	0: Off (user-provided, not screened) 1: On (user-provided, verified and passed)	Off
CALLING TYPE -- for Incoming calls on the ISDN Line, this parameter defines the "Type of Number Plan" provided in Connected Party Information Element of the ISDN call CONNECT message.	3	0: Unknown 1: International 2: National 3: Subscriber 4: Not Used	Subscriber
CALLING NUM PLAN -- select connected number plan of ISDN CONNECT message.	4	0: Unknown 1: I SDN/Telephony 2: Data 3: Telex 4: National 5: Private	Unknown
SEND PROGRESS IND -- if this feature is set to ALL, Progress Indicator is sent to the ISDN PSTN about All Message. If this feature is set to ALERTING, Progress Indicator is sent to the ISDN PSTN about Alerting Message.	5	0 : NO 1: ALL 2: ALERTING	NO
R2 ANI SVC REQ -- if this feature is set to ON to R2 line, system request ANI digits (CLI data) to the calling party.	6	0: Off 1: On	Off
ICLID SERVICE -- if this feature is set to ON, incoming call is routed according to ICLID Table(TRANS/PGM 262)	7	0: Off 1: On	Off
OWN CODE TO TRANSIT CLI -- if this feature is set to ON, original caller's CLI is sent when there is transit call.	8	0: Off 1: On	Off
OWN CODE -- Own Code.	9	Max 16 digits	-
CLI PREFIX CODE -- prefix code is inserted ahead of received CLI data according to call type.	10	Max 2 digits	-

TRANS/PGM 166	BTN	RANGE	DEFAULT
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after timer expires. The warning tone is heard before the line is disconnected.	9	000-255 (min)	000
WAIT CLRFRWD TIME -- Clear Forward Waiting Time.	10	001-300 (sec)	300
MAX RING TIME -- Max. Ring Time for when incoming CO calls are transferred/recalled.	11	015-300 (sec)	120
DISA SUPERVISION TMR -- DISA Supervision Timer.	12	1-9 (sec)	2
VMIB PLAY DELAY TMR -- Determines the amount of time paused before playing VMIB announcement.	13	0-9 (sec)	0
INCOMING TIME TABLE -- The time Table index to be applied to incoming CO Call.	14	1-9, none	none
CO DELAY ANSWER TMR -- For Incoming calls on the ISDN Line, this parameter defines the delay time between Alerting and Connect Message.	15	0-100 (100msec)	0
OFFNET FWD USAGE -- ISDN lines can be set to use Call Deflection/Call Rerouting service if PSTN supports these feature.	16	0:Join 1:Call Deflection 2:Call Rerouting	Join

CO Ring Assignment (TRANS/PGM 167)

Each CO line is assigned to stations or a feature code for an incoming call (Ring). Separate ring assignments are made for Day, Night, and Timed Ring modes. The Ring signal can be set for immediate or delayed ringing allowing other stations to be assigned ringing and answered prior to a delayed station. If 'DISA Tone Service' feature code is assigned, DISA service is activated at the CO line.

1. Press the [TRANS/PGM] button and dial 167.
2. Use the dial pad to enter a CO line range. For a single CO Line, enter the same number twice. For MBX IP-100, acceptable range is 01-80, for MBX IP-300, the acceptable range is 001-240
3. Select Day mode and press the desired Flex button; refer to the following Table.
4. Use the dial pad to enter desired data for the Attribute.
5. Press the [SAVE] button to store the data entered.

TRANS/PGM 168	BTN	RANGE	DEFAULT
CO ACCESS FROM DISA -- If this feature is set to ON, CO to CO call can be made from DISA line.	1	0: Off 1: On	Off
DISA TO CO PASSWORD -- When making CO-to-CO call from DISA line, password can be requested.	2	0: Off 1: On	Off
DISA RETRY COUNT -- When DISA call is failed to route desired destination, the call can be retried as much as Retry Count.	3	1-9	3
PRESET FORWARD TIME -- If the CO is not answered in Preset Forward Time, it will be routed to assigned ring Table.	4	00-20 (sec)	00
PRESET FWD RING TEL -- Preset Forward ring Table index can be assigned. (Refer to TRANS/PGM 181)	5	01-80	-

CO Incoming Alternate Destination (TRANS/PGM 169)

When a DID or DISA is routed to an abnormal destination, the call can be rerouted to alternate destination. The destination is separately defined for Day/ Night/ Timed mode according to several conditions.

1. Press the [TRANS/PGM] button and dial 169.
2. Use the dial pad to enter a CO line range. For a single CO Line, enter the same number twice. For MBX IP-100, acceptable range is 01-80, for MBX IP-300, the acceptable range is 001-240
3. Select Day mode and Dial Error Type; refer to Following Table.
4. Press the desired Flex button; refer to Following Table
5. Use the dial pad to enter desired data for the Attribute.
6. Press the [SAVE] button to store the data entered.

VÜÖE ÙÈÚÏÖT ÁÍ J	ÓVÞ	ÜÖE ÖÒ	ÖÒÖEÞSV
Q& { ¢ * ÁÖUÖE! } ææã^ ÖÖY/ÄÄ	F	ØFkÓ • ^ ØGÖ [ÁÖE • , ^!	Öã& } } ^&c FÁ^&
ÞÖÞVÄÄ	G	ØHÖ çæã Ø kÁ:æ • -! / Á [ÁÖE • , ^!	Öã& } } ^&c FÁ^&
VQ ÖÖÄÄ	H	Ø kÜ^æ / Á [ÁÖE • , ^! Ø kÖÞÖ Ø kÜ` óÁ-Á^! çæ^ Ø kÖ! FkÖã& } } ^&c GkÖE^) áæ ç HkÖUÁú ¢ * I kÖEÖú ¢ * Á/æ^ í kÁ } ^ î kÁ [öP` } ö: [~]	Öã& } } ^&c FÁ^&

CO Outgoing Attributes I (TRANS/PGM 170)

ÔUÁÚ` ¢ [¢ * ÁÖÖäã` ¢ • Á^ ¢ ^ Á çæã` • Á çææ ç ^! ä çæ • Á - Á @ ÁÖUÁú ^ • Á } á ^! Á& [} d [| Á - Á @ Á
• • ¢ { Á @ } Á @ ^! Á çæã Á ` ¢ [¢ * ÁÖUÁú çæÉ

FÈ Ú! • • Á @ Á VÜÖE ÙÈÚÏÖT áã` ¢ } Á çæã áããK

FÍ €Á! ÁÖUÁÚ` ¢ [¢ * ÁÖÖäã` ¢ • ÁÖ

FÍ FÁ! ÁÖUÁÚ` ¢ [¢ * ÁÖÖäã` ¢ • ÁÖ

GÈ W^ Á @ Á çæã Á çæã Á } ¢! Á ÖUÁú ^ Á çæã * ^ ÈÖQ! Á çæã * | ÁÖUÁú ^ Á } ¢! Á @ Á çæã ^ Á { à! Á
ç æ ÈÖQ! Á ÖYÁÚÈ €€Ä&&] çæã | Á çæã * ^ Á Á FÈ €Á! Á ÖYÁÚÈ €€Ä @ Á&&] çæã | Á çæã * ^ Á
ã Á € FÈ ç È

HÈ Ú! • • Á ^ çã` ¢ } Á çæã • • Á ^ • á ^ á Á ^ } ÈÜ^ -! Á! Á @ Á! | | , ¢ * Á çæã | Á çæã ÖÖäã` ¢ • È

I È W^ Á @ Á çæã Á çæã Á çæã * ^ Á @ Á çæã ^ È

Í È Ú! • • Á @ Á VÜÖE Öáã` ¢ } Á çæã Á çæã | Á @ Á çæã * ^ á á çæã È

TRANS/PGM 170	BTN	RANGE	DEFAULT
SCREEN INDICATOR -- Determines if screen indicator is used in ISDN message.	1	0: Off (user-provided, not screened) 1: On (user-provided, verified and passed)	Off
SENDING CALLER NO -- Sending Caller number message of ISDN.	2	0: Off 1: On	On
CALLING TYPE -- For outgoing calls on the ISDN Line, this parameter defines the "Type of Number Plan" provided in Calling Party Information Element of the ISDN call SETUP message.	3	0: Unknown 1: International 2: National 3: Subscriber 4: Not Use	Subscriber
CALLING NUM PLAN -- Select Calling number plan of ISDN SETUP message.	4	0: Unknown 1: I SDN/Telephony 2: Data 3: Telex 4: National 5: Private	Unknown
CALLED NUM PLAN ID -- Select Called number plan of ISDN SETUP message.	5	0: Unknown 1: I SDN/Telephony 2: Data 3: Telex 4: National 5: Private	Unknown
BEARER CAPABILITY - Select Bearer Capability of ISDN SETUP message.	6	0: Speech 1: Unrestricted 2: Restricted 3: 3.1KHz Audio 4: 7KHz 5: Video	Speech
ISDN LINE TYPE -- The system will encode voice using the A-law or u-law PCM format and should be set to match the ISDN Back bone type.	7	0:A-law 1:U-law	A-law
SENDING COMPLETE IE -- If set, will send 'Sending Complete' IE to ISDN SETUP message.	8	0: Off 1: On	Off

CO Outgoing Attributes II (TRANS/PGM 171)

TRANS/PGM 171	BTN	RANGE	DEFAULT
CPT DETECT -- If this feature is set to ON, CPT(Call Processing Tone) is detected and the line can be dropped.	1	0: Off 1: On	On
UNSUP CONF EXTEND -- If this feature is set to ON, Unsupervised Conf Timer can be extended by dialing feature code after warning tone is heard.	2	0: Off 1: On	Off
PROVIDE RING BACK TN -- If this feature is set to ON, dummy ring back tone is heard by system when CO line is seized.	3	0: Off 1: On	Off
BLF USAGE -- If this feature is set to ON, flex button LED will be flashing when CO line is programmed on the button.	4	0: Off 1: On	On
RLS GUARD TIMER -- If CO release signaling is not completed successfully, CO line is disconnected when the timer expires.	5	00-15	02
UNSUP CONF TIMER -- When there is conference call without supervisor, or there is any CO-to-CO call, the call is disconnected after the timer expires. The warning tone is heard before the line is disconnected.	6	000-255 (min)	000
MAX TRANSFER RING TIMER -- Max. Ring Time when outgoing CO is transferred/recalled.	7	001-300 (sec)	120
OUTGOING TIME TABLE -- The time Table index to be applied to outgoing CO Calls	8	1-9, none	none

CO Outgoing Alternate Destination (TRANS/PGM 173)

Calls can be routed to an alternate destination that can be separately defined for Day/ Night/ Timed mode according to several conditions.

1. Press the [TRANS/PGM] button and dial 173.
2. Use the dial pad to enter a CO line range. For a single CO Line, enter the same number twice. For MBX IP-100, acceptable range is 01-80, for MBX IP-300, the acceptable range is 001-240
3. Select Day mode and Dial Error Type; refer to Following Table.
4. Press the desired Flex button; refer to Following Table.
5. Use the dial pad to enter desired data for the Attribute.
6. Press the [SAVE] button to store the data entry.

- Press the [SAVE] button to store the data entry.

TRANS/PGM 174	BTN	RANGE	DEFAULT
SEIZE WAIT TIME -- wait time before first digit.	1	005-200 (100 msec)	020
FIRST DGT -- time limit between first digit and the next digit.	2	010-200 (100 msec)	100
SECOND DGT -- time limit between second digit and the next digit.	3	010-200 (100 msec)	080
THIRD DGT -- time limit between third digit and the next digit.	4	010-200 (100 msec)	070
FORTH DGT -- time limit between forth digit and the next digit.	5	010-200 (100 msec)	060
FIFTH DGT -- time limit between fifth digit and the next digit.	6	010-200 (100 msec)	050
MORE THAN 6TH -- time limit between digit and the next digit after the sixth digit.	7	010-200 (100 msec)	040

CO DTMF Sending Delay Timer (TRANS/PGM 175)

When making outgoing CO calls, the time interval to send DTMF tones of each digit can be adjusted. This feature is useful for the Speed Dial or Redial feature.

- Press the [TRANS/PGM] button and dial 175.
- Use the dial pad to enter a CO line range. For a single CO Line, enter the same number twice. For MBX IP-100, acceptable range is 01-80, for MBX IP-300, the acceptable range is 001-240.
- Press the desired Flex button; refer to Following Table.
- Use the dial pad to enter desired data for the Attribute.
- Press the [SAVE] button to store the data entry.

TRANS/PGM 175	BTN	RANGE	DEFAULT
FIRST DTMF DELAY -- delay time before sending first digit	1	00-90 (100 msec)	05
SECOND DTMF DELAY -- delay time before sending next digit after sending first digit DTMF tone.	2	00-90 (100 msec)	02
THIRD DTMF DELAY -- delay time before sending next digit after sending second digit DTMF tone.	3	00-90 (100 msec)	02
FORTH DTMF DELAY -- delay time before sending next digit after sending third digit DTMF tone.	4	00-90 (100 msec)	02

TRANS/PGM 179	BTN	RANGE	DEFAULT
STATION OUTGOING CALL TRANSFER -- while stations are connected to outgoing CO call of first CO Group, the station can transfer the call to second CO group.	1	0: Off 1: On	On
OUTGOING CALL TRANSFER -- while ATD is connected to outgoing CO call of first CO Group, the ATD can transfer the call to second CO group.	2	0: Off 1: On	On
OUTGOING CALL TRANSFER RELEASE TYPE -- if outgoing CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	3	0: None 1: Release after Release Timer	None
OUTGOING CALL TRANSFER RELEASE TIME -- if an outgoing CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'Rls after Rls Time'. Before disconnecting, a warning tone is provided.	4	000-300 (sec)	060
INCOMING CALL TRANSFER DIRECTLY -- if this feature is set to ON, CO incoming call can be transferred directly without any stations or ATD to transfer the call.	5	0: Off 1: On	Off
STATION INCOMING CALL TRANSFER -- while stations are connected to incoming CO call of first CO Group, the station can transfer the call to second CO group.	6	0: Off 1: On	On
ATD INCOMING CALL TRANSFER -- while ATD is connected to incoming CO call of first CO Group, the ATD can transfer the call to second CO group.	7	0: Off 1: On	On
INCOMING CALL TRANSFER RELEASE TYPE -- If incoming CO call can be transferred to other CO call, release type can be set. If set to None, it is not disconnected.	8	0: None 1: Release after Release Timer	None
INCOMING CALL TRANSFER RELEASE TIME -- If an incoming CO call is transferred to CO call and CO - to - CO call is started, the call is disconnected after release time, when release type is set to 'Rls after Rls Time'. Before disconnected, warning tone is provided.	9	000-300 (sec)	060

CO Group Access Code Attribute (TRANS/PGM 180)

Each CO Group Access Code allows user to access the CO group using different codes and different options.

TRANS/PGM 180	BTN	RANGE	DEFAULT
ARS DGT 2 -- Second alternate CO Group Access code to be used when original CO Group Access code and first ARS code failed to find available CO line.	8	Max 8 digits	-
ARS 2 OGR DGT -- When alternate CO Group Access code is used, this field defines if original digits or converted digits are used.	9	0: Off 1: On	Off

Alternate Ring Assignment (TRANS/PGM 181)

The Supplementary Ring Assignment Table, is used for programming alternate ring destinations which can be stations or any feature code (stations do not have a delay value).

1. Press the [TRANS/PGM] button and dial 181.
2. Enter Table index.
3. Press the desired Flex button; refer to Following Table
4. Use the dial pad to enter desired data for the Attribute.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 181	BTN	RANGE	DEFAULT
SERVICE TYPE -- If set as 0-2, ring option is applied to ring assigned stations. Otherwise, if set to 3, feature code is activated for incoming calls.	1	0: All Ring 1: First Idle 2: Circular 3: Feature Code	All Ring
CO RING ASSIGN -- Destination stations can be edited using a range or one by one. If press Flex 1-4 and then dial station range (up to 30 stations) or edit one station number.	2	(00-30) or one station number	-
FEATURE CODE -- If set to Feature Code and valid feature code is assigned, then assigned feature is activated when there is an incoming call. NOTE: Feature Code is not applied to rerouted calls.	3	Valid Feature Code (Refer to PGM115)	-
FEATURE DELAY -- If Service type is set to Feature code, it can be delayed.	4	00-30 (secs)	00

SYSTEM GROUP DATA - TRANS/PGM 200-215

Stations can be grouped for call routing, dialing, call pick-up, or various purposes.

TRANS/PGM 200	BTN	RANGE	DEFAULT
GROUP TYPE -- this entry defines the type of station group.	1	0:Not Assign 1: Terminal 2: Circular 3: Ring 4: Longest Idle 5: Voice Mail	Not Assign
GROUP NAME -- this entry defines the name of a group.	2	Max 16 chars	-
TENANT NO -- this entry assigns a tenant of a station group.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE IDX -- Time Table index,	4	1-9	1
PICKUP OPTION -- stations can pickup group calls ringing at other stations in the group.	5	0: Disable 1: All Call 2: Intercom 3: External	Disable
MEMBER ASSIGN -- this entry assigns stations as members of a station group.	6	-	-

Station Group Greeting/Queuing Attributes (TRANS/PGM 201)

Each type of group has a different set of available attributes relating to the greeting and queuing announcements, time. Refer to the table below for the descriptions of the attributes, LCD displays and data entries required.

1. Press the [TRANS/PGM] button and dial 201.
2. Use the dial pad to enter the desired Station Group number (620-639 for the MBX IP 100 and 620-669 for MBX IP 300).
3. Press the Flex button for the desired attribute; refer to the following Table.

TRANS/PGM 201	BTN	RANGE	DEFAULT
QUEUING TYPE -- This entry defines the type of queuing tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	3
QUEUING TIMER -- This entry defines the timer for queuing forward or second queuing announcement.	8	000-300 (secs)	30
QUEUING TONE NO -- This entry defines queuing tone number in case queuing type is normal.	9	01-19	Not Assigned
QUEUING PRT/ANNC -- This entry defines queuing prompt / annc. Number in case queuing type is PROMPT/ANNC.	10	001-255	Not Assigned
QUEUING REPEAT NO -- This entry defines queuing repeat number.	11	000-100	3
QUEUING RPT DELAY -- This entry defines the pause timer before queuing repeat.	12	000-100 (secs)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0
MOH FOR ANNC. -- This entry defines MOH option during queuing annc. Pause time.	14	01-12	none

VÜÖP ÒÜWÖT ÅÖF	ÓVP	ÜÖP ÒÖ	ÖÖÖVŠV
ÜÖÖUP ÖÅÜEV YÜÖÄV @ Å } d ^ Å ^ ä ^ Å @ Å [^ Å ^ Å & [] å Å ~ ^ ^ ä * Å } ^ Ä	FÍ	FÉP [!] æÁ GÄU [{] c HÖE } & I ÉP VÁ UP Í ÉÖYVÁ UP Î KÁ T ÖÁ UPF Ï KÁ T ÖÁ UPG Ì KÁ T ÖÁ UPH J KÁ T ÖÁ UPI FÉKÜŠVÁ UPF FFKÜŠVÁ UPG FGKÜŠVÁ UPH FHKÜŠVÁ UPI FI KÜŠVÁ UPI	I
ÜÖÖUP ÖÅÜEV ÖÜÄEV @ Å } d ^ Å ^ ä ^ Å @ Å [^ Å ! Å ! Å ! , æ å Å å ^ c ä æ } É	FÏ	ÉÉÉÉÉÉÉÉ Å ^ & D	HÉ
ÜÖÖUP ÖÅÜUP ÖÅÜEV @ Å } d ^ Å ^ ä ^ Å & [] å Å ~ ^ ^ ä * Å } ^ Ä ~ { à ! Å Å æ Å ^ ^ ä * Å } ^ Ä [!] æ É	FÏ	ÉÉÉÉJ	p [ÖÖ • ä } ^ å
ÜÖÖUP ÖÅÜÜV ÖP ÖÄEV @ Å } d ^ Å ^ ä ^ Å & [] å Å ~ ^ ^ ä * Å [!] [{] ÖÄ } & É ~ { à ! Å Å æ Å ^ ^ ä * Å } ^ Ä Å ÜÜT ÜV ÖP ÖÉ	FÌ	ÉÉÉÉÉ Í	p [ÖÖ • ä } ^ å
ÜÖÖUP ÖÅÜÜÖÜÖV @ Å } d ^ Å ^ ä ^ Å & [] å Å ~ ^ ^ ä * Å ! ^ ^ æ Å ~ { à ! É	FJ	ÉÉÉÉÉÉÉÉ	H
ÜÖÖUP ÖÅÜÜV ÖÖÖV @ Å } d ^ Å ^ ä ^ Å @ Å æ ^ Å Å ! Å à - { ! Å & [] å Å ~ ^ ^ ä * Å } ^ Ä É	ÖE	ÉÉÉÉÉÉÉÉ Å ^ & D	€
ÜÖÖUP ÖÅÜÜV @ Å } d ^ Å ^ ä ^ Å ÖÜÜ [] c } Å ! ä * Å & [] å Å ~ ^ ^ ä * Å } [~] & { ^ } Å ! [] c ä å É	ÖF	ÉÉÉ	€
TUP ÅÜÜÖP ÖÄEV @ Å } d ^ Å ^ ä ^ Å Á UP Å [] c } Å ! ä * Å & [] å Å ~ ^ ^ ä * Å } & Ü æ ^ Å Å É	ÖG	ÉÉÉÉG	} [] ^

Station Group Attributes (TRANS/PGM 202)

ÖæÖÅ } ^ Å - Å [~] ÅÖcä ä ~ c • Å ^ ^ æ Å * Å } [~] & { ^ } ÖÉÅ ! : ÉÅ ! , æ å Å ÖÄV @ Å [!] , ä * Å ^ Å ! [] c ä Å ^ Å ^ & ä c } • Å [Å @ Å c ä ~ c • Å ä Å @ Å c Å } d Å ^ Å ~ å å Ä FÉ Ü ! Å • Å @ Å VÜÖP ÒÜWÖT ÅÖ c } Å ä Å Å ÖGÉ
 GÉ W ^ Å @ Å Å Å Å Å Å } c ! Å @ Å Å ^ å å Ücæä } ÅÖ: [~] Å ~ { à ! Å ÖEÏ HJÅ ! Å @ Á ÖYÁÜÁÉÉÉ
 æ å Å ÖEÏ Í JÅ ! Á ÖYÁÜÁÉÉÉ

3. Press the Flex button for the desired attribute; refer to the following Table
4. Use the dial pad to enter the desired Group Attributes data, refer to the following Table.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 202	BTN	RANGE	DEFAULT
CALL IN GREETING -- This entry defines if a call is routed to a destination during greeting tone is played.	1	0: After Greeting 1: In Greeting	After Greeting
MAX QUEUE COUNT -- This entry defines queue count.	2	00-99	00
FORWARD TYPE -- This entry defines forward type. 0. Not used 1. Unconditional: a call is routed to a forward destination unconditionally. 2. Queuing overflow: a call is routed to a forward destination when a queue is overflow. 3. Timeout: a call is routed to a forward destination when a timeout timer is expired. 4. All: a call is routed to a forward destination when a queue is overflow or Timeout timer is expired.	3	0: 1: Uncond 2: Q Overflow 3: Time out 4: All	Not Used
APPLY TIME TYPE -- This entry defines a time to apply forward type.	4	0: ALL 1: DAY 2: NIGHT 3: TIMED	ALL
FWD DESTINATION -- This entry defines a forward destination. (Trunk access code should be included).	5	Max 16 digits	None
WRAP UP TMR -- This entry defines a wrap up timer. A member is available when this timer is expired after a member goes to idle.	6	000-600	010
MEMBER NO ANS TMR -- This entry defines no answer timer about each member. If this timer is expired, a call is routed to the next member.	7	05-60	15
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer is expired, a call is routed to the forward destination according to forward type.	8	0-180	0
PROVIDE ANNC.-- This entry defines if system answer the call when a greeting or queuing announcement is provided	9	0: With Answer 1: W/o Answer	With Answer

Voice Mail Group Attributes (TRANS/PGM 203)

Voice Mail group has available attributes relating to dialing service as put mail, get mail, etc. The following table provides descriptions for the attributes and data entries required.

1. Press the [TRANS/PGM] button and dial 204.
2. Use the dial pad to enter the desired Pickup Group (01-50 for the MBX IP 100 and 001-100 for the MBX IP 300). The system will display the attribute of pickup group.
3. **NOTE:** for group members, enter a station or station range. For an individual station press the desired Flex button for the position of the station in the group and dial the station number. For a range, enter the first and last station number in the range
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 204	BTN	RANGE	DEFAULT
PICK UP CONDITION -- this entry defines pick up condition. (All/Internal/External)	1	0: All Call 1: Int Call 2: Ext Call	All Call
PICK UP MEMBER ASG -- assigns stations as members of a station pickup group.	2	-	-

Page Group (TRANS/PGM 205)

Under Page Group Assignments members are assigned to the Page Group (refer to the programming table below for a description of the functions and data entries required).

Page Group Capacities

ITEM	MBX IP 100	MBX IP 300
Number of Groups	15	30
Members in a Group	50	50

1. Press the [TRANS/PGM] button and dial 205.
 2. Use the dial pad to enter the desired Page Group (01-15 for the MBX IP 100 and 01-30 for the MBX IP 300). The system will display the member of Page group.
- NOTE:** For group members, enter a station or station range. For an individual station press the desired Flex button for the position of the station in the group and dial the station number. For a range, enter the first and last station number in the range
3. Press the [SAVE] button to store the data entry.

PTT Group (TRANS/PGM 208)

Each Phone can be assigned as a member of one or more Push-To-Talk groups. The PTT Group capacities for the MBX IP system are shown in the table below.

PTT Group Capacities

ITEM	MBX IP 100	MBX IP 300
Number of Groups	10	10
Members in a Group	50	50

1. Press the [TRANS/PGM] button and dial 208.
2. Use the dial pad to enter the desired Page Group (0-9 for the MBX IP 100 and the MBX IP 300). The system will display the member of PTT group.

NOTE: For group members, enter a station or station range. For an individual station press the desired Flex button for the position of the station in the group and dial the station number. For a range, enter the first and last station number in the range

3. Press the [SAVE] button to store the data entry.

TRANS/PGM 208	BTN	RANGE	DEFAULT
PTT MEMBER ASG -- this entry assigns stations as members of a PTT group.	1	-	-

Interphone Group (TRANS/PGM 209)

To call the stations using only one or two digits, some stations can be gathered to the same 'Interphone Group' (refer to TRANS/PGM 209 for a description of the functions and data entries required).

Interphone Group Capacities

ITEM	MBX IP 100	MBX IP 300
Number of Groups	10	10
Members in a Group	10	10

TRANS/PGM 210	BTN	RANGE	DEFAULT
TIME TABLE INDEX -- Time Table index.	3	1-9	1
MEMBER ASG --Assigns stations as members of a Pilot Hunt group.	4	-	-

Pilot Hunt Group Forward Attribute (TRANS/PGM 211)

Each Pilot Hunt group has available attributes relating to forward; the following table provides descriptions for the attributes and the data entries required.

1. Press the [TRANS/PGM] button and dial 211.
2. Use the dial pad to enter the desired Pickup Group (01-20 for the MBX IP 100 and 01-50 for the MBX IP 300). The system will display the attribute of Pilot Hunt group.
3. Press the desired Flex button.
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 211	BTN	RANGE	DEFAULT
DAY FORWARD TYPE -- determines Day time setting for Call Forward type.	1	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
DAY FORWARD DESTINATION -- determines Day time setting for Forward destination.	2	Max. 8 digits	-
NIGHT FORWARD TYPE -- determines the Night time setting for Call Forward type.	3	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
NIGHT FORWARD DESTINATION -- determines the Night time setting for Forward destination.	4	Max. 8 digits	-
TIMED FORWARD TYPE -- determines the Timed setting for Forward type.	5	0: Not Used 1: Uncond 2: Busy 3: No Ans 4: Busy/ No Ans	Not Used
TIMED FWD DESTINATION -- determines the Timed setting for Forward destination.	6	Max. 8 digits	-

TRANS/PGM 212	BTN	RANGE	DEFAULT
GROUP NAME -- ACD Group Name.	1	Start ACD Group Number & End ACD Group Number	-
SERVICE MODE -- ACD Group Status.	2	0: Normal 1: Group Forward 2: Overflow 3: Night 4: Holiday 5: Not Service	Normal
TENANT NO -- ACD Tenant Number.	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
TIME TABLE INDEX -- ACD Group Time Table.	4	1-9	1
AUTO MODE -- ACD Group Status changed according to System Time Table Index.	5	0: Not Use 1: Night Auto 2: Holiday Auto 3: Night/Holiday Auto	Not Use
SUPERVISOR NUM -- ACD Group Supervisor assign.	6	-	-
MEMBER ASSIGN -- ACD Group Agent assign.	7	-	-

ACD Group Attribute I (TRANS/PGM 213)

Stations can be grouped so that incoming calls or internal calls will search (ACD) for an idle station in the group. ACD (Auto Call Distribution) service is to distribute ACD call efficiently to agent. Each agent can set own specific state and make ready for get the ACD call. Also supervisor can make ACD group state

1. Press the [TRANS/PGM] button and dial 213.
2. Use the dial pad to enter the desired ACD Group number (600-619 for the MBX IP 100 and MBX IP 300).
3. Press the Flex button for the desired setting; refer to the following table
4. Use the dial pad to enter the desired ACD Group data.
5. Press the [SAVE] button to store the data entry

TRANS/PGM 213	BTN	RANGE	DEFAULT
FWD AFTER QUEUING -- This entry defines reroute usage after queuing time over.	13	0: Off 1: On	Off
Q-FWD DEST -- Reroute destination after queuing time over.	14	-	-
AGENT NO-ANS OPTION -- This entry defines no-answer Agent No-Answer case about ACD-call. 1 Not use 2 Forward: call will be forwarded to defined destination 3 DND: Agent state will be changed automatically to DND state. 4 DND & Forward: Agent state will be change to DND state, and ACD call will be forwarded to defined destination	15	0: Not use 1: Forward 2: DND state 3: DND & Forward	Not use
AGENT NO-ANS DEST -- When Agent No-Answer option is Forward, applied destination can be assigned.	16	-	-

ACD Group Attribute II (TRANS/PGM 214)

TRANS/PGM 214	BTN	RANGE	DEFAULT
SUPERVISOR PSWD CHECK -- This entry defines check the supervisor password when supervisor change group status.	1	0:Off 1:On	0:Off
AGENT-AGENT CALL -- This entry defines agent to agent call restriction.	2	0:Allow 1:Direct call 2:Forward call	0:Allow
WORK MODE TIMER -- This entry defines wrap up timer of Agent Work State.	3	001-240	60

TRANS/PGM 214	BTN	RANGE	DEFAULT
LOGIN HANDSET -- This entry defines usage of Agent Headset option when agent log-in.	12	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode	1:Handset Mode
LOGOUT HANDSET -- This entry defines usage of Agent Headset option when agent log-out	13	0:Headset mode 1:Handset Mode 2:Eac-Mic Mode 3:Bluetooth mode 4:Logon Mode	1:Handset Mode
LOGOUT RESTRICTION -- This entry defines restriction of Logout State Agent.	14	0:Not use 1:CO outgoing 2:All call	0:Not use
CO ANSWER TIME -- This entry defines when the ACK message is sent to caller party.	15	0:Queued to group 1:Agent Answer	0:Queued to group
INFO DATA PRINT -- This entry defines usage of ACD Call Traffic Information data Print or Not. Information Traffic data will be printed at Information-Print Port.	16	0:Off 1:On	0:Off
INFO PRINT INTERVAL -- This entry defines print interval seconds of Information Traffic data.	17	001-250	001 (10 sec)
INFO CLR AFTER PRT -- If this value is ON, after print Information traffic data, previous data will be deleted.	18	0:Off 1:On	0:Off

ACD Group Announcement (TRANS/PGM 215)

The system provides 9 types of tone. Each tone may be assigned to normal tone, VMIB prompt/Announcement or internal/external music.

1. Press the [TRANS/PGM] button and dial 215.
2. Enter announcement table using dial pad
3. To program tone, dial tone index (1 - 9). Please refer to the Announcement INDEX Table of Web-Admin TRANS/PGM 215 for Announcement index
4. Press the Flex button.
 - Flex 1: Tone Type
 - Flex 2: Tone Time
 - Flex 3: Tone port index (Please refer to the TONE PORT Table)

1. Press the [TRANS/PGM] button and dial:
 220 for System Timers I
 221 for System Timers II
 222 for System Timers III.
2. Press the Flex button for the desired Timer; refer to Tables 2.3.6.1-1 to 3.
3. Use the dial pad to enter the desired Timer data.
4. Press the [SAVE] button to store the Timer data entry.

System Timers I (TRANS/PGM 220)

TRANS/PGM 220	BTN	RANGE	DEFAULT
CO-CO TRANS TMR -- Determines the answer waiting time when CO line is transferred to another CO line. If not answered in this time, transferred CO call is disconnected.	1	000-300 secs	030
HOT-DESK LOGOUT TMR -- Determines the amount of time the attendant receives recall after which the system will disconnect the call.	2	00-24 hrs	00
ACNR PAUSE TMR -- This timer establishes the time between ACNR attempts.	3	005-300 secs	030
PAGE TIME OUT TMR -- Determines the maximum duration of a page after which the caller and Page Zone are released.	4	000-300 secs	15
PAUSE TMR -- A Timed pause of this duration is used in Speed Dial and during other automatically dialed digits sent to the PSTN.	5	1-9 secs	3
VM PAUSE TMR -- When the system sends a "Pause" to Voice Mail using In-band signals, the Pause interval is defined by this timer.	6	1-9 secs	3
VMIB-MSG MIN TMR -- This timer sets the minimum duration allowed for a voice mail message in the system's VMIB. Messages shorter than this period are not stored.	7	1-9 secs	4
VMIB-MSG MAX TMR -- This timer sets the maximum duration allowed for the User Greeting in the system's VMIB.	8	00-999 secs	60
CALL-WAIT WARN TMR -- Determine the call-wait indication tone repeat time.	9	010-1800 secs	030
CAMP-ON WARN TMR -- Determine the camp-on indication tone repeat time.	10	010-1800 secs	030

TRANS/PGM 222	BTN	RANGE	DEFAULT
INTER DIGIT TMR -- Sets the maximum allowed time between user dialed digits; at expiration, the user will receive an error-tone.	3	00-300 (seconds)	015
INC CO INTER DIGIT TMR -- Sets the maximum allowed time between dialed digits from the Incoming CO.	4	01-60 (seconds)	15
NORMAL NO ANSWER TMR -- No answer timer for normal CO ring	5	001-600 (seconds)	30
DID NO ANSWER TMR -- No answer timer for DID CO ring	6	001-600 (seconds)	30
CO RECALL NO ANS TMR -- No answer timer for recall CO ring	7	001-600 (seconds)	30
CO FWD NO ANSWER TMR -- No answer timer for forward CO ring	8	001-600 (seconds)	30
CO XFER NO ANSWER TMR -- No answer timer for transfer CO ring	9	001-600 (seconds)	30

System Attributes (TRANS/PGM 223)

System Attributes programs define settings that affect System-wide features and functions. Generally, these entries will turn the feature ON (enable) or OFF (disable). Refer to the following table for a description of the Attributes and the data entries required.

1. Press the [TRANS/PGM] button and dial 223 for System Attributes I
2. Press the Flex button for the desired Attribute, refer to the following Table.
3. Use the dial pad to enter desired data for the Attribute.
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 223	BTN	RANGE	DEFAULT
WEB ADM PSWD ENCRYPTION -- The Web Admin password can be encrypted for security using RC-6 block encryption A Java VM must be installed on the user's PC.	1	0: Off 1: On	0: Off
PULSE DIAL BREAK RATIO -- The break/make ratio for pulse dialing through analog CO line.	2	0: 60/40 1: 66/33 2: 50/50	1: 66/33
VM SMDI ENABLE -- If it is set to "ON, system interfaces SMDI protocol with external Voice Mail, If 'OFF', system interfaces In-band message with external Voice Mail.	3	0:Off 1:On	0: Off

- Press the [SAVE] button to store the password entry.

TRANS/PGM 226	BTN	RANGE	DEFAULT
USER PASSWORD -- Includes configurable database access in Web Admin., and cannot access Keypad Administration functions.	1	12 digits	none
ADMIN PASSWORD -- Includes configurable database access in Web Admin., and can access Keypad Admin.	2	12 digits	none
MAINT PASSWORD -- Includes full and unlimited access to database and maintenance functions.	3	12 digits	none

Alarm Attributes (TRANS/PGM 227)

The System can monitor an external contact, most often employed as an Alarm indicator or Doorbell. The Alarm attributes define the operation of the external contact. An Alarm Signal sent to assigned stations can be repeating or a single burst, the former is often desired. For the Doorbell, a single tone is sent each time the contact is activated (refer to the programming table below for a description of the features, the data entries required and LCD displays for each attribute).

- Press the [TRANS/PGM] button and dial 227.
- Press the desired Flex button, refer to the following Table.
- Use the dial pad to enter desired data for the attribute.
- Press the [SAVE] button to store the data entry.

TRANS/PGM 227	BTN	RANGE	DEFAULT
ALARM ENABLE -- Enables the external contact monitoring circuitry.	1	0:Off 1:On	0:Off
ALARM CONTACT -- Establishes the contact state that will activate the Alarm, close or open.	2	0:Open 1:Close	0:Open
ALARM MODE -- The contact can be designated to function as a doorbell instead of an alarm.	3	0:Bell 1:Alarm	1:Alarm
ALARM SIGNAL MODE -- The assigned stations will receive a Repeating signal or single burst (ONCE) of the alarm tone.	4	0:Once 1:Repeat	1:Repeat

External Control Contacts (TRANS/PGM 228)

The MPB includes 1 contact, which can be used to control external devices. The contact is assigned to activate under one of several conditions: As a Loud Bell Contact (LBC), the contact will activate when the assigned station receives an external call.

NOTE: Y @} Á•q * /SÓÓÁq áÁ@ÁU•c{ /Á /Á @Áá @Á!Áq ^áÁUq * Á [á^É@Á] } c&Ó q /Á&Óq ^Á!Á q & { q * ÁVUCEÙBUÖT •Áq áÁ q /Á [!^Áq ^Á c&á } Áe•á { ^ } É

V @Á] } c&Ó q áé Áq! } c&á ^! ^Á Á&Óq q áÁe Áe Ö [!Á] & ÁU^!^e ^Á] } c&Ó q @} Á @ÁÖc! } qÁ Uáe ^ÁZ] } ^Á Á&&••^áÉ

FÈ Ú!^•Á @ÁVUCEÙBUÖT áÁ~ c} } Áq áÁ&ÁGG È

GÈ W^Á @Á&Á q áÁ Á} c! Á^•á^Á&áÉ

ÉÁ [cÁ^á
F /SÓÓÁÉÁ c&á } Á~ { á^ÉÖ c&Á ÉD
G Ö [!Á] & ÁU^!^e ^
H Öc! } qÁUáe ^Á&&••

HÈ Ú!^•Á @ÁVUCEÙBUÖT áÁ~ c} } Áq Á q! ^Á @ÁÖc! } qÁÖ [} c&Ó q áÁÁ } d^È

Music Sources (TRANS/PGM 229)

T~•BÁU]~•Áe^Á! [c&á^áÁ!Á•^Áe Á @ÁÖc& *! [~ } áÁ~•BÁe áD!Á~•BÉU} ÉP [!áÁ [~!&Á q]~•ÉY ÓYÁUÁ UÓÁ! [c&á^Á!Á } ^ÁFDÁ~•BÁU]~•ÉÖÁ&ááá } É&ÁXT ÓÁq } [~ } & { ^ } c} áé Á á^Á^& [!á^Áq áÁ] c&^áÁe ÁT UPEÖÁ&ááá } ÉUSVÁ [!c} } ÁUSÖÁ Á•^áÁe ÁT UPE

FÈ Ú!^•Á @ÁVUCEÙBUÖT áÁ~ c} } Áq áÁ&ÁGG È

GÈ Ú!^&Á @Á^•á^ÁÖÁ cÁ~ c} } ÉÁ^!Á Á @Á [||, q * Á/á^È

HÈ W^Á @Á&Á q áÁ Á^!&Á @Á^•á^ÁÁ~•BÁU[~!&È

I È V Á c&^Á @Á~•BÁU[~!&É! ^•Á @ÁVUCEÙBUÖT áÁ~ c} } È

TRANS/PGM 229	BTN	RANGE	DEFAULT
ICM BOX MUSIC CH -- assigns the music source for ICM BOX.	1	00: NO BGM 01: Internal Music 02: External Music 03: VMIB BGM 1 04: VMIB BGM 2 05: VMIB BGM 3 06: VMIB BGM 4 07: SLT MOH 1 08: SLT MOH 2 09: SLT MOH 3 10: SLT MOH 4 11: SLT MOH 5	1
INT MOH TYPE -- assigns the music for internal MOH.	2	00: Romance 01: Turkish March 02: Green Sleeves 03: Fur Elise 04: Carmem 05: Waltz 06: Pavane 07: Siciliano 08: Sonata 09: Spring 10: Campanella 11: Badinerie 12: Blue Dance	-
VMIB MOH -- assigns the VMIB Prompt index of VMIB Slot YY for VMIB MOH X.	3-6 for MPB300 (3-5 for MPB100)	01-70	-
SLT MOH -- assigns the SLT ports for SLT MOH.	7-11 for MPB300 (6-10 for MPB100)	-	-

RS-232 Port Settings (TRANS/PGM 230)

The system has one RS 232 serial port located on the MPB. Certain characteristics of the port are programmable: Baud rate, RS 232 control, and Page settings (refer to Table for a description of the settings, the data entries required and LCD displays).

1. Press the [TRANS/PGM] button and dial 230.
2. Select the desired Flex button, refer to the following Table.

TRANS/PGM 231	BTN	RANGE	DEFAULT
ON LINE SMDR -- Defines the serial port or TCP channel used for the On-line SMDR.	1	0-5	COM
OFF LINE SMDR -- Defines the serial port or TCP channel used for Off-line SMDR.	2	0-5	COM
SMDI -- Defines the serial port or TCP channel used for the SMDI output.	3	0-5	COM1
CALL INFO -- Defines the serial port or TCP channel used to receive Call Information output.	4	0-5	COM
TRAFFIC -- Defines the serial port or TCP channel used for the TRAFFIC report output.	5	0-5	COM
TRACE -- Defines the serial port or TCP channel used for the Trace output.	6	0-5	COM
ADMIN -- Defines the serial port or TCP channel used for the ADMIN Report output.	7	0-5	COM

SMDR Attributes (TRANS/PGM 232)

Station Message Detail Recording (SMDR) is an ASCII output of details on both incoming and outgoing calls. Various SMDR attributes can be assigned including: output records for all calls or Long Distance (LD) only, call cost per pulse when using call metering, etc. (refer to Table for a description of each Attribute, LCD displays and the data entries required).

1. Press the [TRANS/PGM] button and dial 232.
2. Select the desired Flex button, refer to the following Table.
3. Use the dial pad to enter the desired data.
4. To save SMDR Attribute data, press the [SAVE] button.

TRANS/PGM 232	BTN	RANGE	DEFAULT
SMDR FRACTION -- Determines the position of the decimal in the Cost per Pulse, starting from the right-most digit.	10	0-5	0
HIDDEN DIALED DGT -- Determines the number of dialed digits to hide for security purposes, and replaced with "*". Button 13 below defines whether leading or trailing digits are hidden. In addition, the station must be assigned for SMDR HIDE, TRANS/PGM CODE 131 button 7.	11	0-9	0
HIDDEN DGT POSITION -- When "HIDDEN DIALED DIGIT" is enabled, button 12 above, this field determines if leading or trailing digits are hidden.	12	0:Left 1:Right	1:Right
TRANSFER CHARGE MODE -- 1. INDIVIDUAL: When a call is transferred to another station, the transferred call is charged to two stations respectively. 2. INTEGRATE XFERING: When a call is transferred to another station, the call is charged to the transferring station. 3. INTEGRATE XFERED: When a call is transferred to another station, the call is charged to the transferred station.	13	0:Individual 1:Integrate Xfering 2:Integrate Xfered	0:Individual
TRANSFER CHARGE -- 1. NORMAL CHARGING: When Attendant make outgoing call and transfer this call to another station, the transferred will follow the Transfer Charge Mode. 2. ATD CHARGING: When Attendant makes outgoing call and transfers this call to another station, the call is charged to the Attendant. 3. XFERED CHARGING: When Attendant makes outgoing call and transfers this call to another station, the call is charged to the transferred station.	14	0:Normal Charging 1:Atd Charging 2:Xfered Charging	0:Normal Charging
WARNING TONE SVC -- if this option is enabled and SMDR service type is off-line, the system check free records space. And if free space is less than 1000, warning tone will be served as alarm to Attendant.	15	0:Off 1:On	0:Off

VÜÇÈÙÈÛÖT ÁGH-G	ÓVP	ÜÇÈÖÖ	ÖÖØØÈŠV
ÛT ÖÜÁÖUÞÞÁÛÛÖÄÈV@Áæ•ã}•Á[!ç!Á^Á ~•^áÁ!ÁÛT ÖÜÁÖç!æÁÛT ÖÜÁÖç!æÁÁ •^!ç^áÁ@ ~* @ŠÇÞÁ!ÁÛÖÈ	FÍ	€ÛÖ FÍŠÇÈ	€ÛÖ
ÈÛT VÚÁ ÇŠÁÖÜXÖÜÁÖÖÖÜÖÜÈÈÛT VÚÁ æÁ Ù^!ç^!ÁÛ!ÖÁ!^•È	Y ^áÁ U}	È	È
ÈÛT VÚÁ ÇŠÁÖÜXÖÜÁUÜVÈÛT VÚÁ æÁ Ù^!ç^!ÁÛ!ç~{ à^!		È	È
ÈÛT ÖÜÁÖUÜVÖÖÁ ÇŠÁÖÖÖÜÖÜÈÈÛT ÖÜÁ W^!ÁT æÁÖÁ!^•È		T æÁ! Á&@æç!•	È
ÈÛT ÖÜÁÛT VÚÁ ÇŠÁÖÜXÖÜÁÖÈÈÛT VÚÁ æÁ Ù^!ç^!ÁW^!ÁÖ		È	È
ÈÛT ÖÜÁÛT VÚÁ ÇŠÁÖÜXÖÜÁÖÙY UÜÖÈÈ ÛT VÚÁ æÁÙ^!ç^!ÁW^!ÁÛæ•, [!á		È	È
ÈÛT ÖÜÁÛT VÚÁÖÞÖÖÜÁÖÖÖÈÈ^} á^!ÇÈá!^•Á [-Á^!][!ç^!ÁÛT ÖÜÁÖÈ æ		T æÁ! Á&@æç!•	È
ÈÛT ÖÜÁÛT VÚÁÖÞÖÖÁ ÖÖŠŠÁÖVÈÈ^!^&Á ÛT ÖÜÁT æÁ^!} áÖæ		ÞÖÁ [] } áæ ÈÛ } áæ D ÞÖÈ	ÞÖÈ
ÈÛT ÖÜÁ ÇŠÁÖÞÖÖÖÖŠŠÁÖVÈÈ^!^Á ç ^È-Èæ Á!ÁÛT ÖÜÁæç! Á^Á^} ç! Áææ Á áæ áÈÈ! Á[Áæ Á^ç!á• ÈÈÈ-Á! Áç~!Á-Á ç@Áæ ÈÈ		€ÈÈH	€€
ÈÛT ÖÜÁ ÇŠÁÖWUÁÖÞÖÖÁ UÖÖÈÈÖÁ ÛT ÖÜÁ~!Á^ Á È@Á^•ç{ Áç Áç { æç Á •^} áÁ[çæç} Á^ÁÈ æÈ	Y ^áÁ U}	€U~ FKU}	FKU}
ÈÛT ÖÜÁ ÇŠÁÖWUÁÖÖŠVÖÁ UÖÖÈÈ^!^Á ÛT ÖÜÁ^ç!á• Áç!Á^} áç* ÁÈ æÈ		€U~ FKU}	FKU}

System Date, Time (TRANS/PGM 233)

V@Á^•ç{ ÅæÉã Ä^Á•æ!á @áÁ^ÁçÁ}d^ÈV@ÁæÁç áÁç ^Áç^Á{ }|| ^áÁ!Á^ç!áÁ
-æç!^•Áç áÁ} &ç!}•Áç &ç! áç *LŠÖÜÈŠÖÖÁç} |æ•ÈÛT ÖÜÁ^ ç~ç ÈÈ ç ÁÛç* ÁT [áÁ
Ù^!^&ç!} ÈÛ æ^ÈV] ÁÇÈ{ ÈÁçÈ
FÈ Û!^•Á@ÄÛÜÇÈÙÈÛÖT áç~ç!} Áç áÁæÁGHÈ
GÈ Û!^•Á@ÄÛÜÇÈÙÈÛÖT áç~ç!} Áç!Áç@Áç^ááÁÖçæ~ç ÈÈ^!Áç Áç@Áç||, ç* Áæ!È
ç^çÁFÁVá ^Á
ç^çÁGÁÖæÁ

3. Use the dial pad to enter desired data for the Attribute
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 233	BTN	RANGE	DEFAULT
SET SYSTEM TIME/DATE -- Sets the system time.	1	HH:MM	-
SET SYSTEM TIME/DATE -- Sets the system date.	2	MMDDYY	-
DST ENABLE MODE -- Enables DST feature for System Time.	3	0:Off 1:On	0:Off
- DST START TIME -- The DST start time.	Web Only	See DST Table	2nd Sunday of March at 2:00 AM
- DST END TIME -- The DST end time.		See DST Table	1st Sunday in Nov., at 2:00 AM

Button LED Flash Rate (TRANS/PGM 234)

The LED Color and Flash Rate for various functions and states can be assigned to any one of 15 System signals. The various functions and states are shown in the Tables (refer to [COLOR] and [FLASH RATE] Tables).

1. Press the [TRANS/PGM] button and dial 234.
2. Enter the Function range to change the LED Color or Flash rate (refer to Tables).
3. Press the Flex button 1 and dial (1-3) for LED color
OR
4. Press the Flex button 2 and dial (00-14) for LED flash rate.
5. Press the [SAVE] button to store.

VÜCE ÒÈŪŌT ÁGH	ÓVP	ÜCE ÖÖ	ÖÖŌŌŌŠV
ŽÖŠŠÁŌŌŠŌŠ ı } ŠÖÖÁŕæ •ŕ ç!& { Šç/ŠæŠ Š Á æç^É	F	Ō [ÁĒĪ Ōæ @ * Ūæ^ÁĒĒĪ	Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽÖŠŠÁŌŌŠŌŠ ı } ŠÖÖÁŕæ •ŌUÁ^ ^ ă * Š Š Á •^É	G		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽÖŠŠÁŌŌŠŌŠ ı } ŠÖÖÁŕæ •Ā @ } ŠĀ ^••æ^Š Á ^É	H		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŪWŌŠ ı } ŠÖÖÁŕæ •Ā @ } Š [Š Š Á ^ çáÉ	I		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŪWŌŠ ı } ŠÖÖÁŕæ •Ā @ } ŌUŪŠ Š [, } É	í		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŌPŌŠ ı } ŠÖÖÁŕæ •ŕ ŌPŌĒ	î		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŌPŌŠ ı } ŠÖÖÁŕæ •ŕ Ā } ^ÁĒ ^ŌPŌĒ	ï		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŌPŌŠ ı } ŠÖÖÁŕæ •Ā @ } ŪçĒ } Šæ•ă } ŠĀ] ^•^ ^çáĀ ^••æ^É	ì		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽÖŠŠÁŌŌŠŌŠ ı } ŠÖÖÁŕæ •Ā @ } ŌŌPŪŠ Š Á •^É	J		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŪŌŌŌŌŌŪŠ ı } ŠÖÖÁŕæ •Ā @ } Ā } ŠĀ [} ç!•çĒ } Á ^•ă * Š@Á ^æ!] @ } ^É	FĒ		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŪŌŌŌŌŌŪŠ ı } ŠÖÖÁŕæ •Ā @ } Ā } ŠĀ [} ç!•çĒ } Á ^•ă * Š@Á @æ•^É	FF		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ
ŽŪŌŌŌŌŌŪŠ ı } ŠÖÖÁŕæ •Ā @ } Á^&ăă * ŠĀ Á ă ç!& { ŠçĒ	FG		Ōæ @ÁĒĒĪ Ō [ÁŪÖÖ

TRANS/PGM 234	BTN	RANGE	DEFAULT
[HOLD] button LED status while Paging.	13	Color 1-3 Flashing Rate 00-14	Flash: 60 IPM Color: RED
[HOLD] button LED status when in Voice-over mode.	14		Flash: 60 IPM Color: AMBER
[HOLD] Reserved.	15		Flash: 60IPM Color: AMBER
[RING] LED status when receiving an intercom call.	16		Flash: 60 IPM Color: RED
[RING] LED status when receiving an incoming CO call.	17		Flash: 60 IPM Color: RED
[RING] LED status when a message is left.	18		Flash: 60 IPM Color: RED
[HEADSET] LED status when the headset is used (LIP-8000 Phone).	19		Flash: Steady Color: RED
HEADSET] LED status when Bluetooth™ is used (IP-8000 Phone).	20		Flash: 60 IPM Color: RED
[DN] button LED status when I use is active.	21		Flash: Steady Color: GREEN
[DN] button LED status when another station is in use.	22		Flash: Steady Color: RED
[DN] button LED when status in DND.	23		Flash: Off Color: RED
[DN] button LED status when receiving an intercom call.	24		Flash: 60 IPM Color: GREEN
[DN] button LED status when call is in Held state.	25		Flash: 60 IPM Color: AMBER
[DN] button LED status when Call forward is set.	26		Flash: Off Color: RED
[DN] button LED status when I am in conference.	27		Flash: Steady Color: GREEN
[DN] button LED status when another station is in conference mode.	28	Flash: Steady Color: RED	
[DN] button LED status when active conference supervisor.	29	Flash: 60 IPM Color: AMBER	

Color Table

COLOR	DESCRIPTION
1	RED
2	GREEN
3	AMBER

Flash Rate Table

FLASH RATE	DESCRIPTION
00	Flash OFF
01	Steady On
02	30 ipm flash (30% On)
03	60 ipm flash (30% On)
04	60 ipm double wink (30% On-Off-On-Off 70% On)
05	240 ipm flash (30% On)
06	240 ipm flutter (30% On-Off-On-Off-On & 70% Off)
07	480 ipm flash (30% On)
08	480 ipm flutter (30% On-Off-On-Off-On & 70% Off)
09	15 ipm flash (30% On)
10	120 ipm flash (30% On)
11	120 ipm flutter (30% On-Off-On-Off-On & 70% Off)
12	30 ipm double flash (30% On-Off-On & 70% Off)
13	480 ipm double wink (30% On-Off-On-Off 70% On)
14	480 ipm double flash (30% On-Off-On & 70% Off)

ISDN PPP Web Admin Attributes (TRANS/PGM 235)

In addition to remote access via an IP network connection, the system database may be accessed remotely via an ISDN connection. Placing a call over an ISDN Line to the designated PPP Station will provide a connection to the system database. The system will request a user

ÖÁã àÁæ• [láÈ ÖÇÖÁ~•cÁ æ&ÖÁ}^Á Á@ÁV^ÁÖÁã àÁæ• [lá•Áæ•ã}^áÈÖÇc^Á@Á
 { æ&ÖÁ *Áãã} àÁæ•, [láÁ^Á} c^ÁáÈÖÁ ÖYÁÖÁP [^Á æ^ÁÁÁ [çã^Áãã} àÁV^áÁÖÁ { áÁÁ
 æ&Á••áÈÁ

FÈ Ú!Á••Á@ÁVÜÇÈÙÈJÖT ÁGHÍ ÖÁ} Áã àÁãÁGHÍ È

GÈ Ú!Á••Á@ÁÁ•ã^áÁÖ^cÁ~ ÖÁ} ÈÁ^ÁÁÁ Á@ÁÁ ||, á *ÁæÁ^È

HÈ W^áÁ@ÁãÁÁ æÁÁ Á} c^ÁÁ•ã^áÁæáÈ

I È Ú!Á••Á@ÁVÜÇÈÖÁ~ ÖÁ} ÁÁ ÁÁ c^ÁÁ@ÁæáÁ} d^

VÜÇÈÙÈJÖT ÁGHÍ	ÓVP	ÜÇÈÖÒ	ÖÒÇÈVŠV
ÚÚÁÁVÜÇÈÖÁ~c^Á { á^ÁÁÚÚÁÁ} æÁ^áÁ!Áã æÁ^áÈ	F	€K~ FKU}	€K~
ÚÚÁÁÖÜVÇÈVÁWT ÖÜÁÈÖÁ@Á & { á *Áæãæã ÁÁ Í Áã} •Á} !^c^áÁã æÁÁ} áÁ@ÁæÁ^áÁæc^Á~ { à^ÁÁ { æ&@•Á@ÁÚÚÁÁ•c^Á} Á~ { à^ÁÈ@Á^•c^Á ÁÁÁ æÁÁ { æÁÁÁ} •, ^Á@ÁæÁÁ} áÁ~^Á•ÁÚÚÁÁÖÁ} áÁ]æ•, [láÈ	G	Üçã} Á~ { à^Á	P [] ^
ÚÚÁÁVÜÇÈÖÁ~c^Á { Á&&} •Á@ÁÚÚÁÁÖÁÈ	H	T æÁÁÁ&@æáÁ•	P [] ^
ÚÚÁÁÜÇÈÜY ÜÜÖÁÈÁV@Áæ•, [láÁ} c^Á^áÁÁ^áÁÁ æ c@íá^ÁÚÚÁÁÖÁÈ	I	T æÁÁÁ&@æáÁ•	P [] ^
ÚÚÁÁVÜÇÈÖÁ~c^Á { Á&&} •Á@ÁÚÚÁÁÖÁÈ	Í	T æÁÁÁ&@æáÁ•	P [] ^
ÚÚÁÁÜÇÈÜY ÜÜÖÁÈÁV@Áæ•, [láÁ} c^Á^áÁÁ^áÁÁ æ c@íá^ÁÚÚÁÁÖÁÈ	Î	T æÁÁÁ&@æáÁ•	P [] ^

Mobile Attributes (TRANS/PGM 236)

V@Áæ ÖÁã áÁã} áÁ} ~c^Á ^ÁÁ!ÁæÁÁ} •Á!á *ÁÁ [{ Á [àà^Ácc} •á } Áã ÁÁÁ•ã}^áÈ

FÈ Ú!Á••Á@ÁVÜÇÈÙÈJÖT ÁGHÍ ÖÁ} Áã àÁãÁGHÍ È

GÈ Ú!Á••Á@ÁÁ•ã^áÁÖ^cÁ~ ÖÁ} ÈÁ^ÁÁÁ Á@ÁÁ ||, á *ÁæÁ^È

HÈ W^áÁ@ÁãÁÁ æÁÁ Á} c^ÁÁ•ã^áÁæáÈ

I È Ú!Á••Á@ÁVÜÇÈÖÁ~ ÖÁ} ÁÁ ÁÁ c^ÁÁ@ÁæáÁ} d^

VÜÇÈÙÈJÖT ÁGHÍ	ÓVP	ÜÇÈÖÒ	ÖÒÇÈVŠV
ÖÇÈPÁÖÖVÁV@Áæ ÖÁã áÁ [{ Á [àà^Ácc} •á } È	F	T æÁÁÁã á	E
ÖÚWÁÖ ÖÜÁV@Á c^ÁÈá áÁÁ ^ÁÁ Á@Á [àà^Áæ ÖÁã á ÖÁ^ÁÈ	F	€ÈÖÁ^ & } á•D	€Í

One Digit Service Attributes (TRANS/PGM 237)

When performing a call transfer from a mobile extension, the flash digit and input timer can be assigned.

1. Press the [TRANS/PGM] button and dial 237.
2. Press the desired Flex button, refer to the following Table.
3. Used the dial pad to enter desired data.
4. Press the [SAVE] button to store the data entry

TRANS/PGM 237	BTN	RANGE	DEFAULT	
STEP CALL -- determines if Step Call is enabled or disabled.	1	0: Disable 1: Enable	Disable	
DIGIT 1 -- when accessing a busy tone, User may dial for one of the one-touch services.	2	0: N/A 1: Call-Back 2: Camp On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	0: N/A	
DIGIT 2 --	3			
DIGIT 3 --	4			
DIGIT 4 --	5			
DIGIT 5 --	6			
DIGIT 6 --	7			
DIGIT 7 --	8			
DIGIT 8 --	9			
DIGIT 9 --	10			
DIGIT 0 --	11			
DIGIT * --	12			Call Wait
DIGIT # --	13			Voice-Over

Dummy Dial Tone Digit (TRANS/PGM 240)

When digit conversion is programmed, the CO line is seized after digit conversion is completed. When programmed, in the event a user cannot obtain the CO dial tone from PX, a dummy dial tone can be provided.

1. Press the [TRANS/PGM] button and dial 240.
2. Dial bin no.
3. Used the dial pad to enter desired data.
4. Press the [SAVE] button to store the data entry

TRANS/PGM 241	BTN	RANGE	DEFAULT
<p>CALL EXECUTIVE -- This option is to directly route calls to the Executive station.</p> <p>OFF: executive calls are routed to secretary.</p> <p>FIRST SEC. DND: the executive receives call when first secretary is in 'DND'.</p> <p>ALL SEC. DND: the executive receives call when all secretaries in 'DND'.</p>	5	0-2	0
<p>SECRETARY CHOICE -- Determines order in which secretary stations will receive calls (First Idle/Longest Idle).</p>	6	0-1	0
<p>MSG WAIT STATION -- Determines if message wait indication is left at Executive Station or Secretary.</p> <p>EXECUTIVE: message left at Executive station.</p> <p>FIRST SEC: message is left at the first secretary.</p>	7	0:Executive 1:First Secretary	0

Executive-Executive Access (TRANS/PGM 242)

Each Executive can be allowed or denied access to other Executives. As a default, calls between executives are disabled.

1. Press the [TRANS/PGM] button and dial 242.
2. Use the dial pad to enter a bin no.
3. Press desired Flex button number (1-2),
Flex 1: access for 1 to 24
Flex 2: access for 25 to 48
4. Press the desired Flex button to toggle access.
- LED ON: access allowed, LED OFF: access not allowed.
5. Press the [SAVE] button to store the data entry

TABLES DATA - TRANS/PGM 250-269

Toll Tables (TRANS/PGM 250)

Based on Table entries, Stations or DISA users are allowed or denied dialing specified numbers. The following rules apply to establishing restrictions based on the Table entries:

- If entries are only made in the Allow Table, only those numbers entered can be dialed, all other dialed numbers will be restricted.

1. Press the [TRANS/PGM] button and dial 251.
2. Dial Digit Conversion Table Number (1-9).
3. Dial conversion Bin No (001-300)
 - Flex 1: Apply Time Type
 - Flex 2: Dialed Digit
 - Flex 3: Unconditional Changed Digit
 - Flex 4-6: Day/Night Timed Changed Digit
 - Flex 7-15: LCR Time (Day/Time Zone Changed Digit)
 - Flex 16-17: DNT/LCR Time Table Index
 - Flex 18 : DID Name
 - Flex 19 : Apply Option
4. Use the dial pad to enter the dialed number.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 251	BTN	RANGE	DEFAULT
APPLY T-TYPE -- The Apply time type to be applied when the dialed digit is dialed.	1	0:Unconditional 1:Follow DNT 2: Follow LCR	Unconditional
DIALED DIGITS -- The dialed digits.	2	Max 16 digits	-
UNCOND CHANGED -- The CO Group Access Code and digits to be sent to PX when the dialed digit is pressed if Apply time type is 'unconditional'.	3	Max 16 digits	-
DAY CHANGED -- The CO Group Access Code and digits to be sent to PX in Day when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	4	Max 16 digits	-
NIGHT CHANGED -- The CO Group Access Code and digits to be sent to PX in Night when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'	5	Max 16 digits	-
TIMED CHANGED -- The CO Group Access Code and digits to be sent to PX in Timed when the dialed digit is pressed if Apply time type is 'FOLLOW DNT'.	6	Max 16 digits	-
D1/T1 CHANGED -- The CO Group Access Code and digits to be sent to PX in 'Day 1/Time 1' when the dialed digit is pressed if Apply time type is 'FOLLOW LCR'.	7	Max 16 digits	-

VÜÇÈÙÈÚÖT ÁÍ F	ÓVÞ	ÜÇÈÖÒ	ÖÖÇÈVŠV
ÖFV/GÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç FVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	I	T æÁÍ Áä ä	È
ÖFV/HÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç FVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	J	T æÁÍ Áä ä	È
ÖEV/FÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç EVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	F€	T æÁÍ Áä ä	È
ÖEV/GÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç EVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	FF	T æÁÍ Áä ä	È
ÖEV/HÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç EVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	FG	T æÁÍ Áä ä	È
ÖEV/FÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç EVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	FH	T æÁÍ Áä ä	È
ÖEV/GÓPÇÈÖÖÖÆV@Áä ä Áç Á^Áç áÁç ÁÖ ç ÁEVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	FI	T æÁÍ Áä ä	È
ÖEV/HÓPÇÈÖÖÖÆV@ÁUÁÖ; [^] ÁB&••ÁÖ [á^Áç áÁä ä Á ç Á^Á^) ç ÁYÁ ÁÖ ç ÁEVÄ ^ ÁÇ @ } Á@ Áç áÁä ä Á] !••^ áÁÇ] Áç ^ Áç] ^ Á ÇUŠSUY ÁÖÜÈ	FÍ	T æÁÍ Áä ä	È
ÖPVÁ/G ÖÁÖ ÖÖYÆZ ç Þ ä @VÄ ^ áÁVÄ ^ Áç Áç Áç É	FÍ	FÉÇ [] ^	}[] ^
ŠÖUÁ/G ÖÁÖ ÖÖYÆZŠÖUÁVÄ ^ Áç Áç Áç É	FÍ	FÉÇ [] ^	}[] ^
ÞÇÈ ÖÆV @ } ÁÖÖÁ^ ç ç } Á ç ç Áç * Áç @ Á ç ^ Á ää] ç áÁ } Á@ Áç * ç * Á ç } ÇŠÖÈ	FI	T æÁÍ Áä ä	È
ÇÈÚŠYÁUÚVÞÆV@Áç] ÁÚ] ä } Áç Á^Áç] ä áÁ ç ç] äç * Áç Á@ Áç ^ È	FJ	€Ç FKÜç } GÖUÁç ^ HÖç ^	€Ç

Digit Conversion Options (TRANS/PGM 252)

V@!^ Áç Áç [Á] ä } • Áç | Öä äç [} ç^!•ä } | ŠÖÖ/Öä] | ç Áç áÁÜÇ VÄ ^ - | Áç Áç | ^ È

1. Press the [TRANS/PGM] button and dial 252.
2. Dial Digit Conversion Table Number (1-9).
3. Press the Flex button (1-2)
4. Use the dial pad to enter the dialed number.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 252	BTN	RANGE	DEFAULT
DISPLAY CONV. DIGIT -- If it is set to ON, the station LCD is updated to the dialed digits when alerting message is received from the PX after dialing.	1	On/Off	Off
PRINT CONV. DIGIT -- If it is set to ON, the dialed digits are printed to the SMDR.	2	On/Off	Off

Time Table Attributes (TRANS/PGM 253)

The system can automatically select the Ring and COS Mode based on the system time table. Three Ring and COS modes are supported: Day, Night, and Timed modes.

Each Time Table has a ring mode relating to the different ring assignments, COS, and answering method for the system. The ring mode can be controlled automatically through definitions in the Auto Ring Mode & weekly timetable based on the Time Table. The Attendant may change the system mode selection from automatic to manual. Refer to the following table for a description of the functions, the LCD displays and data entries required.

1. Press the [TRANS/PGM] button and dial 253.
2. Use the dial pad to enter the desired Table range.
3. Press the Flex button for the desired setting; refer to the following Table.
4. Use the dial pad to enter the desired flexible button.
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 253	BTN	RANGE	DEFAULT
TIME ZONE COMMENT-- defines the comment of the Time Table.	1	32 characters	none
SYSTEM TIME ZONE -- defines the Time Zone of the Time Table	2	0-73	0: Sys Time
DAYLIGHT SAVINGS -- defines Daylight Saving Time of Time Table.	3	On/Off	Off

VÜCE ÒÜJÖT ÁÍ H	ÓVP	ÜCE ÖÒ	ÖÒÜVŠV
ÜÖÖÁ ÜÖÖÁ^ã ^•Á@Áã * Á [á^Á -Áã ^Áã ÁÈ	I	ÈÖæ FÁã @ GÁã ^á	ÈÖæ
ÜWUÜÖÖÁ ÜÖÖÁ^ã ^•Á@ÁÈ ç Áã * Á [á^Á -Áã ^Á Vã ÁÈ	Í	U} Ü-Á	U~

Weekly Time Table (TRANS/PGM 254)

V@Áã * Á [á^Áã Á^ÁÍ } d [|^áæ ç { æã|Á@ [^ * @Á^ã } •Á @ÁÈ ç Áã * Á [á^Áã áÁ
Y ^\| Áã ^Áã|Áã^áÁ } Á@Áã ^Áã|ÁÈ

V@Áã^ã ^•Á |Áæ Èã @Áã áÁæáá } áÁ ^•Á |Áã ^áÁ [á^Áã] ç|^áÁ |Áæ@Áæ Á
[Á ^\| È

FÈ Ü|^•Á@ÁVÜCE ÒÜJÖT áã ç } Áã áÁã|ÁÍ È

GÈ W^Á@Áã|Áã^áÁ } ç|^Á@Áã^áÁ } æ çáã * ^Á

HÈ Ü|^•Á@ÁçÁÈ Á |Á@Áã^áÁæ Á -Á ^\| ÁÇ [] áæ ÈÜ } áæ ÈÈ

I È Ü|^•Á@ÁçÁÈ Á |Á@Áã^áÁã * Á [á^Áãæ Èã @Áã ^Áã|ÁÈ ç|^Áã|ÁÈ

Í È W^Á@Áã|Áã^áÁ } ç|^Áã ^ÁÇ áã^Áã ^ÖÈÈÈÁ ÁÍ JÈ

Î È Ü|^•Á@ÁVÜCE Öá ç } Á Á ç|^Á@Áã } ç|^áÈ

VÜCE ÒÜJÖT ÁÍ I	ÓVP	ÜCE ÖÒ	ÖÒÜVŠV
T [] áæ ÜÖYÜÖPVEVQ ÖÖÁã * Á [á^Áã^ã ^•Áã áÁQ ÖÖÁ [á^Á ^ } áÁã ^•È	F	ÈÈÈÈÈÍ J	Öæ ÍÁÍÈÈ PãÍÁÍÍÈÈ VÖÜÁ È VÖÖÁ È
V ^•áæ ÜÖYÜÖPVEVQ ÖÖÁã * Á [á^Áã^ã ^•Áã áÁQ ÖÖÁ { [á^Á } áÁã ^•È	G	ÈÈÈÈÈÍ J	Öæ ÍÁÍÈÈ PãÍÁÍÍÈÈ VÖÜÁ È VÖÖÁ È
Y ^á } ^•áæ ÜÖYÜÖPVEVQ ÖÖÁã * Á [á^Áã^ã ^•Áã áÁQ ÖÖÁ { [á^Á } áÁã ^•È	H	ÈÈÈÈÈÍ J	Öæ ÍÁÍÈÈ PãÍÁÍÍÈÈ VÖÜÁ È VÖÖÁ È

TRANS/PGM 254	BTN	RANGE	DEFAULT
Thursday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	4	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Friday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	5	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Saturday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	6	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __
Sunday DAY/NIGHT/TIMED ring mode start times and TIMED mode end times.	7	0000-2359	Day: 9:00 Nite: 18:00 TDS: __ TDE: __

LCR Time Table Attributes (TRANS/PGM 255)

The LCR Time Tables provide a mechanism to define the database with Digit Conversion Table (PGM251-252), which will route outgoing calls, particularly long distance, using the most cost-effective route.

Additionally, days of the week are grouped into zones (Day Zones) and the time of day can be set into three groups (Time Zones). The TRANS/PGM 255 table provides general descriptive information and input ranges.

1. Press the [TRANS/PGM] Button and dial 255
2. Press Flex button 1-4, refer to the Table.
3. For LCR Time Zones, use the dial pad to enter desired data. Refer to the Table for input ranges.
 - Flex 1-7: to select the day of week (1=Monday, 7=Sunday).
4. Enter the desired Day Zone (1-3).
5. Press the [SAVE] button to store the data entered.

- Flex 4: Tenant No
4. Use the dial pad to enter the dialed number.
 5. Press the [SAVE] button to store the data entered.

TRANS/PGM 257	BTN	RANGE	DEFAULT
SYS SPD DIAL -- The System Speed Dial Digits.	1	Max 32 digits	-
SYS SPD NAME -- The System Speed Dial Name.	2	Max 16 characters	-
TOLL FREE -- Assignment to apply toll free.	3	0:Off 1:On	0:Off
TENANT NO -- The tenant number to be applied to the System Speed Access.	4	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

Emergency Code Table Attributes (TRANS/PGM 258)

The Emergency Code Table is used to identify emergency numbers which, when dialed, will override all COS dialing restrictions. An Emergency Code number may be up to fifteen (16) digits iPress the [TRANS/PGM] button and dial 258.

1. Use the dial pad for the desired Emergency code entry, 01-50.
2. Press the Flex button (1-3)
 - Flex 1: Dialed Digit
 - Flex 2: Changed Digit (To be dialed digits)
 - Flex 3: Tenant number
3. Use the dial pad to enter the dialed number.
4. Press the [SAVE] button to store the data entered.

TRANS/PGM 258	BTN	RANGE	DEFAULT
DIALED DIGIT -- The dialed digits from user.	1	Max 16 digits	-
CHANGED DIGIT -- CO Group Access Code and digits to be sent to PX when user dials the dialed digit.	2	Max 16 digits	-
TENANT NO -- The tenant number to be applied when user dials emergency code. If this field be left empty, this entry will be adapted to all tenants.	3	Empty, 1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

Announcement Table (TRANS/PGM 259)

The System Speed can be assigned (refer to Tables).

TRANS/PGM 260	BTN	RANGE	DEFAULT
CCR TABLE -- The destination of CCR input digit; the destination can be a Station number, Station group number or Feature code. NOTE: For Feature codes, refer to the Numbering Plan for the applicable codes.	1-12	Max 8 digits	-

Customer Call Routing Table (TRANS/PGM 262)

The system can employ Incoming Calling Line ID (ICLID) to determine the routing of incoming external calls. Each CO/IP Line may be assigned to employ ICLID routing. The System will compare the received ICLID to entries in the ICLID Route Table, and if a match is found, the System will route the call to the destination indicated by the index (bin) number (TRANS/PGM 181).

1. Press the [TRANS/PGM] button and dial 260.
2. Use the dial pad to select a CCR Table index, 001-100. The index number is the index of Announcement Table (TRANS/PGM 259)
3. Press a Flex button (1-12, 10=0, 11=*, 12=#) to assign a route for the associated CCR dialed digit.
4. Use the dial pad for Destination.
5. Press the [SAVE] button to store the data entered.

TRANS/PGM 262	BTN	RANGE	DEFAULT
ICLID NUMBER -- ICLID used to match the index.	1	24 digits	None
ICLID NAME -- ICLID name that is sent by the System to the destination for the ICLID routed call.	2	16 characters	-
INC CO GROUP NO -- The CO Group Number to apply ICLID route; if not assigned, ICLID is applied to all CO Groups.	3	1-72	-
DAY RING INDEX -- The index to be routed in Day; the Alternative Ring Index (TRANS/PGM 181).	4	1-80	-
NIGHT RING INDEX -- The index to be routed in Night; the Alternative Ring Index (TRANS/PGM 181).	5	1-80	-
TIMED RING INDEX -- The index to be routed in Timed; the Alternative Ring Index (TRANS/PGM 181).	6	1-80	-
TENANT NO -- The tenant number to be applied the ICLID.	7	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1

13	950	0	100 ms ON / 200 ms OFF	2
14	425	0	200 ms ON / 200 ms OFF / 200 msec ON / 3400 msec OFF	255 (Cont.)
15	620	0	100 ms ON / 100 ms OFF	255 (Cont.)
16	425	620	500 ms ON / 500 ms OFF	255 (Cont.)
17	350	0	1 sec ON	255 (Cont.)
18	425	0	200 ms ON / 200 ms OFF / 200 ms ON / 1400 ms OFF	1
19	1260	1633	500 ms ON / 500 ms OFF	255 (Cont.)

Ring Table (TRANS/PGM 265)

Each Ring can have 4 different types among 15 Ring. After 4 different ring index programmed, CO line or Station may select one of 4 types.

INDEX	RING NAME
1	Normal Call Ring (Station)
2	Normal Call Ring (CO)
3	Recall Ring (Station)
4	Recall Ring (CO)
5	Forward Call Ring (Station)
6	Forward Call Ring (CO)
7	Transfer Call Ring (Station)
8	Transfer Call Ring (CO)
9	Call Back Indication Ring
10	Wakeup Indication Ring
11	Revertible Ring
12	Paging Call Ring
13	Handsfree Answer Ring
14	Command Call Ring
15	Alert Ring
16	Alarm Ring
17	Fault Ring

TRANS/PGM 269	BTN	RANGE	DEFAULT
VOICE MAIL 1 -- Put Mail code sent when the voice mail is to receive call to record a message.	1	0: Prefix 1: Suffix Any digits	P#
VOICE MAIL 2 -- Get Mail code sent when the voice mail is to playback recorded messages.	2	0: Prefix 1: Suffix Any digits	P##
VOICE MAIL 3 -- Busy Mail code sent when the voice mail is to receive a call while the user is busy.	3	0: Prefix 1: Suffix Any digits	P#*3P
VOICE MAIL 4 -- DND Mail code sent when the voice mail is to receive a call while the user is in DND.	4	0: Prefix 1: Suffix Any digits	P#*4P
VOICE MAIL 5 -- No Answer Mail code sent when the voice mail is to receive a call when the user did not answer.	5	0: Prefix 1: Suffix Any digits	P#*5P
VOICE MAIL 6 -- Error Mail code sent when the voice mail is to receive a call when a dialing error exists.	6	0: Prefix 1: Suffix Any digits	P#*6P
VOICE MAIL 7 --	7	0: Prefix 1: Suffix Any digits	-
VOICE MAIL 8 --	8	0: Prefix 1: Suffix Any digits	-
VOICE MAIL 9 -- Disconnect Mail code sent when the voice mail is to disconnect a call.	9	0: Prefix 1: Suffix Any digits	*****

TENANTS DATA - TRANS/PGM 270-290

Each tenant on the System can have an Attendant Group. An Attendant group can have up to 5 Attendants.

Attendant Group - TRANS/PGM 270-272

Attendant Group (TRANS/PGM 270)

ÖÖ} ää öÖ} • Ää Ä^Ä:[~] ^äÄ[ÄÖÖÄ] • Ä ä^ä&ÖÄ | Ää Ä^ÖÖ} ää öÖ Ä^Ä:[~] ÖÄ V@Ä • Ö{ Ä[, • Ä • ä } { ^ } ÖÄ Ä^Ä:[& • • Ä Ä^Ä ÄÖä& | äÄ^ | { ä äÄÜä * ÖÖ } * ^ • ÖÄ | Ä { [ä^ • È

Ü^Ä | Ä Ä^Ä | | | , ä * Ää^Ä | Ää^ • & ä ä } Ä Ä^Ä } & ä } • Ö@ ÖÖÖÄä | ä • Ää ä Äää d ä • Ä | ^ ~ ä^äÈ

FÈ Ü | • • Ä@ ÄVÜÖEÜBÜÖT ä ~ ö } Ää ä ÄäÄG €€

GÈ W^Ä@ ÄäÄä äÄ Ä } Ö | Ä@ Ä^ • ä^äÄ } ä ö { ä | ÄFÈ Ä | Ä@ Ä ÖYÄÜÄ€€ä äÄÄÄ | Ä T ÖYÄÜÄ€€È

HÈ Ü | • • Ä@ Ä^Öä ~ ö } Ä | Ä@ Ä^ • ä^äÄ^ä * LÄ^Ä | Ä Ä^Ä | | | , ä * Ää^ÄÈ

I È W^Ä@ ÄäÄä äÄ Ä } Ö | Ä@ Ä^ • ä^äÄÖÖ} ää öÖ:[~] ÄääÈ

NOTE: Ö | Ä | [~] Ä ^ { ä | • ÖÄ } Ö | Ää Ää } ää ö { ä | Ä | Ää } ää öä * ^ ÖÖ | Ää Ää ää ~ äÄ ää } Ä | • • Ä@ Ä^ • ä^äÄ^Öä ~ ö } Ä | Ä@ Ä [• ää] Ä Ä^Ä ää } Ä Ä^Ä | [~] Ää ä ÄäÄ@ Ää } ää ö { ~ { ä | ÖÖ | Äää * ^ Ä } Ö | Ä@ Ää • ää ä Ää Öä ää } Ä { ä | Ä Ä@ Ää * ^ Ä } | Öä ää ÖÖÖÄä { [ä | Ää Ä^Ää • ä } äÈ

Í È Ü | • • Ä@ ÄVÜÖEÜBÜÖT ä ~ ö } Ä Ä ä | Ä@ ÄääÄ } Ö | ^ äÈ

VÜÖEÜBÜÖT ÄG €	ÖVP	ÜÖEÖÖ	ÖÖÖEVSV
ÖEVOÖÜÄYÜÖEÖ^ä • Ä@ Ä^ ^Ä ÖÖ} ää öÄ:[~] È	F	ÖÄ^ { ä ä FÄÖä& ä GÄÜä * HÖÖ } * ^ • ÖÄ Ä	€
ÖEVOÖÜÄÖE ÖÄEÖ^ä • Ä@ Ää ^Ä ÖÖ} ää öÄ:[~] È	G	T äÄÄ	È
ÖÜÄÖÖÄWT ÖÜÄEÖ^ä • Ää } ää öÄÄ { ä Ä ÄÜÄä ^È	H	T äÄÄ	È
T ÖT ÖÜÄÖÜÖÄE • ä } • Ä ää } • Ää ^ { ä • Ä Ää ÖÖ} ää öÄ * [~] È	I	È	Öä • ÖÖää }

Attendant Group Greeting/Queuing (TRANS/PGM 271)

ÖäÖÖ} ää öÄ:[~] ÄÖÖ ÄäÄä^Äää ~ Ö • Ä | ää * Ä Ä^Ä | ^ä * Ää äÄ^ ~ ä * Ä ä } [~] & { ^ } • ÖÄ ^ÈV@Ä | | | , ä * Ää^Ä | [çä^ • Ä^ • & ä ä } • Ä | Ä@ Äää ~ Ö • Ää ä Ä@ ÄääÄ ^ } d ä • Ä^ ~ ä^äÈ

1. Press the [TRANS/PGM] button and dial 271.
2. Use the dial pad to enter the desired tenant number (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Press the Flex button for the desired attribute, refer to Table.
4. Use the dial pad to enter the desired attendant group attributes data, refer to the Table.
5. Press the [SAVE] button to store the data entered.

TRANS/PGM 271	BTN	RANGE	DEFAULT
GREETING TYPE -- Determines the type of Greeting Tone to be used.	1	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	1: Normal
GREETING PLAY -- Determines the Greeting Play time.	2	000-180 (sec)	000
GREETING TONE NO --- Determines the Greeting Tone number when greeting type is set to Normal.	3	01-19	04
GREETING PROMPT/ANNC -- Determines the Greeting Prompt/ Announce Number when Greeting Type is set to Prompt or Announce.	4	001-255	Not Asg
GREETING REPEAT NO -- Determines the number of times the Greeting will repeat.	5	000-100	3
GREETING RPT DELAY -- Determines the length of time the timer will pause before the greeting is repeated.	6	000-100 (seconds)	0

VÜÖÉ ÛÉÚÓÉ ÁÉ F	ÓVP	ÜÖÉ ÖÖ	ÖÖÖÉVŠV
ÚWÖÖÖÖÁYÜÖÁÉÖ^c! { á^•Á@Á] ^Á -ÁÜ^ ^ á*Á [} ^É	í	FÉP [! { áÁ GÁÜ [{] c HÖÉ } & I ÉÖ VÁ UP Í ÉÖ Y VÁ UP Î KÁ T ÖÁ UPF Ï KÁ T ÖÁ UPG Ì KÁ T ÖÁ UPH J KÁ T ÖÁ UPI FÉÜŠVÁ UPF FFÜŠVÁ UPG FGÜŠVÁ UPH FHÜŠVÁ UPI FI KÜŠVÁ UPÍ	I
ÚWÖÖÖÖÁÜÖÁÜÖÁÜÖ^c! { á^•Á@ÁÜ^ ^ á*Á Vá ^ [~ óVá ^!É	ì	ÉÉÉÉÉÁ&D	ÉÉÉ
ÚWÖÖÖÖÁÜÖÁÜÖÁÜÖ^c! { á^•Á@ÁÜ^ ^ á*Á [} ^Á } { à^!Á^•áÁ @ } ÁÜ^ ^ á*Á [] ^Á Á^Á^Á Á [! { áÉ	J	ÉÉÉJ	ÉÉ
ÚWÖÖÖÖÁÜÜÜT ÚVÁÜÖÖÁÉÖ^c! { á^•Á@ÁÜ^ ^ á*Á Ü! [{] ÉÉ } [~] & ^ { à^!Á @ } Á@ÁÜ^ ^ á*Á [] ^Á Á^Á^Á Á Ü! [{] Á! ÉÉ } [~] & É	FÉ	ÉÉÉÉ í	B [ÖÉ *
ÚWÖÖÖÖÁÜÖÜÖÉ/ÁÜÉÁ^c! { á^•Á@ÁÜ^ ^ á*Á Ü^] ^ Á } { à^!É	FF	ÉÉÉÉÉ	H
ÖÜÖÖVÖÖÁÜÜVÁÖÖÖÁÉÖ^c! { á^•Á@ÁÜ^ ^ á*Á Vá ^! Á à^! ^ ÁÜ^ ^ á*Á Á^Á^Á ^ Á É	FG	ÉÉÉÉÉÁ& } á^D	É
ÚWÖÖÖÖÁÜÖÜÁÉV@Á] d^ Á^ á^•Á ÖÖÜÁ [] Á] Á^! á*Á ~ ^ á*Á Á } [~] & { ^ } óÁ Á! [çááÉ	FH	ÉÉ	É

TRANS/PGM 271	BTN	RANGE	DEFAULT
SECOND Q. TYPE -- This entry defines the type of second queuing tone.	14	1: Normal 2: Prompt 3: Annc 4: INT MOH 5: EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10: SLT MOH1 11: SLT MOH2 12: SLT MOH3 13: SLT MOH4 14: SLT MOH5	4: INT MOH
SECOND Q. TIMER -- This entry defines the timer for forward destination.	15	000-300 (seconds)	30
SECOND TONE NO -- This entry defines second queuing tone number in case queuing type is normal.	16	01-19	Not Asg
SECOND PRT ANNCThis entry defines second queuing prompt / annc.Number in case queuing type is PROMPT/ANNC.	17	001-255	Not Asg
SECOND REPEAT NO -- This entry defines second queuing repeat number.	18	000-100	3
SECOND RPT DELAY -- This entry defines the pause timer before second queuing repeat.	19	000-100 (seconds)	0
SECOND CCR -- This entry defines CCR option during second queuing announcement is provided.	20	0-1	0

Attendant Group Attributes (TRANS/PGM 272)

Each attendant group has available attributes relating to announcements, timers, forward, etc. The table below provides descriptions for the attributes and the ata entries required.

1. Press the [TRANS/PGM] button and dial 272.
2. Use the dial pad to enter the desired tenant number (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Press the Flex button for the desired attribute; refer to the Table

Night Attendant Group - TRANS/PGM 275-277

Night Attendant Group covers a call while the Attendant station is in an unavailable mode or system goes to night mode.

Night Attendant Group Assign (TRANS/PGM 275)

Stations can be grouped as night attendant group so that calls will search for an idle station in the night attendant group. The system allows assignment of processes, Circular, Terminal, Ring, and Longest Idle.

Refer to the table below for a description of the functions and the data entries required.

1. Press the [TRANS/PGM] button and dial 275.
2. Use the dial pad to enter the desired tenant number (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Press the Flex button for the desired setting; refer to the following Table.
4. Use the dial pad to enter the desired Attendant Group data.

NOTE: For group members, enter an attendant number or attendant range. For an individual station press the desired Flex button for the position of the station in the group and dial the attendant number. For a range, enter the first and last station number in the range (only Digital/LDP/LIP model can be assigned).

5. Press the [SAVE] button to store the data entered.

TRANS/PGM 275	BTN	RANGE	DEFAULT
NIGHT ATTD GR TYPE -- NightDetermines the type of Night Attendant group.	1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	0: Terminal
NIGHT ATTD GR NAME -- Determines the name of the night Attendant group.	2	Max 16	-
NIGHT MEMBER ASG -- Assigns Stations as members of a Night Attendant group.	3	-	-

Night Attendant Group Greeting/Queuing (TRANS/PGM 276)

Each night attendant group has available attributes relating to the greeting and queuing announcements, time. The table provides descriptions for the attributes and the data entries required.

TRANS/PGM 276	BTN	RANGE	DEFAULT
GREETING RPT DELAY -- Determines the length of time the timer will pause before the greeting is repeated.	6	000-100 (seconds)	0
QUEUING TYPE -- Determines the type of Queuing Tone.	7	1. Normal 2. Prompt 3. Annc 4. INT MOH 5. EXT MOH 6: VMIB MOH1 7: VMIB MOH2 8: VMIB MOH3 9: VMIB MOH4 10:SLT MOH1 11:SLT MOH2 12:SLT MOH3 13:SLT MOH4 14:SLT MOH5	4
QUEUING TIMER -- Determines the Greeting/Queuing Timeout Timer.	8	010-300 (sec)	030
QUEUING TONE NO -- Determines the Queuing Tone number used when Queuing Type is set to Normal.	9	01-19	00
QUEUING PROMPT ANNC -- Determines the Queuing Prompt/ Announce Number when the Queuing Type is set to Prompt or Announce.	10	001-255	Not Asg
QUEUING REPEAT NO -- determines the Queuing Repeat number.	11	000-100	3
GREETING RPT DELAY -- Determines the Pause Timer before Queuing is repeated.	12	000-100 (seconds)	0
QUEUING CCR -- This entry defines CCR option during queuing announcement is provided.	13	0-1	0

4. Use the dial pad to enter the desired Attendant group attributes data (refer to Table).
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 277	BTN	RANGE	DEFAULT
CALL IN GREETING -- Determines if call is routed to the Attendant when Greeting Tone is played.	1	0: After Greeting 1: In Greeting	1: In Greeting
MAX QUEUE COUNT -- Determines the Queue count.	2	00-99	05
FORWARD TYPE -- Determines the Forward type to use. 0: Not used 1: Unconditional - call is routed to a forward destination unconditionally. 2: Queuing overflow - call is routed to a forward destination when a queue overflows. 3: Queuing timeout - call is routed to a forward destination when queuing time expires. 4: Queuing all - call is routed to a forward destination when a queue overflows or queuing time expires.	3	0: Not Used 1: Uncond 2: Q Overflow 3: Time out 4: All	0: Not Used
APPLY TIME TYPE -- Determines the time setting for applying the Forward type.	4	0: All 1: Day 2: Night 3: Timed	0: All
FWD DESTINATION -- Determines the forward destination (trunk access code should be included).	5	Max 16 digits	-
WRAP UP TMR -- Determines the Wrap-up Timer; a member is available when this timer expires after a member goes to idle.	6	000-600 (100ms)	5
MEMBER NO ANS TMR -- Determines the No Answer timer; if this timer expires, a call is routed to the next attendant	7	05-60 (seconds)	15
RING NO ANS TMR -- This entry defines ring no answer timer. If this timer expires, a call is routed to the forward destination according to forward type.	8	0-180 (seconds)	0
PROVIDE ANNC-- This entry defines if system answer the call when a greeting or queuing announcement is provided.	9	0: With Answer 1: W/O Answer	0: With Answer

Tenant Attributes - TRANS/PGM 280-281

One System can be divided as several systems; each Station and CO line are assigned to a specific Tenant group.

TRANS/PGM 281	BTN	RANGE	DEFAULT
<p>CONF MEMBER MANUAL ADD -- Determines if conf-member manual add will be used; when set to ON, each CONF member can be added using the CONF button, when set to OFF, each CONF member will be added automatically.</p>	1	0: Off 1: On	1: On
<p>REDIAL METHOD -- This entry defines the redial method when the User presses the [REDIAL] button. 1: One Touch Call - When [REDIAL] button is pressed, the phone will redial the previously called number. 2: One Touch Log Phone - When [REDIAL] button is pressed on phone with 3-soft button, redialing can be initiated, if phone does not have 3-soft button, a redial list will be displayed. 3: List Dial - When the [REDIAL] button is pressed, redial list is displayed, and user can select which number to redial.</p>	2	0: One Touch Dial 1: One Touch Log Phone 2: List Dial	2: List Dial
<p>DIAL DIGIT PROCESS -- This entry defines the dial digit processing method. 0: TYPE 1 (R-C-S) - If user dials digits, digit are process as listed: 1) Apply Toll Restriction to all digits including CO access code. 2) Converted 3) Seize CO Line 1: TYPE 2 (C-S-R[A]) - If user dials digits, they are processed as listed: 1) Converted 2) Seize CO Line 3) Apply toll Restriction to all digits including CO access code. 2: TYPE 3 (C-S-R[E]) - If user dials digits, digit are processed as listed: 1) Converted 2) Seize CO Line 3) Apply Toll Restriction external phone number</p>	3	0: Type 1 1: Type 2 2: Type 3	2
<p>XFER TO COS 0 STA -- This entry allows transfer to COS 0 station.</p>	4	0: Off 1: On	1: On

VÜÇÈÙÈÚÌÖT ÁÇ F	ÓVP	ÜÇÈ ÕÒ	ÖÒÇÈVŠV
ÖÖÖÁÚÁÖÖÖÚÁÖÖÖÁV@Á} d^ Áç [, • ÁããÁÖUÁ Ç&^••ÁÛ á^ÁÛ ÁÛ ç { * ÁÖÇÁ Á^c !} Á@ ÁçÈ	í	€ÁÚ ~ FÁÚ }	FÁÚ }
ÖUÖÖÖÁÛÜÖÁV@Á} c{ ÁÖ [á^ÁÇ] ^È	î	FÁÖ FF GÁÖ GH HÁÖ GJ I ÁÖ GG	FÁÖ FF
ÖÖÖŠÖP VÁÚÖÖÖÁV@Á} d^ Áç [, • Áãã ã @Á [] ç } Á ÁÚÁ@ } ^Á ç@ã * Á [á^È	ï	€ÁÚ ~ FÁç ÁÚ } GÁã @Á } HÁã ^áÁÚ } I ÁÖÁÚ } Í ÁÖÁÚ } Î ÁÖÁÚ }	€ÁÚ ~
ÖÖÜÁÚÖÖÖÁV@Á} d^ Áç [, • Áãã ã @Á Öç ÁÖ çã } ÁÚ^ d çã } Áç] ^Á @ } Áç Áãã Á } { à^ Á Á [çã @ áÁ ç@Á] ^ çã È	ì	€ÁUÁÖÖÜ FÁç çã GÁç } * HÁç ! } çã } çã I Á^ áãã	È

Tenant Group Access (TRANS/PGM 283)

Üçã } • Á Áç [~] Áç Áç [, ^áÁ | Á^ } áá@ Áãã Áç Á | çã Áç ç ! ç { ÈU Áç Áç ÁÚçã } • Á Á
 [@ | Á [~] • Á } Áç [~] È á È [~] Áçã È

FÈ Ú!^••Á@ ÁÛÜÇÈ ÙÈÚÌÖT çã ç } Áç áÁçÁÇ HÈ

GÈ W^ Á@ Áçã Á çã Á } ç! Á@ Á^ á^áÁ^ } ç Á { à^ Á Ç È Á | Á@ Á ÖÝÁÚÁ Ç È Á á J J Á | Á
 T ÖÝÁÚÁ Ç È

HÈ Ú!^••Á@ Á^ çã ç } Áç Áç&^••È^ ^ Á^ } ç Á

I È Öç@Á^ } ç çã Áç Á | * | çã { ^áÁ Áç [, Á | Á^ ^ Áç Áç Áç [@ | Áç } ç È

Í È Ú!^••Á@ ÁÛÇÖÁç ç } Áç Á ç | ^ Á@ Áçã } d^ È

CO Call Restriction - TRANS/PGM 284-285

V@ÁUÁÖçÁV^ ÁÚ^ d çã } Áç Áç Áç | á á Á^ Á^ } d^ Áç | áã * Áç Áç Áç] ^ Áç [çã] * Á
 Öá çã & Á | Áç ! } çã } ç Áç Áç Áç Áç } Áç @Á^ } ç È

Call Duration Restriction I (TRANS/PGM 284)

Each tenant has attributes relating Call Duration Restriction (CDR) according to call types (refer to the following table for a description of the functions, and data entries required).

1. Press the [TRANS/PGM] button and dial 284.
2. Use the dial pad to enter the desired Tenant range (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Press the Flex button for the desired setting (refer to Table).
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 284	BTN	RANGE	DEFAULT
NORMAL CO LINE -- Determines call restriction for Normal CO line.	1	0: No Restriction 1: All Calls 2: Long/ International 3: Internationa	0: No Restriction
DEDICATED LINE -- Determines the call restriction for TIE line.	2	0: No restriction 1: Restriction	0: No Restriction
LOCAL CALL AFTER R-TIME -- Determines the operation of Local calls after the Restriction timer expires.	3	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
LONG CALL AFTER R-TIME -- Determines the operation of Long Distance calls after the Restriction timer expires.	4	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
INTERNAT AFTER R-TIME Determines the operation of International calls after the Restriction timer expires.	5	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone
DEDICATED CALL AFTER R-TM -- Determines the operation of TIE calls after the Restriction timer expires.	6	0: Single tone 1: Repeat tone 2: Single tone & Drop	0: Single tone

Call Duration Restriction II (TRANS/PGM 285)

Each tenant has available attributes relating to the CDR timer according to call types (refer to the table below for a description of the functions and the data entries required).

1. Press the [TRANS/PGM] button and dial 285.
2. Use the dial pad to enter the desired Tenant range (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).

1. Press the [TRANS/PGM] button and dial 286.
2. Use the dial pad to enter the desired Tenant range (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Use the dial pad to enter the desired bin number (up to 4 digits can be assigned for local call prefix index).
4. Press the [SAVE] button to store the data entry.

Long Distance Call Prefix Table (TRANS/PGM 287)

Each tenant has a Long Distance Call Prefix Table relating to CDR.

1. Press the [TRANS/PGM] button and dial 287.
2. Use the dial pad to enter the desired Tenant range (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Use the dial pad to enter the desired bin number (up to 4 digits can be assigned for the Long Distance call prefix index).
4. Press the [SAVE] button to store the data entry.

International Call Prefix Table (TRANS/PGM 288)

Each tenant has an International Call Prefix Table relating to CDR.

1. Press the [TRANS/PGM] button and dial 288.
2. Use the dial pad to enter the desired Tenant range (1-5 for the MBX IP 100, and 1-9 for MBX IP 300).
3. Use the dial pad to enter the desired bin number (up to 4 digits can be assigned for the International call prefix index).
4. Press the [SAVE] button to store the data entry.

Tenant Tone Table (TRANS/PGM 290)

The system provides 71 tones that can be assigned for use as the normal tone, VMIB prompt/Announcement or internal/external music.

1. Press the [TRANS/PGM] button and dial 290.
2. Enter tenant range using dial pad. For a single tenant group, just enter the same number twice.
3. To program tone, dial tone index (01 - 73). Refer to the Tone Index Table of Web-Admin (TRANS/PGM 264).
4. Press the Flex button.

INDEX	STONE NAME	DESCRIPTION
2	2nd Dial Tone	This is provided when station presses [TRANS] button during conversation to transfer the call.
3	CO Dial Tone	This is provided to transit CO line if he accesses CO line which does not provide CO Dial Tone.
4	DISA Dial Tone	This is provided to external caller through DISA
5	LCR Virtual Tone	Reserved
6	Digit Conversion Virtual Tone	This is provided when station dials 'Dummy Dial-Tone Digit' in TRANS/PGM 240.
7	Password Dial Tone	This is provided when station dials conference room number having password.
8	Internal Busy Tone	This is provided to external caller through DID/DISA when he calls the busy station.
9	External Busy Tone	This is provided when station makes a external call to telephone in use.
10	CO Line Busy Tone	This is provided to station when there is no idle CO line.
11	Uncompleted Dial Error Tone	This is provided when station does not dial within inter-digit timer during dialing.
12	DOD Restriction Tone	This is provided when station dials the toll restriction digits.
13	Internal No-Answer Tone	This is provided when the called station does not answer within 'Normal Call Ring Time' of Ring Table.
14	External No-Answer Tone	This is provided when the called external user does not answer.
15	Internal Vacant Error Tone	This is provided when stations calls vacant number.
16	External Vacant Error one	This is provided when stations calls vacant external telephone number.
17	Call Duration Restriction Tone	Reserved
18	Anonymous Call Restriction Tone	Reserved
19	Error Tone (All the other cases)	This is provided in all error cases

INDEX	-tone NAME	DESCRIPTION
GE	Ü ^ ǫ́ ǫ́ ^ Á Ö [& ä *	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ǫ́ • Á @ Á à [& ^ á Á ǫ́ ǫ́ } É
GF	Ü ^ ǫ́ ǫ́ ^ Á ä ^ Á & Á Ü ~ c	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ǫ́ • Á ǫ́ ǫ́ } Á @ ä ä * Á Q , ä * Á } ^
GG	Ü ^ ǫ́ ǫ́ ^ Á Ö Á [ǫ́ Ö ä ç ì à	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ǫ́ • Á ǫ́ ǫ́ } Á Á Ö P Ö É
GH	Ü ^ ǫ́ ǫ́ ^ Á Ö • ^ } & ^	Ü • ^ ç ^ á
G	Ü ^ ǫ́ ǫ́ ^ Á Ü ~ ǫ́ - Á á !	Ü • ^ ç ^ á
G	Ö ç ǫ́ ! } ə́ Á Ü ^ ǫ́ ǫ́ ^ Á Ü ~ ǫ́ - Á á !	Ü • ^ ç ^ á
G	Ö ç ǫ́ ! } ə́ Á Ü ^ ǫ́ ǫ́ ^ Á Ü ~ ç [ä * Á Ü • d ä ç }	Ü • ^ ç ^ á
G	Ü ^ ǫ́ ǫ́ ^ Á [ǫ́ Ö • \ Á * [~ c	Ü • ^ ç ^ á
G	P [, ä * Á } ^	V @ / ǫ́ Á : [ç ǫ́ ^ á Á ǫ́ • Á ! : [Á } ^ É
GJ	F • Ö ä * Á Ö ǫ́ Á } ^	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ǫ́ • Á ǫ́ [ç ǫ́ : Á • ǫ́ ǫ́ } É
HE	G á Ü ä * Á Ö ǫ́ Á } ^	Ü • ^ ç ^ á
HF	Ö Ü Ä ä * Á Ö ǫ́ Á } ^	V @ / ǫ́ Á : [ç ǫ́ ^ á Á ǫ́ • Á ç ǫ́ ! } ə́ Á ǫ́ • Á @ Á ä & ä * Á ǫ́ • Á ~ ç á Á ǫ́ • ç ǫ́ ǫ́ } É Ö ä Á ä / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ǫ́ • Á ç ǫ́ ! } ə́ Á ǫ́ • Á ç ǫ́ ! * Ö Ü Ä ä ^ Á ä Ö Ü : [ç ǫ́ ^ á Ü ä * Á Ö ǫ́ Á V } ^ ǫ́ Á Ü Ö Æ Ü Æ Ü Ö T Á F É
HG	Ü ^ & ǫ́ Ü ä * Á Ö ǫ́ Á } ^	Ü • ^ ç ^ á
HH	Z [} ^ Á Ü ä ä * Á Ö ǫ́ Ü ä * Á Ö ǫ́ Á } ^	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ä ^ Á ä ä ä * É
H	Ö [{ { ə́ ä Á Ö ǫ́ Ü ä * Á Ö ǫ́ Á } ^	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á ä ^ Á ä & [{ { ə́ ä Á } ^ } & Á ! [~] Á ǫ́
H	Ö F : ǫ́ Á • • ä ^ Á ä ä	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á [^ Á - Q [\ Á Á { ^ • • ä ^ Á Á - c
H	Ö F : ǫ́ Ö Á [ǫ́ Ö ä ç ì à	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á [^ Á - Q [\ Á Á Ö P Ö Á Á c
H	Ö F : ǫ́ Ö ǫ́ , ä ä Á	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á [^ Á - Q [\ Á Á Ö ǫ́ , ä ä Á Á c
H	Ö F : ǫ́ Ö • ^ } & ^	V @ / ǫ́ Á : [ç ǫ́ ^ á Á @ } Á ǫ́ ǫ́ } Á [^ Á - Q [\ Á Á] ! Á ^ Á & ç á Á ^ • • ä ^ Á Á c

INDEX	STONE NAME	DESCRIPTION
39	Camp on Alarm	This is provided to station if camp-on is requested.
40	Conference Alarm	This is provided to station if station makes conference call
41	Conference Join	This is provided when station adds conference member
42	Call Wait Alarm	This is provided to station if call-wait is requested.
43	Break In Alarm	Reserved
44	Conference Room In	This is provided when station enters conference room
45	Conference Room Out	This is provided when conference member is deleted.
46	Call Duration Restriction Alarm	This is provided to station with CDR disconnection indication before the forced disconnection.
47	Confirm Tone	This is confirmation tone
48	Single Error Tone	This is provided when stations dials wrong input during programming.
49	Transfer Hold Tone	This is provided to the external user when he is transferred
50	Transfer Hold Tone (Station)	This is provided to the station when he is transferred
51	Camp On Hold Tone (CO)	This is provided to the external user when they are camped on.
52	Camp On Hold Tone (Station)	This is provided to the station when they are camped on.
53	Call Wait Hold Tone (CO)	This is provided to the external user when they are waiting.
54	Call Wait Hold Tone (Station)	This is provided to the station when they are waiting.
55	Normal Hold Tone (CO)	This is provided to the external user in hold.
56	Normal Hold Tone (Station)	This is provided to station in hold.
57	Normal Hold Tone (Attendant)	Reserved

3. Press the Flex button 1-8 for the desired setting (refer to Table); use the dial pad to enter the required data.
4. Press the [SAVE] button to store the new data.

TRANS/PGM 300	BTN	RANGE	DEFAULT
CRC CHECK -- Enable CRC check.	1	0: Disable 1: Enable	Enable
NT/TE MODE -- After change, the board is automatically restarted.	2	0: TE 1: NT	TE
PORT1 TEI MODE -- TEI mode of BRIB Port 1.	3	N/A	N/A
PORT2 TEI MODE -- TEI mode of BRIB Port 2.	4	N/A	N/A
PORT3 TEI MODE -- TEI mode of BRIB Port 3.	5	N/A	N/A
PORT4 TEI MODE -- TEI mode of BRIB Port 4.	6	N/A	N/A
T1 MODE -- T1 Mode (D4/ESF).	7	0:D4 1:ESF	0
T1 LINE MODE -- T1 Line Mode (B8ZS/AMI).	8	0:B8ZS 1:AMI	B8ZS
T1 PAUSE TIME -- T1 Pause Time.	9	1-9	2
T1 PLS RATE -- T1 PLS Rate.	10	0-3	0
T1 RLS GRD TIME -- T1 release guard time.	11	0-60	20
T1 DT DELAY TIME -- T1 DT Delay time.	12	2-50	10
T1 WINK TIME -- T1 Wink time.	13	7-15	10
T1 SEIZE TIME -- T1 seize time.	14	0-127	3
T1 RLS TIME -- T1 release time.	15	0-127	7
T1 RING DET TIME -- T1 ring detect time.	16	2-9	2
T1 RING STOP TIME -- T1 ring stop time.	17	10-60	60

ISDN Board - Clock Priority (TRANS/PGM 301)

In the MBX IP System, Clock synchronization is controlled by the pre-programmed ISDN Clock priority. The first ISDN board becomes the Clock Master board, and if some error occurs to the Clock Master board, the next board automatically takes on the role as Clock Master. After the original master board recovers, the Clock Master board is changed again. If there is no available ISDN board to become a Clock Master board, the System is synchronized with the internal clock.

FÈ Ú!^••Á@ÃÜÖÐÙÐÏÔ æã ¸} Áæ áÁæãÁÉÈ
 GÈ W^!Á@ÁæãÁ æáÁ Á} ¸!Á@Á^•ãáÁÚ[[¸~ { à!•È
 HÈ Ú!^••Á@ÃÜÖÐÙÐÏÔ æã ¸} Áæ Áç!^Á@Á^, ÁææÈ

IPP Board Attribute (TRANS/PGM 305)

V@ÁKUÖÏæã áÁXT ÓÁ[æáÁÖæãÁ { ^Áæãã ¸•ÁÖæãÁ Á^Á!| *!æ { ^áÁ^Á@Á
 Öá{ çãçæíÈ

FÈ Ú!^••Á@ÃÜÖÐÙÐÏÔ æã ¸} Áæ áÁæãÁÉÈ
 GÈ Ò} ¸!Á^•ãáÁÚ[[¸~ { à!Á æÖÁæã æÈ
 HÈ Ú!^••Á@Áç!^Á@Á Áæ!Á@Á^•ãáÁ^æã *Áç^!Á Áæá^È
 ÍÈ W^!Á@ÁæãÁ æáÁ Á} ¸!Á@Á^~ãáÁææÈ
 ÍÈ Ú!^••Á@ÃÜÖÐÙÐÏÔ æã ¸} Áæ Áç!^Á@Á^, ÁææÈ

VÜÖÐÙÐÏÔ ÁÉÍ	ÓÞ	ÜÖÐÖÒ	ÖÖÖÖÑSV
ÓÁÖÖÖÜÁÖÖÁÖæá!^••Á^Á^!&çáÁ[[È	F	ÓÁÖá!^••	FÈÈÈÈÈ ÖÁ[[¸~ { à!D
ÜUWÖÜÁÖÖÖÜÁÖÜ[~ ¸!ÁÖÖá!^••Á^Á^!&çáÁ[[È	G	ÓÁÖá!^••	ÈÈÈÈÈÈ
ÜWÓÞÖVÁ ÖESÁÖÜ] á) ^çæ æ!Á^Á^!&çáÁ[[È	H	ÓÁÖá!^••	Ç Í È Í È Í È
ÖÞÖÜÁÑÜÖÖÖÖÖÖÞÖÜÁÑ æ^È	I	€U~ FKU}	U~
VHÍ ÁÑÜÖÖÖÖÖVHÍ ÁÑ æ^È	Í	€U~ FKU}	U~
ÜVÚÁÜÖÖWÜQYÁÜVÚÁ^&!æ Wæ æ^È	Î	€U~ FKU}	U~
XSÖÞÁÖXŠæ	Ï	€€€€€ €J	Þ[} ^
ÚÜÖÜQYÁÜ] ç!æ	Ì	€È	€
ÖÖÖÜÖÜXÁÖÖá^!ç	J	€ÈÈ H	€

Reset Board (TRANS/PGM 310)

ÒæçÖÁ[æáÁÁ Á@Á^•¸{ Áæ Á^Á^•¸ çãççÁ^} È
 FÈ Ú!^••Á@ÃÜÖÐÙÐÏÔ æã ¸} Áæ áÁæãÁÉÈ
 GÈ Ò} ¸!Á^•ãáÁÚ[[¸~ { à!Á æÖÁæã æÈ
 HÈ Ú!^••Á@ÃÜÖÐÙÐÏÔ æã ¸} Áæ Á^•¸@Á[æáÈ

NETWORKING DATA - TRANS/PGM 320-321

Net Basic Attribute (TRANS/PGM 320)

The Network Basic Attributes are displayed and the TRANS/PGM 320 table provides general descriptive information and input ranges.

1. Press the [TRANS/PGM] button and dial 320.
2. Press the Flex 1-10 for the desired setting (refer to Table).
3. Use the dial pad to enter the required data.
4. Press the [SAVE] button to store the new data.

TRANS/PGM 320	BTN	RANGE	DEFAULT
NET ENABLE -- Enable Networking function.	1	0:Off 1:On	Off
NET CNIP ENABLE -- The name of the calling station is sent to the called System between MBX IP systems. CNIP is displayed at the called party Stations display based on the programming.	2	0:Off 1:On	On
NET CONP ENABLE -- Reserved for future usage.	3	0:Off 1:On	Off
NET SIGNAL METHOD -- Select the information element type for QSIG supplementary service message.	4	0:UUS 1:FAC	UUS
NET CC RETAIN -- If this value is set to ON, the signaling of call completion retain mode is executed. Used for networking supplementary signaling type of the call completion.	5	0:Off 1:On	Off
BLF USAGE -- Used to set Networking BLF service.	6	0:Off 1:On	Off
TCP PORT FOR BLF -- TCP Port for sending BLF message to BLF Manager.	7	9000-9999	9000
UDP PORT FOR BLF -- UDP Port for sending BLF message to BLF Manager.	8	9000-9999	9001
DURATION OF BLF STS -- Duration for sending the BLF status message to the BLF Server.	9	01-99	10
BLF MANAGER IP -- IP Address of BLF Server used only when 0 MBX IP is configured with MBX IP systems for Voce Networking (Reserved).	10	-	0.0.0.0

TNET, CENTRALIZED NETWORKING - TRANS/PGM 330-335

In a Centralized Control TNET (Transparent Networking), remote devices may be registered to a Central MFIM (CM) and to a Local MFIM (LM). In this way, the CM maintains control of the remote device. Should the WAN connection between an LM and CM fail (2 sec. polling error), the LM will initiate operational control of the locally registered devices. Calls between the systems (CM & LM) can automatically shift to PSTN Modules registered with the LM for Fail-over operation. The configuration and characteristics of LMs and CM are configurable as is Fail-over operation.

TNET Basic Attributes (TRANS/PGM 330)

Each MFIM in a Central Control network environment must be enabled for TNET operation in order to function as part of the network.

1. Press the [TRANS/PGM] button and dial 330.
2. Press Flex 1.
3. Use the dial pad to enable or disable TNET, Central Control networking.
4. Press the [SAVE] button to store the new data.

TRANS/PGM 330	BTN	RANGE	DEFAULT
T-NET ENABLE -- enable T-NET function.	1	0:Off 1:On	Off

TNET CM Attributes (TRANS/PGM 331)

Each LM (Local MFIM), which is part of a Central Control Network, must be defined with the IP Address of the CM (Central MFIM) as well as the LM configuration data that will be sent to the CM at the time the LM registers with the CM. The port counts define the ports, which are allocated in the CM database for use by devices registered to the LM. The number of ports defined in the database of each LM must be equal or less than the ports defined in the CM for the LM (refer to TRANS/PGM 332), in order to register properly.

1. Press the [TRANS/PGM] button and dial 331.
2. Press the Flex button, 1-6 for the desired setting (refer to Table)
3. Use the dial pad to enter the required data (refer to Table).
4. Press the [SAVE] button to store the new data.

TRANS/PGM 333	BTN	RANGE	DEFAULT
ENABLE FoPSTN -- Determines if Fail-over operation is enabled or disabled from the CM or LM.	1	0:Off 1:On	-
INIT FoPSTN TABLE -- Determines how to initialize the FO Table.	2	-	-
FoPSTN Attributes	3	1-100 (MBX IP-100) 1-200 (MBX IP-300)	-
FoPSTN NUM PLAN -- Station numbers associated with the remote System.	3-1	Max 16	-
FoPSTN CO GROUP -- Determines the CO Group of the Local System that will be used to place calls to the stations entered in the FO Numbering Plan, should a WAN failure occur.	3-2	1-24 (MBX IP-100) 1-72 (MBX IP-300)	-
FoPSTN TEL NUMBER -- Determines the telephone number the System should dial to place a call to the Stations entered in the FO Numbering Plan, should WAN failure occur.	3-3	Max 10	-

Board TNET Attributes (TRANS/PGM 334)

When a board or MBX IP-gateway module is to be connected in a Centralized Control network (TNET), the TNET operation of board or MBX IP-gateway module can be enabled or disabled.

1. Press the [TRANS/PGM] button and dial 334.
2. Enter Slot No.
3. Use the dial pad to enable or disable TNET, Central Control networking.
4. Press the [SAVE] button to store the new data.

IP Phone TNET Attributes (TRANS/PGM 335)

When an IP-Phone is to be connected in a Centralized Control network (TNET), the TNET operation of the IP-Phone can be enabled or disabled.

1. Press the [TRANS/PGM] button and dial 335.
2. Enter Bin No of IP Phone (001-108 for MBX IP-100, 001-324 for MBX IP 300).
3. Use the dial pad to enable or disable TNET, Central Control networking.
4. Press the [SAVE] button to store the new data.

4. Use the dial pad to enter the desired data (refer to Table).
5. Press the [SAVE] button to store the data entry.

TRANS/PGM 361	BTN	RANGE	DEFAULT
SETUP MODE -- H.323 IP calls can be set-up using the H.323 Normal or Fast Start mode.	1	0:Normal 1:Fash Mode	Fash Mode
TUNNEL MODE -- H.323 IP calls can be set-up using the H.245 Encapsulation (Tunneling).	2	0:Off 1:On	On
DTMF SEND MODE -- during a connection, DTMF digits can be sent In-band or Out of band (H.245).	3	0:Inband 1:RFC2833 2:Out	Inband
DIFF SERV -- Diffserv pre-tagging for Voice packet. NOTE: High values may cause high packet discard levels.	4	0-63	4
G.711A CODEC -- usage of G.711A Codec Type.	5	0:Not Use 1:Use	Not Use
G.711U CODEC -- usage of G.711U Codec Type.	6	0:Not Use 1:Use	Not Use
G.729 CODEC -- usage of G.729 Codec Type.	7	0:Not Use 1:Use	Not Use
G.723 CODEC -- usage of G.723.1 Codec Type.	8	0:Not Use 1:Use	Not Use
GK USED -- used to determine if Gatekeeper will be used.	9	0:Off 1:On	Off

H.323 Incoming Attributes (TRANS/PGM 362)

To get the direct H.323, the From IP-Address and the CO Group number to be routed should be assigned.

1. Press the [TRANS/PGM] button and dial 362.
2. Enter Bin Number.
3. Press the desired Flex button and enter the appropriate data.
4. Press the [SAVE] button to store the new data.

This feature is not available at this time ...

GAIN & CADENCE CONTROL - TRANS/PGM 400-440

DKT RX Gain (TRANS/PGM 400)

The RX gain of DKT can be adjusted (refer to Table for setting values).

1. Press the [TRANS/PGM] button and dial 400.
2. Press the desired Flex button (refer to Table).
3. Use the dial pad to enter desired data for the attribute setting (refer to Table).
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 400	BTN	RANGE	DEFAULT
DKT RX GAIN -- DKT RX gain from DKT.	1	0-63	26
DKT RX GAIN -- DKT RX gain from SLT.	2	0-63	22
DKT RX GAIN -- DKT RX gain from DECT.	3	0-63	26
DKT RX GAIN -- DKT RX gain from IPDEV.	4	0-63	26
DKT RX GAIN -- DKT RX gain from Analog CO.	5	0-63	26
DKT RX GAIN -- DKT RX gain from Digital CO.	6	0-63	33
DKT RX GAIN -- DKT RX gain from VMIB.	7	0-63	29
DKT RX GAIN -- DKT RX gain from DTMF.	8	0-63	08
DKT RX GAIN -- DKT RX gain from TONE.	9	0-63	32
DKT RX GAIN -- DKT RX gain from MUSIC.	10	0-63	29

SLT RX Gain (TRANS/PGM 401)

The RX gain of SLT can be adjusted (refer to Table for setting values).

1. Press the [TRANS/PGM] button and dial 401.
2. Press the desired Flex button (refer to Table).
3. Use the dial pad to enter desired data for the attribute setting (refer to Table).
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 401	BTN	RANGE	DEFAULT
SLT RX GAIN -- SLT RX gain from DKT.	1	0-63	32
SLT RX GAIN -- SLT RX gain from SLT.	2	0-63	32

1. Press the [TRANS/PGM] button and dial 403.
2. Press the desired Flex button (refer to Table).
3. Use the dial pad to enter desired data for the attribute setting (refer to Table).
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 403	BTN	RANGE	DEFAULT
IP-PHONE RX GAIN -- IP-PHONE RX gain from DKT.	1	0-63	26
IP-PHONE RX GAIN -- IP-PHONE RX gain from SLT.	2	0-63	33
IP-PHONE RX GAIN -- IP-PHONE RX gain from DECT.	3	0-63	26
IP-PHONE RX GAIN -- IP-PHONE RX gain from IPDEV.	4	0-63	26
IP-PHONE RX GAIN -- IP-PHONE RX gain from Analog CO.	5	0-63	38
IP-PHONE RX GAIN -- IP-PHONE RX gain from Digital CO.	6	0-63	33
IP-PHONE RX GAIN -- IP-PHONE RX gain from VMIB.	7	0-63	29
IP-PHONE RX GAIN -- IP-PHONE RX gain from DTMF.	8	0-63	8
IP-PHONE RX GAIN -- IP-PHONE RX gain from TONE.	9	0-63	37
IP-PHONE RX GAIN -- IP-PHONE RX gain from MUSIC.	10	0-63	29

Analog CO RX Gain (TRANS/PGM 404)

The RX gain of Analog CO can be adjusted.

1. Press the [TRANS/PGM] button and dial 404.
2. Press the desired Flex button (refer to Table).
3. Use the dial pad to enter desired data for the attribute setting (refer to Table).
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 404	BTN	RANGE	DEFAULT
ACO RX GAIN -- ACO RX gain from DKT.	1	0-63	40
ACO RX GAIN -- ACO RX gain from SLT.	2	0-63	32
ACO RX GAIN -- ACO RX gain from DECT.	3	0-63	31
ACO RX GAIN -- ACO RX gain from IPDEV.	4	0-63	33
ACO RX GAIN -- ACO RX gain from Analog CO.	5	0-63	32
ACO RX GAIN -- ACO RX gain from Digital CO.	6	0-63	38

VÜCEÜBÜÖT Á É	ÓVP	ÜCEÖÖ	ÖÖCEŠV
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄKT ÖE	İ	EH	H
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄÖVT ÖE	ì	EH	IG
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄUPÖE	J	EH	H
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄWÜÖE	F€	EH	H

Digital CO RX Gain (TRANS/PGM 405)

V@ÄYÄ ä Ä -Öä ää/ÖUÄYÄ ä Ä^Ääb •cäE
 FÈ Ú!^•Ä@ÄVÜCEÜBÜÖT ää } Ää äÄäÄ É È
 GÈ Ú!^•Ä@Ä^•ä^äÄ^cÄ } Ä^Ä!Ä Ää|ÄE
 HÈ W^Ä@ÄäÄ äÄ Ä } c!Ä^•ä^äÄäÄ |Ä@Ää ä^cÄ^cä * Ä^Ä!Ä Ää|ÄE
 I È Ú!^•Ä@ÄVÜCEÜBÜÖT ää } Ä Ä c !^Ä@ÄäÄ } d^E

VÜCEÜBÜÖT Á É	ÓVP	ÜCEÖÖ	ÖÖCEŠV
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄÖSVÈ	F	EH	G
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄŠVÈ	G	EH	G
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄÖÖVÈ	H	EH	G
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄVÜÖXE	I	EH	HH
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ Ää ä * ÄÜÈ	í	EH	FÍ
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ Öä ää/ÖUÈ	Î	EH	HG
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄKT ÖE	İ	EH	HG
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄÖVT ÖE	ì	EH	HG
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄUPÖE	J	EH	HG
ÖÖUÄYÄÖCEÄÖÖÖUÄYÄ ä Ä[{ ÄWÜÖE	F€	EH	HG

VMIB RX Gain (TRANS/PGM 406)

V@ÄYÄ ä Ä -ÄKT ÖE ä Ä^Ääb •cäE
 FÈ Ú!^•Ä@ÄVÜCEÜBÜÖT ää } Ää äÄäÄ É È
 GÈ Ú!^•Ä@Ä^•ä^äÄ^cÄ } Ä^Ä!Ä Ää|ÄE
 HÈ W^Ä@ÄäÄ äÄ Ä } c!Ä^•ä^äÄäÄ |Ä@Ää ä^cÄ^cä * Ä^Ä!Ä Ää|ÄE
 I È Ú!^•Ä@ÄVÜCEÜBÜÖT ää } Ä Ä c !^Ä@ÄäÄ } d^E

TRANS/PGM 406	BTN	RANGE	DEFAULT
VMIB RX GAIN -- VMIB RX gain from DKT.	1	0-63	26
VMIB RX GAIN -- VMIB RX gain from SLT.	2	0-63	29
VMIB RX GAIN -- VMIB RX gain from DECT.	3	0-63	23
VMIB RX GAIN -- VMIB RX gain from IPDEV.	4	0-63	32
VMIB RX GAIN -- VMIB RX gain from Analog CO.	5	0-63	32
VMIB RX GAIN -- VMIB RX gain from Digital CO.	6	0-63	32
VMIB RX GAIN -- VMIB RX gain from VMIB.	7	0-63	32
VMIB RX GAIN -- VMIB RX gain from DTMF.	8	0-63	32
VMIB RX GAIN -- VMIB RX gain from TONE.	9	0-63	32
VMIB RX GAIN -- VMIB RX gain from MUSIC.	10	0-63	32

External Page RX Gain (TRANS/PGM 407)

The RX gain of External Page can be adjusted.

1. Press the [TRANS/PGM] button and dial 407.
2. Press the desired Flex button (refer to Table).
3. Use the dial pad to enter desired data for the attribute setting (refer to Table).
4. Press the [SAVE] button to store the data entry.

TRANS/PGM 407	BTN	RANGE	DEFAULT
EXT PAGE RX GAIN -- External PAGE RX gain from DKT.	1	0-63	26
EXT PAGE RX GAIN -- External PAGE RX gain from SLT.	2	0-63	26
EXT PAGE RX GAIN -- External PAGE RX gain from DECT.	3	0-63	26
EXT PAGE RX GAIN -- External PAGE RX gain from IPDEV.	4	0-63	32
EXT PAGE RX GAIN -- External PAGE RX gain from Analog CO.	5	0-63	28
EXT PAGE RX GAIN -- External PAGE RX gain from Digital CO.	6	0-63	37
EXT PAGE RX GAIN -- External PAGE RX gain from VMIB.	7	0-63	37
EXT PAGE RX GAIN -- External PAGE RX gain from DTMF.	8	0-63	32
EXT PAGE RX GAIN -- External PAGE RX gain from TONE.	9	0-63	32
EXT PAGE RX GAIN -- External PAGE RX gain from MUSIC.	10	0-63	32

SLTM RX RTP Gain (TRANS/PGM 420)

TRANS/PGM 420	BTN	RANGE	DEFAULT
SLTM RX RTP GAIN -- SLTM RX gain from SLTM.	1	0-63	34
SLTM RX RTP GAIN -- SLTM RX gain from DTIM (HS).	2	0-63	34
SLTM RX RTP GAIN -- SLTM RX gain DTIM (HF).	3	0-63	34
SLTM RX RTP GAIN -- SLTM RX gain from IP PHONE (HS).	4	0-63	34
SLTM RX RTP GAIN -- SLTM RX gain from IP PHONE (HF).	5	0-63	34
SLTM RX RTP GAIN -- SLTM RX gain from WIT.	6	0-63	34
SLTM RX RTP GAIN -- SLTM RX gain from VOIB.	7	0-63	34

DTIM (HS) RX RTP Gain (TRANS/PGM 421)

TRANS/PGM 421	BTN	RANGE	DEFAULT
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain from SLTM.	1	0-63	34
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain from DTIM (HS).	2	0-63	34
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain DTIM (HF).	3	0-63	34
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain from IP PHONE (HS).	4	0-63	34
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain from IP PHONE (HF).	5	0-63	34
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain from WIT.	6	0-63	34
DTIM RX HS RTP GAIN -- DTIM (HS) RX gain from VOIB.	7	0-63	34

DTIM (HF) RX RTP Gain (TRANS/PGM 422)

TRANS/PGM 422	BTN	RANGE	DEFAULT
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain from SLTM.	1	0-63	34
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain from DTIM (HS).	2	0-63	34
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain DTIM (HF).	3	0-63	34
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain from IP PHONE (HS).	4	0-63	34
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain from IP PHONE (HF).	5	0-63	34
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain from WIT.	6	0-63	34
DTIM RX HF RTP GAIN -- DTIM (HF) RX gain from VOIB.	7	0-63	34

IP-Phone (HS) RX RTP Gain (TRANS/PGM 423)

VÜÖË ÙÈÚÖT Á GH	ÓVP	ÜÖË ÖÒ	ÖÒÖÖÈŠV
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ Á[{ ÁŠVT È	F	ÈÈ H	H
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ Á[{ ÖVQ ÁP ÙÈÈ	G	ÈÈ H	H
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ ÖVQ ÁP ÖÈÈ	H	ÈÈ H	H
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ Á[{ ÁÖÁPUPÒÁ ËP ÙÈÈ	I	ÈÈ H	H
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ Á[{ ÁÖÁPUPÒÁ ËP ÖÈÈ	í	ÈÈ H	H
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ Á[{ Á ÖÈÈ	î	ÈÈ H	H
ŠÖÁÝÁË ÙÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÙÖÜÝÁ Æ Á[{ ÁKUÖÈÈ	ï	ÈÈ H	H

IP-Phone (HF) RX RTP Gain (TRANS/PGM 424)

VÜÖË ÙÈÚÖT Á G	ÓVP	ÜÖË ÖÒ	ÖÒÖÖÈŠV
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ Á[{ ÁŠVT È	F	ÈÈ H	H
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ Á[{ ÖVQ ÁP ÙÈÈ	G	ÈÈ H	H
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ ÖVQ ÁP ÖÈÈ	H	ÈÈ H	H
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ Á[{ ÁÖÁPUPÒÁ ËP ÙÈÈ	I	ÈÈ H	H
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ Á[{ ÁÖÁPUPÒÁ ËP ÖÈÈ	í	ÈÈ H	H
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ Á[{ Á ÖÈÈ	î	ÈÈ H	H
ŠÖÁÝÁË ÖÁVÚÁÖÖË ÆÁÖÈË ËPUPÒÁË ËP ÖÜÝÁ Æ Á[{ ÁKUÖÈÈ	ï	ÈÈ H	H

WIT RX RTP Gain (TRANS/PGM 425)

VÜÖË ÙÈÚÖT Á Ğ	ÓVP	ÜÖË ÖÒ	ÖÒÖÖÈŠV
Ý ÖÁÝÁVÚÁÖÖË ÆÁ ÖÁÝÁ Æ Á[{ ÁŠVT È	F	ÈÈ H	H
Ý ÖÁÝÁVÚÁÖÖË ÆÁ ÖÁÝÁ Æ Á[{ ÖVQ ÁP ÙÈÈ	G	ÈÈ H	H
Ý ÖÁÝÁVÚÁÖÖË ÆÁ ÖÁÝÁ Æ ÖVQ ÁP ÖÈÈ	H	ÈÈ H	H
Ý ÖÁÝÁVÚÁÖÖË ÆÁ ÖÁÝÁ Æ Á[{ ÁÖÁPUPÒÁË ËP ÙÈÈ	I	ÈÈ H	H

TRANS/PGM 425	BTN	RANGE	DEFAULT
WIT RX RTP GAIN -- WIT RX gain from IP PHONE (HF).	5	0-63	34
WIT RX RTP GAIN -- WIT RX gain from WIT.	6	0-63	34
WIT RX RTP GAIN -- WIT RX gain from VOIB.	7	0-63	34

VOIB RX RTP Gain (TRANS/PGM 426)

TRANS/PGM 425	BTN	RANGE	DEFAULT
VOIB RX RTP GAIN -- VOIB RX gain from SLTM.	1	0-63	34
VOIB RX RTP GAIN -- VOIB RX gain from DTIM (HS).	2	0-63	34
VOIB RX RTP GAIN -- VOIB RX gain DTIM (HF).	3	0-63	34
VOIB RX RTP GAIN -- VOIB RX gain from IP PHONE (HS).	4	0-63	34
VOIB RX RTP GAIN -- VOIB RX gain from IP PHONE (HF).	5	0-63	34
VOIB RX RTP GAIN -- VOIB RX gain from WIT.	6	0-63	34
VOIB RX RTP GAIN -- VOIB RX gain from VOIB.	7	0-63	34

RTP RX Gain (TRANS/PGM 430-436)

Each device can adjust its own RTP TX gain to another device (refer to the following tables for RTP TX gain adjustment of devices).

1. Press the [TRANS/PGM] button and dial.
 - 430: SLTM TX RTP GAIN
 - 431: DTIM(HS) TX RTP GAIN
 - 432: DTIM(HF) TX RTP GAIN
 - 433: IP-Phone(HS) TX RTP GAIN
 - 434: IP-Phone(HF) TX RTP GAIN
 - 435: WIT TX RTP GAIN
 - 436: VOIB TX RTP GAIN
2. Press the desired Flex button (refer to the tables below).
3. Use the dial pad to enter desired data for the attribute setting.
4. Press the [SAVE] button to store the data entry.

IP-Phone (HS) TX RTP Gain (TRANS/PGM 433)

TRANS/PGM 433	BTN	RANGE	DEFAULT
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain from SLTM.	1	0-63	34
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain from DTIM (HS).	2	0-63	34
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain DTIM (HF).	3	0-63	34
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain from IP PHONE (HS).	4	0-63	34
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain from IP PHONE (HF).	5	0-63	34
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain from WIT.	6	0-63	34
LIP TX HS RTP GAIN -- IP-PHONE (HS) TX gain from VOIB.	7	0-63	34

IP-Phone (HF) TX RTP Gain (TRANS/PGM 434)

TRANS/PGM 434	BTN	RANGE	DEFAULT
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain from SLTM.	1	0-63	34
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain from DTIM (HS).	2	0-63	34
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain DTIM (HF).	3	0-63	34
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain from IP PHONE (HS).	4	0-63	34
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain from IP PHONE (HF).	5	0-63	34
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain from WIT.	6	0-63	34
LIP TX HF RTP GAIN -- IP-PHONE (HF) TX gain from VOIB.	7	0-63	34

WIT TX RTP Gain (TRANS/PGM 435)

TRANS/PGM 435	BTN	RANGE	DEFAULT
WIT TX RTP GAIN -- WIT TX gain from SLTM.	1	0-63	34
WIT TX RTP GAIN -- WIT TX gain from DTIM (HS).	2	0-63	34
WIT TX RTP GAIN -- WIT TX gain DTIM (HF).	3	0-63	34
WIT TX RTP GAIN -- WIT TX gain from IP PHONE (HS).	4	0-63	34

TRANS/PGM 440	BTN	RANGE	DEFAULT
CO RING REPEAT -- Determines the number of times the SLT CO ring will repeat; 255 means infinite repetition.	1	0-255	255
CO RING TIME UNIT -- Determines the duration in msec. for ON/OFF ring time.	2	0:10 msec 1:100 msec	100
CO RING 1 ON -- Determines the first ON ring duration.	3	0-255	010
CO RING 1 OFF-- Determines the first OFF ring duration.	4	0-255	040
CO RING 2 ON -- Determines the second ON ring duration.	5	0-255	000
CO RING 2 OFF -- Determines the second OFF ring duration.	6	0-255	000
CO RING 3 ON -- Determines the third ON ring duration.	7	0-255	000
CO RING 3 OFF -- Determines the third OFF ring duration.	8	0-255	000
CO RING 4 ON -- Determines the fourth ON ring duration.	9	0-255	000
CO RING 4 OFF -- Determines the fourth OFF ring duration.	10	0-255	000

SLT ICM Ring Cadence

TRANS/PGM 440	BTN	RANGE	DEFAULT
ICM RING REPEAT -- Determines the number of times the SLT ICM ring will repeat; 255 means infinite repetition.	1	0-255	255
ICM RING TIME UNIT -- Determines the duration in msec. for ON/OFF ring time.	2	0:10 msec 1:100 msec	100 msec
ICM RING 1 ON -- Define the first ON ring duration.	3	0-255	006
ICM RING 1 OFF-- Define the first OFF ring duration.	4	0-255	002
ICMCO RING 2 ON -- Define the second ON ring duration.	5	0-255	002
ICM RING 2 OFF -- Define the second OFF ring duration.	6	0-255	040
ICM RING 3 ON -- Define the third ON ring duration.	7	0-255	000
ICM RING 3 OFF -- Define the third OFF ring duration.	8	0-255	000
ICM RING 4 ON -- Define the fourth ON ring duration.	9	0-255	000
ICM RING 4 OFF -- Define the fourth OFF ring duration.	10	0-255	000

ACNR Tone Cadence (TRANS/PGM 441)

ÓÐÞÚÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I FD
 FÈ Ú!^••Á@ ÁVÜCE ÞÚJÖT á~ } Á á Á Á I F
 GÈ Ú!^••Á@ ÁVÜCE ÞÚJÖT á~ } Á È ÁVÜCE ÞÚJÖT Á I F
 Ø^cÁÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F
 Ø^cÁÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F
 HÈ W^Á@ ÁVÜCE ÞÚJÖT á~ } ÁVÜCE ÞÚJÖT Á I F
 I È Ú!^••Á@ ÁVÜCE ÞÚJÖT á~ } ÁVÜCE ÞÚJÖT Á I F

VÜCE ÞÚJÖT Á I F	ÓVP	ÜCE ÖÖ	ÖÖCEVŠV
ÓÐÞÚÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F	F	ÖÖ	È
ÜCE ÖÖCEVŠV ÓÐÞÚÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F	G	ÖÖ	È
ÓWÝÁVÜCE ÞÚJÖT Á I F	H	ÖÖ	È
ÖÜÜÜÁVÜCE ÞÚJÖT Á I F	I	ÖÖ	È
ŠÖÜÜÁVÜCE ÞÚJÖT Á I F	Í	ÖÖ	È

DB INITIALIZATION (TRANS/PGM 499)

FÈ Ú! [*!æ { ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F
 GÈ Ú!^••Á@ ÁVÜCE ÞÚJÖT á~ } ÁVÜCE ÞÚJÖT Á I F
 HÈ Ú!^••Á@ ÁVÜCE ÞÚJÖT á~ } ÁVÜCE ÞÚJÖT Á I F
 I È W^Á@ ÁVÜCE ÞÚJÖT á~ } ÁVÜCE ÞÚJÖT Á I F
 I È Ú!^••Á@ ÁVÜCE ÞÚJÖT á~ } ÁVÜCE ÞÚJÖT Á I F

VÜCE ÞÚJÖT Á J J	ÓVP	ÜCE ÖÖ	ÖÖCEVŠV
ÓÐÞÚÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F	F	ÖÖ	È
ÜCE ÖÖCEVŠV ÓÐÞÚÁ[} ^ÁÓæ^ } & ÁVÜCE ÞÚJÖT Á I F	G	ÖÖ	È

TRANS/PGM 499	BTN	RANGE	DEFAULT
INIT STATION DATA -- Initializes Station-based data (except flexible button data),	3	Desired station range (initialize whole data when no range)	-
INIT STATION DATA -- Initializes flexible button data,	4	-	-
INIT STATION DATA -- Initializes CO line-based data),	5	-	-
INIT STATION DATA -- Initializes Station Group-based data.	6	-	-
INIT STATION DATA -- Initializes System-based data,	7	-	-
INIT STATION DATA -- Initializes SMDR data,	8	-	-
INIT STATION DATA -- Initializes System Timers,	9	-	-
INIT STATION DATA -- Initializes Table-based data,	10	-	-
INIT STATION DATA -- Initializes Tenancy Group-based data.	11	-	-
INIT STATION DATA -- Initializes Networking data,	12	-	-
INIT STATION DATA -- Initializes SIP data.	13	-	-

Hotel Management

System Capacity and License

The following tables list the specifications for both types of **MBX IP** systems:

Items	MBX IP 100	MBX IP 300
KSU No.	2	3
Slot No. per KSU	6	6
Total Port (Extension + CO line)	200	414 (if IP Phone/DECT not included)
		564 (if IP Phone/DECT included)
Number of extension Port	120	324
Number of extension	180 (Ext 120 + DN 60)	648 (324 x 2)
Number of CO Line	80	240
Number of Tenant Group	5	9
Numbering Plan	Extension: 8 Digits	Extension: 8 Digits
	Feature: 8 Digits	Feature: 8 Digits
	Trunk: 8 Digits	Trunk: 8 Digits
Attendant	5/Tenant	5/Tenant
DSS/BLF Console	5	5
Member of conference	13 party	13 party
Internal Page zone	15	30
System speed dial	1000 (32 digits)	2000(32 digits)
Station Speed Dial	50 (32 digits)	50 (32 digits)
Call Log (Outgoing/Incoming/Missed Call)	100 (32 digits) (Not protected)	100 (32 digits) (Not protected)
Save Number Redial (SNR)	1 (32 digits)	1 (32 digits)

Items	MBX IP 100	MBX IP 300
Number of SMDR Records	5000	5000
Authorization Code	Max. 12Digits 180: Extension	Max. 12Digits 648: Extension
CO Group No	24	72
Station Group	20 (50 member/Group)	50 (50 member/Group)
Pickup Group	20 (100 member/Group)	50 (100 member/Group)
Command Call Group	10 (12 member + 1 initiator/Group)	10 (12 member + 1 initiator /Group)
Interphone Group	10 (10 member/Group)	10 (10 member/Group)
Page Group	15 (50 member/Group)	30 (50 member/Group)
PTT Group	10 (50 member/Group)	10 (50 member/Group)
Conference Room	9	9
Number of Hot Desk Agent	60	324
Station Name Information	16 Characters	16 Characters
Digit Restriction	COS: 16	COS: 16
	Allow/Deny Entry per COS: 100	Allow/Deny Entry per COS: 100
	Max. Digit: 16	Max. Digit: 16
Digit Translation	Table No: 9	Table No: 9
	Number of Digit: 16	Number of Digit: 16
	300 per 1 table	300 per 1 table
No Of Bar Record	3000	7000

Ü•c{ ÁŒ ašā

License for Hotel (Lock Key)	Note
PMS lock key for Hotel	PMS interface will be available
Fidelio lock key for Hotel	PMS and Fidelio interface will be available

Šā }•^Á |Á [c|

The **MBX IP** system supports hospitality features like check-in/check-out, management of guest room information (Guest name, Guest Class of Service, Maid Status, Mini-bar, etc.), convenient features for hotel guests (Wake-up, DND, Message Wait, Bath Alarm, etc.), and efficient hotel operation and services through interworking with PMS (Property Management System) system.

In the **MBX IP** system, hotel features and office features are available in one software package. Basically, the hotel features are available only for hotel stations like guest station, front desk, and service station. But other normal call features like call transfer, call forward, camp-on, message wait and etc are common to both hotel and office stations. It is also possible to allow or deny calls between hotel and office stations. This configuration would be very useful in case there is a client who wants to have an office solution and hotel solution at the same time with only one physical telephony system.

Hotel Service Type

Each extension of the **MBX IP** is assigned its own hotel service type, and typical features and services are provided depending on the allocated hotel service type.

There are 4 hotel service types: Office Station, Guest Station, Front Desk, and Service Station.

In order to use hotel features, stations must be programmed to have hotel service types like guest station, front desk and service station.

One station can have only one hotel service type. It is impossible to have a station that is a front desk and also a service station. For another example, office station cannot be a front desk.

Office Station

It is not possible to use hospitality features like check-in, check-out, maid status and etc from an office station. But all the basic telephony services are available in an office station.

CONDITIONS

- Office station is the default hotel service type in the **MBX IP** system.
- The calls from office stations to hotel stations (guest station, front desk, and service station) can be allowed or denied.

Guest Station

A Guest station is a terminal that is in a hotel guest room and used by the hotel guest.

From the guest station, it is possible to use hotel-specific features like room monitor, maid status and etc. In addition, all the basic telephony services like DN (Directory Number) features, system features (Transfer, Forward, Speed Dial, VM features), CO features (DID, DISA) are available.

CONDITIONS

Program Menu	Menu	Sub Menu
[#] Hotel Feature	[4] Hotel Room Setting	[1] Room Wake Up Register
		[2] Room Wake Up Cancel
		[3] Room DND Setting
		[4] Room Message Wait
		[5] Room Bath Alarm Enable
		[6] Room Bath Alarm Disable
		[7] Room Author Code
		[8] Room Prepaid Money
	[5] Hotel Room-Swap Setting	
	[6] Hotel Room Maid Status	
	[7] Hotel Room Charge/Status	[1] Room Charge Print
		[2] Room Status Print
		[3] Delete SMDR (Service Station)
	[8] Hotel Room Rate	[1] Room Rate Register
		[2] Room Rate Assign
		[3] Room Part Time Fee
		[4] Room Bar/Mini-bar Charge
	[9] Hotel Room Call Rate	[1] Room Call Rate Register
		[2] Room Call Rate Assign
	[0] Hotel Misc Program	[1] Hotel Name
		[2] Set Call Forward

Front Desk

Front desk is a terminal that can be used in hotel front desk.

It provides more hotel features than the guest station. Features like check-in, check-out, guest info setting and display, room swapping and etc are supported for front desks. Front desk can provide hotel services to the hotel guests and service stations.

CONDITIONS

- Front desk program menus are available only from front desks.
- There can be multiple front desks and there is no limit on the number of front desks.

- The calls from service stations to office stations can be allowed or denied.
- At hotel service station, a guest can make an outgoing CO call with password by using 'Walking COS' feature or by using One-Time-CO-Call Enable Feature.

OPERATION

To call Hotel Service Station:

1. Lift handset or press [SPEAKER] button.
2. Dial the service station number as a normal intercom call.

Multiple Front Desks

Multiple front desks can be activated via programming. A station becomes a front desk if it is assigned a hotel service type as front desk.

CONDITIONS

- There is no limit on the number of front desks.
- If there are multiple front desks, they can be put into one station hunt group so that the multiple front desks can receive calls from guest stations or service stations.
- If the attendants are programmed to be front desks, the attendants will be able to cover office stations and hotel stations. In this case, calls between office stations and front desks should be enabled.
- Simultaneous front desk programming is possible in iPECS-MG system. Only the latest update will be effective if multiple front desks program the same settings.

OPERATION

Front desk features and program menu are available from front desk.

Check In

It allocates a guest room to each guest, changes the maid status and registers basic information of the guest(s) individually or entirely. This feature is available from PMS (Property Management System), and Front Desk.

CONDITIONS

- System checks if a room to check in is set to provide WAKE-UP, Call Forward, DND, Absence and Message Wait. If they are registered, all those features are canceled.
- When check-in is registered from PMS, guest grade, language ID, COS, name, PMS group number, and expected check out time must be entered.
- If check-in to a new room is confirmed by the front desk without programming any data, system processes the check-in with default values.

- 4 : Designate digit restriction class
 - 5 : Designate digit conversion class
 - 6 : Designate guest name
 - 7 : PMS group setting
 - 8 : Expected check-out date and time
 - 9 : Confirm check-in completion
5. Press a desired value of each sub menu and press the [SAVE] button.
 6. When completing setting of all values, dial 9 to finish check-in.
 7. Select Check-In Confirmation and press the [SAVE] button. (0 : Confirm, 1 : Cancel)
 8. When check-in is successful, you may hear a service set tone; check the result through the phone LCD.
 9. When check-in fails, you may hear an error tone.

Check Out

It registers check-out of hotel guests individually or entirely from PMS (Property Management System) and Front Desk.

CONDITIONS

- Upon check-out, guest name is deleted and it is restored to be "ROOM". Language ID and the COS are changed into values programmed in hotel general information (PGM XXX).
- When check-out is performed, maid status of the room is changed to "DIRTY (To be cleaned)". And the followings are automatically cleared or set:

Fields that are cleared:

Absence message and Message Wait / Guest Name / DND / Wake-Up Time /
Call Forward Status / Authorization Code / Maid Status / Station COS /
Prepaid Money / Voice mail

Fields that are set:

ICM disable / LCD language (PGM XXX) / Prompt language (PGM XXX) /
Room to room Call Group /
Call charge rate (default call charge rate assigned at PGM XXX)

1. Dial the [PGM] button + #2.
2. Press a phone number or a phone number range of desired room(s).
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. Select Check Out Confirm. (0 : Confirm, 1 : Cancel)
5. Press the [SAVE] button.
6. If it is successful, you may hear a service set tone; check the result through the phone LCD.
7. When check-out fails, you may hear an error tone.

Call Barring

CO Call Barring (Room Cut)

The use of CO lines from guest stations can be allowed or denied from Front Desk or PMS.

CONDITIONS

- It is possible to register or cancel room cut individually or entirely from PMS.
- If room cut off is registered from PMS, registered room number, cut off status and input location must be entered.
- If C/O line is accessed for an outgoing call from a room, room cut setting is checked. If room cut is registered, the call is released.

OPERATION

Front Desk

To register/cancel room cut information:

1. Dial the [PGM] button + #31.
2. Dial a phone number or a phone number range.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. Designate whether to use trunk call. (0 : Allowed, 1 : Not Allowed)
5. Press the [SAVE] button.
6. If it is successful, you may hear a service set tone; check the result through the phone LCD.
7. Otherwise, you may hear an error tone.

- Basically, a guest station can call hotel guest stations in the same PMS group except PMS group 0. In other words, if ICM Call is not allowed, a guest station can call guest stations only included in its PMS group. If, however, ICM Call is permitted, a guest station can call guest stations which belong to other PMS groups.
- Regardless of ICM Call Barring, a guest station can make calls to all service stations, front desks and attendants. Generally, a guest station cannot call office extension. If, however, "Call Office from Hotel Room" of Hotel Normal Information is permitted, office extension can be called.
- Regardless of ICM Call Barring, a service station can call other service stations, front desks and attendants. Generally, a service station cannot call office extension. If, however, "Call Office from Hotel Service" of Hotel Normal Information is permitted, office extension can be called
- Regardless of ICM Call Barring, a front desk can call guest stations, service stations, front desk and attendants. Generally, a front desk cannot call office extension. If, however, "Call Office from Hotel Front" of Hotel Normal Information is permitted, office extension can be called.
- Regardless of ICM Call Barring, a hotel attendant can call guest stations, service stations, front desks and attendants. Generally, a hotel attendant cannot call office extension. If, however, "Call Office from Hotel Attendant" of Hotel Normal Information is permitted, office extension can be called.

OPERATION

Front Desk

To register ICM Call Barring:

1. Dial the [PGM] button + #32.
2. Dial a room phone number or a phone number range.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. Designate whether to use ICM. (0 : Allowed, 1 : Not Allowed)
5. Press the [SAVE] button.
6. If it is successful, you may hear a service set tone; check the result through the phone LCD.
7. Otherwise, you may hear an error tone.

One-Time CO Call Use

By the request of guest, front desk can enable one-time CO call to an intercom-only station. In this time calling station's COS is temporally changed to that of the charged station's COS.

- When wake up is registered/cancelled from Attendant, Front Desk, Guest Station or PMS, wake-up service result is notified to PMS.

OPERATION

Attendant

To register wake up for a room:

1. Dial {Wake-up Register} feature code or [PGM] button + 045.
2. Press a phone number range of desired room(s).
3. Dial four digits of desired time suitable for 24 HR mode.
4. If wake up is required to be repeated, dial #.
5. Press the [SAVE] button.
6. If it is successful, you may hear a service set tone; check the result through the phone LCD.
7. Otherwise, you may hear an error tone.

To cancel wake up for a room:

1. Dial {Wake-up Cancel} feature code or [PGM] button + 046.
2. Press a phone number or a phone number range of desired room(s).
3. Check current wake up time.
4. Press the [SAVE] button.
5. If it is successful, you may hear a service set tone; check the result through the phone LCD.
6. Otherwise, you may hear an error tone.

Front Desk

To register wake up for a room:

1. 1.Dial {Wake-up Register} feature code or [PGM] button + #41.
2. Press a phone number range of desired room(s).
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. Dial "1" to register wake up.
5. Dial four digits of desired time suitable for 24 HR mode.
6. If wake up is required to be repeated, dial #.
7. Press the [SAVE] button.

Ì È Ó ã ã Á ^ & & ^ • • ~ | È Ì [^ Á æ Á @ æ Á æ Á ^ ç æ Á ^ Á ã } ^ Ì & @ & Á @ Á ^ • | ó @ [^ * ó @ Á @ } ^ Á S Ò Ò È

J È U c @ ! , ã ^ È Ì [^ Á æ Á @ æ Á æ Á :: | | Á } ^ È

To cancel wake up for a room:

F È Ö ã ã Á Y æ ^ È] Á Ì æ & | ð Á æ | ^ Á & | á ^ Á | Á Û Ö T æ ~ ç } È Á Ì È È

G È Ú | ^ • • Á @ } ^ Á { à ^ | Á | Á @ } ^ Á { à ^ | Á æ * ^ Á Á ^ • á á Á [[{ G È Ú | ^ • • Á ^ ç ^ } Á @ } ^ Á { à ^ | Á @ } Á } ç | á * Á @ } ^ Á { à ^ | Á æ * ^ Á È

H È Ú | ^ • • Á @ Á Û Ö X Ò æ ~ ç } È

I È Ö ã ã Á Y æ ^ È] Á Ì æ & | Á æ ^ Á] È

Ì È Ô @ & Á & :: | ^ } ç æ ^ Á] Á ^ È

Î È Ú | ^ • • Á @ Á Û Ö X Ò æ ~ ç } È

Ì È Ó ã ã Á ^ & & ^ • • ~ | È Ì [^ Á æ Á @ æ Á æ Á ^ ç æ Á ^ Á ã } ^ Ì & @ & Á @ Á ^ • | ó @ [^ * ó @ Á @ } ^ Á S Ò Ò È

Ì È U c @ ! , ã ^ È Ì [^ Á æ Á @ æ Á æ Á :: | | Á } ^ È

Guest Station (Digital Phone)

To register wake up time:

F È Ö ã ã Á Y æ ^ È] Á Û ^ * ã ç | ð Á æ | ^ Á & | á ^ Á | Á Û Ö T æ ~ ç } È Á È È

G È Ö ã ã Á ^ | Á æ æ Á ^ | ^ • ^ } ç * Á @ ^ | Á æ á Á ç ^ ç È

H È Ö ã ã Á ç Á ^ | ^ æ Á æ ^ Á] Á ^ È

I È Ú | ^ • • Á @ Á Û Ö X Ò æ ~ ç } È

To cancel wake up time:

F È Ö ã ã Á Y æ ^ È] Á Ì æ & | ð Á æ | ^ Á & | á ^ Á | Á Û Ö T æ ~ ç } È Á È È

G È Ú | ^ • • Á @ Á Û Ö X Ò æ ~ ç } È

Guest Station (Single Line Telephone)

To register wake up time:

F È Š ä ç @ Á ç á • ^ È

G È Ö ã ã Á ç * | Á ç ^ Á | | @ } ^ Á Y æ ^ È] Á Û ^ * ã ç | ð Á æ | ^ Á & | á ^ È

H È Ö ã ã Á ^ | Á æ æ Á ^ | ^ • ^ } ç * Á @ ^ | Á æ á Á ç ^ ç È

I È Ö ã ã Á ç Á ^ | ^ æ Á æ ^ Á] Á ^ È

Ì È W [] Á @ [\ È ç ç Á } ç { æ } Á } ^ Á Á @ æ á È

To cancel wake-up time:

1. Lift the handset.
2. Dial Single Line Telephone {Wake-up Cancel} feature code.
3. Upon hook-flash, a confirmation tone is heard.

Do No Disturb Registration/Cancellation

DND (Do Not Disturb) can be registered/canceled from Front Desk, Guest Station or PMS to a specific room.

CONDITIONS

- Unless a room is checked in, it is impossible to register/cancel DND.
- It is possible to register/cancel DND individually or entirely from the front desk. The existing terminal registers only its own DND but Front Desk registers DND of other rooms.
- Guest station registers/cancels its own DND. The existing DND procedure is maintained.

OPERATION

Front Desk

To register/cancel DND:

1. Dial {DND Register/Cancel} feature code or [PGM] button + #43.
2. Press a phone number or a phone number range of desired room(s).
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. Select DND registration or cancellation. (0 : Register, 1 : Cancel)
5. Press the [SAVE] button.
6. If it is successful, you may hear a service set tone; check the result through the phone LCD.
7. Otherwise, you may hear an error tone.

Guest Station (Digital Phone)

To apply DND to prime directory number (P-DN):

Press the [DND] button when it is not active. [DND] LED turns on.

To remove DND from prime directory number (P-DN):

Press the [DND] button when it is not active. [DND] LED turns on.

To apply DND to sub directory number (S-DN):

FÈ Ú|^••Á@ÁÖPÁ~ æ } Á Á^* ã ÇÌÈ

GÈ ÖæÁÖPÖÁÚ^* ã ÇÌÈÐæ &||Áæ |^Á &| á^È@|^Á Á [&@æ *^Á ÁÖPÖáSÖÖÁ -Á | { ã æÁ æ } á^SÖÖÁ -Á @ &| |^••] [] äã * ÁÜÈPÁ~ æ } Á | ã • È

To remove DND from sub directory number (S-DN):

FÈ Ú|^••Á@ÁÖPÁ~ æ } Á Á^* ã ÇÌÈ

GÈ ÖæÁÖPÖÁÚ^* ã ÇÌÈÐæ &||Áæ |^Á | á^È@|^Á Á [&@æ *^Á ÁÖPÖáSÖÖÁ -Á ÇÌ | { ã æÁ æ } á^SÖÖÁ -Á @ &| |^••] [] äã * ÁÜÈPÁ~ æ } Á | } • Á -È

Guest Station (Single Line Telephone)

To register DND:

ÖæÁÖPÖÁÚ^* ã ÇÌÈÐæ &||Áæ |^Á &| á^È | Çæ Á^* ã dææ } Á | } ^Á Á @ æ á È

To cancel DND:

ÖæÁ@ÁÖPÖÁÚ^* ã ÇÌÈÐæ &||Áæ |^Á &| á^È | Çæ Á^* ã dææ } Á | } ^Á Á @ æ á È

Message Wait Registration/Cancellation

ÇÁ^* ã ÇÌÈ | Á | &æ &|^Á T^••æ^ÁY æÁÚ | { Á | } ÇÖ^•\ ÈÖ^• ÇÚææ } Á æ á Á Ú Ù È

CONDITIONS

ÈÁ ÇÁ | { •• æ | Á Á^* ã ÇÌÈ | Á^••æ^Á ææ á ææ æ æ | Á | Á } ÇÁ | Á | { Á Ú Ù È

ÈÁ ÇÁ | { •• æ | Á Á^* ã ÇÌÈ | Á | &æ &|^Á T^••æ^Á ææ á ææ æ æ | Á | Á } ÇÁ | Á | { Á | } ÇÁ^•\ ÈÁ V@Á Çæ Çæ * Á^••æ^Á æÁ | &| á^Á Á ææ ææ á È

ÈÁ T^••æ^Á ææ Á^* ã ÇÌÈ | Á | &æ &|^Á | { Á^• ÇÁææ } ÈÁ @Á Çæ Çæ * Á^••æ^Á æÁ | | &| á^Á Á ææ ææ á È

OPERATION

Front Desk

To register/cancel a message:

FÈ ÖæÁ@ÁÜÖT á~ æ } Á È Á | È

GÈ ÖæÁÁ^••æ^Á^* á | ÇÁ @ } ^Á ~ { à | Á æ á È

HÈ ÖæÁÁ^••æ^Á^* &| ÇÁ @ } ^Á ~ { à | Á | Á @ } ^Á ~ { à | Á æ *^È Ú|^••Á^Á Çæ ^Á @ } ^Á ~ { à | Á @ } ^Á ÇÌ æ * Á @ } ^Á ~ { à | Á æ *^È

I È Ú|^••Á@ÁÜÖXÖá~ æ } È

Í È Ú|^Á &Á^••æ^Á^* ã dææ } Á | &æ &||ææ } È ÇÁÚ^* ã ÇÌÈ Á Çæ &| D

Î È Ú|^••Á@ÁÜÖXÖá~ æ } È

7. If it is successful, you may hear a service set tone; check the result through the phone LCD.
8. Otherwise, you may hear an error tone.

Guest Station (Digital Phone)

To leave message wait when there is no answer:

1. Press the [CALL BK] button. A confirmation tone is heard.
2. Hang up the call.
3. The receiver's [CALL BK] button LED blinks.

To leave message wait in DND mode:

1. Press the [CALL BK] button. A confirmation tone is heard.
2. Hang up the call.
3. The receiver's [CALL BK] button LED blinks.

To leave call back when the other party is in talk state :

1. Press the [CALL BK] button. A confirmation tone is heard.
2. Hang up the call.

To make a call when a reserved ring is received:

1. Lift the handset or press the [SPEAKER] button.
2. A call is made to the extension previously reserved.

To make a call when message wait is received:

1. Press the blinking [CALL BK] button.
Then, the following screen is displayed.

MWI(00) VMS(00)

2. In order to check a type of waiting message, dial 1-2 and select message type.
1 (MWI: Check a list of missed calls.)
2 (VMS: Check VM message.)
3. Check MWI detail through Volume Up/Down.
4. Press the [HOLD] button to select an appropriate item.

Guest Station (Single Line Telephone)

To leave message wait when there is no answer

FÈ T æ^Á@[\ Áæ È
 GÈ ÖæÁT^••æ^Á æÁ^* ä c!Áæ æ!^Á&| á^ÈÖ&| }-ä{ æä } Á } ^Á@æáÈ
 HÈ Pæ * Á] Á@ÁæÈ

To leave message wait in DND mode

FÈ T æ^Á@[\ Áæ È
 GÈ ÖæÁT^••æ^Á æÁ^* ä c!Áæ æ!^Á&| á^ÈÖ&| }-ä{ æä } Á } ^Á@æáÈ
 HÈ Pæ * Á] Á@ÁæÈ

To make a call when message wait is received

Y @} Á[~ Á æ Á] Á@Á } ^È[~ Á@æÁæ } ^Á^!^•^} ç * Á ^••æ^Á æÁæ áÁ@ } Á
 áæÁ } ^ÈÖæÁT^••æ^Á æÁ^| Áæ æ!^Á&| á^È

To leave call back when the other party is in talk state

FÈ T æ^Á@[\ Áæ È
 GÈ ÖæÁÖæÁÖæÁ ÖæÁ ðÛ ^~ ä * ÁÛ^* ä c!Áæ æ!^Á&| á^È
 HÈ Pæ * Á] Á@ÁæÈ

To make a call when a reserved ring is received

FÈ Šæó@Áæ} á^È
 GÈ ÖæÁÁæ Á æÁÁ] Á@Áæ } • ä } Á!^çä ~ • | Á^•^!ç^áÈ

Bath Alarm

ÓæÁ æä } Á[^•^Á -È@[\ Áæ} áÁ@Áæ} á^È öÁ^Áæ } ^Á æ@ ~ óáæä * Á! Á@Áæ } Á -Á
 àæÁæ{ Áæ ^!ÁÜÖT ÁYYÖæÁ]! *!æ { ^ááá ä Áæ^Áæä áÁæ ç { æææÈ È

CONDITIONS

- ÈÁ Óæ@Œæ{ ÁæÁÜä * Öæ } [óÁÁ! , æá^áÁæ Áæ } [!{ æÁæÈ
- ÈÁ Û•c{ Áæc } áæ óÁæ Áæ &| Áæ@Œæ{ Áæ * ÈÁ ~ óÁæ@Œæ{ Áæ } ááä } Á Á ç| Áæç ÈÁ
 àæ@Œæ{ Áæ * Á] [óÁ { [ç^áÈÖæ} áææ{ Áæ * Áæ Á^Á^ { [ç^áÁ] | Áææ{ Áæ } ááä } Á
 ä Á^æ^áÈ
- ÈÁ Y @} Áæ@Œæ{ Áæ] ^•^ Áæ áÁ&| æ^áÁ^ Áæc } áæ ÈÁ ^••æ^Á æ@Á ^Áææá ç| Á
 á^Á] ç^áÁ@ [* @ÁÜÈHGÖÈ
- ÈÁ Óæ@Œæ{ Áæ æ!^Á Á [óæææ | Á [{ ÁÜÖÁæ ÁY ÖÁ] @ } ^•È

OPERATION

Front Desk

To enable bath alarm for room:

1. Dial the [PGM] button + #45.
2. Dial a phone number or a phone number range of room.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. If it is successful, you may hear a service set tone; check the result through the phone LCD.
5. Otherwise, you may hear an error tone.

To disable bath alarm for room:

1. Dial the [PGM] button + #46.
2. Dial a phone number or a phone number range of room.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. If it is successful, you may hear a service set tone; check the result through the phone LCD.
5. Otherwise, you may hear an error tone.

To reset Bath Alarm Ring;

1. Lift handset or press [SPEAKER] button.
2. Dial station no. or press associated {DSS} button at system attendant station.
If bath alarm condition is already cleared, bath alarm ring will be removed. Otherwise, bath alarm ring will not be removed.

Register/Change Authorization Code

At front desk, it is possible to register or change the authorization code of hotel guest stations.

CONDITIONS

- A user may enter an authorization code from any station to place a CO/IP call using walking COS feature.
- An authorization code may include any dial pad digit except * and #.
- The total number of Authorization Codes in system is 648 in MBX-IP 300 and 180 in MBX-IP 100.

OPERATION

Front Desk

To Register/Change Authorization Code;

Room Swapping

This feature allows a user to change the room without additional check-out and check-in procedure. The existing information will be delivered to the new room.

CONDITIONS

- The new room must be checked out before room swapping.

OPERATION

Front Desk

To swap rooms:

1. Dial the [PGM] button + #5.
2. Dial a phone number of room which is currently being used and *.
3. Dial a phone number of an empty room to be used and *1.
4. Decide whether to swap rooms. (0 : Confirm, 1 : Cancel)
5. Press the [SAVE] button.
6. If it is successful, you may hear service set tone.
7. Otherwise, you may hear an error tone.

Maid Status

Maid status can be registered from front desk, guest station and PMS.

The following maid status settings are supported.

- 1: TO_BE_CLEANED
- 2: UNDER_CLEANING
- 3: READY_FOR_SELL
- 4: OUT_OF_SERVICE
- 5: UNDER_REPAIR
- 6: REPAIR_COMPLETED
- 7: ROOM_OCCUPIED

CONDITIONS

- It is possible to register maid status individually or entirely from PMS.
- It is possible to register maid status from front desk.
- From guest room, maid status can be registered for itself.
- It is impossible to register maid status from an office station or a service station.

3. Make hook flash.
4. Designate Maid Status (1-7).
5. Make hook flash.
6. Designate MAID ID (0000-9999).
7. Make hook flash.
8. If it is successful, you may hear a service set tone.
9. Otherwise, you may hear an error an tone.

Room Charge/Status Print

Room Charge Display/Print

Front desk can see total charge of a single room or multiple rooms on LCD display, and can print SMDR records of the room(s) through RS-232C port.

CONDITIONS

- SMDR MAX record message number is 5000; alarm message is automatically received at the Attendant Station if recorded number is 4000 or 4500.
- Total number of Bar Records is 7000 in **MBX IP** 300 and 3000 in **MBX IP** 100; alarm message is automatically received at the Attendant Station if recorded number is 6000 or 6500 in **MBX IP** 300 and 2000 or 2500 in **MBX IP** 100.
- SMDR and BAR detailed record and total room charge for the room is deleted upon check-out for the next guest.
- After printing, system sends a Form Feed.
- The information print of Guest Room can be blocked by Admin **XXX**.

OPERATION

Front Desk

To display and print Room Charge Information (total charge only or detailed information):

1. Dial the [PGM] button + #71.
2. Dial station number + "*" .
Then, LCD will show the total charge of that station.
Digit "*" is the end mark of station number.
3. Dial station number + "*" again if you want to enter another station number.
LCD will display the summation of total charge of those stations.
In this case, system does not support room range input.

HOTEL NAME						
TOTAL CHARGE IN ROOM 100 (Guest-Name :)						
Check - In : 94/12/26-18						
Current-time : 94/12/31-11 (5 days)						
Start-Time	CQ	Duration	Dialed-No.	Count	Call-Cost	Remark
12/27-13:10	01	00:00:32	000182343507951	0	0	Unanswered
12 / 27 - 13: 30	01	00:01:23	000182343507951	3	1500	
12/28-21:22	02	00:10:18	000182343507953	31	15500	
Charge-Time	Charged-STA	Item	Bar-Cost	tax		
12/28-21:32	COFFEE-SHOP	COFFEE	5000	100		
12/29-10:10	FRONT-DESK	COKE	3000	30		
Item	Charge	Tax(rate)	Sum			
(1) ROOM CHARGE :	300000	30000(10.00%)	330000			
(rate 02 : GOLD)						
(2) CALL CHARGE :	17000	170(10.00%)	17170			
(3) BAR CHARGE :	8000	130	8130			
(4) PRE-PAID :			-20000			
Method of payment : VISA						
TOTAL :			335300	WON		

NOTE: Currency Unit/SMDR Fraction depends on Admin Programming 232.

HOTEL NAME					
TOTAL CHARGE IN ROOM 102 (Guest-Name :)					
Check - In : 94/12/26-18					
Current-time : 94/12/31-11 (5 days)					
Start-Time	CQ	Duration	Dialed-No.	Count	Call-Cost Remark
12/27-13:10	01	00:00:32	000182343507951	0	0 Unanswered
12/27-13:30	01	00:01:23	000182343507951	3	1500
12/28-21:22	02	00:10:18	000182343507953	31	15500
Charge-Time	Charged-STA	Item	Bar-Cost	tax	
12/28-21:32	COFFEE-SHOP	COFFEE	5000	100	
12/29-10:10	FRONT-DESK	COKE	3000	30	
Item	Charge	Tax(rate)	Sum		
(1) ROOM CHARGE :	300000	30000(10.00%)	330000		
(rate 02 : GOLD)					
(2) CALL CHARGE :	17000	170(10.00%)	17170		
(3) BAR CHARGE :	8000	130	8130		
(4) PRE-PAID :			-20000		
Method of payment : VISA					
TOTAL :			35300	WON	

NOTE: Ó ð Ì ^ } & Å Þ æ Þ ! ð c } Å ^ } å • Å } Å ð { å Á ! [* ! æ { å * Å Ç È
 È Ö ç ã å Å ð [| { æ } Á ð å ð [| { æ Å ! Å ð Å ç Å ç } Å ç Å ð Å ç } Å ç Å ð Å ç } Å ç Å ð Å ç

HOTEL NAME						
TOTAL CHARGE IN SERVICE STATION 101						
Check - In : 94/12/26-18						
Current-time : 94/12/31-11 (5 days)						
Start-Time	CO	Duration	Dialed-No.	Count	Call-Cost	Remark
12/27-13:10	01	00:00:32	o00182343507951	0	0	Unanswered
12 / 27 - 13: 30	01	00:01:23	000182343507951	3	1500	
12/28-21:22	02	00:10:18	000182343507953	31	15500	
Item	Charge	Tax(rate)	Sum			
(1) CALL CHARGE :	17000	170(10.00%)	17170			
(2) PRE-PAID :		-	0			
TOTAL :			17170 WON			

NOTE: Currency Unit/SMDR Fraction depends on Admin Programming 232.

Print Room Status through RS-232C

This feature allows printing room status through RS-232C.

CONDITIONS

- Data for the service stations within room range input will not be printed.
- If room is vacant, then only maid status will be printed.
- Room status is printed through RS-232C port and printed format is as follows:

Status											
S	ROOM	CHECK_IN	GUEST_NAME	COS	ICM	GRP	WAKE	AUTH	PRE-PAID	C-RT	CHARGE
C	0100	12/29-23	C.H. Kim	1	Yes	No	20000	.	12345
C	0102	12/25-18	C.B. Choi	1	No	..	07:00	No	0	1	500000
C	0103	12/29-15	I.S. Lee	1	No	..	08:00	Yes	0	2	500
D	0104	Vacant									
C	0105	Vacant									

S means maid status, and C clean and D dirty.

C-RT means call charge rate.

PRE-PAID and CHAGE fields use the SMDR fraction in PGM 232.

OPERATION

Front Desk

Room type and rate program:

1. Dial the [PGM] button + #81.
The LCD will display the room cost and room type name of the first entry in the room rate table.

```

RATE (00)
0000000  .....
```

2. Dial a desired room rate bin number (00-19) if you want to program another entry. LCD will display the room cost and room type name of the selected entry.
3. Press Flex button 1 and dial room cost (7 digits).
4. Press Flex button 2 and enter room type name (Max 6 characters).
5. Press [SAVE] button to update the database permanently.
Go to step 2) to program another entry.

To assign room rate to rooms:

1. Dial the [PGM] button + #82.
2. Dial a phone number or a phone number range.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. LCD displays currently assigned Room Rate Bin No. of the first room of selected range. For example, if selected rooms are 100 - 105, the LCD will display as follows:

```

100 - 105
00 : 0020000 SINGLE
```

5. Dial a desired room rate bin number (00-19).
6. Press [SAVE] button to update the database permanently.
Go to step 2 to assign a room rate to another room(s).

Fee For Part Time

In case check-in and check-out happens in a day, part time fee may be charged according to the room type or hotel policy. Each room type may have up to 6 fields for different part time range and fee. There are 32 entries in part time table in which the part time range and associated fee can be programmed.

- Lower number entries will be referenced first in part time table. That is, if the different entries include the same duration, lowest entry will be applied.
- The duration of stay denotes the elapsed time from check-in to check-out. And only hour information is meaningful so that minute data is just ignored
- If nothing is programmed in part time table, one-day charge will be applied.

OPERATION

Front Desk

Register and change fee for part time table:

1. Dial the [PGM] button + #83.
LCD will display the duration of stay and its fee of the first entry in part time table.

RATE (00) 01 - 03 : 050 %

2. Dial a desired room rate bin number (00-31) if you want to program another entry.
LCD will display the duration of the stay and its fee of the selected entry.
3. Press Flex button 1 and dial the duration of stay (4 digits).
Press [SPEED] button to erase the data.
4. Press Flex button 2 and dial the associated rate (000-100).
5. Press [SAVE] button to update the database permanently.
Go to step 2) to program another entry.

Upon check-out for the part-time stay, the guest bill will look similar to the following:

OPERATION

Front Desk

To register bar or mini-bar charge

1. Dial the [PGM] button + #84.
2. Dial the guest room number + "*" .
3. Dial product code (00-99).
4. Press the [SAVE] button.
5. Dial (mini) bar cost (Max 6 digits).
LCD will show room no, (mini) bar cost, the name of item.
6. If you dial #, the cost becomes a minus value. The value is toggled between minus and plus by dialing #. Plus is the default sign.
7. Press the [SAVE] button to save the cost.
If it is successful, you may hear a service set tone. And (mini) bar cost is registered and SMDR Information for the (mini) bar cost will be printed through RS-232C.
Otherwise, you may hear an error tone.

Service Station

To register bar or mini-bar charge

1. Dial {Hotel Mini-bar Register} feature code.
2. Dial the guest room number + * .
3. Dial product code (00-99).
4. Press the [SAVE] button.
5. Dial (mini) bar cost (Max 6 digits).
LCD will show room no, (mini) bar cost, the name of item.
6. If you dial #, the cost becomes a minus value. The value is toggled between minus and plus by dialing #. Plus is the default sign.
7. Press the [SAVE] button to save the cost.
If it is successful, you may hear a service set tone. And (mini) bar cost is registered and SMDR Information for the (mini) bar cost will be printed through RS-232C.
Otherwise, you may hear an error tone.

Guest Station (Digital Phone)

To register bar or mini-bar charge

FÈ Ôæ|Ûæ| c|Á q ææÛ^* æ c|Áæ æ |^&| á^È
 GÈ Ôæ|Ûæ| | á &æ| á^ÁææJÈ
 HÈ Ú|^••Á@ÛOXÒá~ æ } È
 I È Ôæ|Ûæ| q æææ&| •c| æ^Á áæ æ È
 SÔÓÁ q|Á @, Á| |{ Á | Èæ q æææ&| •æ@Áæ ^Á -æ { È
 Í È GÁ | ~ ÁææÁæ@&| •c|æ| { ^•Áæ q ~ •Áæ ^ÈV@Áæ ^Áæ **|^áæç ^) Á q ~ •Á
 æ áÁ | •Á ^ Áææ * ÁÈÛ | •Á Á@Áæ-æ |Á á } È
 Î È Ú|^••Á@ÛOXÒá~ æ } Á Áæ^Á@&| •c|
 GÁæ Á ~ &&••~ |È | ~ Á æ Á@æÁ^çæ Á^æ } ^Èæ áÁ q æææ&| •c| Á^* æ c|^áÁ
 æ áÁÛT ÖÜÁ | |{ æ } Á | Á@Á q æææ&| •c| q|Á^Á | q c|á@ | ~ * @ÛÛÈçGÔÈ
 U@ |, æ^È | ~ Á æ Á@ææ Á | | | Á } ^È

Guest Station (Single Line Telephone)

To register bar or mini-bar charge

FÈ Ôæ|Ûæ| c|Á q ææÛ^* æ c|Áæ æ |^&| á^È
 GÈ Ôæ|Ûæ| | á &æ| á^ÁææJÈ
 HÈ T æ^Á@ | \ Áæ @ È
 I È Ôæ|Ûæ| q æææ&| •c| æ^Á áæ æ È
 Í È GÁ | ~ ÁææÁæ@&| •c|æ| { ^•Áæ q ~ •Áæ ^ÈV@Áæ ^Áæ **|^áæç ^) Á q ~ •Á
 æ áÁ | •Á ^ Áææ * ÁÈÛ | •Á Á@Áæ-æ |Á á } È
 Î È T æ^Á@ | \ Áæ @ Á Áæ^Á@&| •c|
 GÁæ Á ~ &&••~ |È | ~ Á æ Á@æÁ^çæ Á^æ } ^Èæ áÁ q æææ&| •c| Á^* æ c|^áÁ
 æ áÁÛT ÖÜÁ | |{ æ } Á | Á@Á q æææ&| •c| q|Á^Á | q c|á@ | ~ * @ÛÛÈçGÔÈ
 U@ |, æ^È | ~ Á æ Á@ææ Á | | | Á } ^È

Call Rate

Call Charge Rate Register/Assign

V@Áæ |^&| , •Á | } c|æ • Á Áæ • á | ææ|æ@æ^Áæ Á Áæ Áæ áææ æÁ | |{ Á | Á Áæ^çæ Á
 •ææ } Á | Á@ææá^ | ^) c|æ | ææ^Áæ Áæ | Áæ | | æáÈV Á^Á@Áæ |^ÈæÁæ •Á | } c|æ • Á
 { ~ •Á^* æ c|^ææ|ææ^Áæ Áæ | Èæ áÁ@ } Áæ • á } Á@Á^* æ c|^áÁæ Á Áæ@ | |{ ÈOæ|Á
 &æ^Áæ Á^ } | c| Á@Á^ | & } æ^Á } ÁÛT ÖÜÁæ|Á •c|

CONDITIONS

ÈÁ V@|^Áæ Á^Á | Á Á Á } dæ • Á @ Áæ|ææ^Áæ Áæ | Áç | { Á Á Á È

- If a room or a service station is not assigned a call charge rate, 100 percent of SMDR call cost is charged.
- It is optional to program the call charge rate type.

OPERATION

Front Desk

Register or change an entry in call charge rate table:

1. Dial the [PGM] button + #91.
LCD will display the call charge rate of the first entry in table.

CALL CHARGE RATE (0) 000 %

2. Dial a desired room rate bin number (0-5) if you want to program another entry.
LCD will display the call charge rate of the selected entry.
3. Press Flex button 1 and dial the call charge rate (3 digits).
Press [SPEED] button to erase the data.
4. Press Flex button 2 and enter the name of rate (Max 6 characters).
5. Press [SAVE] button to update the database permanently.
Go to step 2) to program another entry.

To assign call charge rate to rooms:

1. Dial the [PGM] button + #92.
2. Dial a phone number or a phone number range.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. LCD displays currently assigned index of call charge rate table of the first room in selected range. For example, if selected rooms are 100 - 105, the LCD will display as follows:

100 - 105 0 : 090 % HOLIDAY

5. Dial a desired call charge rate bin number (0-5).
6. Dial # to erase the bin number.
7. Press [SAVE] button to update the database permanently.
Go to step 2) to assign a room rate to another room(s).

6. Press the [SAVE] button.
7. Replace the handset, return to idle.

To deactivate call forward for the room(s):

1. Dial the [PGM] button + #02.
2. Dial a phone number or a phone number range.
Press * between phone numbers when entering a phone number range.
3. Press the [SAVE] button.
4. Dial # to cancel call forward.
5. Replace the handset, return to idle.

Additional Tax Fields

Different tax rates can be applied for the various charges in hotel.

Example: Tax 0 = 10.00 %
Tax 1 = 20.00 %
Tax 2 = 0 %
....

Each bar item in the bar terminal table (PGM **XXX**) can have a tax rate index such as TAX 0, TAX 1, TAX 2, and etc.

Tax rates for call charge and room charge is fixed as the first tax rate entry, that is, Tax 0.

CONDITIONS

- Tax index for the telephone and room charge is 0, that is, Tax 0 will be applied.
- There are up to 5 programmable tax rates (0 to 4) in PGM **XXX**.
- Every tax rates has 00.00 % by default and may have the value from 00.00 % to 99.99%.
- Each bar item can have only one index of tax rate.
- The index of tax rate in bar item table is 0 by default.
- Total tax of each item is only the integer part of the result that is calculated by the following equation.

Equation for tax: [Total tax] = INTEGER ([Charge] * [Tax rate] * 100 / 10000).

Guest Station

To use Dial One Digit Service:

1. Lift the handset or press the [SPEAKER] button.
2. Dial one digit registered.
3. After a certain period of time, a call is made.

Room Monitor / Baby Listening

It allows guests to monitor their rooms outside of the rooms in a hotel. In order to perform this function, an extension to be monitored must be set to room monitor mode. If monitoring is activated, all sounds of the monitored station can be heard from the monitoring extension. But the monitoring party's sounds are not delivered to the monitored extension.

CONDITIONS

- This feature is available only for extension call in the system.
- Monitor mode can be set only from a checked-in guest station.
- If the monitored extension is called, DND rejection tone is heard. In this case, step call and camp-on cannot be performed, but message wait, redial and pilot hunt can be performed.
- If a 3rd party calls the extension currently being monitored, busy tone is heard. Then, the 3rd party can perform step call and call back.
- External caller cannot monitor internal stations. That is, the extension currently being monitored cannot perform CO transfer.
- SIP extension cannot be monitored.

OPERATION**Guest Station**

To put an extension into monitor mode:

1. Lift the handset or press the [SPEAKER] button.
2. Dial {Hotel Room Monitor} feature code.
3. Service set tone is heard and the extension is monitored.

To clear extension monitoring:

1. Hang up the monitored station or press the active [SPEAKER] button.
2. The extension goes on-hook and extension monitor is finished.

To monitor a guest station:

FÈ Šãó@Á@æ å^oÁ!Á!^•Á@ÁÛÚÓCSÒÜã~æ }È
 GÈ ÖãÁ@Á@æ }Á }Á { à^!ÁÁ Á [] æ |È
 HÈ ÖPÖÁ^b&ç }Á }^Á Á@æåÈ
 I È ÖãÁ@Á@æ ^Á @ }^Á { à^!È
 Í È Û[~}ãÁ-Á@Á [] æ !^ãÁ[[{ ÁÁ@æåÈ

Call Answer Recognition (not available in U.S.)

QÜÖPÁ@Á^ÁÁ^aÁ!Á~c[ã*Á@æ}ÁÁÁ^~ã^aÁ@æá@æ^aÁæcÁ@æ • ^!Áã }æÁÁ
 !^&|*}ã^aÁ^Á@Á^c{Á@æãÁæ*^aÁ}Á@Á^•cÁá|Á@æãÁÁ|**ã*ÁÛÖÜÁ~d~c

OPERATION

When a call is made from a guest station and the call is disconnected without answer, the call will be displayed on the guest's bill as follows:

HOTEL NAME					
TOTAL CHARGE IN ROOM 100 (Guest-Name :)					
Check - In : 94/12/26-18					
Check - Out : 94/12/31-11 (5 days)					
Start-Time	CQ	Duration	Dialed-No.	Count	Call-Cost Remark
12/27-13:10	01	00:00:32	000182343507951	1	0 Unanswered
12/27-13:30	01	00:01:23	000182343507951	3	1500
12/28-21:22	02	00:10:18	000182343507953	31	15500
Charge-Time	Charged-STA	Item	Bar-Cost	tax	
12/28-21:32	COFFEE-SHOP	COFFEE	5000	100	
12/29-10:10	FRONT-DESK	COKE (MINI-BAR)	3000	30	
Item	Charge	Tax(rate)	Sum		
(1) ROOM CHARGE :	300000	30000(10.00%)	330000		
(rate 02 : GOLD)					
(2) CALL CHARGE :	17000	170(10.00%)	17170		
(3) BAR CHARGE :	8000	130	8130		
(4) PRE-PAID :			-20000		
Method of payment : VISA					
TOTAL :			335300 WON		

NOTE: Currency Unit/SMDR Fraction depend on PGM 232

The SMDR print out will show the following:

NO	STA	CO	TIME	START	DIALED	CNT	COST	REMARK
0009	101	01	00:04	13/06/95 12:47	O123	1	0.10	
0010	101	01	00:15	13/06/95 12:50	o01444872014	0	0.00	UNANSWERED

Alphabet small o in the DIALED field means unanswered outgoing call using ISDN line.

CONDITIONS

call answer is sequential in the order of call's entrance into the queue. If prioritized queuing of VIP guest call is set, calls from VIP guests are firstly answered by an operator.

CONDITIONS

- This feature is only available for attendants.
- VIP guests are determined depending on guest grade designated upon check-in.

VIP Guest Wake-Up Call

It allows an attendant to be informed of VIP guests' wake-up call and provide wake-up call service. When it is wake-up call time designated for VIP guest room, the attendant is alerted for the wake up of the guest. The attendant can see VIP guest's room number and extension status together with the alarm. If the attendant dials {VIP Wake Up} feature code, the list of wake up calls for VIP guests are shown and a call can be made to the VIP guest by pressing [HOLD/SAVE] button.

CONDITIONS

- This feature is only available for attendants.
- VIP guests are determined depending on guest grade designated upon check-in.
- There can be maximum 20 VIP wake-up logs in system. The log is deleted once the attendant presses [SAVE] button while checking VIP wake-up logs.

OPERATION

To make a {VIP WAKE UP} button:

[PGM] + {FLEX} + Button Feature Type (1) + {VIP Wake Up Feature Code} + [SAVE]


To check and serve VIP wake-up call:

1. Lift the handset or press the [SPEAKER] button.
2. Dial {VIP Wake Up Feature Code} or press {VIP WAKE UP} button.
3. Wake-up information and current status of VIP guest is displayed on LCD.
If there're multiple wake-up calls, the information can be scrolled by using the [VOL UP]/[VOL DOWN] keys
4. Press the [SAVE] button to call the VIP guest.
5. If the guest answers the call, announce the wake-up feature.

Fidelio Hotel Feature (optional with license)

MBX IP is a feature that allows you to use a single IP address for multiple phones. This is useful for hotels where you have many phones on a single line. The feature is optional with license.

When you enable this feature, you will need to configure the phones to use the IP address. This is done through the phone's web interface. The feature is supported on all FIAS phones.



© 2012 Vertical Communications, Inc. All rights reserved.

© 2012 Vertical Communications, Inc. All rights reserved.

Feature Category	Specific Features
Guest Data	Check In
	Check Out
	Room Change
	Guest Info/Name Change
Room Data	Room Status: Inspect, Clean, Dirty
	Voice Mail Notification
Charge Posting	Call Charge Posting : Classification of local call, long distance call, international call, and mobile call
	Mini-Bar Charge Posting

Fidelio Hotel Feature

THIS PAGE INTENTIONALLY LEFT BLANK.

Quick Reference

This appendix contains Quick Reference tables for the following types of information:

- Database Index [on page C-1](#)
- Default Numbering Plan [on page C-8](#)
- Fixed Function/User Program Codes [on page C-17](#)
- Default Values [on page C-21](#)
- Alpha-numeric Entry Charts [on page C-105](#)

DATABASE INDEX

The Database index is divided into groups of "PROGRAMS" based on specific characteristics associated with the data such as, Numbering Plans, Station oriented database entries, or CO Line oriented values. These groupings are identified as the Program Group in Web Admin. The individual PROGRAMS are identified in the Table with the ADMIN STATION PROGRAM CODE (PGM Code) and a corresponding Web sub-menu and description.

PROGRAM GROUP	PGM CODE	PGM NAME	WEB SUB-MENU
PRE-PROGRAMMED DATA	100	Location Program	Location Program
	102	Slot Assignment	Slot Assignment
	103	Logical Slot Assignment	Logical Slot Assignment
	104	DECT/IP/SIP MAX Port	DECT/IP/SIP MAX Port
	106	IP-Phone/Phontage Registration	IP-Phone/Phontage Registration
	107	DTIM/SLTM Registration	DTIM/SLTM Registration
	108	IP Address Plan	IP Address Plan
	109	System Info Display	
NUMBERING PLAN DATA	110	Numbering Plan Type	Numbering Plan Type
	111	System Numbering Plan	System Numbering Plan
	112	Flexible Station Number	Flexible Station Number
	113	Feature Numbering Plan	Feature Numbering Plan

PROGRAM GROUP	PGM CODE	PGM NAME	WEB SUB-MENU
CO LINE DATA	162	CO Line Attribute 3	
	163	CO CID Attribute	
	165	Incoming CO Attribute 1	Incoming CO Attribute
	166	Incoming CO Attribute 2	
	167	CO Ring Assignment	CO Ring Assignment
	168	Incoming CO Normal/DISA Attribute	Normal/DISA CO Attribute
	169	Incoming CO Alternative Destination	Incoming CO Alternative
	170	Outgoing CO Attribute 1	Outgoing CO Attribute
	171	Outgoing CO Attribute 2	
	173	Outgoing CO Alternative Destination	Outgoing CO Alternative
	174	CO Inter Digit Timer	CO Inter Digit Timer
	175	DTMF Sending Delay Timer	DTMF Send Interval
	177	CO COS Assignment	CO COS Assignment
	179	CO to CO Attribute	CO-to-CO Attribute
	180	CO Group Access Code Attribute	CO Group Access Code
181	Alternative Ring Table	Alternative Ring Table	
STATION GROUP DATA	200	Station Group Assign	Station Group Assign
	201	Greeting/Queuing Attribute	Station Group Attribute
	202	Station Group Attribute	
	203	VM Group Attribute	Voice Mail Group
	204	Pickup group Index	Call Pick-up Group
	205	Page group Index	Page Group
	206	Command Conference Group Index	Command Conference Group
	208	PTT Group Index	PTT Group
	209	Interphone Group Index	Interphone Group
	210	Pilot Hunt Group Index	Pilot Hunt Group
	211	Pilot Hunt Group Forward	
SYSTEM DATA	220	System Timer 1	System Timer

PROGRAM GROUP	PGM CODE	PGM NAME	WEB SUB-MENU
ÛÛÛÛÛÛ ÖË/ÖË	GGF	Û•Ö{ Áv̄ ^!ÁG	
	GGG	Û•Ö{ Áv̄ ^!ÁH	
	GGH	Û•Ö{ ÁÖÖä~ Ö	Û•Ö{ ÁÖÖä~ Ö
	GGI	Û•Ö{ ÁÜæ•, [!ä	Û•Ö{ ÁÜæ•, [!ä
	GGJ	Û•Ö{ ÁÖÖä{ ÁÖÖä~ Ö	ÖÖä{ ÁÖÖä~ Ö
	GGK	ÖÖä!} äÖ[] d[Ö[] æ&c	ÖÖä!} äÖ[] d[Ö[] æ&c
	GGL	T~•äÖ•ä}	T~•äÜ[]!&
	GGM	ÛÛG-HÁÜ[]!Ö^Ö*	ÛÛG-HÁÜ^Ö*
	GGN	Ü!ä ÖÜ[]!Ö^!&Ö}	Ü!ä:äÜ[]!Ö^!&Ö}
	GGO	ÛT ÖÜÖÖä~ Ö	ÛT ÖÜÖÖä~ Ö
	GGP	Û^Ö•Ö{ Áv̄ ^ÖÖä	Û•Ö{ Áv̄ ^ÖÖä
	GGQ	ÖÖÖÖ[]! :ÖÖä @Üæ	ÖÖÖÖ[]!@ *Üæ
	GGR	T[]ä~^ÖÖä~ Ö	T[]ä~^ÖÖä~ Ö
	GGS	U]^ÖÖä äÜ!çä	ÖÖä!ç { Ö•^Áä!^
	GGT	Ö { { ^ÖäM]^Öä ä	ÖäM]^Öä ä!ä!^
	GGU	ÖÖ& Ö^Ö!&^Öä Ö•ä}	ÖÖ& Ö^Ö!&^Öä Ö•ä}
	GGV	ÖÖ& Ö^ÖÖÖ& Ö^ÖÖÖ••	ÖÖ& Ö^ÖÖÖ••
	GGW	Y^äÁ U}r	ÛÛÛÛÖÖä~ Ö
	GGX	Y^äÁ U}r	Y^äÖÖÖ••Á ÖÖÖ!ä ää}
	VOËÖÖÖÖÖ/ÖË	GGY	V[] ÖÖ&] Ö{ }Áä!^
GGZ		Öä äÖ[]ç!•ä }Áä!^	Öä äÖ[]ç!•ä }Áä!^
GGAA		Öä äÖ[]ç!•ä }ÁÜ Ö{ }	
GGAB		v̄ ^Áä!^ÖÖä~ Ö	Û•Ö{ Áv̄ ^Áä!^
GGAC		Y^^\r Áv̄ ^Áä!^	
GGAD		ÖÖÜÁv̄ ^Áä!^ÖÖä~ Ö	ÖÖÜÁv̄ ^Áä!^
GGAE		P[]ää Áv̄ ^Áä!^	P[]ää Áv̄ ^Áä!^
GGAF		Û•Ö{ ÁÜ]^^äÖä!^	Û•Ö{ ÁÜ]^^äÖä!

PROGRAM GROUP	PGM CODE	PGM NAME	WEB SUB-MENU
TABLE DATA	258	Emergency Code Table	Emergency Code Table
	259	Announcement Table	Announcement Table
	260	Custom Call Routing	CCR Table
	262	ICLID Table	ICLID Table
	263	CLI Conversion Table	CLI Conversion Table
	Web Only		Tone Frequency/Cadence
	Web Only		Ring Table
	Web Only		Ring Frequency/Cadence
	269		Voice Mail Dial Table
TENANT DATA	270	Attendant Group Assignment	Attendant Group Assignment
	271	Attendant Group Greeting/Queuing Attribute	Attendant Group Attribute
	272	Attendant Group Attribute	
	275	Night Attendant Group Assignment	Night Attendant Group Assignment
	276	Night Attendant Group Greeting/Queuing Attribute	Night Attendant Group Attribute
	277	Night Attendant Group Attribute	
	280	Tenant Attribute 1	Tenant Attribute
	281	Tenant Attribute 2	
	283	Tenant Group Access	Tenant Group Access
	284	Call Restriction Restriction 1	CO Call Restriction
	285	Call Restriction Restriction 2	
	286	Local Call Prefix Table	Local Call Prefix Table
	287	Long Call Prefix Table	Long Call Prefix Table
	288	International Call Prefix Table	International Call Prefix Table
290	Tenant Tone Table	Tone Table	

PROGRAM GROUP	PGM CODE	PGM NAME	WEB SUB-MENU
ZONE DATA	Web Only		Zone RTP Relay Group
	Web Only		Inter Zone Attribute
SNMP DATA	Web Only		SNMP Data
DECT DATA	Web Only		DECT Registration
	491	DECT Attribute	DECT Attribute
GREEN MODE	Web Only		Green Mode Activation
	Web Only		Green Mode Time Setting
NATION SPECIFIC	400	DKT RX Gain	TDM Gain
	401	SLT RX Gain	
	402	DECT RX Gain	
	403	IP-Phone RX Gain	
	404	ACO RX Gain	
	405	DCO RX Gain	
	406	VMIB RX Gain	
	407	External Page RX Gain	
	415	DSP RX Gain	DSP Gain
	420	SLTM RX RTP Gain	RTP Gain
	421	DTIM RX Handset RTP Gain	
	422	DTIM RX Handsfree RTP Gain	
	423	LIP RX Handset RTP Gain	
	424	LIP RX Handsfree RTP Gain	
	425	WIT RX RTP Gain	
	426	VOIB RX RTP Gain	
	440	SLT Ring Cadence	SLT Ring Cadence
441	ACNR Tone Cadence	ACNR Tone Cadence	
INITIALIZATION	499	Initialization	Initialization

FEATURE CODE

No	Feature Name	NUM SET 1	NUM SET 2	NUM SET 3
1	Attendant Call	0	*9	0
2	Conference Room 1	571	*571	571
3	Conference Room 2	572	*572	572
4	Conference Room 3	573	*573	573
5	Conference Room 4	574	*574	574
6	Conference Room 5	575	*575	575
7	Conference Room 6	576	*576	576
8	Conference Room 7	577	*577	577
9	Conference Room 8	578	*578	578
10	Conference Room 9	579	*579	579
11	Internal Page	543	*543	543
		<i>543 + 00, xx 00: All Call Page Xx: Page Group #</i>		
12	Personal VM Page	544	*544	544
13	Announcement Page For Attendant	545	*545	545
14	Page Auto Answer	546	*546	546
15	Internal Page Answer (Meet-Me Page)	547	*547	547
16	External Page	548	*548	548
17	Internal-External Page All	549	*549	549
18	Call Forward Register	554	*554	554
		<i>554 + Type + Destination</i>		
19	Pilot Hunt Call Forward Register	514	*514	514
		<i>554 + Type + Destination</i>		
20	Pilot Hunt Call Forward Cancel	515	*515	515
21	DND Status Change	516	*516	516
22	DND Delete	517	*517	517
23	Account Code	550	*550	550
24	CO Flash	551	*551	551
25	Last Number Redial	552	*552	552
26	Station Speed PGM	553	*553	553
27	Speed Dial	555	*555	555

No	Feature Name	NUM SET 1	NUM SET 2	NUM SET 3
G Á	T Y ÖŸ^* ä c!Á	í í í Á	é í í Á	í í í Á
GJ Á	T Y ÖŸ •, ^!Á	í í í Á	é í í Á	í í í Á
HE Á	T Y ÖŸ & ^!Á	í í J Á	é í J Á	í í J Á
HF Á	ÖŸ/ÖŸ ÁŸ^* ä c!Á	í F í Á	é F í Á	í F í Á
HG Á	ÖŸ/ÖŸ ÁŸ & ^!Á	í F J Á	é F J Á	í F J Á
HH Á	Ö: [~] ÁŸ/ÁŸ ~] Á	í í í Á	é í í Á	í í í Á
HI Á	Ö^ & ÖŸ/ÁŸ ~] Á	í Á	é Á	í Á
HI Á	Y äŸ ä * ÁŸÜÁ	í GÉ Á	é GÉ Á	í GÉ Á
HI Á	ÖŸ/ÁŸ \ ä * ÁŸ [& äŸ] Á	í I F Á	é I F Á	í I F Á
		541 + xx Xx: Parking Location (00 - 49)		
HI Á	Ú Ö T Á [ä^ ÁŸ & •• Á	í G F Á	é G F Á	í G F Á
HI Á	V, [Ë ä ÁŸ & ! á Á	í G G Á	é G G Á	í G G Á
HJ Á	X T ÖŸ ÁŸ & •• Á	í G H Á	é G H Á	í G H Á
I € Á	ÖŸ ÖŸ ÁŸ & •• Á	í G Á	é G Á	í G Á
I F Á	ÖŸ ÁŸ ^ ÁŸ & •• Á	í ì Á	é ì Á	í ì Á
		88 + xxx Xxx: CO Line # (001-200 : MBX IP-300 01-80: MBX IP-100)		
I G Á	X T Á Y ÖŸ äŸ ^!Á	é Á	é À Á	é Á
I H Á	X T Á Y ÖŸ & ^!Á	E J Á	é À J Á	E J Á
II Á	T ÖŸ ÁŸ ^ ~ ^ • ö	É É Á	é À É Á	É É Á
II Á	WŸ • ~] ^ ! ç ä ^ á ÁŸ [- ÁŸ c c } á Á	í À Á Á	é À Á Á	í À Á Á
II Á	Ú V V ÁŸ [~] ÁŸ & •• Á	í H Á	é H Á	í H Á
		524 + (0-9,*) 0-9: PTT Group # *: Log out		
II Á	P [öŸ • \ ÁŸ [* ÁŸ ÉŸ * ÁŸ ~ ö	í G Á	é G Á	í G Á
II Á	P äŸ ^ ÁŸ ^* ä c!Á	í G Á	é G Á	í G Á
I J Á	Ö ! ^ äŸ ÁŸ [} - ÁŸ [[{ Á	í G Á	é G Á	í G Á
		í G Á É ÁŸ [} - É ÁŸ [[{ Á		
I € Á	Ö ! ^ c! ÁŸ [} - ÁŸ [[{ Á	í G Á	é G Á	í G Á
		528 + Conf. Room #		
I F Á	Y äŸ ^ ÁŸ ÁŸ ^* ä c!Á	í G J Á	é G J Á	í G J Á
		529 + HH:MM		
I G Á	Y äŸ ^ ÁŸ ÁŸ & ^!Á	í HE Á	é HE Á	í HE Á

No	Feature Name	NUM SET 1	NUM SET 2	NUM SET 3
53	Temporarily COS Down	531	*531	531
54	Cancel Temp COS Down	532	*532	532
55	Password Change	533	*533	533
56	Inter-Phone Group Access	534	*534	534
57	Call Wait Request	535	*535	535
58	Preselected MSG PGM	536	*536	536
59	Forced Handsfree Call	537	*537	537
60	Call Based CLIR	582	*582	582
61	CLIR Access	583	*583	583
62	COLR Access	584	*584	584
63	Pilot Hunt Call	585	*585	585
64	Command Call Oneway	581	*581	581
65	Command Call Conf	580	*580	580
66	Intrude Register	589	*589	589
67	Camp On Register	590	*590	590
68	OHVO Register	591	*591	591
69	Mobile Num Register	592	*592	592
70	Mobile CLI Register	593	*593	593
71	Mobile Access	594	*594	594
72	CCR Access	670	*670	670
73	CCR Access And Drop	671	*671	671
74	System Hold	560	*560	560
75	Return Held CO	8**	*8**	8**
76	Sys Memo	675	*675	675
77	DISA Tone Service	678	*678	678
78	All Feature Cancel	679	679	679
79	Add Conf Member	680	*680	680
80	System Alarm Reset	565	*565	565
81	Fault Alarm Reset	564	*564	564
82	Door Open	#*1	#*1	#*1
83	Keypad Facility	##*	##*	##*
84	T-Net Log-In/Out	586	*586	586

No	Feature Name	NUM SET 4	NUM SET 5	NUM SET 6
1	Attendant Call	0	9	#9
2	Conference Room 1	571	571	*571
3	Conference Room 2	572	572	*572
4	Conference Room 3	573	573	*573
5	Conference Room 4	574	574	*574
6	Conference Room 5	575	575	*575
7	Conference Room 6	576	576	*576
8	Conference Room 7	577	577	*577
9	Conference Room 8	578	578	*578
10	Conference Room 9	579	579	*579
11	Internal Page	543	543	*543
		<i>543 + 00, xx 00: All Call Page Xx: Page Group #</i>		
12	Personal VM Page	544	544	*544
13	Announcement Page For Attendant	545	545	*545
14	Page Auto Answer	546	546	*546
15	Internal Page Answer (Meet-Me Page)	547	547	*547
16	External Page	548	548	*548
17	Internal-External Page All	549	549	*549
18	Call Forward Register	554	554	*554
		<i>554 + Type + Destination</i>		
19	Pilot Hunt Call Forward Register	514	514	*514
		<i>514 + Type + Destination</i>		
20	Pilot Hunt Call Forward Cancel	515	515	*515
21	DND Status Change	516	516	*516
22	DND Delete	517	517	*517
23	Account Code	550	550	*550
24	CO Flash	551	551	*551
25	Last Number Redial	552	552	*552
26	Station Speed PGM	553	553	*553
27	Speed Dial	555	555	*555
28	MWI Register	557	556	*556

No	Feature Name	NUM SET 4	NUM SET 5	NUM SET 6
GJÁ	T Y ÖÖ, ^Á	íííÁ	íííÁ	ÉííÁ
HEÁ	T Y ÖÖæ & Á	ííJÁ	ííJÁ	ÉíJÁ
HFÁ	Öæ/Öæ ÁÚ^* ä c!Á	íFíÁ	íFíÁ	ÉFíÁ
HCÁ	Öæ/Öæ Öæ & Á	íFJÁ	íFJÁ	ÉFJÁ
HHÁ	Ö: ~] Öæ/ÁÚæ~]Á	ÉÉÁ	íííÁ	ÉííÁ
H Á	Öä^&Öæ/ÁÚæ~]Á	íÁ	íÁ	ÉÁ
HÍÁ	Y æ ä * ÖUÜÁ	íGÉÁ	íGÉÁ	ÉGÉÁ
HÍÁ	Öæ/ÁÚæ\ ä * Á[&æ] Á	ííFÁ	ííFÁ	ÉíFÁ
		541 + xx Xx: Parking Location (00-49)		
HíÁ	ÚÖT Á [ä^Öæ&••Á	íGFÁ	íGFÁ	ÉGFÁ
HíÁ	V, [È æ ÁÚ^& áÁ	íGGÁ	íGGÁ	ÉGGÁ
HJÁ	XT ÖÖ&••Á	íGHÁ	íGHÁ	ÉGHÁ
IÉÁ	ÖÖ ÖÖ&••Á	íGÁ	íGÁ	ÉGÁ
IFÁ	ÖUÁä^Öæ&••Á	ííÁ	ííÁ	ííÁ
		88 + xxx Xxx: CO Line # (001-200: MBX IP-300 01-80: MBX IP-100)		
IGÁ	XT Á Y ÖÖ) æ ^Á	ÉÁ	ÉÁ	ÉÀÁ
IHÁ	XT Á Y ÖÖæ & Á	EJÁ	EJÁ	ÉJÁ
IIÁ	T ÖÖÁÚ^~^•cÁ	ÉÉÁ	ÉÉÁ	ÉÀÉÁ
IÍÁ	W,~] ^ çä^áÖ[~] ÖÖc} áÁ	íÁÁÁ	íÁÁÁ	ÉÁÁÁ
IÍÁ	ÚVV/Ö: ~] ÖÖ&••Á	íHÁ	íHÁ	ÉHÁ
		524 + (0-9,*) 0-9: PTT Group # *: Log out		
IÍÁ	P[ÖÖ^•\ Á[* ÖÖ] * Á~cÁ	íGÁ	íGÁ	ÉGÁ
IíÁ	pæ ^ÁÚ^* ä c!Á	íGÁ	íGÁ	ÉGÁ
IJÁ	Ö: ^æ/Ö[~] ÁÚ[[{ Á	íGÁ	íGÁ	ÉGÁ
		527 + Conf. Room #		
íÉÁ	Ö^ ^c/Ö[~] ÁÚ[[{ Á	íGÁ	íGÁ	ÉGÁ
		528 + Conf. Room #		
íFÁ	Y æ ^ÁÚ] ÁÚ^* ä c!Á	íGJÁ	íGJÁ	ÉGJÁ
		529 + HH:MM		
íGÁ	Y æ ^ÁÚ] ÖÖæ & Á	íHEÁ	íHEÁ	ÉHEÁ
íHÁ	V{] [æ ä ÖUÜÖ[, }Á	íHFÁ	íHFÁ	ÉHFÁ

No	Feature Name	NUM SET 4	NUM SET 5	NUM SET 6
54	Cancel Temp COS Down	532	532	*532
55	Password Change	533	533	*533
56	Inter-Phone Group Access	534	534	*534
57	Call Wait Request	535	535	*535
58	Preselected MSG PGM	536	536	*536
59	Forced Handsfree Call	537	537	*537
60	Call Based CLIR	582	582	*582
61	CLIR Access	583	583	*583
62	COLR Access	584	584	*584
63	Pilot Hunt Call	585	585	*585
64	Command Call Oneway	581	581	*581
65	Command Call Conf	580	580	*580
66	Intrude Register	589	589	*589
67	Camp On Register	590	590	*590
68	OHVO Register	591	591	*591
69	Mobile Num Register	592	592	*592
70	Mobile CLI Register	593	593	*593
71	Mobile Access	594	594	*594
72	CCR Access	670	670	*670
73	CCR Access And Drop	671	671	*671
74	System Hold	560	560	*560
75	Return Held CO	8**	8**	*8**
76	Sys Memo	675	675	*675
77	DISA Tone Service	678	678	*678
78	All Feature Cancel	679	679	*679
79	Add Conf Member	680	680	*680
80	System Alarm Reset	565	565	*565
81	Fault Alarm Reset	564	564	*564
82	Door Open	#*1	#*1	#*1
83	Keypad Facility	##*	##*	##*
84	T-Net Log-In/Out	586	586	*586

No	Feature Name	NUM SET 4	NUM SET 5	NUM SET 6
ÌÍÁ	W, ǎ, ʌ, •, ǎ, ǎ, •, ʌ, ʌ	íîïá	ìïîá	éïíá
ÏÏÁ	Ö, ʌ, ʌ, ǎ, ǎ, ǎ, ʌ, ʌ	îïfá	ïïfá	ëïíá
ÏÏÁ	X, T, ʌ, ǎ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	îïgá	ïïgá	ëïíá
ÏÏÁ	Ö, ǎ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	îïhá	ïïhá	ëïíá
JÉÁ	Š, [], Š, ʌ, ʌ	íîíá	ìïíá	éïíá
JFÁ	Ô, ǎ, [], Š, ʌ, ʌ	îïíá	ïïíá	ëïíá
JG	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	íëë	ìëë	éëë
JH	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	íëf	ìëf	éëf
JI	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	íëg	ìëg	éëg
JÍ	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	íëh	ìëh	éëh
JÎ	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	íë	ìë	éë
JÏ	P, U, P, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	íëj	ìëj	éëj
JJ	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjë	ïjë	èjë
Fëë	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjf	ïjf	èjf
Fëf	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjg	ïjg	èjg
Fëg	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjí	ïjí	èjí
Fëh	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjî	ïjî	èjî
Fëi	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjï	ïjï	èjï
Féí	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjì	ïjì	èjì
Féí	Ö, Ö, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ìjj	ïjj	èjj
Féí	Ö, ǎ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ, ʌ	ífh	éfh	ífh

FIXED FUNCTION/USER PROGRAM CODES

Fixed Function Codes in the two tables that follow, are digit sequences users and the Attendant may dial while in the USER PROGRAM MODE.

STATION USER PROGRAM FIXED FUNCTION CODES

USER PGM CODE	DESCRIPTION	REMARK
11	Intercom Answer Mode	1:H, 2:T, 3:P
12 + Name	User Name Creation	2 digits for each character
13 + Time	Set Wake-up Alarm Time	HH/MM, 24-hour clock
14	Cancel Wake-up Alarm	
15	Set Display Language	00-14
16	LCD Date Mode Change	DD/MM/YY or MMDDYY
17	LCD Time Mode Change	12 Hour/24 Hour
18	Set Backlight	0-2
21	ICM Ring Type	
22	Trunk Ring Type	
23	Ring Download	23 is BGM on digital phones & Ring Download on IP phones.
24	Back Ground Music	
31	Temporary COS	Auth. Code required
32	Retrieve COS	Auth. Code required
33	COS Override (Walking COS)	Auth. Code required
34	Register Password	
35	Call Log Protect	
36	SMS Message Protect	IP-Series/LDP6000-Series
41 + MSG number [xx]	Set Pre-Defined Message.	0-9, MBX IP *: User Custom # Deactivation
42	Create a Station User Message	
43	Send SMS Message	IP Series/LDP6000 Series
44	Receive SMS Message	IP Series/LDP6000 Series

USER PGM CODE	DESCRIPTION	REMARK
Í FÉÁ	T [àá^ÁÚ@ } ^ÁBÇāæā } }	ÝMFÈG
Í GÉÁ	T [àá^ÁÚ@ } ^ÁÚ^* ā dæā } }	ÝMFÈG
Í HÉÁ	T [àá^ÁÚ@ } ^ÁÚ^* ā dæā } }	ÝMFÈG
Í Í ÁÉÚ { Á B Á C E Ϟ ϙ [á ^	Ô [] - Á Ú [[{ Á Ú ç c	
Í Î ÁÉÚ { Á B Á C E Ϟ ϙ [á ^	Ô [] - Á Ú [[{ Á Ô [] • ^	
Í F	Ù] ^ à á ^ ! Á P ^ à á • ^ c Á [á ^	Ù] ^ à á ^ ! Á P ^ à á • ^ c Á [á ^
Í G	P ^ à á • ^ c Á Ú ā * Á T [á ^	Ù] ^ à á ^ ! Á P ^ à á • ^ c Á [á ^
Ï F	Û ^ * ā c ! Á Ú ç c } Á Ô Š Ő	
Ï G	X ā , Á Ú ç c } Á Ô Š Ő	
Ì F	X ā , Á Ú Á C E á ! • • Á	Ù Á Ú @ } ^ Á Ô V C Á Á Ú Š T
Ì G	X ā , Á T ç c Á C E á ! • •	Ù Á Ú @ } ^ Á Ô V C Á Á Ú Š T
Ì H	X ā , Á Ú Á Ú @ } ^ Á Á ^ ! • ā }	
Ì €	Ɔ ^ c [! Á Ú ç c *	Ù Á Ú ! ā •
JF	Û • c { Á Á ^ ! • ā }	
JG	Û • c { Á Ú Á C E á ! • •	

ATTENDANT USER PROGRAM FIXED FUNCTION CODES

USER PGM CODE	ITEM DESCRIPTION	REMARK
01 SMDR		
€ F	Û Ú @ V Á Ú V C E / W P Á Ú T Ö Ü	Ù ç c } Á Ú ā * ^
€ G	Ö Ö Š Ö V Ö Á Ú V C E / W P Á Ú T Ö Ü	Ù ç c } Á Ú ā * ^
€ H	Û Ú @ V Á C E Š Ö Ö Á C E Š Á Ú T Ö Ü	
€ I	Ö Ö Š Ö V Ö Á C E Š Ö Ö Á C E Š Á Ú T Ö Ü	
€ Í	Ö Ö Š Ö V Ö Á C E Š Á Ú T Ö Ü	
€ Î	œ Ú Ü V Á Ú @ V C E Ö	
02 TRAFFIC		
€ F	Û Ú @ V Á Ú C E Š Ö Ö Á Ú V C E V D	

USER PGM CODE	ITEM DESCRIPTION	REMARK
022	PRINT TRAFFIC (CALL TYPE)	
023	PRINT TRAFFIC (CO GRP)	
03 COS / PASSWORD		
031	TEMPORARY COS MODE	Station Range
032	RETRIEVE COS	Station Range
033	REGISTER PASSWORD	Station Range
034	CALL LOG PROTECT	Station Range
04 DATE / TIME		
041	SET SYSTEM DATE	
042	SET SYSTEM TIME	
043	LCD DATE MODE	Station Range
044	LCD TIME MODE	Station Range
045	SET WAKE UP	Station Range
046	RESET WAKE UP	Station Range
05 MULTI MESSAGE		
051	PRESELECTED MESSAGE	Station Range, MSG No
052	SET USER MESSAGE	Station Range
06 VMIB ANNOUNCEMENT		
061	LISTEN VM ANNOUCEMENT	
062	RECORD VM ANNOUCEMENT	
07 USER PROGRAM		
071	STATION NAME	Station Range
072	LANGUAGE PROGRAM	Station Range
073	PREPAID CALL	Station Range

USER PGM CODE	ITEM DESCRIPTION	REMARK
€ I	ΣΥΣΤΗΜΑ ΠΡΟΝΟΜΙΩΝ ΟΥΔΕΡΩΝ	Υποστήρικται *
08 SYSTEM		
€ F	ΣΥΣΤΗΜΑ ΠΡΟΝΟΜΙΩΝ ΟΥΔΕΡΩΝ	
€ G	TYPQUUÁOUPΘÁUUT	
€ H	ØÜÔÒÖÁÒŠÒNÒÁOUPΘÁUUT	
€ I	ÚÚÚÁOUPΠÒNOMΠ	Ü^*ãç!^áÁ!ç!P~{ à!
09 USB		
€ JF	ÙUØVY ÆÏÒÁMÚÖÜÆÒ	
€ JG	ÖÓÁOUY PŠUÆÁUÁMÓ	
€ JH	ÖÓÁMÚŠUÆÁUÁMÓ	
€ JI	XT ØÁ ÜÖÁOUY PŠUÆ	
0# WTU SUBSCRIBE		

DEFAULT VALUES

The following Tables are divided based on PROGRAM groups and provide the default values assigned to all Admin entries. Prior to changing an entry during programming assure you have an understanding of the PROGRAM and its purpose.

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
PRE-PROGRAMMED DATA					
PRE-PROGRAMMED DATA	A-8	100	-	-	-
Nation Code			1	-	1 - max 4 digits
Site Name			2	-	max 24 chars
SLOT ASSIGNMENT	A-11	101	-	-	-
Slot			1	-	2 digits
DEVS			2	-	2 digits
LOGICAL SLOT ASSIGN	A-11	103	-	-	-
COL			1	-	-
STA			2	-	-
VMIB			3	-	-
DECT/IP/SIP Max Port	A-12	104	-	-	-
Max No of DECT			1	-	8 (000-192)
Max No of IP Phone			2	-	32 (000-324)
Max No of SIP Phone			3	-	32 (999-324)
IP-PHONE/PHONTAGE REG.	A-12	106	-	-	-
MAC Address			1	-	-
User ID			2	-	-
User Password			3	-	-
Station Number			4	-	-
IP Address			5	-	-
F/W IP Address			6	-	-
RTP Security			7	-	-

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
NUMBERING PLAN					
NUMBERING PLAN TYPE	A-15	110	-	-	-
Default Numbering Plan Type			-	-	1
SYSTEM NUMBERING PLAN	A-15	111	-	-	-
Prefix Code			1	Sys No. Plan Index 001 to 150	Flex01 - 1 Flex02 - 2 Flex03 - 3 Flex04 - 4
Prefix Code			1	Sys No. Plan Index 001 to 150	Flex05 - 5 Flex06 - 6 Flex07 - 7 Flex08 - 8 Flex09 - 9 Flex10 - 0 Flex11 - * Flex12 - #
Additional Digits			2	Sys No. Plan Index 001 to 150	Flex01 - 2 Flex02 - 2 Flex03 - 2 Flex04 - 2 Flex05 - 2 Flex06 - 2 Flex07 - 0 Flex08 - 2 Flex09 - 0 Flex10 - 0 Flex11 - 1 Flex12 - 2

PROGRAM GROUP	ÚŮÄ	ÚŮT Á ÖVÞ	ÜÖÞ ÖÖ	ÖÖZÖVŠVÁ	
ÞWT ÖÖÜÖ ÖÁÚŠÖÞ					
ÖŠÖÝÖŠÖÁÚVÖÞÖÞÁÞWT ÖÖÜ	ÖËÍ	FFG	Ë	Ë	
Ö^Öä Ö^ÁÜöä } Á^ { à^:			Ë	Ö^æ ö^ ÖÜ ö^ ÁÖ [~] d^ Á Ö ä^/	Ë Ë Ì H
ÖÖÖVÜÖÖÞWT ÖÖÜÖ ÖÁÚŠÖÞ	ÖËÍ	FFH	Ë	Ë	
Öö } äö öÖö			F	Ë	€
Ö [] -^ ^ } & ÁÜ [[{ /			G	Ë	í ï F
Ö [] -^ ^ } & ÁÜ [[{ ÁG			H	Ë	í ï G
Ö [] -^ ^ } & ÁÜ [[{ ÁH			I	Ë	í ï H
Ö [] -^ ^ } & ÁÜ [[{ Á			Í	Ë	í ï I
Ö [] -^ ^ } & ÁÜ [[{ Á			î	Ë	í ï í
Ö [] -^ ^ } & ÁÜ [[{ Á			ï	Ë	í ï î
Ö [] -^ ^ } & ÁÜ [[{ Á			ì	Ë	í ï ì
Ö [] -^ ^ } & ÁÜ [[{ Á			J	Ë	í ï j
Ö [] -^ ^ } & ÁÜ [[{ Á			F€	Ë	í ï J
Öö } öö öö			FF	Ë	í ï H
Ö^ • [] ööKT ÁÜö ^			FG	Ë	í ï I
Öö } [~] & { ^ } öö öö ^ ÁÜ ÁÜö } äö c			FH	Ë	í ï í
Öö ^ ÁÜ ö ö öö , ^			FI	Ë	í ï î
Öö } öö öö ^ ÁÜö , ^ ÁÜ ^ öö ^ ÁÜö ^ D			FÍ	Ë	í ï ï
Ööö } öö öö ^			Fî	Ë	í ï ì
Öö } öö öö } öö öö ^ ÁÜö			Fï	Ë	í ï J
Öö ÁÜ , öö ÁÜ ^* öö			Fì	Ë	í ï I
Öö öö } öö öö , öö ÁÜ ^* öö			FJ	Ë	í ï FI
Öö öö } öö öö , öö öö & ^	G€	Ë	í ï Fí		
Öö Öö öö • ÁÜö * ^	GF	Ë	í ï Fî		
Öö Öö Öö ^ öö	GG	Ë	í ï Fï		
Öö & [~] öö ä ^	GH	Ë	í ï €		
Öö ÁÜö @	G	Ë	í ï F		
Šö öö { à^ ÁÜ ^ äö	Gí	Ë	í ï G		

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
NUMBERING PLAN					
Station Speed PGM	A-17	113	26	-	553
Speed Dial			27	-	555
MWI Register			28	-	557
MWI Answer			29	-	558
MWI Cancel			30	-	559
Call Back Register			31	-	518
Call Back Cancel			32	-	519
Group Call Pickup			33	-	564
Direct Call Pickup			34	-	7
Walking COS			35	-	520
Call Parking Location			36	-	541
PGM Mode Access			37	-	521
Two-Way Record			38	-	522
VMIB Access			39	-	523
AME Access			40	-	524
CO Line Access			41	-	888
VM MWI Enable			42	-	*8
VM MWI Cancel			43	-	*9
MCID Request			44	-	*0
Unsupervised Conf Extend			45	-	5##
PTT Group Access			46	-	524
Hot Desk Log In/Log Out			47	-	525
Name Register			48	-	526
Create Conf Room			49	-	527
Delete Conf Room			50	-	528
Wake Up Register			51	-	529
Wake Up Cancel			52	-	530
Temporarily COS Down			53	-	531

PROGRAM GROUP	ÚŮÄ	ÚŮT Á ÖVP	ÜŮĚ ÖÒ	ÖÖZÖBŠVÁ	
PWT ÖÖÜŮÖÁÜŠŮĚ					
Ůæ & \ Á \ {] Á Ö Ü Ü Ö [, } Úæ•, [! á Á Ö æ ^ ^ Ůæ ! Ě Ů @ ^ Á Ö ! [~] Á Ö & ^ •• Ůæ \ Á \ æ Á Ů ^ ~ ^ • c Ú ! ^ • ^ \ ^ & ç á Á Ů Ü Ö T Ů ! & á Á P æ á • † ^ Á Ö æ Ůæ \ Á Ö æ ^ á Á Ö Š Ů Ů Š Ů Á Ö & ^ •• Ů Ü Š Ů Á Ö & ^ •• Ú æ \ Ů P ^ } Ů Ö æ Ů [{ { æ á Á Ö æ \ Á } ^ , æ Ů [{ { æ á Á Ö æ \ Á Ö [] ~ Ů ç ^ á Á Ů ^ * á ç ! Ů æ] Á } Á Ů ^ * á ç ! Ü P X Ü Á Ů ^ * á ç ! T [á æ \ Á ^ ~ { Á Ů ^ * á ç ! T [á æ \ Á Ö Š Ů ^ * á ç ! T [á æ \ Á Ö & ^ •• Ů } [~] & \ ^ } Ů æ \ ^ Ů } [~] & \ ^ } Ů æ \ ^ æ á Ö ! [] Ů • ç \ Á P [! á Ů ^ ç ! } Á ^ \ á Á Ö Ü Ů • Á ^ { [] Ů Ů Ě Á [] ^ Á Ů ! ç æ Ů \ Á Ů æ ! ^ Á Ö æ & \ Ů á Á Ö [] - Á ^ { á ! Ů • ç \ Á Ů æ { Á Ů ^ • c Ů æ \ Ů Ů æ { Á Ů ^ • c	ŮĚİ	FFH	í I	Ě	í HG
			í I	Ě	í HH
			í İ	Ě	í H
			í İ	Ě	í H
			í İ	Ě	í H
			í J	Ě	í H
			í Ě	Ě	í Ě
			í F	Ě	í Ě
			í G	Ě	í İ
			í H	Ě	í İ
			í I	Ě	í F
			í İ	Ě	í Ě
			í İ	Ě	í J
			í İ	Ě	í Ě
			í J	Ě	í JG
			í Ě	Ě	í JH
			í F	Ě	í JI
			í G	Ě	í Ě
			í H	Ě	í F
			í I	Ě	í Ě
			í İ	Ě	í Ě
			í İ	Ě	í İ
			í İ	Ě	í J
			í J	Ě	í Ě
			í Ě	Ě	í İ
			í F	Ě	í İ

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
NUMBERING PLAN					
Door Open	A-17	113	82	-	#*1
Keypad Facility			83	-	##*
T-Net Log-In/Out			84	-	586
Universal Answer			85	-	587
Delete All VM Message			87	-	681
VM Page Message Record			88	-	682
Direct VM Transfer			89	-	683
Loop Key			90	-	684
Call Log			91	-	685
ACD Agent Log-In/Out			92	-	500
ACD Agent DND			93	-	501
ACD Agent Word Mode			94	-	502
ACD Agent Auto Work			95	-	503
ACD Agent Auto Answer			96	-	504
ACD Call Indication			97	-	508
Non-ACD Call Indication			98	-	509
ACD Supervisor Group Forward			99	-	890
ACD Supervisor Night			100	-	891
ACD Supervisor Holiday			101	-	892
ACD Supervisor Queued Call Answer			102	-	893
ACD Supervisor Agent State Check			103	-	894
ACD Supervisor Silent Monitor			104	-	895
ACD Supervisor Call Traffic Check			105	-	896
ACD Announcement Play & Check			106	-	899
Day/Night/Timed Mode Change			107	-	513
DID/DISA Restriction			108	-	685

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
STATION PORT DATA					
STATION PORT ATTRIBUTES II	A-25	122	-	-	-
LCD Language Display mode			1	00: English 01: Italian 02: Finnish 03: Dutch 04: Swedish 05: Danish 06: Norwegian 07: Hebrew 08: Germany 09: French 10: Portuguese 11: Spanish 12: Korean 13: Estonian	English - - - - - - - - - - - -
LCD Language Display Mode			1	14: Russian	English
LCD Date Display Mode			2	1: MMDDYY 0: DDMMYY	DDMMYY
LCD Time Display Mode			3	1: 24 Hour Mode 0: 12 Hour Mode	12 Hour Mode
Backlight Usage			4	0: Always Off 1: Busy Only 2: Always On	Busy Only
IP-8000 Phone Font			5	0: Times New Roman 1: Gothic	Times New Roman
IP-8000 Phone LCD Brightness			6	01-15	07
Group Queue Display			7	1: On, 0: Off	Off

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
STATION PORT DATA					
Off-Hook On Paged	A-27	124	7	0: Paged 1: Dial Tone	Paged
Preferred Line Answer			8	1: ON, 0: OFF	ON
Pick-Up By DSS Button			9	0: Disable 1: Group Pick-Up 2: Direct Pick-Up	Direct Pick-Up
CTI IP Address			10	0.0.0.0	0.0.0.0
FLEXIBLE BUTTON ASSIGNMENT					
Button Type	A-29	126	-	-	-
			1	Not Assigned	-
				Station DSS	-
				CO Number	-
				Loop Key	-
				CO Group Access	-
				Sta Grp Number	-
				Dial Number	-
				Directory Number	-
				Redial	-
Button Type	1	1	Speed	-	
			Conference	-	
			Mute	-	
			Call Back	-	
			DND/FWD	-	
			Transfer	-	
			Flash	-	
			PTT	-	
Ring Option (Button Type DirectoryNo.)	2	Immediate Ring Delay Ring 1-9 No Ring	-		

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
STATION NUMBER DATA					
DND Access	A-31	132	4	EN/DIS	Enable
Intrusion Access			5	EN/DIS	Disable
Mobile Extension Access			6	EN/DIS	Enable
Hook Flash Mode			7	0: Flash Normal 1: Flash Ignore 2: Flash Drop 3: Hold Release	Flash Normal
Auto Pick-Up			8	EN/DIS	Disable
STATION DN ATTRIBUTES III	A-31	133			
CO Queue Access			1	EN/DIS	Enable
Conference Access			2	EN/DIS	Enable
Wake-Up Access			3	EN/DIS	Enable
Station Call Back Access			4	EN/DIS	Enable
ACNR Access			5	EN/DIS	Enable
Absence Notice Access			6	EN/DIS	Enable
Call Wait Access			7	EN/DIS	Enable
Camp-On Access			8	EN/DIS	Enable
Voice Over Access			9	EN/DIS	Disable
Prepaid Call Access			10	EN/DIS	Disable
Keypad Facility Usage			11	EN/DIS	Disable
STATION DN ATTRIBUTES IV	A-31	134			
Speed Access			1	EN/DIS	Enable
Page Access			2	EN/DIS	Enable
Meet-Me Page Access	A-31	134	3	EN/DIS	Enable
CO Call Duration Restrict			4	EN/DIS	Disable
SLT Block Back Call			5	EN/DIS	Disable
Pilot Hunt Ring			6	EN/DIS	Enable
ACR User			7	1: On, 0: Off	Off
Wake-Up Time			8	-	-

PROGRAM GROUP	ÚŌÄ	ÚŌT Á ÓVÞ	ÚŌÞ ÖŌ	ÖÖZÖVŠVÁ
ÚVŌVŌÞ Á Þ WT ÖŌÚ Á ÖŌVŌE				
Ü^] ^æÁ æ ^ËM	ŌËF	FH	J FkU } ÊÆÁÜ ~	U ~
Ó:æ &ŌŠá ^ ÁŌ:ã * ^ Šá ^ ÁT [à^			F€ €ÁÜ ~ FkÓ:æ &@ GkÓ:ã * ^ HkÓ:ã * ^ Ë [-q @] ^	U ~
ŌE q ÁÜ! q:æ			FF FkU } ÊÆÁÜ ~	U ~
ÚVŌVŌÞ Á Þ ÖŌVŌWŌÙ ÁK	ŌËF	FHÍ		
ÔŠŌÁŌã] æ			F Ò; Ëã	Ò; æã ^
ÔUŠÚÁŌã] æ			G Ò; Ëã	Ò; æã ^
ÔŠŌÁ ^ áã ^ &c			H ÔŠŌÁ ^ áã ^ &c	ÔŠQ
ÔŠŌÁ @ } ÁÜ * c [q *			I Ò; Ëã	Ôã æã ^
ÔUŠÚÁ @ } ÁÜ { q * ÁÜ • , ^!			Í Ò; Ëã	Ôã æã ^
ÔŠŌÁ ~ { à^!			Î Ë	Ë
ÔæÁÜ !, æá ÔŠŌÁ ^ áã ^ &c			Ï ÔŠŌÁ ^ áã ^ &c	ÔŠQ
Q] [! ^ ÁÜ ! q ÁŌŠŌÁÜ q }			Ì Ò; Ëã	Ôã æã ^
T [àã ÁŌc } • q } ÁŌŠQ			J ÔæÁÜ ÁÜ ~ { à^! T [àã ÁÜ ~ { à^! ÔæÁÜ ÁÜ [àã ^	ÔæÁÜ ÁÜ ~ { à^!
Š] * ÁŌŠÁ			F€ Ë	Ë
Š] * ÁŌŠG			FF Ë	Ë
Š] * ÁŌŠH			FG Ë	Ë
ÔŠŌÁ æ ^ ÁŌã] æ			FH Ò; Ëã	Ôã æã ^
COS ASSIGNMENT	ŌËF	FHÍ	Ë Ë	Ë
Ōæ ÁÜÙ			F Ë	Ë
Þá @ ÁÜÙ			G Ë	Ë
Vá ^ á ÁÜÙ	ŌËI		H Ë	Ë
AUTO DIAL ATTRIBUTE	ŌËI	FHÍ	Ë Ë	Ë
ŌE q ÁÜ ÁÜ á			F Ë	Ë
ŌE q ÁÜ ÁÜ æ • ^ ÁÜ ^			G €ËËÁÜ • ^ &D	€€

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
STATION NUMBER DATA					
PRESET CALL FORWARD	A-39	142	-	-	-
Internal Unconditional			1	-	-
Internal Busy			2	-	-
Internal No-Answer			3	-	-
External Unconditional			4	-	-
External Busy			5	-	-
External No-Answer			6	-	-
CALL FORWARD	A-40	143	-	-	-
Forward Type			1	Not Assigned Unconditional Busy No-Answer Busy / No-Answer	Not Assigned
Forward Number			2	-	-
Forward Apply Time			3	0: All 1: Day 2: Night 3: Timed	All
Call-Forward No-Answer Timer			4	000-600	15
Forward Information Display			5	1: On, 0: Off	On
VMIB ATTRIBUTE	A-40	145	-	-	-
VMIB Access			1	En/DIS	Disable
Prompt Language Index			2	1: First 2: Second 3: Third	First
Auto-Record Service			3	En/Dis	Disable
Two-Way Record Access			4	En/Dis	Disable
Two-Way Recording Destination			5	-	-
VM Message Backup Phontage Number			6	-	-
VM Message Backup Delete			7	En/Dis	Disable

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
CO LINE ATTRIBUTES I	A-45	160			
CO Line Type			1		
Service Type			2	0: Normal 1: DID	Normal
Outgoing Group Number			3	01-72	01
Incoming Group Number			4	01-72	01
Tenant Number			5	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
Digit Conversion Table			6	1-9	1
Signal Type			7	0: No Signal 1: Send Wink 2: Wait Seize Ack 3: Send Wink & Wait Seize Ack 4: Send Sub Answer & Wait Sub Answer 5: Send Wink & Send Sub Ans 6: Wait Ack & Wait Sub Answer 7: Send Wink and Sub Answer & Wait Wink and Sub Ans	No Signal
Release Timing			8	0: First Release 1: Caller Release 2: Called Release	First Release
Incoming/Outgoing Mode			9	0: Incoming 1: Outgoing 2: Both	Both
Dialing Type			10	0: DTMF 1: Pulse 2: R2	DTMF
Charge Mode			11	0: Free 1: Report	Report

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
CO LINE ATTRIBUTES III	A-47	162			
CO Access Mode			1	0: Blocked Line 1: Normal CO Line 2: Dedicated Line	Normal CO Line
Digit Sending Mode			2	Overlap Enblock	Overlap
Max Digit Length			3	00-32	32
Min Digit Length for Overlap Mode			4	00-32	00
Check Password			5	1: On, 0: Off	Off
R2 Connect Mode			6	0: End-to-End 1: Link-by-Link	End-to-End
R2MFC Backward Value			7	01-15	01
Dummy Dial Tone Service			8	1: On, 0: Off	Off
CO LINE ATTRIBUTES IV	A-48	163			
CID Mode			1	0: Disable 1: FSK 2: DTAS FSK 3: DTMF 4: Russia-CID	Disable
Russia CID Detect			2	1: All / 0: Local	All
Russia CID Request			3	1: Auto / 0: User	Auto
Russia CID Digit Number			4	04-10	7
Russia CID No-Answer Timer			5	001-300 (1sec)	20
Russia CID Request Count			6	1-3	1
Russia CID Request First Delay Timer			7	010-150 (10msec)	030
Russia CID Request Retry Delay Timer			8	10-30 (10msec)	10

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
Block After Clear Forward Waiting Time	A-50	166	4	1: On, 0: Off	Off
CPT Detect			5	1: On, 0: Off	On
Answer to Waiting Call			6	1: On, 0: Off	Off
Universal Answer			7	1: On, 0: Off	Off
Release Guard Time			8	00-15 (1sec)	1
Unsupervised Conference Timer			9	000-255 (1min)	0
Clear Forward Waiting Timer			10	001-300 (1sec)	300
Max Ring Time			11	015-300 (1sec)	120
DISA Supervision Timer			12	1-9 (1sec)	2
VMIB Play Delay Timer			13	0-9 (1sec)	0
Incoming Time Table Index			14	None, 1-9	None
CO RING ASSIGNMENT	A-51	167	-	-	-
Day			1	Flex1 - Service Type 0: Ring Assign 1: Feature Code Flex2 - Feature Not Assigned CCR CCR Drop DISA Tone Digits Flex3 - Feature Delay Flex4 - Member Display Flex5 - Member Assign	Ring Assign Not Assigned Delay 0 Member 100

PROGRAM GROUP	ÚŮÄ	ÚŮT Á ÓVÞ	ÜCEÖÒ	ÖÖZÖVŠVÁ
ÖU/ŠÖ/ÖÖ/CE				
pã @	ŮĚ F	FĪ Ī	G Ø^cFÄÜ!cã^Á^] ^ €ÄÜ * ÄÖ • ä } FÄÜ^æ ^ÄÖ[ä^ Ø^cGÄÜ^æ ^Á Þ[öÖ • ä } ^ä ÔÖÜ ÔÖÜ/Ä: [] ÖWÖM [] ^ Öä ä Ø^cHÄÜ^æ ^ÄÖ æ Ø^cI ÄT ^{ ä^!/Öä æ Ø^cI ÄT ^{ ä^!/ÖÖ • ä }	Üä * ÄÖ • ä } Þ[öÖ • ä } ^ä Ö^ æ ÄE T ^{ ä^!/ÄEE
vã ^ä			H Ø^cFÄÜ!cã^Á^] ^ €ÄÜ * ÄÖ • ä } FÄÜ^æ ^ÄÖ[ä^ Ø^cGÄÜ^æ ^Á Þ[öÖ • ä } ^ä ÔÖÜ ÔÖÜ/Ä: [] ÖWÖM [] ^ Öä ä Ø^cHÄÜ^æ ^ÄÖ æ Ø^cI ÄT ^{ ä^!/Öä æ Ø^cI ÄT ^{ ä^!/ÖÖ • ä }	Üä * ÄÖ • ä } Þ[öÖ • ä } ^ä Ö^ æ ÄE T ^{ ä^!/ÄEE
ÞUÜT ÖŠÖÖ/ÖU/CE/VÜÖWÒÙ	ŮĚ G	FĪ Ī	Ě	Ě
Öäe			F Ø^cFÄÜ/ÖÜ/ÖB&••ÄÖ [{ Ä ÖWÖE FÄÜ } FÄÜ -- Ø^cGÄÜ/ÖWÖE/ÖB&••Ö [ä^ FÄÜ } FÄÜ -Ä Ø^cHÄÜ/ÖWÖE/Ä^ÄÖ [~ } c FÄÜ Ø^cI ÄÜ!^•^öÄ, äÄvã ^ €ÄCEÄF^•^&D Ø^cI ÄÜ!^•^öÄ, äÄÜä * Ä Vää ^Ä ä^c FÄÜ €	UØØ UØØ H €

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
Night	A-52	168	2	Flex1 - CO Access From DISA 1: On, 0: Off Flex2 - DISA Acct Code 1: On, 0: Off Flex3 - DISA Retry Count 1 - 9 Flex4 - Preset Fwd Time 0 - 20 (1sec) Flex5 - Preset Fwd Ring Table Index 1 - 80	OFF OFF 3 0
Timed			3	Flex1 - CO Access From DISA 1: On, 0: Off Flex2 - DISA Acct Code 1: On, 0: Off Flex3 - DISA Retry Count 1 - 9 Flex4 - Preset Fwd Time 0 - 20 (1sec) Flex5 - Preset Fwd Ring Table Index 1 - 80	OFF OFF 3 0

PROGRAM GROUP	ÚŮÄ	ÚŮT Á ÓVÞ	ÜŮP ÖÒ	ÖÖZÖVŠVÁ
ÖUŠÖÖÖÖVE				
ÖÖUT ÖÖÁÖUÁÖŠVÖÜPÖVÖÖ	ÖĚ H	F Ī J	Ě Ě	Ě
Öæ			F Ö^cFÄÖ^•^ Ö^cGÄP[ĚĚ • ^! Ö^cHÄKaeä öP { à^! Ö^cl ÄV:äĚ • Ä[ĚĚ • ^! Ö^cl ÄU^&äP[ĚĚ • ^! Ö^cl ÄÖPÖ Ö^cl ÄP äĚ • ä^öŠae ä Ö^cl ÄÖ: ! FĪÖä & } } ^&c GÄÖc^ ääĚ c HÖUÄĵä * ÄĚ • ä } I KÖŠVÄĵä * Ävää Í KÄ } ^ Ī KÄĵ[öP^ } öÖ: [~]	Öä & } } ^&c
pä @			G Ö^cFÄÖ^•^ Ö^cGÄP[ĚĚ • ^! Ö^cHÄKaeä öP { à^! Ö^cl ÄV:äĚ • Ä[ĚĚ • ^! Ö^cl ÄU^&äP[ĚĚ • ^! Ö^cl ÄÖPÖ Ö^cl ÄP äĚ • ä^öŠae ä Ö^cl ÄÖ: ! FĪÖä & } } ^&c GÄÖc^ ääĚ c HÖUÄĵä * ÄĚ • ä } I KÖŠVÄĵä * Ävää Í KÄ } ^ Ī KÄĵ[öP^ } öÖ: [~]	Öä & } } ^&c

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
Timed	A-53	169	3	Flex1 - Busy Flex2 - No-Answer Flex3 - Vacant Number Flex4 - Trans No-Answer Flex5 - Recall No-Answer Flex6 - DND Flex7 - Handset Lifted Flex8 - Error 1: Disconnect 2: Attendant 3: CO Ring Assign 4: ALT Ring Table 5: Tone 6: Pilot Hunt Group	Disconnect
OUTGOING CO ATTRIBUTES I	A-54	170	-	-	-
ISDN Screen Indicator			1	User Provided, Not Screened User Provided, Verified and Passed	User Provided, Not Screened
Sending Caller Number			2	1: On, 0: Off	On
Calling Type			3	0: Unknown 1: International 2: National 3: Subscriber 4: Not Used	National
Calling No. Plan Identification			4	0: Unknown 1: ISDN Telephony No. Plan 2: Data 3: Telex 4: National Standard 5: Private	Unknown

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
OUTGOING CO ATTRIBUTES II	A-57	171	-	-	-
CPT Detect			1	1: On, 0: Off	On
Unsupervised Conference Extend			2	1: On, 0: Off	Off
Provide Ring-Back Tone			3	1: On, 0: Off	Off
BLF Usage			4	1: On, 0: Off	On
Release Guard Timer			5	00-15 (1sec)	2
Unsupervised Conference Timer			6	000-255 (1min)	0
Max Transfer Ring Timer			7	001-300 (sec)	120
Outgoing Time Table Index			8	None, 1-9	None
OUTGOING CO ALTERNATIVE	A-57	173	-	-	-
Day			1	Flex1 - Recall No-Answer Flex2 - Transfer No-Ans Flex3 - No-Answer 1: Disconnect 2: Attendant 3: CO Ring Assign 4: ALT Ring Table 5: Tone 6: Pilot Hunt Group	Disconnect
Night			2	Flex1 - Recall No-Answer Flex2 - Transfer No-Ans Flex3 - No-Answer 1: Disconnect 2: Attendant 3: CO Ring Assign 4: ALT Ring Table 5: Tone 6: Pilot Hunt Group	Disconnect

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
CO LINE DATA					
CO-TO-CO ATTRIBUTES	A-60	179	-	-	-
Station Outgoing Call Transfer			1	EN/DIS	Enable
Attendant Outgoing Call Transfer			2	EN/DIS	Enable
Outgoing Transfer Release Type			3	0: None 1: Release After Time	None
Outgoing Transfer Release Time			4	000-300	60
Incoming Call Transfer Directly			5	EN/DIS	Disable
Station Incoming Call Transfer			6	EN/DIS	Enable
Attendant Incoming Call Transfer			7	EN/DIS	Enable
Incoming Transfer Release Type			8	0: None 1: Release After Time	None
Incoming Transfer Release Time			9	000-300 (1sec)	60
CO GROUP ACCESS CODE	A-61	180	--	-	-
Access Code Name			1		
CO Line choice			2	0: Round Robin 1: Last Line 2: First Line	Round Robin
Outgoing Group Number			3	01-72	
AND Digit			4		
ARS Service			5	1: On, 0: Off	Off
ARS Digit 1			6		
ARS Digit 2			7		
ALTERNATIVE RING TABLE	A-63	181	-	-	-
Service Type			1	0: Ring Assign 1: Feature	Ring Assign
CO Ring Assign			2		

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
STATION GROUP DATA					
Greeting Repeat Count	A-65	201	5	000-100	3
Greeting Repeat Delay Timer			6	000-100 (1sec)	0
Queuing Tone Type			7	0: Normal 1: Prompt 2: Announcement 3: Internal MOH 4: External MOH	Internal MOH
Greeting/Queuing Timeout Timer			8	000-300 (1sec)	30
Queuing Tone Number			9	01-19	
Queuing Prompt/Announcement Table No.			10		
Queuing Repeat Count			11	000-100	3
Queuing Repeat Delay Timer			12	000-100 (1sec)	0
STATION GROUP ATTRIBUTES II	A-68	202			
Call-In Greeting			1	0: After Greeting 1: In Greeting	
Max Queue Count			2	00-99	
Forward Type			3	0: Not Used 1: Unconditional 2: Queuing Overflow 3: Time Out 4: Queuing Overflow / Time Out	Not Used
Apply Time Type			4	0: All 1: Day 2: Night 3: Timed	All
Forward Destination			5		
Wrap-Up Timer			6	000-600 (100msec)	10
Member No-Answer Timer			7	50-600 (100msec)	150
VOICE MAIL GROUP	A-69	203			
Put Mail Index			1	1-9	1
Get Mail Index			2	1-9	2

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
STATION GROUP DATA					
Digit '5' Service	A-73	209	1	Station	
Digit '6' Service				Station	
Digit '7' Service				Station	
Digit '8' Service				Station	
Digit '9' Service				Station	
PILOT HUNT GROUP I	A-74	210	-	-	-
Pilot Hunt Call Service			1	0: All Call 1: Intercom Call 2: External Call	All Call
Service Type			2	0: Terminal 1: Circular	Circular
Time Table Index			3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
Pilot Hunt Member Assignment			4		
PILOT HUNT GROUP II	A-75	211	-	-	-
Day Forward Type			1	0: Not Used 1: Unconditional 2: Busy 3: No-Answer 4: Busy/No-Answer	Not Used
Day Forward Destination			2		
Night Forward Type			3	0: Not Used 1: Unconditional 2: Busy 3: No-Answer 4: Busy/No-Answer	Not Used
Night Forward Destination			4		

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
Message Wait Alert Tone Timer	A-84	222	2	0-60 (1min)	0
Inter-Digit Timer			3	0-300 (1sec)	15
Incoming CO Inter-Digit Timer			4	1-60 (1sec)	15
SYSTEM ATTRIBUTES	A-85	223	-	-	-
Web Admin Password Encryption			1	1: On, 0: Off	Off
Pulse Dial Break/Make Ratio			2	0: 60/40 1: 66/33 2: 50/50	60/40
Voice Mail SMDI Interface			3	1: On, 0: Off	Off
VMIB SMTP Port			4	0000-9999	25
Network Time/Date			5	0: Disable 1: ISND Clock 2: NTP	Disable
CLI Print			6	1: On, 0: Off	Off
TLS for Web			7	1: On, 0: Off	Off
Web Server Port			8	00001-65535	80
Database Auto USB Download			9	1: On, 0: Off	Off
Database Auto USB Download Hour			10	00-23	0
UC Server IP Address			11	IP Addr	0.0.0.0
CTI Server IP Address			12	IP Addr	0.0.0.0
Modem Associated CO Line			13	CO Number	0
IP Phone Registration by STA Number			14	1: On, 0: Off	Off
Analog Line Busy Tone Detection Times			15	3-9	
Analog Line Error Tone Detection Times			16	3-9	
PSU Fan Alarm	17	1: On, 0: Off	On		
Line Fault Alarm	18	1: On, 0: Off	On		
Traffic Operation	19	1: On, 0: Off	Off		
Enhanced VM Features	20	1: On, 0: Off	On		
SYSTEM PASSWORD	A-86	226	-	-	-

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
Internal Music Type	A-88	229	2	Romance Turkish March Green Sleeves Fur Elise Carmen Waltz Pavane Sichiliano Sonata Spring Campanella Badinerie Blue Danube	Romance
VMIB MOH 1 Assignment			3	Announcement	
VMIB MOH 2 Assignment			4	Announcement	
VMIB MOH 3 Assignment			5	Announcement	
VMIB MOH 4 Assignment			6	Announcement	
SLT MOH 1 Assignment			7	Station	
SLT MOH 2 Assignment			8	Station	
SLT MOH 3 Assignment			9	Station	
SLT MOH 4 Assignment			10	Station	
SLT MOH 5 Assignment			11	Station	
RS-232 SETTING	A-89	230			
Baud Rate			1	1: 9600 Baud 2: 19200 Baud 3: 38400 Baud 4: 57600 Baud 5:115200 Baud	115200 Baud
Page Break			2	1: On, 0: Off	Off
Line Per Page			3	001-199	66
XON / XOFF			4	0: XOFF 1: XON	XOFF

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
Trace Print	A-90	231	6	0: Serial Port 1: Modu Port 2: TCP 1 3: TCP 2 4: TCP 3 5: TCP 4 6: TCP 5	Serial Port
ADMIN Data Print			7	0: Serial Port 1: Modu Port 2: TCP 1 3: TCP 2 4: TCP 3 5: TCP 4 6: TCP 5	Serial Port
SMDR ATTRIBUTES	A-91	232			
SMDR Save Enable			1	1: On, 0: Off	Off
SMDR Print Enable			2	1: On, 0: Off	Off
Record Type			3	0: All Call 1: Long Distance	All Call
Long Distance Call Digit Counter			4	07-15	07
Print Incoming Call			5	1: On, 0: Off	Off
Print Lost Call			6	1: On, 0: Off	Off
SMDR Currency Unit			7		
SMDR Cost per Metering Pulse			8		
SMDR Fraction			9	0-5	0
SMDR Transfer Charge Mode			10	0: Individual 1: Integrate Transferring 2: Integrate Transferred	Individual
SMDR Attendant Charge Mode			11	0: Normal Charging 1: Attendant Charging 2: Transferred Charging	Normal Charging
SMDR Dialed Digit Hidden Number	12	0-9	0		

PROGRAM GROUP	ÚŮĂ	ÚŮŤ Á	ÓVÞ	ÛŒÖŦ	ÖÖZÖVŠVÁ
ÛYUÜŦ ÖŒŒ					
ÛŦ ÖŮÁ Ąá^} ÁŮ[•ąą }	ŒĚF	GHG	FH	€Š^c FŮá @	Ůá @
ÛŦ ÖŮÁŦ ÁŮá^	ŒĚF	GHG	FI	FŮ} ĚÁŮ~	U~
ÛŦ ÖŮÁŦ ÁŮá c			FÍ	FŮ} ĚÁŮ~	U~
ÛŦ ÖŮÁŦ Ąá^ ÁŮ!čá^			FĪ	FŮ} ĚÁŮ~	U~
ÛŦ ÖŮÁŦ Ąá^ ÁŮ[]^ &ą } ÁŮ] ^			FĪ	€ŮŮ FŮŒ	ŮŮ
ÛŦ ÖŮÁŦ Ąá^ ÁŮWPAŮá^c			FI	FŮ} ĚÁŮ~	U~
ÛŦ VŮÁŦ Ąá^ ÁŮ!čá^ ÁŮáá!^••				ŮÁá!	€€€€
ÛŦ ÖŮÁŦ Ąá^ ÁŮáá!^••					
ÛŦ ÖŮÁŦ Ąá^ ÁŮ[{ ąą ÁŮá ^					
ÛŦ ÖŮÁŦ Ąá^ ÁŮ} áŮ ^^ Ů ÁŮc				b[ŒŒ•ą } T[] V^ Y^á V@ Ůá Ůœ Ů~ }	b[ŒŒ•ą }
ÛŦ ÖŮÁŦ Ąá^ ÁŮ} áŮą ÁŮc				€€GH	€€
ÛŦ ÖŮÁŦ Ąá^ ÁŮ} áŮc				FŮ} ĚÁŮ~	U~
ÛŦ ÖŮÁŦ Ąá^ ÁŮ} áŮc				FŮ} ĚÁŮ~	U~
ÛYÜVŦ ÖŒŒŮÁŮŮ	ŒĚI	GH	Ě	Ě	Ě
Ů•č{ ÁŮ ^			F	ŮPKTD	
Ů•č{ ÁŮœ			G	ŮT ÖŮŮD	
ÖŮVŮ) ąá^ ÁŮ [á^			H	FŮ} ĚÁŮ~	U~
ÖŮVŮ) ąá^ ÁŮ ^			I		
ÖŮVŮ) áÁŮ !			Í		
Þ^ç [! ÁŮ ^ ÁŮœ				Ůá ąá^ ŮŮŮŮ[& ÞVŮ	

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
NTP Primary Server Address					
NTP Secondary Server Address					
Standard Time Zone	A-94	233	-	-	-
LED FLASHING RATE	A-95	234	-	-	-
[CALLBK] Intercom			1	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 30 IPM
[CALL BK] CO Line			2	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 120 IPM
[CALL BK] MSG Wait			3	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 120 IPM
[MUTE] Transmission			4	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[MUTE] COS Change			5	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 120 IPM
[DND] DND			6	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[DND] One-Time			7	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 60 IPM

PROGRAM GROUP	ÚŮÄ	ÚŮT Á ÓVÞ	ÜÇP ÖÒ	ÖÖZÖVŠVÁ
UYUUÖT ÁČE/CE				
ŽPÖÁÚ!^•^!&Ů ÚŮÁ	ČEĚÍ	GH	ì Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ FÍ ÁŮT
ŽČEŠŠÁČSÁČŮPÜÁ			J Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ ì í €ŮT Á
ŽÚSÁÚ] ^æ ^!Á			F€ Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ Qæ @U^æä^
ŽÚSÁŮ^æä^Á			FF Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ Qæ @U^æä^
ŽÚSÁŮ& { ä * ÁČAÁ			FG Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ î í €ŮT Á
ŽPÜŠÖÁÚæ ä * Á			FH Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ î í €ŮT Á
ÄPÜŠÖÁÚ] æ ÁÚç^!Á			FI Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ î í €ŮT Á
ŽPÜŠÖÁÚ!^•^!ç^áÁ			FÍ Ø^cFkÖ [: Á Ü^áÁÖ : ^; ÁČE à^!Á Ø^cGkQæ @ Qæ @U - ÁU } ÁŮT	ÜÖÖ î í €ŮT Á

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
[RING] ICM Ring	A-95	234	16	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 60 IPM
[RING] CO Ring			17	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 60 IPM
[RING] MSG Wait			18	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 60 IPM
[HEADSET] Headset			19	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[HEADSET] Bluetooth			20	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 60 IPM
[DN] I Use			21	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[DN] Other Use			22	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[DN] DND			23	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash off

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
DSS] DND	A-95	234	32	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash off
[DSS] Call Forward			33	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash off
[DSS] Handset-Lift			34	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash off
[DSS] Preselected MSG			35	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash off
[DSS] Hold			36	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[CO] Call Setup			37	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 60 IPM
[CO] Co Talk			38	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED Flash Steady
[DN] VM Message Wait			39	Flex1: Color Red / Green / Amber Flex2: Flash Flash Off / On / IPM	RED 120 IPM

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
INTERCOM BUSY DIGIT	A-101	237	-	-	-
Step Call	A-101	237	1	EN/DIS	Disable
Digit '1' Service			2	0: Not Assign 1: Call-Back 2: Camp-On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	Not Assign
Digit '2' Service			3	0: Not Assign 1: Call-Back 2: Camp-On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	Not Assign
Digit '3' Service			4	0: Not Assign 1: Call-Back 2: Camp-On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	Not Assign
Digit '4' Service			5	0: Not Assign 1: Call-Back 2: Camp-On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	Not Assign

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SYSREM DATA					
Digit '** Service			12	0: Not Assign 1: Call-Back 2: Camp-On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	Not Assign
Digit '#' Service	A-101	237	13	0: Not Assign 1: Call-Back 2: Camp-On 3: Call Wait 4: Voice Over 5: Intrusion 6: Hunt	Not Assign
DIAL-TONE DIGIT TABLE	A-101	240	-	-	-
Dummy Dial-Tone Digit				Max 6 Digits	-
EXECUTIVE / SECRETARY ASSIGN	A-102	241	-	-	-
Executive Number			1	Station	-
Secretary 1-3			2	1-3 Station	-
ICM Call to Exec.			3	0: Secretary 1: Sec if Exec DND	Secretary
CO Call To Exec.			4	0: Secretary 1: Sec if Exec DND	Secretary
Call Executive			5	0: Off 1: First Sec DND 2: All Sec DND	Off
Sec. Choice			6	0: First Idle 1: Longest Idle	First Idle
Message Wait Station			7	0: Executive 1: First Secretary	Executive
EXECUTIVE ACCESS	A-103	242	-	-	-
Executive / Executive Access				Each Exec EN/DIS	All Disable
PPTP ATTRIBUTES	Web	Only	-	-	-

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
TABLE DATA					
SYSTEM TIME TABLE	A-107	253		System Time Table 1-9	
Time Zone Comment			1	Max 32 Chars	
Time Zone			2	System Time / GNT Time	
Daylight Saving Time			3	1: On, 0: Off	Off
Ring Mode			4	0: Day 1: Night 2: Timed	Day
Auto Ring Mode			5	1: On, 0: Off	Off
WEEKLY TIME TABLE	A-108	254			
Monday			1	Flex1: Day Start Time Flex2: Night Start Time Flex3: Timed Start Time Flex4: Timed End Time Flex5: Work / Holiday	09:00 18:00 Workday
Tuesday			2	Flex1: Day Start Time Flex2: Night Start Time Flex3: Timed Start Time Flex4: Timed End Time Flex5: Work / Holiday	09:00 18:00 Workday
Wednesday			3	Flex1: Day Start Time Flex2: Night Start Time Flex3: Timed Start Time Flex4: Timed End Time Flex5: Work / Holiday	09:00 18:00 Workday
Thursday			4	Flex1: Day Start Time Flex2: Night Start Time Flex3: Timed Start Time Flex4: Timed End Time Flex5: Work / Holiday	09:00 18:00 Workday
Friday			5	Flex1: Day Start Time Flex2: Night Start Time Flex3: Timed Start Time Flex4: Timed End Time Flex5: Work / Holiday	09:00 18:00 Workday

PROGRAM GROUP	ÚŮÄ	ÚŮT Á ÓVÞ	ÜČP ÖÒ	ÖÖZÖBŠVÁ
VOČŠÓÁŮČE/ČE				
Üæ áæ			î Ø^cFkÖæ ÁÜæóÁq ^ Ø^cGhã @ÁÜæóÁq ^ Ø^cHÁq ^áÁÜæóÁq ^ Ø^cl kÁq ^áÁÜq ^ Ø^cl kÁ [\ ÁP [ææ	€€€€ P [ææ
Û } áæ			ï Ø^cFkÖæ ÁÜæóÁq ^ Ø^cGhã @ÁÜæóÁq ^ Ø^cHÁq ^áÁÜæóÁq ^ Ø^cl kÁq ^áÁÜq ^ Ø^cl kÁ [\ ÁP [ææ	€€€€ P [ææ
ŠŮŮÁŮ ŌÁVČŠŌ	ČĚČ	Ĝ Ĩ		ŠŮŮÁq ^ÁVæ ^ÁĚĚ
Öæ Á [] ^ ÁŮ ^ q ää } T [] áæ V ^ ^ áæ Y ^ á } ^ ^ áæ V @ ! ^ áæ Ø ææ Üæ áæ Û } áæ			F Z [] ^ F Á [] ^ G Á [] ^ H	Z [] ^ Á Z [] ^ Á Z [] ^ Á Z [] ^ Á Z [] ^ Á Z [] ^ Á
Öæ Á [] ^ ÁÁ			G Ø^cFkÁq ^ Á [] ^ F Ø^cFkÁq ^ Á [] ^ G Ø^cFkÁq ^ Á [] ^ H	€€€€
Öæ Á [] ^ ÁĜ			H Ø^cFkÁq ^ Á [] ^ F Ø^cFkÁq ^ Á [] ^ G Ø^cFkÁq ^ Á [] ^ H	€€€€
Öæ Á [] ^ ÁÁÁ			I Ø^cFkÁq ^ Á [] ^ F Ø^cFkÁq ^ Á [] ^ G Ø^cFkÁq ^ Á [] ^ H	€€€€
PUŠŮŮÁŮ ŌÁVČŠŌ	ČĚČČ	Ĝ Ĩ		P [ææ Áæ ^ ÁĚĚ Öæ @ Áæ ^ Á ^ ČĚĚ €
Š } æ ÁŮæ } áæ			F	
P [ææ ÁŮæ			G	
ÛYÛVŌT ÁÜÜŌŌÁŮČŠ	ČĚČČ	Ĝ Ĩ	Ě Û ^ á ÁŮæ ^ Á ^ ČÁ ČČČÁ Á H J J	Ě

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
TABLE DATA					
System Speed Dial	A-110	257	1	Max 32 Digits	
System Speed Name			2	Max 16 Ch	
Toll Free			3	1: On, 0: Off	Off
Tenant Number			4	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
EMERGENCY CODE TABLE	A-111	258		Emergency Table Index 01-50	
Dialed Digit			1	Max 16 Digits	
Changed Digit			2	Max 16 Digits	
Tenant Number	A-111	258	3	1-9 (MBX IP-300) 1-5 (MBX IP-100)	1
ANNOUNCEMENT TABLE	A-111	259		Announcement Table Index 001-100	
First				1: VMIB Slot 2: Announce Num	
Second				1: VMIB Slot 2: Announce Num	
Third				1: VMIB Slot 2: Announce Num	
Fourth				1: VMIB Slot 2: Announce Num	
CCR				1-100	

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Digit '4'			4	Not Assign Station Number Station Group CCR CCR Drop System Speed Conference Room Attendant Call VMIB Access Networking Num Digits	Not Assign
TABLE DATA					
Digit '5'			5	Not Assign Station Number Station Group CCR CCR Drop System Speed Conference Room Attendant Call VMIB Access Networking Num Digits	Not Assign
Digit '6'	A-112	260	6	Not Assign Station Number Station Group CCR CCR Drop System Speed Conference Room Attendant Call VMIB Access Networking Num Digits	Not Assign

PROGRAM GROUP	ÚŮÄ	ÚŮT Á	ÓVÞ	ÜCEÖÒ	ÖÖZCEŠVÁ
Öä äÁ q			İ	Þ[öĚ•ä } Ücæä } Ä~ { à^! Ücæä } /Ö:[~] ÔÔÜ ÔÔÜ/Ö:[] Û•c{ Ä] ^^ä Ô[]-^!^} &ÄÜ[[{ ÖĚ^} äæ öÖæ! XT ÖÄĚ&^•• Þ^ç [\ ä * Ä~ { Öä ä	Þ[öĚ•ä }
VCEŠÖ/ÖCE/CE					
Öä äÁ q			İ	Þ[öĚ•ä } Ücæä } Ä~ { à^! Ücæä } /Ö:[~] ÔÔÜ ÔÔÜ/Ö:[] Û•c{ Ä] ^^ä Ô[]-^!^} &ÄÜ[[{ ÖĚ^} äæ öÖæ! XT ÖÄĚ&^•• Þ^ç [\ ä * Ä~ { Öä ä	Þ[öĚ•ä }
Öä äÁ q	ÜFFG	Ĝ €	J	Þ[öĚ•ä } Ücæä } Ä~ { à^! Ücæä } /Ö:[~] ÔÔÜ ÔÔÜ/Ö:[] Û•c{ Ä] ^^ä Ô[]-^!^} &ÄÜ[[{ ÖĚ^} äæ öÖæ! XT ÖÄĚ&^•• Þ^ç [\ ä * Ä~ { Öä ä	Þ[öĚ•ä }

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Digit '0'			10	Not Assign Station Number Station Group CCR CCR Drop System Speed Conference Room Attendant Call VMIB Access Networking Num Digits	Not Assign
TABLE DATA					
Digit '**'			11	Not Assign Station Number Station Group CCR CCR Drop System Speed Conference Room Attendant Call VMIB Access Networking Num Digits	Not Assign
Digit '#'	A-112	260	12	Not Assign Station Number Station Group CCR CCR Drop System Speed Conference Room Attendant Call VMIB Access Networking Num Digits	Not Assign
ICLID TABLE	A-113	262		ICLID Tble Index 001-250	
ICLID Number			1	Max 24 Digits	
ICLID Name			2	Max 16 Ch	

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Forward Call Ring (Station)			5	1 st : Ring Port 1-15	5
				2 nd : Ring Port 1-15	6
				3 rd : Ring Port 1-15	7
				4 th : Ring Port 1-15	8
Forward Call Ring (CO)			6	1 st : Ring Port 1-15	9
				2 nd : Ring Port 1-15	10
				3 rd : Ring Port 1-15	11
				4 th : Ring Port 1-15	12
Transfer Call Ring (Station)			7	1 st : Ring Port 1-15	5
				2 nd : Ring Port 1-15	6
				3 rd : Ring Port 1-15	7
				4 th : Ring Port 1-15	8
TABLE DATA					
Transfer Call Ring (CO)			8	1 st : Ring Port 1-15	9
				2 nd : Ring Port 1-15	10
				3 rd : Ring Port 1-15	11
				4 th : Ring Port 1-15	12
Call Back Indication Ring			9	1 st : Ring Port 1-15	1
				2 nd : Ring Port 1-15	1
				3 rd : Ring Port 1-15	1
				4 th : Ring Port 1-15	1
Wakeup Indication Ring			10	1 st : Ring Port 1-15	1
				2 nd : Ring Port 1-15	1
				3 rd : Ring Port 1-15	1
				4 th : Ring Port 1-15	1
Reversible Ring	A-115	265	11	1 st : Ring Port 1-15	1
				2 nd : Ring Port 1-15	1
				3 rd : Ring Port 1-15	1
				4 th : Ring Port 1-15	1
Paging Call Ring			12	1 st : Ring Port 1-15	5
				2 nd : Ring Port 1-15	5
				3 rd : Ring Port 1-15	5
				4 th : Ring Port 1-15	5

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Voice Mail 5 – Error			5	1:Prefix: 2:Suffix	P#*5P
Voice Mail 6 – DND			6	1:Prefix: 2:Suffix	P#*6P
Voice Mail 7			7	1:Prefix: 2:Suffix	-
Voice Mail 8			8	1:Prefix: 2:Suffix	-
Voice Mail 9 - Disconnect			9		****
TENANT DATA					
ATD GROUP ASSIGNMENT	A-118	270			
Group Type			1	0: Terminal 1: Circular 2: Ring 3: Longest Idle	Terminal
Group Name			2	Max 16 Ch	-
CO Attendant Number			3	Station	-
Member			4	Station	100
ATD GROUP ATTRIBUTES I	A-118	271			
Greeting Tone Type			1	0: Normal 1: Prompt 2: Annc 3: Int MOH 4: Ext MOH	Normal
Greeting Play Timer			2	000-180 (1sec)	0
Greeting Tone No			3	01-19	4
Greeting Prompt/Announcement Table No.			4	001-255	3
Greeting Repeat Count			5	000-100	0
Greeting Repeat Delay Timer	A-118	271	6	000-100 (1sec)	

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Group Name	A-123	275	2	Max 16 Ch	
Member			3	Station	
NIGHT ATD GROUP ATTRIBUTES I	A-123	276			
Greeting Tone Type			1	0: Normal 1: Prompt 2: Annc 3: Int MOH 4: Ext MOH	Normal
Greeting Play Timer			2	000-180 (1sec)	0
Greeting Tone No			3	01-19	4
Greeting Prompt/Announcement Table No.			4	001-255	
TENANT DATA					
Greeting Repeat Count			5	000-100	3
Greeting Repeat Delay Timer			6	000-100 (1sec)	0
Queuing Tone Type			7	0: Normal 1: Prompt 2: Annc 3: Int MOH 4: Ext MOH	Int MOH
Greeting/Queuing Timeout Timer			8	010-300 (1sec)	30
Queuing Tone No			9	01-19	
Queuing Prompt/Announcement Table No			10	001-255	
Queuing Repeat Count			11	000-100	3
Queuing Repeat Delay Timer			12	000-100 (1sec)	0
Night ATD Group Attributes II	A-126	277			
Call In Greeting			1	0: After Greeting 1: In Greeting	In Greeting
Max Queue Count			2	00-99	5
Forward Type			3	0: Not Used 1: Uncond 2: Q Overflow 3: Time Out 4: All	Not Used

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Backlight Option	A-128	281	7	0: All Off 1: Day On 2: Night On 3: Timed On 4: D/N On 5: D/T On 6: N/T On 7: All On	All Off
TENANT GROUP ACCESS	A-130	283			
Between Tenant Group Access				EN/DIS	All DISABLE
CO CALL RESTRICTION I	A-131	284			
TENANT DATA					
Restriction (Normal CO Line)			1	0: No Restriction 1: All Call 2: Long / International Call	No Restriction
Restriction (Dedicated CO Line)			2	0: No Restriction 1: All Call 2: Long / International Call	No Restriction
Svc After Restriction Time (Local Call)			3	0: No Restriction 1: All Call 2: Long / International Call	No Restriction
Svc After Restriction Time (Long Dist Call)			4	0: No Restriction 1: All Call 2: Long / International Call	No Restriction
Svc After Restriction Time (Internatl Call)			5	0: No Restriction 1: All Call 2: Long / International Call	No Restriction
Svc After Restriction Time (Dedicated Call)			6	0: No Restriction 1: All Call 2: Long / International Call	No Restriction
CO CALL RESTRICTION II	A-131	285			
Tone Repeat Time (Local Call)			1	10-254 (1sec)	20
Tone Repeat Time (Long Call)			2	10-254 (1sec)	20
Tone Repeat Time (International Call)			3	10-254 (1sec)	20

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
2nd Dial Tone			2	Tone Type Time Tone Number	Normal 10 sec 11
CO Dial Tone	A-133	290	3	Tone Type Time Tone Number	Normal 10 sec 17
DISA Dial Tone			4	Tone Type Time Tone Number	Normal 10 sec 10
LCR Virtual Tone			5	Tone Type Time Tone Number	Normal 10 sec 17
TENANT DATA					
Digit Conversion Virtual Tone			6	Tone Type Time Tone Number	Normal 10 sec 17
Password Dial Tone			7	Tone Type Time Tone Number	Prompt 10 sec 10
Internal Busy Tone			8	Tone Type Time Tone Number	Prompt 10 sec 11
External Busy Tone			9	Tone Type Time Tone Number	Normal 10 sec 16
CO Line Busy Tone			10	Tone Type Time Tone Number	Normal 10 sec 17
Uncompleted Dial Error Tone			11	Tone Type Time Tone Number	Normal 20 sec 1
DOD Restriction Tone			12	Tone Type Time Tone Number	Normal 20 sec 1

PROGRAM GROUP	ÚŌÄ	ÚŌŤ Á	ÓVÞ	ÜŒÖÖ	ÖÖZÖVŠVÁ
Qc!) æÁP[ĚĚ •, ^!ÁM] ^			FH	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	Ú! [{] c GEÁ ^ & FÍ
Öcc!) æÁP[ĚĚ •, ^!ÁM] ^	ŌĚFH	GJ€	FI	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	Ú! [{] c GEÁ ^ & FÍ
Qc!) æÁKææ cŌ! [:ÁM] ^			FÍ	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	Ú! [{] c GEÁ ^ & Í I
Öcc!) æÁKææ cŌ! [:ÁM] ^			FÍ	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	Ú! [{] c GEÁ ^ & Í I
VÖÞŒVÄŒŒŒ					
Ōæ Ō~ :ææ } ÁŮ^ dææ } ÁM] ^			Fİ	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	P! [{ æ GEÁ ^ & F
Œ [] ~ { [~ •Ōæ Ů^ dææ } ÁM] ^			Fİ	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	P! [{ æ GEÁ ^ & F
Ō! [:ÁM] ^ ÁŒÁ@Á c@! &æ^•D			FJ	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	P! [{ æ GEÁ ^ & F
Ü^ææ^Ō [& ä *			GE	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	P! [{ æ GEÁ ^ & F
Ü^ææ^Œ^Œ & ÁŮ^ c			GF	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	P! [{ æ GEÁ ^ & F
Ü^ææ^Ō [Á [cŌä c :à			GG	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	Ú! [{] c Í Á ^ & G
Ü^ææ^Ōæ^) &			GH	V } ^Á^] ^ Vā ^ V } ^Á~ { à^!	P! [{ æ GEÁ ^ & F

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Relative Out of Order			24	Tone Type Time Tone Number	Normal 20 sec 1
External Relative Out of Order	A-133	290	25	Tone Type Time Tone Number	Normal 20 sec 1
External Relative Outgoing Restriction			26	Tone Type Time Tone Number	Normal 20 sec 1
Relative Hot Desk Logout			27	Tone Type Time Tone Number	Normal 20 sec 1
TENANT DATA					
Howling Tone			28	Tone Type Time Tone Number	Normal 30 sec 19
1 st Ring Back Tone			29	Tone Type Time Tone Number	Normal 10 sec 4
2 nd Ring Back Tone			30	Tone Type Time Tone Number	Normal 10 sec 4
CO Ring Back Tone			31	Tone Type Time Tone Number	Normal 10 sec 4
Recall Ring Back Tone			32	Tone Type Time Tone Number	Normal 10 sec 4
Zone Paging Call Ring Back Tone			33	Tone Type Time Tone Number	Normal 10 sec 4
Command Call Ring Back Tone			34	Tone Type Time Tone Number	Normal 30 sec 4

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
Call Duration Restriction Alarm			46	Tone Type Time Tone Number	Normal 1 sec 13
Confirm Tone	A-133	290	47	Tone Type Time Tone Number	Normal 1 sec 8
Single Error Tone			48	Tone Type Time Tone Number	Normal 3 sec 9
Transfer Hold Tone			49	Tone Type Time Tone Number	Internal MOH 30 sec
TENANT DATA					
Transfer Hold Tone (Station)			50	Tone Type Time Tone Number	Internal MOH 30 sec
Camp On Hold Tone (CO)			51	Tone Type Time Tone Number	Normal 30 sec 14
Camp On Hold Tone (Station)			52	Tone Type Time Tone Number	Normal 30 sec 14
Call Wait Hold Tone (CO)			53	Tone Type Time Tone Number	Normal 30 sec 14
Call Wait Hold Tone (Station)			54	Tone Type Time Tone Number	Normal 30 sec 14
Normal Hold Tone (CO)			55	Tone Type Time Tone Number	Internal MOH 30 sec
Normal Hold Tone (Station)			56	Tone Type Time Tone Number	Internal MOH 30 sec

PROGRAM GROUP	ÚŌÄ	ÚŌŤ Á	ÓVÞ	ÜŌÞŌÒ	ÖÖZÖVŠVÁ
Þ[{: æÁŦ[áÁ[}^ÁČE} áæ Þ			íï	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Ŧc!} æÁŦ UP HEÁ^&
ŌæÁÚæ\ ÁŦ[áÁ[}^	ŌĚFH	GJ€	íï	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ FGĚÁ^& FI
ŌæÁÚæ\ ÁŦ[áÁ[}^ÁČE} Þ			íJ	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ FGĚÁ^& FI
ŌÁČE ħ ÁŦ[áÁ[}^			í€	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ HEÁ^& FI
VŌÞŌÞVÁŌČE					
ŌÁČE ħ ÁŦ[áÁ[}^ÁČE} áæ Þ			îF	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ HEÁ^& FI
Ō[{: { æ áŌæÁČE, ^!Á[}^			îG	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ FEÁ^& FI
ÜGÁ[{: æÁŦ~c[ā*Á[}^			îH	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ FEÁ^& I
ÜGÁ-Ě^ŌæÁŦ[!, æáÁ[}^			îI	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ FEÁ^& I
Ÿ æ^Ě] ÁČE, ^!Á[}^			îí	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Ů[{: }c FEÁ^& FG
Ů!çæÁŦ^ŌÁ[}^			îî	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Þ[{: æ FEÁ^& V }^ÁŦ[!Ō
ÖŌŌŮ^d^ Á[}^			îï	V }^ÁŦ]^ Vā ^ V }^ÁŦ~{ à^!	Ů[{: }c íÁ^& í

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
ICLID Restrict Tone			68	Tone Type Time Tone Number	Normal 10 sec 1
Auto Call Answer Alert Tone	A-133	290	69	Tone Type Time Tone Number	Normal 1 sec 13
VM Interaction Confirm Tone			70	Tone Type Time Tone Number	Normal 1 sec 8
Authorization Code Dial Tone			71	Tone Type Time Tone Number	Prompt 10 sec 10
TENANT DATA					
Tenant Dial Tone			72	Tone Type Time Tone Number	Normal 10 sec 10
Two-way Record Warning Tone			73	Tone Type Time Tone Number	Normal 1 sec 13
BOARD DATA					
ISDN BOARD ATTRIBUTES	A-138	300			
PRIB CRC Check			1	0: Disable / 1: Enable	Enable
PRIB Line Mode			2	0: TE / 1: NT	TE
BRIB TEI Mode Port1 - n/a			3	0: Fixed / 1: Auto	Auto
BRIB TEI Mode Port2 - n/a			4	0: Fixed / 1: Auto	Auto
BRIB TEI Mode Port3 - n/a			5	0: Fixed / 1: Auto	Auto
BRIB TEI Mode Port4 - n/a			6	0: Fixed / 1: Auto	Auto
ISDN CLOCK PRIORITY	A-139	301			
ISDN BRD Clock Priority				Slot No.	Net
VOIB/VMIB BOARD ATTRIBUTES	A-140	305			
IP Address			1	IP Address	10. 10. 10. # (# : slot number)
Router IP Address			2	IP Address	0.0.0.0

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
BOARD DATA					
BLF Destination System Port			9	0000-9999	9500
Firewall Routing			10	0: OFF / 1: ON	ON
T-NET DATA					
T-NET ATTRIBUTE	A-143	330	-	-	-
TNET Enable			1	0: OFF / 1: ON	OFF
CM ATTRIBUTE	A-143	331	-	-	-
Register Enable			1	0: OFF / 1: ON	ON
IP Address	A-143	331	2	IPv4 address	0.0.0.0
IPKTS Port Number			3	0001-9999	5588
Total No of Ports			4	000-999	000
Polling Count			5	00-99	05
Polling Interval			6	00-99	02
FOPSTN ATTRIBUTE	A-144	333	-	-	-
Enable FoPSTN			1	0: OFF / 1: ON	OFF
Initialize Call			2	-	-
Index			3	1-100 (MBX IP-100) 1-200 (MBX IP-300)	-
Numbering Plan			3-1	Max 16	-
CO Group			3-2	1-24 (MBX IP-100) 1-72 (MBX IP-300)	-
Tel Number			3-3	Max 10	-
T-NET BOARD ATTRIBUTE	A-145	334	-	-	-
TNET Enable			1	0: OFF / 1: ON	OFF
IP-PHONE T-NET ENABLE	A-145	335	-	-	-
TNET Enable			1	0: OFF / 1: ON	OFF
H.324 DATA					
H.323 ROUTING ATTRIBUTE	A-146	360	-	-	-
Digit			1	Max 8 digits	
Destination IP Address			2		0.0.0.0

This feature is not available at this time ...

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SIP CO DATA					
SIP CO BASIC REGISTRATION	WEB	ONLY	-	-	-
Main Proxy Address			-	-	-
Main Proxy Port			-	1024-9999	5060
Main Domain Name			-	-	-
Proxy Type				Normal / Dacom / KT	Normal
SIP CO ADDITIONAL REGISTRATION	WEB	ONLY	-	-	-
User ID Start Index			-	-	-
User ID End Index			-	-	-
Main Outbound Proxy Address			-	-	-
Main Outbound Proxy Port			-	1024 – 9999	5060
Sub Proxy Address			-		
Sub Proxy Port	WEB	ONLY	-	1024 – 9999	5060
Sub Domain Name			-	-	-
Sub Outbound Proxy Address			-	-	-
Sub Outbound Proxy Port			-	1024 – 9999	5060
Connection Mode			-	UDP / TCP / TLS	UDP
Registration Timer			-	60-86400	3600
100rel Support			-	ON/OFF	OFF
Session Timer Support			-	ON/OFF	OFF
Max Session Timer			-	180-3600	1800
Use 181 Message			-	ON/OFF	OFF
Use RPORT			-	ON/OFF	OFF
P-Asserted-Identity			-	NOT USE / USE	NOT USE
DTMF Send Mode			-	IN / OUT / RFC2833	RFC2833
SIP CO CODEC	WEB	ONLY	-	-	-
First Codec Type				Not Use / 711U/A/729/723A	G.711A
Second Codec Type				Not Use / 711U/A/729/723A	Not Use

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
SIP STATION DATA					
Retry Count				3-10	5
407 Authentication				ON/OFF	OFF
100rel Support				ON/OFF	OFF
Session Timer Support				ON/OFF	OFF
Max Session Timer				180-3600	1800
Min Session Timer				60-150	90
ZONE DATA					
ZONE ATTRIBUTE	WEB	ONLY	-	-	-
Nation Code				-	Same with system nation
Memo				-	
Codec Type				Tenant Codec / G.711 / G.723 / G.729 / G.722 / Not Assign	Tenant Codec
RTP Relay Rule				Automatic / Follow Relay Group	Automatic
VOIB Slot for RTP Relay				-	VOIB Slot
VMIB Slot				-	VMIB Slot
Peer To Peer				Disable/Enable	Enable
ZONE RTP RELAY GROUP	WEB	ONLY	-	-	-
Force To RTP Relay				00-63	32
INTER ZONE ATTRIBUTE	WEB	ONLY	-	-	-
Codec Type				Station Codec / G.711 / G.723 / G.729	Station Codec
RTP Rule				If Need / Always Not / Forced To Do	If Need
Src. RTP Relay VOIB Slot					
Dest. RTP Relay VOIB Slot					
STATION ZONE ATTRIBUTE	WEB	ONLY	-	-	-
Zone No				1-9	1

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
GAIN AND CADENCE CONTROL					
TONE			9	00-63	32/38/37/32/37/3 2/32/32
MUSIC			10	00-63	29/40/29/29/37/3 2/32/32
DSP RX GAIN	A-154	415			
DTMF/A			1	00-63	32
DTMF/D			2	00-63	32
CPT			3	00-63	32
CID/FSK			4	00-63	32
CID/D			5	00-63	32
CID/RUS			6	00-63	32
SMS/TRK			7	00-63	32
SMS/SLT			8	00-63	32
DEVICE (SLTM/DTIM(HS)/DTIM(HF)/IP-PHONE(HS)/ IP-PHONE(HF)/WIT/VOIB) RX RTP GAIN	A-154	420- 426			
SLTM			1	00-63	34/34/34/34/34/3 4/34
DTIM (HF)			2	00-63	34/34/34/34/34/3 4/34
DTIM (HS)			3	00-63	34/34/34/34/34/3 4/34
IP-Phone (HS)			4	00-63	34/34/34/34/34/3 4/34
IP-Phone (HF)			5	00-63	34/34/34/34/34/3 4/34
WIT			6	00-63	34/34/34/34/34/3 4/34
VOIB			7	00-63	34/34/34/34/34/3 4/34

PROGRAM GROUP	PG #	PGM	BTN	RANGE	DEFAULT
DECT DATA					
PARK (view)			4		
Wtu User Authenticate			5	Station Number	
Park			6		
Wtu Subs All Data Erase			7		
Wtu Subscription Erase			8	Station Number	
Wtu (Un)Subscription Range (view)			9		
DECT Mobility			10	Station Number	
WTIM DECT ATTRIBUTE	A-162	492			
Auto Call RIs			1	ON/OFF	OFF
Base Fault Alarm			2	Enable/Disable	Disable
GREEN MODE					
GREEN MODE ACTIVATION	WEB	Only			
Power Save Mode				Enable/Disable	Disable
GREEN MODE TIME SETTING	WEB	Only			
Monday Power ON/OFF Time				0000-2359	
Tuesday Power ON/OFF Time				0000-2359	
Wednesday Power ON/OFF Time				0000-2359	
Thursday Power ON/OFF Time				0000-2359	
Friday Power ON/OFF Time				0000-2359	
Saturday Power ON/OFF Time				0000-2359	
Sunday Power ON/OFF Time				0000-2359	
INITIALIZATION					
INITIALIZATION		499			
All Database			1		
System Reset			2		
Station Data			3		
Station Button Data			4		
CO Line Data			5		

PROGRAM GROUP	ÚŌÄ	ÚŌT Á ÓVÞ	ÛœŦŌŌ	ÖÖZÖVŠVÁ
INITIALIZATION				
Ùœä } ÁŌ! [~] ÁŌœœ			î	
Ù^•œ{ ÁŌœœ			ï	
ÛT ÖÜÁŌœœ			ì	
Ù^•œ{ Áŧ ä ^!			J	
Vœà ^ ÁŌœœ			F€	
V^} œ} œŌœœ			FF	
Þ^ç [\ ä * ÁŌœœ			FG	
ÙŪÁŌœœ			FH	
P[ç^• \ Š [* [~ ç			FI	

USER ENTRY GUIDES

Alphanumeric Entry Chart

The following guide may be used to enter Customized Messages, Speed Dial Numbers, or User Names:

Q - 11 Z - 12 . - 13 1 - 10	A - 21 B - 22 C - 23 2 - 20	D - 31 E - 32 F - 33 3 - 30
G - 41 H - 42 I - 43 4 - 40	J - 51 K - 52 L - 53 5 - 50	M - 61 N - 62 O - 63 6 - 60
P - 71 R - 72 S - 73 Q - 7* 7 - 70	T - 81 U - 82 V - 83 8 - 80	W - 91 X - 92 Y - 93 Z - 9# 9 - 90
Blank - *1 : - *2 , - *3	0-00	#

Index

A

ACD

- Agent Log-in / Log-out Default Setting, 10-39
- Agent State, 10-33
- Basic Feature, 10-1
- Call Distribution by Priority, 10-16
- Call Indication, 10-44
- Call Queuing Service, 10-21
- Group Call Traffic, 10-58
- Group Service Status, 10-9
- Group Supervisor Functions, 10-50

Alternate

- Incoming CO Service, 5-19
- Outgoing CO Service, 5-25

Alternative Route Selection, 5-1

Answering Machine Emulation (AME), 6-30

Attendant

- Group, 7-1
- Recall, 7-29
- Station Program Codes, 7-32

Automatic Network Dialing, 5-2

Automatic Speaker Select, 6-4

B

Background Music (BGM), 6-5

Broker Call, 8-1

C

Call Log Display, 6-6

CCR Service During ACD Announcement, 10-28

CCR Service for Attendant Queuing Announcement, 7-19

CO COS, 5-28

CO Group Access Code, 5-3

CO/IP Line Groups, 5-7

CO/IP LINE PRESET FORWARD, 5-35

CO/IP Ring Assignment, 5-37

CO Line Flash, 5-5

CO Line Name Display, 6-8

CO Line Release Guard Time, 5-41

CO Line Service, 5-9

CO OWN CODE SERVICE, 5-36

CO Ring Detect, 5-42

CO Transit Service, 5-42

D

Day/Night/Timed Ring Mode, 7-37

Dial Pulse Signaling, 5-44

DID/DISA Restriction, 5-34

DID Name Service, 5-29

Differential Ring, 6-17

Digit Sending Mode, 5-28

Direct Inward Dial (DID), 5-45

Direct Inward System Access (DISA), 5-50

DSS/BLF, 4-1

Dual Tone Multi-Frequency (DTMF) Signal Sending, 5-55

E

EZ-Attendant, 7-41

F

Forward Destination, Overflow Service, 7-25

N

Night Attendant Group, 7-10

O

Off-Hook Signaling, 6-14

One Time DND, 6-9

On-Hook Dialing, 6-15

Outgoing CO Line Option, 5-14

P

Prime Line Immediately/Delayed, 6-16

Push-To-Talk Paging, 4-23

R

Representative CLI Service, 5-77

S

Saved Number Redial (SNR), 6-18

SIP

3-Party Conference, 9-5

Call Forward, 9-4

Call Pick-Up, 9-3

Call Wait/Broker Call, 9-5

Do Not Disturb (DND), 9-4

Hold Call, 9-3

Name Registration, 9-2

Placing Calls, 9-2

SMS, 9-5

Terminal Registration, 9-1

Transfer Call, 9-3

Video Call, 9-6

Voice Mail Notification, 9-6

SLT Message Wait Indication, 8-4

SLT Name Registration, 8-5

Auto Release of, 6-4

Speakerphone, 6-19

Station

ICLID Call Routing, 6-23

Message Wait/Call Back, 4-11

Úæä } Á| ^ ç ä | ^ Á Ó ç | } • Æ Ä È Ç
 Úæä } Á| ^ ç ä | ^ Á Ö Ö Á ç æ @ Ú æ ^ • Æ Ä È Ç G
 Úæä } Á ^ ^ | Á Ú | * | æ { ä * Á Á Ö | ä ^ • Æ Ä È Ç
 Û • ç { Ö æ æ ä ä • Æ Ä È Ç
 Û • ç { Ö | | & Á ^ ä Ä È Ç G

T

V, [È æ Á Ú ^ & | ä Ä È Ç

U

W Ò Ó Ö Ó Á M È Ö [, } | | æ Á | [{ È | Á W Ò Ó Ä È È Í
 W Ò Ó Á M * | æ ^ Ä È È H

V

X T Á Ú æ ä * Æ Ä È Ç
 X | æ ^ Á Ú ç ^ | Ä È Ç G