AR5000 Quick Reference Guide

The label on a particular key generally points to ite's function([MODE] to set receive mode). The labels above the keys are additional functions which are accessed by first pressing the **[FUNC]** key and then the key in question. Many of the second functions will access a menu with several selections. Normally the **[UP],[DOWN]** buttons are then used to move between selections and sub-dial is used to adjust settings, with the [PASS] key being also used occasionally for some selections.

A

AGC set	[FUNC][STEP]
Alarm active	[FUNC][8]
Alarm set	[FUNC] press & hold [8]
Antenna select	[FUNC][ATT]
Attenuator set	[ATT]
Audio input	[FUNC][MODE] : AF Set Menu
Audio De-emphasis	[FUNC][MODE] : AF Set Menu

B, C

Baud rate, set	[FUNC][kHz] : Config Menu
Beep	[FUNC][kHz] : Config Menu
Clock, display	[FUNC][7]
Clock set	[FUNC] press & hold [7]
Cyberscan, activate	[FUNC] press & hold [ENT]
CW pitch, set	[FUNC] : AF Set Menu

D,E

Delete, Memory CH	[FUNC][.] in Scan or M.RE mode
Delete, Memory bank	[FUNC] press & hold [.] Del. Mode, select MEM-CH using [UP],[DOWN] keys, select bank # with sub-dial, press [PASS] to delete
Delete, Search bank	[FUNC] press & hold [.] Del. Mode, select SRCH using [UP][DOWN] keys, select bank # with sub-dial, press [PASS] to delete
DTMF select	[FUNC][0]
External IF output	[FUNC][kHz]

H, I, K, L, M

High-pass filter	[FUNC][Mode] : AF Set Menu
IF bandwidth select	[FUNC][3]
Key lock, activate	[FUNC][2] toggle on/off
Lamp	[FUNC] [kHz] : Config Menu
Low-pass filter	[FUNC][MODE] : AF Set Menu
Memory channel write from VFO	press & hold [ENT]

O, P, R

Offset, initiate	[FUNC][5]
Offset, Specify	[FUNC] press & hold [5]
Priority channel, activate	[PRIO] toggles on/off
Priority channel, set	[FUNC][PRIO]
RF gain cont., activate	[FUNC][6]
CW pitch, set	[FUNC] : AF Set Menu

Scan

Bank link	
Pause	[FUNC][SCAN] accesses menu [UP],[DOWN] to change selec-tions sub-dial to adjust setting
Delay	
Level squelch	
Voice squelch	
Mode	

Search

Initiate	[SRCH]
Bank link	[FUNC][SRCH] accesses menu [UP],[DOWN] to change selec-tions sub-dial to adjust setting
Pause	
Delay	
Level squelch	
Voice squelch	
Auto store	
Search bank, programming	[FUNC][1]

S, T

Select Scan, add freq. to list	[FUNC][1]
Select Scan, initiate	[FUNC][4] toggles on/off
Sleep timer, activate	[FUNC][9] toggles on/off
Sleep timer, set	[FUNC] press & hold [9]
Text, display	[FUNC][ENT] toggle on/off

Please see the separate instruction manual for detailed explanation of specific functions by use purpose.