	Tesla, Inc. Service Bulletin	Replace LH Repeater Camera				
SB-21-17-006						
December 8, 2021						
Classification		Section/Group	Mobile Service			
Campaign Bulletin		17 - Electrical	Can Perform (where permitted)			
Model Yea	r Model	Country/Region	Version			
2020	Model S, Model X, Model 3	All	All			
The model(s) and model year(s) listed are a general approximation of the affected VIN list. Refer to the VIN/Bulletin Tracker or Customer/Vehicle profile to determine applicability of this bulletin for a particular vehicle.						

Campaign Bulletin: This campaign bulletin addresses a known non-safety-related condition and provides recommended technical diagnosis and repair procedures. Apply this procedure to all vehicles in the affected VIN list.

Condition

On certain Model S, Model X, and Fremont-built Model 3 vehicles, the Printed Circuit Board (PCB) for the LH side repeater camera may lose electrical continuity over time, resulting in premature failure of the camera.

Correction

Replace the LH repeater camera.

Correction Description	Correction	Time (Model S)	Time (Model X)	Time (Model 3)
Replace LH Repeater Camera To Premature Future Failure	S012117006	0.10	0.05	0.15

	Part Number	Description	Quantity
Parts Required	1642010-00-A	Model S or Model X LAMP ASY, SIDE REPEATER CAMERA, LH	1
	1495864-20-C or 1495864-20-D	Model 3 M3 LAMP ASY, SIDE REPEATER CAMERA (LH)	1
If Needed	1514877-01-C	Model 3 SIDE REPEATER TRIM - CHROME AERO RIB, LH	1
		NOTE: 1495864-20-C or 1495864-20-D comes with the aero rib trim in carbon black. Order this part if the vehicle has a chrome aero rib.	

These part numbers were current at the time of publication. Use the revisions listed or later, unless otherwise specified in the Parts Catalog.

Shop Supplies Masking tape

Procedure

Replace the LH repeater camera (refer to Service Manual procedure 17403002; Model S, Model X, Model 3).

- NOTE Model 3 Only: The new side repeater camera aero rib trim comes in carbon black. If the vehicle currently has a chrome aero rib trim, replace the cabon black trim on the new camera with chrome:
- 1. Carefully insert a trim tool under the rear edge of the trim, and then separate it from the camera (Figure 1).
- 2. Align the top of the new trim onto the camera, and then apply equal pressure to fully attach the trim onto the camera.

