

1.1 - 05308 - 1 - 00-3300

TARG<sup>TM</sup>

Technical Manual 1.1

© 1980 Exidy, Inc.  
390 Java Drive, Sunnyvale, California 94086  
Telephone: (408) 734-9410  
Telex: 357-499

TABLE OF CONTENTS

I. TARG Audio Description of Operation ..... 1  
A. Introduction ..... 1  
B. Address Decoding and Input Data Latches ..... 1  
C. Clock Divider ..... 1  
D. Tone Sequence Generator ..... 2  
E. White Noise Generator ..... 2  
F. Explosion/Crash Sound Generator ..... 2  
G. Shot Sound Generator ..... 3  
H. Spectar (Special Target) Sound Generator ..... 3  
I. Summing Amplifier and Integrator ..... 3  
J. Audio Amplifier ..... 4

II. Logic Description and Operation ..... 5

III. Audio Adjustments ..... 8

IV. Power Supply Adjustments ..... 9

V. Mechanical Assemblies .....10  
A. Control Panel .....10  
B. Joystick .....12  
C. Monitor .....12  
D. Logic and Audio Boards .....14

VI. Schematics .....15

VII. Parts List

LIST OF FIGURES

Figure 1 Logic Board Block Diagram ..... 7  
Figure 2 Audio Board Adjustments ..... 8  
Figure 3 Power Supply Adjustment ..... 9  
Figure 4 Control Panel .....11  
Figure 5 Four-way Joystick .....12  
Figure 6 Logic and Audio Boards .....24

## I. TARG Audio Description of Operation

### A. Introduction

The TARG audio PCB is comprised of the following functionally distinct sections:

- Address Decoding and Input Data Latches
- Clock divider
- Tone sequence generator
- White noise generator
- Explosion/Crash sound generator
- Shoot sound generator
- Special Target (SPECTAR) sound generator
- Summing Amplifier and Integrator
- Audio Amplifier

### B. Address Decoding and Input Data Latches

A two-to-four line decoder IC at location 1D detects the combination of the audio board select signal ABSEL and the WRITE signal. The WRITE signal is derived from the CPU read/write signal R/W, logically AND'ed with CPU clock  $\phi_2$  (phase two).

Address line A0 (Address Zero) is used to route the incoming data byte from the Logic PCB to one of two 8-bit latches, where data are held until new data are written to the same latch. If A0 is a logical zero at the time of a write to the audio PCB, the latch at location 2C will receive the data byte. If A0 is a logical one at this time, the latch at location 2D will receive the data byte instead.

The bits that comprise these data bytes are directly used as enables for the various sound generation circuits.

### C. Clock Divider

The clock divider simply divides the  $\phi_2$  (phase two) clock frequency downward approximately near 706 Khz to approximately 10 Khz. This puts the clock frequency in the proper range to generate the musical tone sequence used for the player (Wummel) image movement.

The clock divider consists of counters 1A and 1B, whose preload combination divides the  $\phi_2$  clock by 71.

#### D. Tone Sequence Generator

This generates the musical tone sequence used for the player (WUMMEL) image movement. The 10 Khz clock provided by counters 1A and 1B is further divided by counters 3A and 3B to a frequency determined by their preload supplied by PROM 2B.

PROM 2B is programmed to supply the necessary preloads, in sequence by address, to generate a half-cycle of desired tones. The addresses of the PROM are incremented by counter 2A, which counts once each time signal NOTE is set to a high (logical one) state. Setting NOTE high also enables the flip-flop segment 5D which receives the terminal count of the counters (from counter 3B). This terminal count is of short duration, so flip flop 5D simultaneously divides the frequency by two and creates a 50 % duty cycle (high time = low time) which is pleasant to the ear. The tone will continue until NOTE is set once again to a low (logical zero) state.

PROM 2B is programmed to supply two different tone sequences. One sequence begins the game and continues until the CPU sets signal UPPER to a high state. This causes the PROM to issue the preloads for the second of the two tone sequences. The second sequence is used when the CPU decides that a sufficient state of tension now exists in the play of the game.

#### E. White Noise Generator

This generates the white noise (noise across a wide bandwidth) that is used by the explosion/crash sound generator circuit.

This noise is created by amplifying electron agitation generated in a transistor junction (Q4) which is reverse biased to a degree that causes the junction to "break down".

Transistor Q5 forms a low impedance output source for this noise.

#### F. Explosion/Crash Sound Generator

The crash/explosion sound is generated by active-filtering the white noise, and gating it through to the summing amp at the selected time. The trailing edge of the crash/explosion sound is allowed to dissipate slowly (rather than an abrupt halt) due to the discharge of capacitors C35, C36 through resistor R24. The circuit is enabled by signal CRASH, and the trailing edge length of decay can be changed by the use of signal LONG. In this case, however, (TARG), LONG remains in an enabled state throughout the game.

#### G. Shoot Sound Generator

The SHOOT sound is actually a combination of a triangular wave tone and white noise.

The tone is created by VCO 4B. Its oscillating range is set by pot R10. When signal SHOOT is held low (logic zero state), transistor Q1 is turned on, developing a voltage across its emitter resistor R2. This voltage, applied to the control input of amplitude modulator 4A, inhibits the output of amplitude modulator 4A.

When SHOOT is set high, transistor Q1 turns off, enabling the Amplitude Modulator output. This also puts a virtual ground on one side of capacitor C29 and results in dragging the control voltage input of VCO 4B low, raising its frequency of oscillation.

The virtual ground at the control voltage input of VCO 4B lasts only as long as it takes C29 to charge up again, so the frequency out of VCO sweeps from high to low.

The tone is given the "hissing" sound by applying a small white noise signal to the base of transistor Q1, which varies the output amplitude.

When SHOOT is again set low, the output amplitude (out of 4A) decreases at a rate determined by the charge rate of capacitor C14.

#### H. Spectar (Special Target) Sound Generator

Consists of two halves of a 556 timer IC (5A), both configured in a free-running state.

Signal 5SPEC, when set low, enables both oscillators. The charge/discharge ramp at the THRESHOLD input of the first stage is coupled to the CONTROL VOLTAGE input of the second stage to provide a frequency varying tone out of the second stage. Signal 5WARN, when set high, provides a slowly varying frequency output, and when set low provides a rapidly varying frequency output.

#### I. Summing Amplifier and Integrator

Two segments of an LM324 operational amplifier are used here. The first is configured as a summing amplifier. It is the common point at which all the various sounds are algebraically added to become one signal which is the composite of all individually developed sounds. Thus this is also the location of the MASTER VOLUME control (R22).

The second LM324 segment is configured as an INTEGRATOR. Its purpose is to eliminate some of the higher frequencies, in order to make a more pleasant sound and also to aid in the prevention of oscillation due to those higher frequencies.

#### J. Audio Amplifier

The final audio amplifier is a single IC (6A) which is configured as a bridge amplifier. The composite audio signal is applied to the input of one of the two internal segments and the output swings in accordance with the input signal. The feedback on this segment is not only fed back to the inverting input of the same segment, but is also applied to the inverting input of the other segment. This creates a condition wherein one segment swings positive, and the other segment simultaneously swings in a negative direction, creating an output twice the voltage of a single segment.

Note that three types of audio amplifier IC's may be found in this position. They are all identical except for total power output and pinout. They are: LM377 DUAL 2W, LM378 Dual 4W, and LM 379 Dual 6W.

## II. LOGIC DESCRIPTION AND OPERATION

TARG uses a 6502 MICROPROCESSOR. For more detailed information on this processor, refer to MOSTEK publication #6500-10A, MCS Microcomputer Family Hardware Manual.

The memory in this system is mapped as follows:

0000-00FF	Base Page RAM
0100-01FF	Stack
0200-03FF	Scratch Pad RAM
1800-3FFF	Program ROM
4000-43FF	Screen RAM
4800-4FFF	Character Generator RAM
5000-503F	Wummel Image Horizontal Position
5040-507F	Wummel Image Vertical Position
5100	On Board Dip Switch (Read)
5100	Wummel Image Rotation Latch
5101	Switch Register
5103	Interrupt Register
5200	Audio Board Register
5201	Audio Board Register
FFF7-FFFF	Interrupt & Reset vectors

Note that this processor does not have a separate I/O structure. Rather, it treats I/O as if it were memory. Base page RAM is used for storage of dynamic variables during program execution. The processor uses stack RAM to hold return addresses and important data during subroutine execution. The program ROM is where the non-variable, actual game program is stored.

The screen RAM consists of 1K bytes which, when not accessed by the processor, are scanned by main timing to display 1024 squares in a matrix of 32 x 32. The data stored in the screen RAM then selects one of 256 (8-element-wide by 8-line-high) images in the character generator RAM. These 8 x 8 bit blocks fit together to form the playfield imagery. (Alphanumeric characters take one block each to be displayed). The Wummel and its missiles are each positioned by two sets of counters (horizontal and vertical). The actual imagery for these is generated by feeding the outputs of the counters, along with data from a special rotation latch, to the hardware moving object ROM. That ROM then places the correct image in the correct place on the screen. The processor controls this operation by preloading the counters and writing to the rotation latch during vertical retrace.

The processor reads data from the control or option switches by gating the data from the appropriate port onto the bus when the correct address is selected.



The processor controls the operation of the audio board by writing data onto the bus when the address for the audio board bus buffer is selected.

Interrupts can come from three different sources. The first is a synchronous hardware generated interrupt. This occurs regularly at the vertical rate and can be detected by reading the 5L256 bit on the interrupt condition latch. This interrupt is important for providing the processor with a known real time interval used to update the screen, time counters, image velocity rates, etc. The remaining event causing interrupts is the presence of a coin signal on either of the two coin inputs. These are obviously asynchronous and are discernable from each other and from the vertical rate interrupt by testing their respective bits on the interrupt condition latch.

Main address decoding is accomplished by using A15 through A5 inputs to a PROM. The 5 outputs of the PROM are further decoded into "blocks" in minimum increments of 2K. The signals associated with these blocks are enables for other address decoding circuits that "break up" those blocks. By using lower order address bits, the blocks break into smaller pieces giving peripheral devices a specific, unique address. This is accomplished by loading data from the screen RAM, character generator RAM and moving object ROM into parallel-in/serial-out data at 256 times the horizontal rate. This is the screen element rate. It therefore follows that 256 elements = 1 horizontal line and 256 horizontal lines make a full screen.




Figure 1:  
LOGIC BOARD BLOCK DIAGRAM  
TARGETM

### III. AUDIO ADJUSTMENTS

The following is a diagram of the audio board adjustments.




Figure 2. Audio Board Adjustments

## IV. POWER SUPPLY ADJUSTMENTS

1. Connect a voltmeter to the +5 and ground traces on the logic board.
2. Adjust the power supply potentiometer for  $+5.0 \pm .1$  VDC.




Figure 3. Power Supply Adjustment

## V. MECHANICAL ASSEMBLIES

## A. Control Panel

To service the Control Panel do the following:

1. Unplug the power cord.
2. Open and remove the back door.
3. From inside the cabinet, remove the upper three control panel nuts.
4. Open the coin door.
5. From the front of the cabinet, swing the control panel out and down; let it rest on the open coin door.
6. Check all terminal connections to the pushbuttons and the four-way control.




Figure 4: Control Panel


1 Carriage bolt	4 Control panel
2 Start buttons	5 Four-way joystick
3 Fire button	6 Control harness

### B. To Service the Four-way Joy Stick

The four-way joy stick is assembled with four long screws and spacers. Four pairs of spring steel cup washers surround the control stick, between the control panel and the top plate (see Figure 4). These cup washers bear against a disk welded to the control stick, and push the stick towards its center (rest) position. Four leaf switches on the bottom plate (activated by the control stick) signal lane changes to the logic board.

Figure 4: Four-way Joy Stick

- 1 flat head screws
- 2 control stick
- 3 upper plate
- 4 carriage bolt
- 5 flat washer
- 6 control panel
- 7 cup washer
- 8 spacer, short
- 9 kep nut
- 10 lower disk
- 11 spacer, long
- 12 switch plate (bottom plate)
- 13 kep nut
- 14 leaf switch
- 15 phillips screw




Do the following to service the Four-way Joy Stick:

1. Unplug the power cord.
2. Open the control panel by removing 3 black carriage bolts.
3. Check the harness connectors to each leaf switch.
4. Check the throw of each microswitch; the control stick should activate, but not bottom-out against, each switch.
5. If microswitches are broken or switch actuator bent, replace only with Exidy authorized parts. Do not use substitution.


C. To Remove the Monitor do the following:

1. Unplug the power cord.
2. Open and remove the back door or monitor access panel.
3. Unplug the harness connector from the monitor and the Monitor Power Connector.
4. Remove the four bolts from the monitor chassis flange mounts.
5. Lift the monitor up and slide it out of the cabinet.






NO.	QTY	DESCRIPTION	DATE	APPROVED
1	1	6502	5-6-80	[Signature]
2	1	6555		
3	1	7805		
4	1	74LS00		
5	1	74LS04		
6	1	74LS10		
7	1	74LS125		
8	1	74LS161		
9	1	74LS244		
10	1	74LS273		
11	1	74LS374		
12	1	74LS47		
13	1	74LS48		
14	1	74LS54		
15	1	74LS593		
16	1	74LS670		
17	1	74LS688		
18	1	74LS74		
19	1	74LS85		
20	1	74LS90		
21	1	74LS93		
22	1	74LS95		
23	1	74LS96		
24	1	74LS97		
25	1	74LS98		
26	1	74LS99		
27	1	74LS100		
28	1	74LS101		
29	1	74LS102		
30	1	74LS103		
31	1	74LS104		
32	1	74LS105		
33	1	74LS106		
34	1	74LS107		
35	1	74LS108		
36	1	74LS109		
37	1	74LS110		
38	1	74LS111		
39	1	74LS112		
40	1	74LS113		
41	1	74LS114		
42	1	74LS115		
43	1	74LS116		
44	1	74LS117		
45	1	74LS118		
46	1	74LS119		
47	1	74LS120		
48	1	74LS121		
49	1	74LS122		
50	1	74LS123		
51	1	74LS124		
52	1	74LS125		
53	1	74LS126		
54	1	74LS127		
55	1	74LS128		
56	1	74LS129		
57	1	74LS130		
58	1	74LS131		
59	1	74LS132		
60	1	74LS133		
61	1	74LS134		
62	1	74LS135		
63	1	74LS136		
64	1	74LS137		
65	1	74LS138		
66	1	74LS139		
67	1	74LS140		
68	1	74LS141		
69	1	74LS142		
70	1	74LS143		
71	1	74LS144		
72	1	74LS145		
73	1	74LS146		
74	1	74LS147		
75	1	74LS148		
76	1	74LS149		
77	1	74LS150		
78	1	74LS151		
79	1	74LS152		
80	1	74LS153		
81	1	74LS154		
82	1	74LS155		
83	1	74LS156		
84	1	74LS157		
85	1	74LS158		
86	1	74LS159		
87	1	74LS160		
88	1	74LS161		
89	1	74LS162		
90	1	74LS163		
91	1	74LS164		
92	1	74LS165		
93	1	74LS166		
94	1	74LS167		
95	1	74LS168		
96	1	74LS169		
97	1	74LS170		
98	1	74LS171		
99	1	74LS172		
100	1	74LS173		
101	1	74LS174		
102	1	74LS175		
103	1	74LS176		
104	1	74LS177		
105	1	74LS178		
106	1	74LS179		
107	1	74LS180		
108	1	74LS181		
109	1	74LS182		
110	1	74LS183		
111	1	74LS184		
112	1	74LS185		
113	1	74LS186		
114	1	74LS187		
115	1	74LS188		
116	1	74LS189		
117	1	74LS190		
118	1	74LS191		
119	1	74LS192		
120	1	74LS193		
121	1	74LS194		
122	1	74LS195		
123	1	74LS196		
124	1	74LS197		
125	1	74LS198		
126	1	74LS199		
127	1	74LS200		
128	1	74LS201		
129	1	74LS202		
130	1	74LS203		
131	1	74LS204		
132	1	74LS205		
133	1	74LS206		
134	1	74LS207		
135	1	74LS208		
136	1	74LS209		
137	1	74LS210		
138	1	74LS211		
139	1	74LS212		
140	1	74LS213		
141	1	74LS214		
142	1	74LS215		
143	1	74LS216		
144	1	74LS217		
145	1	74LS218		
146	1	74LS219		
147	1	74LS220		
148	1	74LS221		
149	1	74LS222		
150	1	74LS223		
151	1	74LS224		
152	1	74LS225		
153	1	74LS226		
154	1	74LS227		
155	1	74LS228		
156	1	74LS229		
157	1	74LS230		
158	1	74LS231		
159	1	74LS232		
160	1	74LS233		
161	1	74LS234		
162	1	74LS235		
163	1	74LS236		
164	1	74LS237		
165	1	74LS238		
166	1	74LS239		
167	1	74LS240		
168	1	74LS241		
169	1	74LS242		
170	1	74LS243		
171	1	74LS244		
172	1	74LS245		
173	1	74LS246		
174	1	74LS247		
175	1	74LS248		
176	1	74LS249		
177	1	74LS250		
178	1	74LS251		
179	1	74LS252		
180	1	74LS253		
181	1	74LS254		
182	1	74LS255		
183	1	74LS256		
184	1	74LS257		
185	1	74LS258		
186	1	74LS259		
187	1	74LS260		
188	1	74LS261		
189	1	74LS262		
190	1	74LS263		
191	1	74LS264		
192	1	74LS265		
193	1	74LS266		
194	1	74LS267		
195	1	74LS268		
196	1	74LS269		
197	1	74LS270		
198	1	74LS271		
199	1	74LS272		
200	1	74LS273		
201	1	74LS274		
202	1	74LS275		
203	1	74LS276		
204	1	74LS277		
205	1	74LS278		
206	1	74LS279		
207	1	74LS280		
208	1	74LS281		
209	1	74LS282		
210	1	74LS283		
211	1	74LS284		
212	1	74LS285		
213	1	74LS286		
214	1	74LS287		
215	1	74LS288		
216	1	74LS289		
217	1	74LS290		
218	1	74LS291		
219	1	74LS292		
220	1	74LS293		
221	1	74LS294		
222	1	74LS295		
223	1	74LS296		
224	1	74LS297		
225	1	74LS298		
226	1	74LS299		
227	1	74LS300		
228	1	74LS301		
229	1	74LS302		
230	1	74LS303		
231	1	74LS304		
232	1	74LS305		
233	1	74LS306		
234	1	74LS307		
235	1	74LS308		
236	1	74LS309		
237	1	74LS310		
238	1	74LS311		
239	1	74LS312		
240	1	74LS313		
241	1	74LS314		
242	1	74LS315		
243	1	74LS316		
244	1	74LS317		
245	1	74LS318		
246	1	74LS319		
247	1	74LS320		
248	1	74LS321		
249	1	74LS322		
250	1	74LS323		
251	1	74LS324		
252	1	74LS325		
253	1	74LS326		
254	1	74LS327		
255	1	74LS328		
256	1	74LS329		
257	1	74LS330		
258	1	74LS331		
259	1	74LS332		
260	1	74LS333		
261	1	74LS334		
262	1	74LS335		
263	1	74LS336		
264	1	74LS337		
265	1	74LS338		
266	1	74LS339		
267	1	74LS340		
268	1	74LS341		
269	1	74LS342		
270	1	74LS343		



**CHARACTER IMAGE STORAGE**  
 See Page 3 for  
 Alternative: RAM used  
 for PROGRAM generated  
 changeable imagery.



**PROM 4 SIGNAL SELECTION**  
 NO SHUNT USED FOR TARG

CHARACTER GENERATOR  
IMAGE STORAGE RAMS

For use with PROGRAM  
generated changeable imagery.

USED on "TARG"

VA9	15	VD7
VA8	16	VD6
VA7	17	VDS
VA6	1	VD4
VA5	2	2114
VA4	3	13C
VA3	4	
VA2	5	
VA1	6	
VA0	7	
CBCG1	8	
CSWR	10	

VA9	15	VD7
VA8	16	VD6
VA7	17	VD5
VA6	1	VD4
VA5	2	2114
VA4	3	14C
VA3	4	
VA2	5	
VA1	6	
VA0	7	
CBCG2	8	
CSWR	10	

VA9	15	VD3
VA8	16	VD2
VA7	17	VD1
VA6	1	VDD
VA5	2	RAM
VA4	3	2114
VA3	4	11C
VA2	5	
VA1	6	
VA0	7	
CBCG1	8	
CSWR	10	

VA9	15	VD3
VA8	16	VD2
VA7	17	VD1
VA6	1	VDD
VA5	2	RAM
VA4	3	2114
VA3	4	12C
VA2	5	
VA1	6	
VA0	7	
CBCG2	8	
CSWR	10	

6502 GAME LOGIC PCB

DATE: 4/23/68

DESIGNED BY: [Signature]





IMAGE STORAGE RAM

3 OF 8

REV: 1-3344-11




**PROGRAM MEMORY**



Configuration shown for "TARG"


Configuration shown for "3 VALTAR"

**DATA BUSS TERMINATION**  
Ringing Suppression









MOVING OBJECT ROTATION LATCH  
 OPTIM. SWITCH BUFFER  
 SELECTABLE OPTIONS SWITCH  
 A/D CONVERSION LATCH  
 A/D CONVERSION  
 NOT USED "TARG"  
 NOT USED "TARG"  
 NOT USED "TARG"  
 I/O DECODING  
 INTERRUPT DECODING  
 INTERRUPT CONDITION LATCH  
 CONTROL INPUT REGISTER BUFFER  
 AUDIO BOARD BUS BUFFER  
 DATA BUSS  
 CONTROL PORT LATCH  
 JUMPER USED FOR TARG  
 AUXILIARY COIN INPUT 50 Pence etc.


8

DATE	4-23-80
REV	6502
PROJECT	GAME LOGIC PCB
PCB	310 PORT 3
DESIGNER	AKA
CHECKED	
APPROVED	
808#	










NOTES:

- Jumpers shown indicate configuration for LM379. Amp dip switch used to change configuration to LM379 or LM378 pin configuration as shown.
- .75V Bypass Capacitors (0.1µF cer disc): C1-C5, C6, C8, C23, C24, C25, C27, C30, C33
- +12V Bypass Capacitors (33µF tantalum): C19, C20



NOTES: 1. All capacitance values show in microfarads (uF).

REVISIONS		
ZONE	LTR	DATE

DESCRIPTION	DATE	APPROVED


CONTRACT NO.			
APPROVALS	DATE		
DRAWN <i>DK</i>	26/11/78		
CHECKED			
MATERIAL			
FINISH			
DO NOT SCALE DRAWING			
NEXT ASSY			
APPLICATION			
USED ON			
SIZE	CODE IDENT NO.	DRAWING NO.	SHEET
B		77-3365-11	1 OF 1

UNLESS OTHERWISE SPECIFIED DIMENSIONS ARE IN INCHES FRACTIONS DECIMALS ANGLES	
± .005	± .001
± .010	± .002
± .020	± .005
± .030	± .010
± .040	± .015
± .050	± .020
± .060	± .025
± .070	± .030
± .080	± .035
± .090	± .040
± .100	± .045
± .110	± .050
± .120	± .055
± .130	± .060
± .140	± .065
± .150	± .070
± .160	± .075
± .170	± .080
± .180	± .085
± .190	± .090
± .200	± .095
± .210	± .100
± .220	± .105
± .230	± .110
± .240	± .115
± .250	± .120
± .260	± .125
± .270	± .130
± .280	± .135
± .290	± .140
± .300	± .145
± .310	± .150
± .320	± .155
± .330	± .160
± .340	± .165
± .350	± .170
± .360	± .175
± .370	± .180
± .380	± .185
± .390	± .190
± .400	± .195
± .410	± .200
± .420	± .205
± .430	± .210
± .440	± .215
± .450	± .220
± .460	± .225
± .470	± .230
± .480	± .235
± .490	± .240
± .500	± .245
± .510	± .250
± .520	± .255
± .530	± .260
± .540	± .265
± .550	± .270
± .560	± .275
± .570	± .280
± .580	± .285
± .590	± .290
± .600	± .295
± .610	± .300
± .620	± .305
± .630	± .310
± .640	± .315
± .650	± .320
± .660	± .325
± .670	± .330
± .680	± .335
± .690	± .340
± .700	± .345
± .710	± .350
± .720	± .355
± .730	± .360
± .740	± .365
± .750	± .370
± .760	± .375
± .770	± .380
± .780	± .385
± .790	± .390
± .800	± .395
± .810	± .400
± .820	± .405
± .830	± .410
± .840	± .415
± .850	± .420
± .860	± .425
± .870	± .430
± .880	± .435
± .890	± .440
± .900	± .445
± .910	± .450
± .920	± .455
± .930	± .460
± .940	± .465
± .950	± .470
± .960	± .475
± .970	± .480
± .980	± .485
± .990	± .490
± 1.000	± .495
± 1.010	± .500
± 1.020	± .505
± 1.030	± .510
± 1.040	± .515
± 1.050	± .520
± 1.060	± .525
± 1.070	± .530
± 1.080	± .535
± 1.090	± .540
± 1.100	± .545
± 1.110	± .550
± 1.120	± .555
± 1.130	± .560
± 1.140	± .565
± 1.150	± .570
± 1.160	± .575
± 1.170	± .580
± 1.180	± .585
± 1.190	± .590
± 1.200	± .595
± 1.210	± .600
± 1.220	± .605
± 1.230	± .610
± 1.240	± .615
± 1.250	± .620
± 1.260	± .625
± 1.270	± .630
± 1.280	± .635
± 1.290	± .640
± 1.300	± .645
± 1.310	± .650
± 1.320	± .655
± 1.330	± .660
± 1.340	± .665
± 1.350	± .670
± 1.360	± .675
± 1.370	± .680
± 1.380	± .685
± 1.390	± .690
± 1.400	± .695
± 1.410	± .700
± 1.420	± .705
± 1.430	± .710
± 1.440	± .715
± 1.450	± .720
± 1.460	± .725
± 1.470	± .730
± 1.480	± .735
± 1.490	± .740
± 1.500	± .745
± 1.510	± .750
± 1.520	± .755
± 1.530	± .760
± 1.540	± .765
± 1.550	± .770
± 1.560	± .775
± 1.570	± .780
± 1.580	± .785
± 1.590	± .790
± 1.600	± .795
± 1.610	± .800
± 1.620	± .805
± 1.630	± .810
± 1.640	± .815
± 1.650	± .820
± 1.660	± .825
± 1.670	± .830
± 1.680	± .835
± 1.690	± .840
± 1.700	± .845
± 1.710	± .850
± 1.720	± .855
± 1.730	± .860
± 1.740	± .865
± 1.750	± .870
± 1.760	± .875
± 1.770	± .880
± 1.780	± .885
± 1.790	± .890
± 1.800	± .895
± 1.810	± .900
± 1.820	± .905
± 1.830	± .910
± 1.840	± .915
± 1.850	± .920
± 1.860	± .925
± 1.870	± .930
± 1.880	± .935
± 1.890	± .940
± 1.900	± .945
± 1.910	± .950
± 1.920	± .955
± 1.930	± .960
± 1.940	± .965
± 1.950	± .970
± 1.960	± .975
± 1.970	± .980
± 1.980	± .985
± 1.990	± .990
± 2.000	± .995

SCHEMATIC	
UNIVERSAL POWER SUPPLY	
SCALE	
SHEET	1 OF 1




CONTROL PANEL HARNESS  
SCHEMATIC



- NOTES:
1. All wires 22 awg. insulated unless otherwise specified.
  2. ABSOLUTELY NO SUBSTITUTIONS ON SPECIFIED WIRE COLORS

COIN HARNESS SCHEMATIC  
(UNIVERSAL COIN HARNESS)



AC Line Cord Harness Assembly

PART #	DESCRIPTION	REFERENCE LOCATION
71-2070	AC line cord	PL1
60-6020	fuse holder	F1
60-6001	fuse 3AMP slow blo	F1
61-8048	3 pin molex recept	J1
61-8055	individual female pins	J1
88-4002	small tie wrap	
61-8051	fast-on push on terminals.8175"	E1-E2
61-8072	TFB butt splice	E3
	wire list attached	

TARG Audio Assembly

48-2321	741LS139	ID
48-2314	74LS374	2C,2D
48-2071	74LS112	3D
48-2308	74LS161	1A,2A,1B,3B,3A
48-2210	72748 (TI)	6D
48-2342	LM324	5B
48-2215	NE566	4B
48-2212	NE556	5A
48-2221	MC3340	4A
48-2211	LM379 (Dual 6 w audio AMP)	6A
48-2015	7407	4C
48-2302	741S04	IC 3C
47-3005	ZN3904	Q1,Q2,Q3,Q4,Q5
46-3030	IN4454	CR2,CR3,CR4,CR1
59-5110	2.2 K resistor 1/4w 5%	R7
59-5100	3.3 K resistor 1/4w 5%	R14
54-5021	100K potentiometer	R35
54-5019	10K potentiometer	R1,R10,R22,R23, R29,R38
59-5070	22K resistor 1/4 w 5%	R20,R30,R19, R31,R36,R37
59-5125	1K resistor 1/4 w 5%	R33,R40,R45,R13
59-5163	820K resistor 1/4w 5%	R41
59-5025	1meg ohm resistor 1/4w 5%	R9-R16,R17,R42, R47, R50
59-5055	47K resistor 1/4w 5%	R43
59-5080	10K resistor 1/4w 5%	R8,R12,R34,R41, R48
59-5140	100 ohm resistor 1/4w 5%	R44
59-5086	6.8K resistor 1/4w 5%	R11
59-5069	120K resistor 1/4w 5%	R4,R24,
59-5050	68K resistor 1/4w 5%	R3
59-5120	1.2K resistor 1/4w 5%	R2,R25,R5
59-5095	4.7K resistor 1/4w 5%	R21,R49,R6
59-5045	100K resistor 1/4w 5%	R28,R15
59-5040	150K resistor 1/4w 5%	R26



AC Line Cord Harness Assembly, cont.

PART #	DESCRIPTION	REFERENCE LOCATION
59-5030	560K resistor 1/4w 5%	R27
59-5065	33K resistor 1/4w 5%	R18,R39
23-4030	.22uf ceramic disk capacitor	C41,C44
23-4035	.1uf ceramic disk capacitor	C9,C12,C17,C31,C32 C34,C37,C42,C43
21-4015	6.8uf dipped tantalum capacitor 25v	C14,C21,C22,C36 C40,C46,C47,C50
21-4020	2.2uf dipped tantalum capacitor 15v	C48,C49
23-4070	22pf ceramic disk capacitor	C45
23-4060	.001uf ceramic disk capacitor	C11,C13
23-4050	.01f ceramic disk capacitor	C1,C2,C3,C4,C6,C7, C8,C16,C24,C25,C27 C23,C30,C33,C38, C39
21-4010	33uf dipped tantalum capacitor 25V	C19,C20,C28,C5,C29
22-4025	.47uf dipped tantalum capacitor 25v	C15,C10,C35
61-8042	10 pin female connector	J2,J3
68-3041	thermalloy 6072 heat sink	6A for use only with LM379
74-2506	4-40 x 1/4" machine screw	6A heatsink
72-3025	dip package shunt-16 pin amp p-n 435704-8	6B
74-5065	y:32 x 5/8" nylon standoff	between logic and audio PCB's
or		"
74-5075	6-32 x 1/2" nylon standoff	"
77-3371	TARG audio [bare] PCB	
47-3505	6-32 x V4 machine screw	board mounting
23-54040	.047uf ceramic disc cap	C76
48-9124-01	6331 PROM [MMI] program #HRA 2B-1	2B

Universal Power Supply PCB

77-3190	printed circuit board
20-4000	4000 uf 50v axial lead capacitor
21-4010	33uf 35v dip tantalum capacitor
21-4015	6.8uf 35v dip tantalum capacitor
46-3016	60SI diode
47-3004	MDA 970-I bridge rectifier
47-3041	2N3055 transistor
47-3011	2N6246 transistor
48-2337	7905T negative 5v LM320T-5 regulator
48-2217	7912T negative 12v LM320T-12 regulator
48-2338	7812T positive 12v LM340T-12 regulator
68-3041	thermalloy 6072 heat sink

Universal Power Supply PCB, cont.

PART #	DESCRIPTION	REFERENCE LOCATION
68-2038	thermally alloy 6015 heat sink	
61-8010	12 pin male molex	
74-2514	4-40 x 3/8 phillips pan head machine screw	
74-5216	#4 flat metal washer	
74-5191	#4-40 kep nut	

Monitor Isolation Transformer Assembly

FR 63-4029	isolation transformer midwest 773P7	
61-8058	molex connector 03-09-2032	AC input P22
61-8054	male molex pins 02-09-2118	P22
61-8057	molex connector 03-09-1023	AC to monitor J23
61-8055	female molex pins 02-09-1118	J23

6502 Game Logic PCB Assembly

48-2000	IC 7400	3D 15H
48-2005	IC 7402	1H 6H 8F
48-2010	IC 7404	ID 3F 4D 10F 11F
48-2015	IC 7407	2C
48-2020	IC 7408	5E
48-2332	IC 74LS11	3H
48-2035	IC 7420	2F
48-2316	IC 74LS21	12F 15E
48-2045	IC 7427	7F 2H
48-2055	IC 7432	6F
48-2067	IC 7474	IC 5H
48-2071	IC 74LS112	2E 6E
48-2307	IC 74LS138	5B 5D
48-2321	IC 74LS139	73 16H
48-2090	IC 74157	14A 14E
48-2095	IC 74161	1E 2D 4F 5F
48-2100	IC 74166	12B 12D 13D 14D 15D
48-2115	IC 74193	10E 12E 13F 15F 14F 16F 11E 13E
48-2328	IC 74LS241	8C 1A 3A 3B 4H 6B 7D 9B 9E 15A
48-2350	IC 74LS 245	3C 4C 6C 15B 13B
48-2314	IC 74LS 374	1F 14B 7C 8E
48-6502	6502 microprocessor	2A
48-2334	2114 [1Kx4] RAM	4A 5A 7B 8B 11C 12C 13C 14C
48-9125-01	2708 EPROM [1Kx8] HRL 110-1	11D [use w/ hdwe moving objects]
48-9099-01	6331 PROM [32x8]	6D

6502 Game Logic PCB Assembly, cont.

PART #	DESCRIPTION	REFERENCE LOCATION
48-9099-02	6331 PROM [32x8]	14H use w/ hdwe moving objects
48-9099-04	6301 PROM [256x4]	5C
46-3025	IN4002 diodes	8F 9E
59-5135	470 ohm resistor v4w 5%	1D
59-5120	1.2K ohm resistor 1/4w 5%	2C 7H
59-5115	1.8K ohm resistor 1/4w 5%	1C 2C
59-5110	2.2K ohm resistor 1/4w 5%	2A
59-5105	2.7K ohm resistor 1/4w 5%	1C 2C 5H
59-5095	4.7K ohm resistor 1/4w 5%	5H
59-5080	10K 1/4W 5% resistor	7H
51-0003	220ohm 1/4 w 5% 8 pin resistor sip	9E
51-0002	2.2K 1/4w 5% 8 pin resistor sip	16A
51-0001	4.7K 1/4w 5% 8 pin resistor sip	15A
51-0004	6.8K 1/4w 5% 8 pin resistor sip	14A
23-4033	.01mf ceramic disc capacitor	1D
23-4035	.1mf ceramic disc capacitor	air (per Assy dwg)
20-4011	6.8uf dipped tantalum capacitor 25v	1C 6E 15D 6H
20-4014	33uf dipped tantalum capacitor 25V	1C 2C
20-4005	470uf 10v electrolytic capacitor	10H
72-3025	dip shunt jumper paks 16 pin	4B 10B 10D 11B
72-3042	8pos dip switch	16A
45-3036	11.289 mhz crystal	1D
61-8041	10 pin male molex connector	16C 16E
61-8062	16 pin low profile dip sockets	3E 4E 5C 6C 14H
77-3361-14	printed circuit board	
61-8045	24 pin low profile dip sockets	9A 10A 11D 6A 7A 8A
61-8035	40 pin low profile dip socket	2A
61-3060	14 pin low profile dip socket	16B
48-9126-04	2716 EPROM programmed HRL 6A-1	6A
48-9126-03	2716 EPROM programmed HRL 7A-1	7A
48-9126-02	2716 EPROM programmed HRL 8A-1	8A
48-9126-01	2716 EPROM programmed HRL 9A-1	9A
48-9126-05	2716 EPROM programmed HRL 10A-1	10A

6502 Color Adapter PCB Assembly

PART #	DESCRIPTION	REFERENCE LOCATION
48-2080	IC 74151	5A 5B 5C
48-2305	IC 74LS74	1A
48-2321	IC 74LS139	2A
48-2079	IC 74148	2B
48-2341	IC 74LS86	1C 6A
48-2333	IC 74LS174	6B
20-4011	6.8uf dipped tantalum capacitor	C1
59-5136	resistor 330 ohm 1/4w 5%	R1THRU R10
59-5103	9 pin sip resistor pak 1Kohm	3A 3B 3C
23-4033	.01uf ceramic disc capacitor	C2 C4 C5 C6
61-8203	10 pin male molex connector .156 center	P2
61-8127	14 pin socket stan-profile w/lock	J1
77-3373	printed circuit board	