

Partner Processor Beep Test

Access any c.o. line on the Partner system and dial Feature #1. You will hear a series of beep tones. Use the following chart to identify your Partner processor.

<u>Beeps</u>	<u>System</u>
1	Basic R1
3	Basic R2
1/3	Basic R3.1
2/3	Basic R4
4/1	Basic R4.1
2	Partner Plus R1
4	Partner Plus R2
2/4	Partner Plus R3
1/2	Partner Plus R3.1
3/2	Partner Plus R4
4/2	Partner Plus R4.1
2/2/1	Partner II R1
2/2	Partner II R2
3/1	Partner II R3
1/4	Partner II R3.1
3/3	Partner II R4
3/4	Partner II R4.0.1
4/3	Partner II R4.1
5/1	ACS R1
5/2	ACS R2
5/3	ACS R3
5/4	ACS R4
5/5	ACS R5
5/6	ACS R6