


# Panasonic

# KX-TCA88HA

## HANDS-FREE HEADSET



### [CONNECTION]

Plug the Headset into a Panasonic cordless phone for hands-free conversations (see diagram A).

### [HOW TO USE]

1. Place the Headset on your head and attach the clip to the desired position (see diagram B).
  - The side without an earpiece should rest comfortably against the side of your head, above your ear.
2. Adjust the Microphone to a comfortable position (see diagram C).
  - Place the Microphone near your mouth.

### [NOTE]

- Do not use this Headset near water—for example, near a bathtub, washbowl, kitchen sink, or the like.
- Do not remove the sponge-covered Microphone while talking.
- Hearing aid compatible.

\* The KX-TCA88HA headset may not work with the Panasonic 900 MHz Digital Spread Spectrum Cordless Phones.

### [CONEXIÓN]

Conecte el audífono para conversaciones con manos libres en el auricular de su teléfono inalámbrico de Panasonic (Véase diagrama A).

### [USO DE LOS AURICULARES]

1. Póngase el auricular en la cabeza y coloque la presilla (Véase diagrama B).
  - El lado sin pieza auricular deberá apoyarse confortablemente contra el lado de su cabeza por encima de su oído.
2. Ajuste el micrófono en una posición confortable (Véase diagrama C).
  - Ponga el micrófono cerca de su boca.

### [NOTA]

- No utilice este auricular cerca del agua, por ejemplo, cerca de una bañera, palangana, fregadero de cocina o algo similar.
- No extraiga la esponja protectora del micrófono mientras esté hablando.
- Aparato auditivo compatible.

\* El audífono KX-TCA88HA puede no funcionar con el teléfono inalámbrico de 900 MHz de Amplio Espectro Digital (Digital Spread Spectrum) de Panasonic.

PANASONIC CONSUMER ELECTRONICS COMPANY,  
DIVISION OF MATSUSHITA ELECTRIC CORPORATION OF AMERICA  
One Panasonic Way  
Secaucus, New Jersey 07094

PANASONIC SALES COMPANY,  
DIVISION OF MATSUSHITA ELECTRIC OF PUERTO RICO, INC.,  
Ave. 65 de Infantería, Km. 9.5 San Gabriel Industrial Park  
Carolina, Puerto Rico 00985

## Panasonic Accessory Products Limited Warranty

### Limited Warranty Coverage

If your product does not work properly because of a defect in materials or workmanship, Panasonic Consumer Electronics Company or Panasonic Sales Company (collectively referred to as "the warrantor") will, for the length of the period indicated on the chart below, which starts with the date of original purchase ("Limited Warranty period"), at its option either (a) repair your product with new or refurbished parts, or (b) replace it with a new or a refurbished product. The decision to repair or replace will be made by the warrantor.

Parts	Labor
Ninety (90) Days	Ninety (90) Days

During the "Labor" Limited Warranty period there will be no charge for labor. During the "Parts" Limited Warranty period, there will be no charge for parts. You must mail-in your product during the Limited Warranty period. This Limited Warranty only applies to products purchased and serviced in the United States or Puerto Rico. This Limited Warranty is extended only to the original purchaser and only covers products purchased as new. A purchase receipt or other proof of the original purchase date is required for Limited Warranty service.

To obtain service in the USA please contact:  
**Panasonic Services Company, Panasonic Plus Department**  
20421 84th Avenue South Kent, WA 98032  
Tel: 1-800-833-9626 Fax: 1-800-237-9080

For hearing or speech impaired TTY users, TTY: 1-877-833-8855

To obtain service in Puerto Rico call **Panasonic Sales Company**  
Tel: (787)-750-4300 or fax (787)-768-2910.

### Limited Warranty Limits And Exclusions

This Limited Warranty ONLY COVERS failures due to defects in materials or workmanship, and DOES NOT COVER normal wear and tear or cosmetic damage. The Limited Warranty ALSO DOES NOT COVER damages which occurred in shipment, or failures which are caused by products not supplied by the Limited warrantor, or failures which result from accidents, misuse, abuse, neglect, mishandling, misapplication, alteration, faulty installation, set-up adjustments, misadjustment of consumer controls, improper maintenance, power line surge, lightning damage, modification, or commercial use (such as in a hotel, office, restaurant, or other business), rental use of the product, service by anyone other than a Factory Servicenter or other Authorized Service, or damage that is attributable to acts of God.

**THERE ARE NO EXPRESS WARRANTIES EXCEPT AS LISTED UNDER "LIMITED WARRANTY COVERAGE". THE WARRANTOR IS NOT LIABLE FOR INCIDENTAL OR CONSEQUENTIAL DAMAGES RESULTING FROM THE USE OF THIS PRODUCT, OR ARISING OUT OF ANY BREACH OF THIS LIMITED WARRANTY.** (As examples, this excludes damages for lost time, travel to and from the servicer. The items listed are not exclusive, but are for illustration only.) **ALL EXPRESS AND IMPLIED WARRANTIES, INCLUDING THE WARRANTY OF MERCHANTABILITY, ARE LIMITED TO THE PERIOD OF THE LIMITED WARRANTY.**

Some states do not allow the exclusion or limitation of incidental or consequential damages, or limitations on how long an implied Limited Warranty lasts, so the exclusions may not apply to you.

This Limited Warranty gives you specific legal rights and you may also have other rights which vary from state to state. If a problem with this product develops during or after the Limited Warranty period, you may contact your dealer or Servicenter. If the problem is not handled to your satisfaction, then write to the warrantor's Consumer Affairs Department at the addresses listed for the warrantor.

**PARTS AND SERVICE WHICH ARE NOT COVERED BY THIS LIMITED WARRANTY ARE YOUR RESPONSIBILITY.**



KX-TCA88HA

UPC



0 37988 47372 4



Distributed by Panasonic Consumer Electronics Company  
Division of Matsushita Electric Corp. of America, Secaucus, NJ 07094  
Made in China  
[www.panasonic.com](http://www.panasonic.com)

© PQPK14031YA