Panasonic

Easa-PhoneKey Telephone System

VA-208

Operational Procedures List

(For the details, refer to the operating instructions)

INTERCOM COMMUNICATION

	ITEM			SEQUENCE	REMARKS	
Individual access to intercom voice		→ Intercom No. x		• 1 ~ 8 are available for intercom No.		
Temporarily holding intercom			< Intercom busy HOLD	> HOLD < Reanswering>		
Transferring intercom to another party			1	> HOLD → Intercom No. → sation → CONF →	Intercom conference among three parties is also available.	
Intercom pilot answering			$\rightarrow \boxed{\times} \boxed{\times}$			
ion	When answer	tele-	idicator lights	~		
hone	phone with o	loor- one. After INT	T indicator is OFF $\longrightarrow \pm \rightarrow 1$ or 2		Doorphone	
000		ing through the thout doorphone	* → [#] → 1]	or [2]		
Ali	Extern	al paging only.	> → # → 9			
paging	Simulatan and exterr	eous telephone on al paging	Use 🛱 🛱 for answering			

Cone-Touch One Touch Button, ... Operation by the party,

ECOL COMMUNICATION

ITEM			SEQUENCE	REMARKS
Making a call		Normal	COL → Telephone No. → <answering> → Telephone No.</answering>	The telephone call is also enabled by lifting off Handset or by pressing SPKR Button
		Redialing	COL → REDIAL	instead of directly pressing Line Selector Button of the Telephone number.
Auto Dialing	Common	Dialing	COL → AUTO → Dialing Button XX	• 0 0 ~ 8 7 are available fo Dialing Button X X .
		Emergency call	COL→Emergency	88~89 are assigned for Emergency Call.
		Storing	$\begin{array}{c} \hline \text{SPKR} \rightarrow \boxed{\text{AUTO}} \rightarrow \text{Dialing Button } \boxed{x} \rightarrow \\ \hline \text{Telephone No.} \rightarrow \boxed{\text{CONF}} \rightarrow \boxed{\text{SPKR}} \\ \hline \end{array}$	 Reform the storing operation through the telephone baring Intercom No.1.
	Individual	Dialing	COL → One-Touch Button	One-Touch Buttons of are available. Dialing is enabled only by the telephone through which the numbers were stored.
		Storing	SPKR → AUTO → One-Touch Button → Telephone No. → CONF → SPKR	
Receiving a call	When answering through th telephone with incoming ringing tone.			
		wering through without incomone.		

ITEM			SEQUENCE	REMARKS
Temporarily holding the CO line			< COL Busy > HOLD	When using another COL or Intercom after holding one line, perform the normal operation for COL communi- cation or Intercom Communi- cation.
Transferring	Simple transfer		$<$ COL Busy $>$ HOLD $\rightarrow \mathcal{R} \rightarrow$ Call notification $\rightarrow \hat{\otimes}$ COL	
another party	Automatic transfer			COL Conference among three parties is also available.
Transferring DTMF signal			< After Conversation > ⋈ → #	 Enabled only by the outpulse dial line. Clearing can be done by just hanging up the handset.
Interruption to COL call			COL to be interrupted	
night transfer setting			SPKR → # → 6	The clearing operation is the same as the setting operation.

.... Lifting off Handset, Hanging up (returning) Handset, COL Line Selector Button, One-Touch One-Touch Button, Emergency Emergency Button, Operation by the party,