

Model 3 Correction Codes. Codes are updated every week and are valid as of 5/20/2022.

Correction Code	Name	FRT	Model
00000010	Remote – Education	0.25	Model 3
00003064	Perform Final Check (CN)	0	Model 3
00004935	Perform Vehicle Inspection for Spring Festival holiday (CN Only)	0.2	Model 3
00008598	Tesla Body Repair - Menu Pricing	1	Model 3
00020003	Firmware Update	0.05	Model 3
00020007	Firmware Update - Garage	0.05	Model 3
00020008	Firmware Redeploy - Toolbox	0.05	Model 3
00020010	Remote – Known Characteristic of Current Firmware	0.25	Model 3
00020018	Software Reinstall	0.05	Model 3
00020020	Remote – Over the Air Update	0.25	Model 3
00022008	User Data (Factory Reset)	0.05	Model 3
00030007	Enable Model 3 AWD Acceleration Boost	0	Model 3
00030017	Enable Model 3 SR / SR+ Rear Seat Heater OTA Upgrade	0	Model 3
00030018	Enable Model 3 SR / SR+ Winter Package OTA Upgrade	0	Model 3
00030100	PDI (Without Test Drive)	0.3	Model 3
00030300	Perform North Carolina State Inspection	0.1	Model 3
00030400	Courtesy Inspection	0.1	Model 3
00030500	Perform State Inspection - Texas	0.1	Model 3
00030600	Perform China Safety Inspection	1	Model 3
00030700	Perform General Inspection	1.2	Model 3
00030800	Perform Belgium Safety Inspection	1	Model 3
00030900	Perform Hawaii State Inspection	0.35	Model 3
00031000	Perform New York State Inspection	0.2	Model 3
00031100	Perform Missouri State Inspection	0.25	Model 3
00031300	Vehicle Transfer Inspection	0.1	Model 3
00031500	Perform Nova Scotia Provincial Motor Vehicle Inspection	0.5	Model 3
00031600	Norway EU Inspection Control	0.8	Model 3
00031700	Norway EU Post Inspection Control	0.4	Model 3
00032000	Used Vehicle Inspection	1.2	Model 3
00032100	Used Vehicle Final Quality Check	0.3	Model 3
00032200	Pre-Loaner Vehicle Inspection	1	Model 3
00032500	Shaken Inspection (Japan)	2.4	Model 3
00032700	Perform Germany MOT Pre-Inspection	0.4	Model 3
00032800	Perform Germany MOT Post-Inspection	0.4	Model 3
00034000	Perform Total Loss Vehicle (Soaking in Water) Inspection (CN only)	32	Model 3
00037000	Perform Final Inspection China	0.25	Model 3
00038000	Global Press Vehicle inspection	5.1	Model 3
00039000	Used Vehicle Intake Inspection (UVIS Only)	0	Model 3
00039100	Extend Warranty Agreement Inspection (China)	0.75	Model 3
00040100	Perform Validation Test Drive	0.3	Model 3
00040900	Virginia Safety Inspection	0.5	Model 3
00041000	Annual Service Inspection (Japan Only)	0	Model 3
00041100	NSW e-Safety Inspection (Pink Slip)	0.3	Model 3
00041110	NSW e-Safety Inspection (Blue Slip)	0.7	Model 3
00042000	Warrant of Fitness - New Zealand	0.75	Model 3
00070018	Vehicle Sanitation - Tunap (Basic Package)	0.2	Model 3
00100004	General Diagnosis	0.5	Model 3
00100014	General Diagnosis - No Trouble Found	0.1	Model 3
00100024	Remote Diagnosis	0.3	Model 3
00100034	Repair Plan Confirmation	0.05	Model 3
1027521	Assistance with Refund of Reservation		Model 3
1524001	Model 3 Wipe Package Tray(test)	0.35	Model 3
7000005	Mobile Ranger Service (includes travel)	0	Model 3
7000022	Fluid Disposal (Remove & Replace)	0.5	Model 3
7000030	Parts Not Available - Add to future service visit.	0	Model 3
7000060	Valet Service	0	Model 3
7000070	Tesla (Internal Loaner or Rental)	0	Model 3
7000090	Roadside Assistance - Tow	0	Model 3

7000200	Extended Service Agreement - Deductible	1	Model 3
7000201	Service Loaner Damage - Deductible	1	Model 3
7000400	Shipping/Handling	0	Model 3
7000405	Vehicle Storage	0	Model 3
7000410	Placement of Documentation in Glove Box	0.05	Model 3
7007100	Towing - Sublet	0	Model 3
7007200	Parking - Sublet	0	Model 3
7007300	Other – Sublet	0	Model 3
7100001	NO LABOR PERFORMED	0	Model 3
7100002	Seasonal Tire Storage	1	Model 3
10000105	Jack Mode Activation	0.05	Model 3
10001105	Raise Vehicle - 2 Stands	0.4	Model 3
10010007	Tesla Body Repair - Paint Supplies	0	Model 3
10010008	Tesla Body Repair - Miscellaneous Labor	0	Model 3
10010009	Storage Fees	1	Model 3
10010010	Tesla Body Repair - Frame Labor	0	Model 3
10010011	Tesla Body Repair - Structural	0	Model 3
10010012	Tesla Body Structural--Sheet Metal Quotation	1	Model 3
10010013	Tesla Body Structural--Vehicle Dismantling	1	Model 3
10010014	Tesla Body Structural--Sheet Metal Repair	1	Model 3
10010015	Tesla Body Structural--Reassemble Parts	1	Model 3
10010016	Tesla Body Repair - Aluminum Labor	0	Model 3
10011001	Fascia Assembly - Front (Remove & Install)	0.35	Model 3
10011002	Fascia Assembly - Front (Remove & Replace)	0.75	Model 3
10011008	Fascia Assembly - Front (Swap)	0.6	Model 3
10011011	Cover - Tow Hook - Front (Remove & Install)	0.05	Model 3
10011012	Bracket - Fascia To Fender - LH (Remove & Replace)	0.1	Model 3
10011058	Fascia Assembly - Front (Refinish)	4.5	Model 3
10011102	Bumper Beam - Front (Remove & Replace)	0.8	Model 3
10011112	Bracket - Fascia To Fender - RH (Remove & Replace)	0.1	Model 3
10011202	Ankle Catcher Assembly (Remove & Replace)	0.8	Model 3
10011502	Grille - Fascia - Front (Remove & Replace)	0.5	Model 3
10011602	Extrusion - Bumper Beam - Active Hood- Front (Remove and Replace)	0.6	Model 3
10011702	Foam - Bumper Beam - Front (Remove & Replace)	0.4	Model 3
10012202	Valance - Front Fascia (Remove & Replace)	0.4	Model 3
10012402	Crush Can - Front - LH (Remove & Replace)	1.05	Model 3
10012412	Crush Can - Front - RH (Remove & Replace)	1.05	Model 3
10012802	Fascia Assembly - Rear - Upper (Remove & Replace)	0.6	Model 3
10012902	Fascia Assembly - Rear - Lower (Remove & Replace)	0.6	Model 3
10013001	Fascia Assembly - Rear (Remove & Install)	0.5	Model 3
10013002	Fascia Assembly - Rear (Remove & Replace)	0.6	Model 3
10013008	Fascia Assembly - Rear (Swap)	0.8	Model 3
10013102	Bumper Beam - Rear (Remove & Replace)	0.9	Model 3
10014002	Cover - Tow Hook - Front (Remove & Replace)	0.05	Model 3
10014302	Bracket - Rear - Center (Remove & Replace)	0.85	Model 3
10014602	Air Extractor - LH (Remove & Replace)	0.75	Model 3
10014902	Air Extractor - RH (Remove & Replace)	0.75	Model 3
10016102	Bracket - Rear Wing - LH (Remove & Replace)	0.55	Model 3
10016202	Bracket - Rear Wing - RH (Remove and Replace)	0.55	Model 3
10016302	Bracket - Rear Wing - Pair (Remove & Replace)	0.6	Model 3
10017102	Bracket - Taillight - LH (Remove & Replace)	0.75	Model 3
10018102	Bracket - Fascia Center To Fender - LH (Remove and Replace)	0.4	Model 3
10018202	Bracket - Fascia Center To Fender - RH (Remove and Replace)	0.35	Model 3
10100008	Tesla Body Repair - Mechanical Labor	0	Model 3
10100301	Hood Assembly (Remove & Install)	0.15	Model 3
10100302	Hood Assembly (Remove & Replace)	0.4	Model 3
10101001	Bracket - Taillight - LH (Remove & Install)	0.75	Model 3
10101002	Carrier - Front End (Remove & Replace)	1.3	Model 3
10101012	Carrier - Front End (Heat Pump) (Remove & Replace)	0.9	Model 3
10101602	Bracket - Crash Can - SubFrame - LH (Remove & Replace)	0.65	Model 3

10101702	Bracket - Crash Can - RH (Remove & Replace)	0.65	Model 3
10102202	Brace - Shock Tower (Remove & Replace)	0.6	Model 3
10102212	Brace - Shock Tower (Heat Pump) (Remove & Replace)	0.5	Model 3
10103001	Fender Assembly - Front - LH (Remove & Install)	0.85	Model 3
10103002	Fender Assembly - Front - LH (Remove & Replace)	0.95	Model 3
10103101	Fender Assembly - Front - RH (Remove & Install)	0.85	Model 3
10103102	Fender Assembly - Front - RH (Remove & Replace)	0.95	Model 3
10106001	Door Assembly - Front - LH (Remove & Install)	0.3	Model 3
10106002	Door Assembly - Front - LH (Remove & Replace)	1.15	Model 3
10106052	Check Strap - Door - Front - LH (Remove and Replace)	0.25	Model 3
10106101	Door Assembly - Front - RH (Remove & Install)	0.3	Model 3
10106102	Door Assembly - Front - RH (Remove & Replace)	1.15	Model 3
10106152	Check Strap - Door - Front - RH (Remove and Replace)	0.25	Model 3
10106501	Door Assembly - Rear - LH (Remove & Install)	0.15	Model 3
10106502	Door Assembly - Rear - LH (Remove & Replace)	0.85	Model 3
10106552	Check Strap - Door - Rear - LH (Remove and Replace)	0.5	Model 3
10106601	Door Assembly - Rear - RH (Remove & Install)	0.15	Model 3
10106602	Door Assembly - Rear - RH (Remove & Replace)	0.85	Model 3
10106652	Check Strap - Door - Rear - RH (Remove and Replace)	0.5	Model 3
10107001	Trunk (Remove & Install)	0.4	Model 3
10107002	Trunk (Remove & Replace)	0.7	Model 3
10107101	Power Trunk (Remove & Install)	0.35	Model 3
10107102	Power Trunk (Remove & Replace)	0.75	Model 3
10108008	Color Matching / Tint Refinement (Refinish)	0.5	Model 3
10108108	Cover Car Exterior (Refinish)	0.3	Model 3
10108208	Corrosion Protection (Refinish)	0.3	Model 3
10108500	Create Imprint of VIN	0.1	Model 3
10108608	Tesla Body Repair - Body Labor	0	Model 3
10108808	Tesla Body Repair - Sublet	0	Model 3
10109008	Structural Body Repair	0	Model 3
10109108	Non-Structural Body Repair	0	Model 3
10109608	Tesla Body Repair - Insurance Pay	0	Model 3
10114863	Model 3 Powered Liftgate Retrofit	1.45	Model 3
10182019	Customer Generated Quote - Issue (Transaction) Resolved - Bound		Model 3
10200108	Glass Chip Repair - Windshield	0.4	Model 3
10200301	Windshield (Vehicles with 2nd Generation or Later Autopilot Hardware) (Remove & Install)	2.25	Model 3
10200302	Windshield (Remove & Replace)	1.9	Model 3
10200312	Windshield (Reuse Humidity and Temperature Sensor) (Remove & Replace)	2.15	Model 3
10200348	Windshield (Clean Camera Area)	0.1	Model 3
10203001	Glass - Rear Quarter - LH (Remove & Install)	0.8	Model 3
10203002	Glass - Rear Quarter - LH (Remove & Replace) (Requires Urethane and Primer. Reference TBX Article # 55577)	0.7	Model 3
10203101	Glass - Rear Quarter - RH (Remove & Install)	0.8	Model 3
10203102	Glass - Rear Quarter - RH (Remove & Replace)	0.7	Model 3
10204001	Glass - Backlight (Remove & Install)	1.75	Model 3
10204040	Roof Glass Inspection - Remove & Replace Roof Glass	1.5	Model 3
10204102	Glass - Backlight (Remove & Replace)	1.15	Model 3
10204111	Glass - Backlight (Heat Pump) (Remove & Install)	1.75	Model 3
10204112	Glass - Backlight (Heat Pump) (Remove & Replace)	1.25	Model 3
10205002	Glass - Roof - Fixed (Remove & Replace)	1.35	Model 3
10205102	Seal - Trunk Flip - Backlight (Remove & Replace)	0.55	Model 3
10206002	Sensor - Relative Humidity and Temperature (Remove & Replace)	0.25	Model 3
10209628	Roof Glass Inspection - No Issues Found	0.15	Model 3
10300020	Touch Up Paint - Apply - 0.2	0.2	Model 3
10300040	Touch Up Paint - Apply - 0.4	0.4	Model 3
10300060	Touch Up Paint - Apply - 0.6	0.6	Model 3
10300250	Paint Defects - Denib/Polish - 0.25	0.25	Model 3
10300500	Paint Defects - Denib/Polish - 0.5	0.5	Model 3
10301000	Paint Defects - Denib/Polish - 1	1	Model 3
10302008	Clean Up Water Ingress	0	Model 3
10303025	Dent Repair - Paintless - 0.25	0.25	Model 3

10303050	Dent Repair - Paintless - 0.5	0.5	Model 3
10303100	Dent Repair - Paintless - 1	1	Model 3
11330012	Bracket - Active Hood Strut - LH (Remove & Replace)	0.3	Model 3
11330022	Bracket - Active Hood Strut - RH (Remove & Replace)	0.3	Model 3
11330052	Bracket - Passive Hood Strut - LH (Remove & Replace)	0.25	Model 3
11330092	Bracket - Passive Hood Strut - RH (Remove & Replace)	0.25	Model 3
11330302	Hinge - Hood - LH (Remove & Replace)	0.6	Model 3
11330402	Hinge - Hood - RH (Remove & Replace)	0.6	Model 3
11330502	Gas Strut - Hood - LH (Remove & Replace)	0.05	Model 3
11330602	Gas Strut - Hood - RH (Remove & Replace)	0.05	Model 3
11330702	C-Clips - Strut - Hood - LH (Remove and Replace)	0.05	Model 3
11330712	C-Clips - Strut - Trunk - LH (Remove and Replace)	0.05	Model 3
11330812	C-Clips - Strut - Trunk - RH (Remove and Replace)	0.05	Model 3
11331522	Actuator - Active Hood Strut - LH (Remove & Replace)	0.25	Model 3
11332392	Replace Trunk Power Strut (Model 3 Power Trunk Retrofit) (CN Only)	0.5	Model 3
11332602	Hinge - Power Trunk - LH (Remove & Replace)	0.25	Model 3
11332702	Hinge - Power Trunk - RH (Remove & Replace)	0.25	Model 3
11332802	Strut Reinforcement - Hood - LH (Remove and Replace)	0.05	Model 3
11333502	Power Strut - Trunk (Remove & Replace)	0.05	Model 3
11333902	Replace Power Trunk ECU (Model 3 Power Trunk Retrofit) (CN Only)	0.1	Model 3
11334002	Gas Strut - Trunk - LH (Remove & Replace)	0.1	Model 3
11334102	Gas Strut - Trunk - RH (Remove & Replace)	0.1	Model 3
11335602	Hinge - Trunk - LH (Remove & Replace)	0.25	Model 3
11335702	Hinge - Trunk - RH (Remove & Replace)	0.8	Model 3
11336402	Hinge - Door - Front - Upper - LH (Remove & Replace)	0.2	Model 3
11336502	Hinge - Door - Front - Upper - RH (Remove & Replace)	0.2	Model 3
11336602	Hinge - Door - Front - Lower - LH (Remove & Replace)	0.15	Model 3
11336702	Hinge - Door - Front - Lower - RH (Remove & Replace)	0.15	Model 3
11336802	Hinge - Door - Rear - Upper- LH (Remove & Replace)	0.11	Model 3
11336902	Hinge - Door - Rear - Upper - RH (Remove & Replace)	0	Model 3
11337002	Hinge - Door - Rear - Lower - LH (Remove & Replace)	0.2	Model 3
11337102	Hinge - Door - Rear - Lower- RH (Remove & Replace)	0.2	Model 3
11350010	Latch Integrity Check	0.5	Model 3
11350020	Actuator Integrity Check	0.5	Model 3
11350302	Latch - Hood (Single Actuator System) (Remove & Replace)	0.1	Model 3
11350402	Actuator - Latch - Hood (Single Actuator System) (Remove & Replace)	0.15	Model 3
11351002	Latch - Door - Front - LH (Remove & Replace)	0.35	Model 3
11351102	Latch - Door - Front - RH (Remove & Replace)	0.35	Model 3
11351802	Latch - Door - Lubricate (Remove & Replace)	0.05	Model 3
11352002	Latch - Hood (Remove & Replace)	0.2	Model 3
11352702	Switch - Power Trunk - Interior (Remove and Replace)	0.1	Model 3
11352902	Striker - Hood (Remove & Replace)	0.05	Model 3
11353002	Striker - Door - Front - LH (Remove & Replace)	0.05	Model 3
11353102	Striker - Door - Front - RH (Remove & Replace)	0.05	Model 3
11353402	Striker - Trunk (Remove & Replace)	0.1	Model 3
11353702	Latch - Door - Rear - LH (Remove & Replace)	0.5	Model 3
11353802	Latch - Door - Rear - RH (Remove & Replace)	0.5	Model 3
11354002	Striker - Door - Rear - LH (Remove & Replace)	0.05	Model 3
11354102	Striker - Door - Rear - RH (Remove & Replace)	0.05	Model 3
11355002	Latch - Trunk (Remove & Replace)	0.1	Model 3
11355012	Latch - Cinch - Trunk (Remove & Replace)	0.1	Model 3
11355202	Actuator - Latch - Hood - Primary (Remove & Replace)	0.2	Model 3
11355302	Actuator - Latch - Hood - Secondary (Remove & Replace)	0.15	Model 3
11355602	Switch - Exterior Release - Trunk (Remove & Replace)	0.1	Model 3
11358005	Manual Release - Door - Rear - LH (Actuate)	0.05	Model 3
11359005	Manual Release - Door - Rear - RH (Actuate)	0.05	Model 3
11359602	Replace Trunk Latch (Model 3 Power Trunk Retrofit) (CN Only)	0.1	Model 3
11451002	Handle - Exterior Release - Door - Front - LH (Remove & Replace)	0.6	Model 3
11451102	Handle - Exterior Release - Door - Front - RH (Remove & Replace)	0.6	Model 3
11452002	Handle - Exterior Release - Door - Rear - LH (Remove & Replace)	0.5	Model 3

11452102	Handle - Exterior Release - Door - Rear - RH (Remove & Replace)	0.5	Model 3
11455002	Hall Sensor - Exterior Release - Door - Front - LH (Remove & Replace)	0.6	Model 3
11455102	Hall Sensor - Exterior Release - Door - Rear - LH (Remove & Replace)	0.5	Model 3
11456002	Hall Sensor - Exterior Release - Door - Front - RH (Remove & Replace)	0.6	Model 3
11456102	Hall Sensor - Exterior Release - Door - Rear - RH (Remove & Replace)	0.5	Model 3
11500100	Door Glass - Front - LH (Adjust)	0.45	Model 3
11500102	Door Glass - LH - Front (Remove & Replace)	0.35	Model 3
11500200	Door Glass - Front - RH (Adjust)	0.45	Model 3
11500202	Door Glass - RH - Front (Remove & Replace)	0.35	Model 3
11500300	Door Glass - Rear - LH (Adjust)	0.35	Model 3
11500302	Door Glass - LH - Rear (Remove & Replace)	0.3	Model 3
11500400	Door Glass - Rear - RH (Adjust)	0.35	Model 3
11500402	Door Glass - RH - Rear (Remove & Replace)	0.3	Model 3
11501006	Window Guide Rail - Front - LH	0.1	Model 3
11501106	Window Guide Rail - Front - RH	0.1	Model 3
11501202	Window Guide Rail - Rear - LH (Remove & Replace)	0.1	Model 3
11501302	Window Guide Rail - Rear - RH (Remove & Replace)	0.1	Model 3
11501908	Clean Up Broken Glass	0	Model 3
11502000	Window Regulator - Front - LH (Recalibrate)	0.1	Model 3
11502002	Window Motor/Regulator Assembly - Front - LH (Remove & Replace)	0.65	Model 3
11502100	Window Regulator - Front - RH (Recalibrate)	0.1	Model 3
11502102	Window Motor/Regulator Assembly - Front - RH (Remove & Replace)	0.65	Model 3
11502200	Window Regulator - Rear - LH (Recalibrate)	0.1	Model 3
11502202	Window Regulator - Rear - LH (Remove & Replace)	0.45	Model 3
11502300	Window Regulator - Rear - RH (Recalibrate)	0.1	Model 3
11502302	Window Regulator - Rear - RH (Remove & Replace)	0.5	Model 3
11502502	Switch - Window - Driver (Remove & Replace)	0.3	Model 3
11502702	Switch - Window - Front Passenger (Remove & Replace)	0.2	Model 3
11503002	Switch - Window - Rear - LH (Remove & Replace)	0.2	Model 3
11503102	Switch - Window - Rear - RH (Remove & Replace)	0.2	Model 3
11700302	Seal - Body - Side - Front - Primary - LH (Remove & Replace)	0.2	Model 3
11700402	Seal - Body - Side - Front - Primary - RH (Remove & Replace)	0.2	Model 3
11700502	Seal - Body - Side - Rear - Primary - LH (Remove & Replace)	0.2	Model 3
11700602	Seal - Body - Side - Rear - Primary - RH (Remove & Replace)	0.2	Model 3
11700802	Seal - B-Pillar Applique - LH (Remove & Replace)	0.5	Model 3
11700902	Seal - B-Pillar Applique - RH (Remove & Replace)	0.5	Model 3
11701001	Closeout Panel - Door - Front - LH (Remove & Install)	0.35	Model 3
11701101	Closeout Panel - Door - Front - RH (Remove & Install)	0.4	Model 3
11701112	Seal - Glass Run - Front Door - LH (Remove & Replace)	0.25	Model 3
11701122	Seal - Glass Run - Front Door - RH (Remove & Replace)	0.25	Model 3
11701401	Closeout Panel - Door - Rear - LH (Remove & Install)	0.5	Model 3
11701501	Closeout Panel - Door - Rear - RH (Remove & Install)	0.5	Model 3
11701802	Seal - Hood (Remove & Replace)	0.1	Model 3
11702002	Seal - Trunk (Remove & Replace)	0.15	Model 3
11703000	Seal - Outer Belt - Front Door - LH (Adjust)	0.05	Model 3
11703002	Seal - Outer Belt - Front Door - LH (Remove & Replace)	0.05	Model 3
11703102	Seal - Outer Belt - Front Door - RH (Remove & Replace)	0.05	Model 3
11703202	Seal - Inner Belt - Front Door - LH (Remove & Replace)	0.2	Model 3
11703302	Seal - Inner Belt - Front Door - RH (Remove & Replace)	0.2	Model 3
11704102	Seal - Inner Belt - Rear Door - LH (Remove & Replace)	0.3	Model 3
11704202	Seal - Inner Belt - Rear Door - RH (Remove and Replace)	0.3	Model 3
11704400	Seal - Outer Belt - Rear Door - LH (Adjust)	0.05	Model 3
11704402	Seal - Outer Belt - Rear Door - LH (Remove & Replace)	0.05	Model 3
11704502	Seal - Outer Belt - Rear Door - RH (Remove & Replace)	0.05	Model 3
11705002	Seal - Secondary - Front Door - LH (Remove & Replace)	0.1	Model 3
11705102	Seal - Secondary - Front Door - RH (Remove & Replace)	0.1	Model 3
11705402	Seal - Secondary - Rear Door - LH (Remove & Replace)	0.2	Model 3
11705502	Seal - Secondary - Rear Door - RH (Remove & Replace)	0.2	Model 3
12010102	Noise Absorber - Motor Bay - Front (Remove & Replace)	2.7	Model 3
12010202	Noise Absorber - Motor Bay - Rear (Remove & Replace)	3.45	Model 3

12010902	Wheel Arch Liner - Front - LH (Remove & Replace)	0.2	Model 3
12011002	Wheel Arch Liner - Front - RH (Remove & Replace)	0.2	Model 3
12011102	Wheel Arch Liner - Rear - LH (Remove & Replace)	0.2	Model 3
12011202	Wheel Arch Liner - Rear - RH (Remove & Replace)	0.2	Model 3
12030101	Panel - Aero Shield - Front (Remove & Install)	0.2	Model 3
12030102	Panel - Aero Shield - Front (Remove & Replace)	0.15	Model 3
12030501	Panel - Aero Shield - Mid (Remove & Install)	0.2	Model 3
12030502	Panel - Aero Shield - Mid (Remove & Replace)	0.2	Model 3
12030802	Diffuser - Rear Fascia (Remove & Replace)	0.2	Model 3
12050502	Tesla Badge - Front (Remove & Replace)	0.2	Model 3
12050602	Vehicle Configuration Badge (Remove & Replace)	0.1	Model 3
12050606	Vehicle Configuration Badge (Retrofit)	0.1	Model 3
12050607	Vehicle Configuration Badge (Remove)	0.05	Model 3
12050702	Tesla Badge - Rear (Remove & Replace)	0.2	Model 3
12051102	Sill Plate - Front - LH (Remove & Replace)	0.1	Model 3
12051202	Sill Plate - Front - RH (Remove & Replace)	0.1	Model 3
12051306	Sill Plate - illuminated - Front - Pair (Retrofit)	0.25	Model 3
12052006	Paint Protection Film - Rocker Panels (Retrofit)	0.2	Model 3
12052007	Paint Protection Film - Remove	0.5	Model 3
12070102	Bracket - License Plate - Front (Remove & Replace)	0.1	Model 3
12070106	Bracket - License Plate - Front (Retrofit)	0.1	Model 3
12070206	Install Tesla License Plate Frame	0.1	Model 3
12071001	License Plates (Install Onto Existing Brackets)	0.05	Model 3
12072302	Bracket - License Plate - Rear (EMEA and APAC) (Remove & Replace)	0.05	Model 3
12091101	Door Mirror Assembly - LH (Remove & Install)	0.5	Model 3
12091102	Door Mirror Assembly - LH (Remove & Replace)	0.5	Model 3
12091201	Door Mirror Assembly - RH (Remove & Install)	0.5	Model 3
12091202	Door Mirror Assembly - RH (Remove & Replace)	0.5	Model 3
12091702	Skull Cap - Door Mirror - LH (Remove & Replace)	0.05	Model 3
12091802	Skull Cap - Door Mirror - RH (Remove & Replace)	0.05	Model 3
12092002	Glass - Door Mirror - LH (Remove & Replace)	0.05	Model 3
12092102	Glass - Door Mirror - RH (Remove & Replace)	0.05	Model 3
12200102	Applique - B-Pillar - LH (Remove & Replace)	0.15	Model 3
12200202	Applique - B-Pillar - RH (Remove & Replace)	0.15	Model 3
12200302	Brightwork - Upper - LH (Remove & Replace)	0.25	Model 3
12200402	Brightwork - Upper - RH (Remove & Replace)	0.25	Model 3
12200502	Brightwork - Body Side - LH (Remove & Replace)	0.1	Model 3
12200602	Brightwork - Body side - RH (Remove & Replace)	0.1	Model 3
12200702	Brightwork - Quarter Panel - LH (Remove & Replace)	0.1	Model 3
12200802	Brightwork - Quarter Panel - RH (Remove & Replace)	0.1	Model 3
12201102	Applique - A-Pillar - LH (Remove & Replace)	0.25	Model 3
12201112	Applique - A-Pillar - RH (Remove & Replace)	0.25	Model 3
12202602	Cover - Rocker Panel - Lower - LH (Remove & Replace)	0.1	Model 3
12202702	Cover - Rocker Panel - Lower - RH (Remove & Replace)	0.1	Model 3
12207006	Mud Flaps (Retrofit)	0.15	Model 3
12207102	Mud Flap - LH (Remove and Replace)	0.1	Model 3
12207202	Mud Flap - RH (Remove and Replace)	0.1	Model 3
12208006	Splash Guards (Retrofit)	0.2	Model 3
12208102	Splash Guard - LH (Remove and Replace)	0.1	Model 3
12208202	Splash Guard - RH (Remove and Replace)	0.1	Model 3
12220401	Spoiler - Rear (Remove and Install)	0.5	Model 3
12220402	Spoiler - Rear (Remove & Replace)	0.35	Model 3
12220406	Spoiler - Rear (Retrofit using Tape)	0.2	Model 3
12220407	Spoiler - Rear (Remove)	0.15	Model 3
12220416	Spoiler - Rear (Retrofit using Jig)	0.2	Model 3
12250902	Panel - Cowl Screen (Remove & Replace)	0.3	Model 3
12251011	Cover - Shock Tower - LH (Remove & Install)	0.15	Model 3
12251012	Cover - Shock Tower - LH (Remove & Replace)	0.15	Model 3
12251102	Underhood Apron - Rear (Remove & Replace)	0.05	Model 3
12251111	Cover - Shock Tower - RH (Remove & Install)	0.15	Model 3

12251112	Cover - Shock Tower - RH (Remove & Replace)	0.15	Model 3
12300202	Assembly - Trailer Hitch (Remove & Replace)	0.7	Model 3
12302102	ECU - Trailer Hitch (Remove and Replace)	0.5	Model 3
12302202	Cover - Trailer Hitch (Remove and Replace)	0.05	Model 3
12302302	Ball Neck - Trailer Hitch (Remove and Replace)	0.1	Model 3
12400001	Roof Rack (Install)	0.3	Model 3
12400002	Roof Rack (Remove)	0.3	Model 3
12584004	Apply Paint to B-Pillar	3	Model 3
13010300	Seat - Driver - Calibration	0.05	Model 3
13010400	Seat - Front Passenger - Calibration	0.05	Model 3
13011102	Track - Inner - Driver's Seat (Remove & Replace)	0.55	Model 3
13011202	Motor - Seat Track - Driver Seat (Remove & Replace)	0.55	Model 3
13011415	Front Passenger Seat Lumbar Switch Rework (China only)	0.3	Model 3
13011502	Motor - Seat Tilt - Driver Seat (Remove & Replace)	0.45	Model 3
13011602	Motor - Seat Height - Driver Seat (Remove & Replace)	0.4	Model 3
13011812	Cover - Front - Seat Track - 1st Row Seat (Remove & Replace)	0.05	Model 3
13011822	Cover - Rear - Seat Track - 1st Row Seat (Remove & Replace)	0.05	Model 3
13012202	Frame - Seat Cushion - Driver Seat (Remove & Replace)	0.85	Model 3
13012302	Frame - Seat Cushion - Front Passenger Seat (Remove & Replace)	0.85	Model 3
13013102	Track - Inner - Front Passenger's Seat (Remove & Replace)	0.55	Model 3
13013202	Motor - Seat Track - Front Passenger Seat (Remove & Replace)	0.7	Model 3
13013502	Motor - Seat Tilt - Front Passenger Seat (Remove & Replace)	0.5	Model 3
13013602	Motor - Seat Height - Front Passenger Seat (Remove & Replace)	0.4	Model 3
13014097	Retrofit Passenger Lumbar Support Switch (CN only)	0.3	Model 3
13015102	Switch - Back Rest and Cushion Adjust - Driver Seat (Remove & Replace)	0.1	Model 3
13015202	Switch - Back Rest and Cushion Adjust - Front Passenger Seat (Remove & Replace)	0.1	Model 3
13015203	Switch - Back Rest and Cushion Adjust - Front Passenger Seat (Rework)	0.15	Model 3
13016602	Motor - Recliner - Back Rest - Driver Seat (Remove & Replace)	0.8	Model 3
13016702	Motor - Recliner - Back Rest - Front Passenger Seat (Remove & Replace)	0.8	Model 3
13018102	Button - Cushion Adjust - Driver Seat (Remove & Replace)	0.05	Model 3
13018202	Button - Cushion Adjust - Front Passenger Seat (Remove & Replace)	0.05	Model 3
13021750	Clip - Seat Cushion- Lower- 2nd Row -LH (Remove and Replace)	0.1	Model 3
13040101	Seat - Driver (Remove & Install)	0.3	Model 3
13040102	Seat - Driver (Remove & Replace)	0.35	Model 3
13040201	Seat Assembly - Front Passenger (Remove & Install)	0.6	Model 3
13040202	Seat - Front Passenger (Remove & Replace)	0.4	Model 3
13041002	Shell - Seat Back - Driver (Remove & Replace)	0.1	Model 3
13041102	Shell - Seat Back - Front Passenger (Remove & Replace)	0.1	Model 3
13042002	Trim - Headrest - Driver (Remove & Replace)	0.15	Model 3
13042102	Trim - Headrest - Front Passenger (Remove & Replace)	0.2	Model 3
13043002	Lumbar Support - Backrest - Driver Seat (Remove & Replace)	0.3	Model 3
13043202	Lumbar Support - Back Rest - Front Passenger Seat (Remove & Replace)	0.3	Model 3
13043402	Frame - Seat Back Rest - Driver's Seat (Remove & Replace)	0.9	Model 3
13043502	Frame - Seat Back Rest - Front Passenger's Seat (Remove & Replace)	0.9	Model 3
13050612	Bracket - Edge Support - Seat Cushion - 2nd Row - LH (Remove & Replace)	0.1	Model 3
13050622	Bracket - Edge Support - Seat Cushion - 2nd Row - RH (Remove & Replace)	0.1	Model 3
13050902	Trim - Headrest - 2nd Row - Center (Remove & Replace)	0.05	Model 3
13051002	Seat Cushion - Lower - 2nd Row (Remove & Replace)	0.05	Model 3
13052002	Rail - 2nd Row - Outer - LH (Remove & Replace)	0.2	Model 3
13052102	Rail - 2nd Row - Outer - RH (Remove & Replace)	0.2	Model 3
13052202	Rail - 2nd Row - Inner - LH (Remove & Replace)	0.2	Model 3
13052302	Rail - 2nd Row - Inner - RH (Remove & Replace)	0.2	Model 3
13053502	Cap - HV - Penthouse (Remove & Replace)	0.1	Model 3
13053602	Cap - 12V - Penthouse (Remove & Replace)	0.1	Model 3
13054001	Seat Back - 2nd Row - LH (Remove & Install)	0.2	Model 3
13054012	Handle - Seat Back - 2nd Row - LH (Remove & Replace)	0.5	Model 3
13054101	Seat Back - 2nd Row - RH (Remove & Install)	0.2	Model 3
13054112	Handle - Seat Back - 2nd Row - RH (Remove and Replace)	0.5	Model 3
13054702	Frame - Seat Back - 2nd Row - LH (Remove & Replace)	0.5	Model 3
13054802	Frame - Seat Back - 2nd Row - RH (Remove & Replace)	0.5	Model 3

13055102	Bolster - Outer - Seat - 2nd Row - LH (Remove & Replace)	0.1	Model 3
13055202	Bolster - Outer - Seat - 2nd Row - RH (Remove & Replace)	0.1	Model 3
13055402	Bezel - Handle - Seat Back - 2nd Row - RH (Remove & Replace)	0.05	Model 3
13055902	Latch - Seat Back - 2nd Row Seat - LH (Remove & Replace)	0.5	Model 3
13056002	Latch - Seat Back - 2nd Row Seat - RH (Remove & Replace)	0.5	Model 3
13056302	Striker - Seat Back - 2nd Row Seat - LH (Remove & Replace)	0.3	Model 3
13056402	Striker - Seat Back - 2nd Row Seat - RH (Remove & Replace)	0.3	Model 3
13057102	Pivot Sleeve - Seat Back - 2nd Row Seat - LH (Remove & Replace)	0.2	Model 3
13057202	Pivot Sleeve - Seat Back - 2nd Row Seat - RH (Remove & Replace)	0.1	Model 3
13057402	Bracket - Hinge - Seat Back - 2nd Row Seat - LH (Remove & Replace)	0.2	Model 3
13057502	Bracket - Hinge - Seat Back - 2nd Row Seat - RH (Remove & Replace)	0.2	Model 3
13058002	Armrest - 2nd Row (Remove & Replace)	0.1	Model 3
13058012	Closeout - Armrest - 2nd Row (Remove & Replace)	0.1	Model 3
13059252	Adjustment Guide - Headrest - 2nd Row (Remove and Replace)	0.05	Model 3
13059452	Guide Lock - Headrest - 2nd Row (Remove and Replace)	0.05	Model 3
13070101	Trim and Foam Assembly - Driver Seat (Remove & Install)	0.1	Model 3
13070102	Foam - Cushion - Driver Seat (Remove & Replace)	0.55	Model 3
13070202	Foam - Cushion - Front Passenger Seat (Remove & Replace)	0.55	Model 3
13072002	Trim - Seat Back - Driver Seat (Remove & Replace)	0.7	Model 3
13072102	Trim - Seat Back - Front Passenger Seat (Remove & Replace)	0.7	Model 3
13072202	Trim - Cushion - Driver Seat (Remove & Replace)	0.55	Model 3
13072302	Trim - Cushion - Front Passenger Seat (Remove & Replace)	0.55	Model 3
13072602	Foam - Seat Back - Driver Seat (Remove & Replace)	0.7	Model 3
13072702	Foam - Seat Back - Front Passenger Seat (Remove & Replace)	0.65	Model 3
13074001	Cover - Outer Side - Driver Seat (Remove & Install)	0.1	Model 3
13074101	Cover - Outer Side - Passenger Seat (Remove & Install)	0.1	Model 3
13074202	Side Shield - Outboard - Driver Seat (Remove & Replace)	0.1	Model 3
13074302	Side Shield - Outboard - Front Passenger Seat (Remove & Replace)	0.1	Model 3
13074602	Side Shield - Inboard - Driver Seat (Remove & Replace)	0.05	Model 3
13074702	Side Shield - Inboard - Front Passenger Seat (Remove & Replace)	0.05	Model 3
13081002	Cover - Seat Back - 2nd Row Seat - RH (Remove & Replace)	0.5	Model 3
13081102	Cover - Seat Back - 2nd Row Seat - LH (Remove & Replace)	0.5	Model 3
13082002	Cup Holder - 2nd Row (Remove & Replace)	0.05	Model 3
14051001	Glove Box (Remove & Install)	0.45	Model 3
14051002	Glove Box (Remove & Replace)	0.45	Model 3
14051012	Glove Box (Without Knee Airbags) (Remove & Replace)	0.2	Model 3
14051022	Glove Box - With Knee Airbag (Heat Pump) (Remove & Replace)	0.35	Model 3
14051102	Solenoid - Glove Box (Remove & Replace)	0.5	Model 3
14051202	Damper - Glove Box (Remove & Replace)	0.5	Model 3
14051302	NVH Pad - Glove Box (Remove & Replace)	0.3	Model 3
14052102	IP Carrier/Cover (Remove & Replace)	2	Model 3
14052122	IP Carrier (RHD) (Remove and Replace)	1.8	Model 3
14052202	Cross Car Beam (Remove & Replace)	3.5	Model 3
14053102	Vent - Front - LH (Remove & Replace)	0.2	Model 3
14053202	Vent - Front - RH (Remove & Replace)	0.3	Model 3
14053213	Inspect the RH Front Vent, No Action Required(CN Only)	0.05	Model 3
14054102	End Cap - Instrument Panel - LH (Remove & Replace)	0.05	Model 3
14054202	End Cap - Instrument Panel - RH (Remove & Replace)	0.05	Model 3
14054701	Grille - Speaker - Instrument Panel (Remove & Install)	0.15	Model 3
14054702	Grille - Speaker - Instrument Panel (Remove & Replace)	0.15	Model 3
14055002	Skin - Dash - Lower (Remove & Replace)	0.1	Model 3
14055102	End Cap - Air Wave - LH (Remove & Replace)	0.05	Model 3
14055202	End Cap - Air Wave - RH (Remove & Replace)	0.05	Model 3
14055212	Cross Car Beam (RHD) (Remove & Replace)	3	Model 3
14055302	Cover - Footwell - Driver (Remove & Replace)	0.1	Model 3
14055402	Cover - Footwell - Passenger (Remove & Replace)	0.1	Model 3
14055412	Cover - Footwell - Passenger (RHD) (Remove & Replace)	0.05	Model 3
14056002	Cover - Knee Airbag - Driver (Remove & Replace)	0.3	Model 3
14056102	Cover - Knee Airbag - Front Passenger (Remove & Replace)	0.3	Model 3
14056680	Inspect the RH Front Vent, Adjust Vent Position(CN Only)	0.15	Model 3

14057002	Decor - Instrument Panel - Main (Remove & Replace)	0.1	Model 3
14057502	Finisher - Vent (Remove & Replace)	0.2	Model 3
14057802	Housing - Center Display (Remove & Replace)	0.3	Model 3
15050202	Mirror - Rear View (Remove & Replace)	0.05	Model 3
15050402	Assembly - Mirror - Sun Visor - LH (Remove & Replace)	0.1	Model 3
15050702	Assembly - Mirror - Sun Visor - RH (Remove & Replace)	0.1	Model 3
15050902	Quad Camera Cover – Lower (Remove & Replace)	0.05	Model 3
15051002	Sun Visor - Driver (Remove & Replace)	0.1	Model 3
15051052	Check Base - Sun Visor - Driver (Remove & Replace)	0.05	Model 3
15051072	Check Base - Magnetic - Sun Visor - Driver (Remove & Replace)	0.05	Model 3
15051202	Sun Visor - Front Passenger (Remove & Replace)	0.1	Model 3
15051252	Check Base - Sun Visor - Front Passenger (Remove & Replace)	0.05	Model 3
15051302	Triple Cam Hood (Remove & Replace)	0.05	Model 3
15051802	Quad Camera Cover - Upper (Remove & Replace)	0.05	Model 3
15110102	Cover - Latch - Power Trunk (Remove & Replace)	0.05	Model 3
15110202	Trim - Lid - Power Trunk (Remove & Replace)	0.05	Model 3
15111102	Garnish - Trunk (Remove and Replace)	0.05	Model 3
15111107	Garnish - Trunk (Modify)	0.1	Model 3
15111901	Trim - Lid - Trunk (Remove & Install)	0.05	Model 3
15111902	Trim - Lid - Trunk (Remove & Replace)	0.05	Model 3
15112102	Speaker Grille - Parcel Shelf - LH (Remove and Replace)	0.25	Model 3
15130201	Panel - Door Trim - Front - LH (Remove & Install)	0.2	Model 3
15130202	Panel - Door Trim - Front - LH (Remove & Replace)	0.2	Model 3
15130301	Panel - Door Trim - Front - RH (Remove & Install)	0.2	Model 3
15130302	Panel - Door Trim - Front - RH (Remove & Replace)	0.15	Model 3
15130602	Reflector - Door Trim - Front -LH (Remove & Replace)	0.05	Model 3
15130702	Reflector - Door Trim - Front -RH (Remove & Replace)	0.05	Model 3
15131002	Decor - Trim - Front Door - LH (Remove & Replace)	0.05	Model 3
15131102	Decor - Trim - Front Door - RH (Remove & Replace)	0.05	Model 3
15131402	NVH Pad - Panel - Door Trim - Front - LH (Remove & Replace)	0.01	Model 3
15131502	NVH Pad - Panel - Door Trim - Front - RH (Remove & Replace)	0.01	Model 3
15132001	Panel - Door Trim - Rear - LH (Remove & Install)	0.2	Model 3
15132002	Panel - Door Trim - Rear - LH (Remove & Replace)	0.2	Model 3
15132101	Panel - Door Trim - Rear - RH (Remove & Install)	0.2	Model 3
15132102	Panel - Door Trim - Rear - RH (Remove & Replace)	0.2	Model 3
15132702	NVH Pad - Panel - Door Trim - Rear - LH (Remove & Replace)	0.01	Model 3
15132802	NVH Pad - Panel - Door Trim - Rear - RH (Remove & Replace)	0.15	Model 3
15180012	Bracket - B-Pillar - Upper - LH (Remove & Replace)	0.3	Model 3
15180022	Bracket - B-Pillar - Upper - RH (Remove & Replace)	0.3	Model 3
15180502	Trim - Sill Panel - Rear - LH (Remove & Replace)	0.1	Model 3
15180602	Trim - Sill Panel - Rear - RH (Remove & Replace)	0.1	Model 3
15182402	Trim - A-Pillar - Lower - LH (Remove & Replace)	0.1	Model 3
15182502	Trim - A-Pillar - Lower - RH (Remove & Replace)	0.1	Model 3
15182602	Trim - A-Pillar - Middle - LH (Remove & Replace)	0.1	Model 3
15182702	Trim - A-Pillar - Middle - RH (Remove & Replace)	0.1	Model 3
15183002	Trim - B-Pillar - Upper - LH (Remove & Replace)	0.1	Model 3
15183102	Trim - B-Pillar - Upper - RH (Remove & Replace)	0.1	Model 3
15183402	Trim - B-Pillar - Lower - LH (Remove & Replace)	0.2	Model 3
15183502	Trim - B-Pillar - Lower - RH (Remove & Replace)	0.2	Model 3
15184001	Trim - A-Pillar - Upper - LH (Remove & Install)	0.05	Model 3
15184002	Trim - A-Pillar - Upper - LH (Remove & Replace)	0.05	Model 3
15184101	Trim - A-Pillar - Upper - RH (Remove & Install)	0.05	Model 3
15184102	Trim - A-Pillar - Upper - RH (Remove & Replace)	0.05	Model 3
15185002	Footrest - Driver (Remove & Replace)	0.1	Model 3
15185102	Trim - C-Pillar - Rear - LH (Remove & Replace)	0.2	Model 3
15185202	Trim - C-Pillar - Rear - RH (Remove & Replace)	0.2	Model 3
15186002	Trim - C-Pillar - Upper - LH (Remove & Replace)	0.2	Model 3
15186102	Trim - C-Pillar - Upper - RH (Remove & Replace)	0.2	Model 3
15186601	Trim - Side Rail - LH (Remove & Install)	0.1	Model 3
15186602	Trim - Side Rail - LH (Remove & Replace)	0.1	Model 3

15186701	Trim - Side Rail - RH (Remove & Install)	0.1	Model 3
15186702	Trim - Side Rail - RH (Remove & Replace)	0.1	Model 3
15190101	Center Console Assembly (Remove & Install)	0.4	Model 3
15190102	Center Console Assembly (Remove & Replace)	0.5	Model 3
15190112	Center Console Assembly (2nd Generation) (Remove & Replace)	0.6	Model 3
15190202	Bright Strip - Center Console - LH (Remove & Replace)	0.05	Model 3
15190252	Brightwork - Center Console (Remove & Replace)	0.2	Model 3
15190302	Bright Strip - Center Console - RH (Remove & Replace)	0.05	Model 3
15190401	Decor Trim - Cup Holder - Center Console (Remove & Install)	0.35	Model 3
15190402	Decor Trim - Cup Holder - Center Console (Remove & Replace)	0.35	Model 3
15190411	Decor Trim - Cup Holder - Center Console (2nd Generation) (Remove & Install)	0.25	Model 3
15190412	Decor Trim - Cup Holder - Center Console (2nd Generation) (Remove & Replace)	0.25	Model 3
15190502	Air Vent - Center Console (Remove & Replace)	0.1	Model 3
15190702	Panel - Air Vent - Center Console (Remove & Replace)	0.1	Model 3
15191802	Cup Holder (Remove & Replace)	0.4	Model 3
15191812	Cup Holder (2nd Generation) (Remove & Replace)	0.3	Model 3
15191822	Liner - Cup Holder - Center Console (2nd Generation) (Remove & Replace)	0.25	Model 3
15191832	Sliding Lid - Center Console (Remove & Replace)	0.65	Model 3
15191902	Trim - Center Console - Front (Remove & Replace)	0.55	Model 3
15192002	Trim - Center Console - Rear (Remove & Replace)	0.05	Model 3
15192502	Armrest - Center Console (Remove & Replace)	0.2	Model 3
15193602	Decor Trim - Center Console - LH (Remove & Replace)	0.05	Model 3
15193702	Decor Trim - Center Console - RH (Remove & Replace)	0.05	Model 3
15193902	Module - Inductive Charger - Center Console (2nd Generation) (Remove & Replace)	0.1	Model 3
15195002	End Panel - Center Console (Remove & Replace)	0.2	Model 3
15195202	Panel - Lower Rear - Center Console (Remove & Replace)	0.1	Model 3
15195402	Carpet - Side Panel - Center Console (Remove & Replace)	0.1	Model 3
15195602	Insert - Front Bin - Center Console (Remove & Replace)	0.75	Model 3
15196202	Front Bin Door (Remove & Replace)	0.1	Model 3
15196402	Phone Tray - Center Console (Remove & Replace)	0.1	Model 3
15196802	Side Panel - Center Console - LH (Remove & Replace)	0.1	Model 3
15196902	Side Panel - Center Console - RH (Remove & Replace)	0.1	Model 3
15198002	Mat - Console Bin (2nd Generation) (Remove & Replace)	0.05	Model 3
15202302	Overhead Console - Front (Remove & Replace)	0.1	Model 3
15202402	Overhead Console - Rear (Remove & Replace)	0.05	Model 3
15203101	Headliner (Remove & Install)	0.55	Model 3
15203102	Headliner (Remove & Replace)	0.6	Model 3
15203111	Headliner (Heat Pump) (Remove and Install)	0.5	Model 3
15203112	Headliner (Heat Pump) (Remove and Replace)	0.5	Model 3
15204012	Coat Hook - Rear- LH (2 Piece Headliner) (Remove & Replace)	0.25	Model 3
15204112	Coat Hook - Rear- RH (2 Piece Headliner) (Remove & Replace)	0.25	Model 3
15204302	Coat Hook - Rear - LH (1 Piece Headliner) (Remove & Replace)	0.6	Model 3
15204402	Coat Hook - Rear - RH (1 Piece Headliner) (Remove & Replace)	0.6	Model 3
15240701	Underhood Storage Unit (Remove & Install)	0.1	Model 3
15240702	Underhood Storage Unit (Remove & Replace)	0.1	Model 3
15241102	Hood Latch Cover (Remove & Replace)	0.05	Model 3
15241402	Switch - Underhood Storage Area - Child Safety (Remove & Replace)	0.05	Model 3
15243002	Trim - Package Tray (Remove & Replace)	0.3	Model 3
15243102	Flip Door - Tether Anchor - LH (Remove and Replace)	0.3	Model 3
15243202	Flip Door - Tether Anchor - Center (Remove and Replace)	0.3	Model 3
15243302	Flip Door - Tether Anchor - RH (Remove and Replace)	0.3	Model 3
15244802	Trim - Sill - Trunk (Remove & Replace)	0.1	Model 3
15245002	Trim - Side - Trunk - LH (Remove & Replace)	0.3	Model 3
15245102	Trim - Side - Trunk - RH (Remove & Replace)	0.3	Model 3
15245302	Trim - Floor - Rear Trunk (Remove & Replace)	0.1	Model 3
15245402	Carpet - Rear Trunk (Remove & Replace)	0.3	Model 3
15248949	Measure hood latch alignment (CN only)	0.1	Model 3
15301001	Carpet - Front - LH (Remove & Replace)	0.4	Model 3
15301101	Carpet - Front - RH (Remove & Replace)	0.6	Model 3
15301902	Floor Mat Set (Remove & Replace)	0.05	Model 3

15302002	Carpet - Underhood Storage (Remove & Replace)	0.1	Model 3
15302102	Carpet - Interior Complete (Remove & Replace)	0.1	Model 3
15302602	Front Carpet - Trunk (2-Piece) (Remove & Replace)	0.3	Model 3
15302702	Rear Carpet - Trunk (2-Piece) (Remove & Replace)	0.05	Model 3
15303002	Carpet – Front – LH (Remove & Replace)	0.1	Model 3
15303102	Carpet – Front – RH (Remove & Replace)	0.6	Model 3
15303202	Carpet – Rear (Remove & Replace)	0.7	Model 3
15521717	Model 3 paint		Model 3
16010101	HV Battery (Remove & Install)	3.55	Model 3
16010102	HV Battery (Remove & Replace)	4.45	Model 3
16010201	HV Battery (Dual Motor) (Remove & Install) (Add Coolant 1029320-00 if Needed)	3.25	Model 3
16010202	HV Battery (Dual Motor) (Remove & Replace)	4.55	Model 3
16010806	Access Ports – Shipping Crate – HV Battery (Retrofit)	0.01	Model 3
16011002	Flood Port - LH (Remove & Replace)	1.1	Model 3
16011102	Flood Port - RH (Remove & Replace)	0.1	Model 3
16011908	Inspection for Vehicle Soaking in Water	1.7	Model 3
16013774	Apply Glue to HV Battery Platter (China Only)	1.1	Model 3
16015300	Discharge HV Battery (At Pack Contactors)	0.8	Model 3
16015400	Discharge HV Battery (Smart CAN Off)	0.8	Model 3
16018725	Check SOC Imbalance	0.2	Model 3
16100400	Penthouse Air Leak Test	0.35	Model 3
16100410	Penthouse Air Leak Test (Busbar Type)	0.35	Model 3
16101002	Cover - Penthouse (Remove & Replace)	0.9	Model 3
16101602	Cover - HV Probe - HV Battery (Remove & Replace)	0.3	Model 3
16102000	Platter Enclosure Air Leak Test	0.35	Model 3
16102002	Skid Plate - HV Battery - Front (Remove & Replace)	0.3	Model 3
16102010	Platter Enclosure Coolant Leak Test	1.15	Model 3
16102020	Platter Enclosure Coolant (Drain and Refill) (Add Coolant 1029320-00 if Needed)	0.1	Model 3
16102100	HV Battery Air Leak Test	0.5	Model 3
16102102	Vent Assembly - HV Battery - LH (Remove & Replace)	0.6	Model 3
16102112	Vent Assembly - HV Battery - RH (Remove & Replace)	0.6	Model 3
16102202	Skid Plate - HV Battery - Rear (Remove & Replace)	0.4	Model 3
16102302	Breathers - HV Battery (Remove & Replace)	0.25	Model 3
16102602	Ski - Center Rail - HV Battery (Remove & Replace) (Add Coolant 1029320-00 if Needed)	1.25	Model 3
16102612	Ski - Center Rail - HV Battery (Dual Motor) (Remove & Replace)	1.75	Model 3
16102702	Flood Ports - 2nd Generation (Remove & Replace)	0.75	Model 3
16102706	Flood Ports - 2nd Generation (Retrofit)	0.75	Model 3
16103002	Gasket - Cover - HV Battery (Remove & Replace)	4.3	Model 3
16103101	Compression Strips - Cover - HV Battery (Install)	0.15	Model 3
16200200	Penthouse Coolant Leak Test (Add Coolant 1029320-00 if Needed)	0.1	Model 3
16200505	Coolant - HV Battery (Drain and Refill) (Add Coolant 1029320-00 if Needed)	0.9	Model 3
16202000	Penthouse Coolant (Drain and Refill) (Add Coolant 1029320-00 if Needed)	1.9	Model 3
16202002	Tube - Input - Coolant - Power Conversion System (Remove & Replace) (Add Coolant 1029320-00 if Needed)	2.7	Model 3
16202202	Tube - Output - Coolant - Power Conversion System (Remove & Replace) (Add Coolant 1029320-00 if Needed)	2.1	Model 3
16300002	Pyrotechnic Battery Disconnect (Remove & Replace)	0.95	Model 3
16300100	Resistance Meter (Zero Adjust)	0.01	Model 3
16300500	HV Integrity Check - HV Battery	0.1	Model 3
16301002	Power Conversion System (Remove & Replace)	2.45	Model 3
16301602	Controller - High Voltage (Remove & Replace)	1	Model 3
16302001	Insulators - HV Battery (Remove & Install)	0.05	Model 3
16302002	Contactors - Negative - HV Battery (Remove & Replace)	0.9	Model 3
16302102	Contactors - Positive - HV Battery (Remove and Replace)	1.35	Model 3
16302302	DC Input Assembly - HV Battery (Harness Type) (Remove & Replace)	1.15	Model 3
16302402	DC Input Assembly - HV Battery (Busbar Type) (Remove & Replace)	1.3	Model 3
16302602	Contactors - Fast Charge - HV Battery (Remove & Replace)	2.5	Model 3
16302806	Busbar DC Input to Harness DC Input (Retrofit)	0.9	Model 3
16302906	Harness-Type Charge Port And DC Input To Busbar-Type Charge Port And DC Input (3 Phase) (Retrofit)	2	Model 3
16303002	Busbar - HV Battery - Negative (Remove & Replace)	0.1	Model 3
16303102	Busbar - HV Battery - Positive (Remove & Replace)	1	Model 3
16303602	Shunt - HV Battery (Remove & Replace)	1.05	Model 3

16303802	Guide - Probing - HV Battery (Remove & Replace) (Add Coolant 1029320-00 if Needed)	2.15	Model 3
16304002	Fuse - HV Battery - Cabin Heater (Remove & Replace)	0.9	Model 3
16304202	Fuse - HV Battery - A/C Compressor (Remove & Replace)	0.9	Model 3
16304402	Fuse - Power Conversion System - HV Battery (Remove & Replace)	0.9	Model 3
16304675	Reset Brick CAC for Model 3	0.17	Model 3
16305002	Harness - HV Battery - High Voltage Controller (Remove & Replace) (Add Coolant 1029320-00 if Needed)	3.2	Model 3
16305012	Harness - Penthouse - HV Battery (Structural Pack) (Remove & Replace)	2.25	Model 3
16305102	Harness - HV Battery - PCS to HV Modules (Remove & Replace)	0.1	Model 3
16305202	Harness - HV Battery - PCS to Charge Port Connector (Remove & Replace)	0.1	Model 3
16305302	Harness - HV Battery - Fast Charge (Remove & Replace) (Add Coolant 1029320-00 if Needed)	2.45	Model 3
16306002	Passthrough - DCDC - 12V (Remove & Replace)	1	Model 3
16306052	Passthrough - DCDC - 12V (Cable Type) (Remove and Replace)	1	Model 3
16306102	HV Header - Front Drive Unit - HV Battery (Remove & Replace)	0.8	Model 3
16306202	HV Header - PTC Heater and A/C Compressor - HV Battery (Remove and Replace)	0.9	Model 3
16306302	HV Header - Rear Drive Unit - HV Battery (Remove & Replace)	0.8	Model 3
16306402	Busbar - Contactor - Positive - HV Battery (Remove and Replace)	2.55	Model 3
16306502	HV Header - 3-Phase Input - HV Battery (Remove & Replace)	0	Model 3
16307102	AC Filter - Harness - Penthouse - HV Battery (Remove & Replace)	0	Model 3
16307152	AC Filter - Harness - Penthouse - HV Battery (3-Phase) (Remove & Replace)	1.3	Model 3
16309000	HV Battery Contactor Seize Check	0	Model 3
16900308	HV Battery Damage Evaluation (Reman)	1	Model 3
16900508	HV Battery Safety Check (Reman)	1	Model 3
16901008	HV Battery Standard Remanufacturing (Reman)	7.45	Model 3
16902008	HV Battery Capacity Test (Reman)	1	Model 3
16903108	HV Battery Coolant Leak Rectification (Reman)	1	Model 3
16903308	Umbrella Valves - HV Battery (Reman)	0.15	Model 3
16903708	Ski - Side Rail - HV Battery - LH (Reman)	0.25	Model 3
16903808	Ski - Side Rail - HV Battery - RH (Reman)	0.25	Model 3
16904008	Enclosure - HV Battery - Remanufactured (Reman)	5.35	Model 3
16904208	Enclosure - HV Battery - New (Reman)	4.6	Model 3
16904508	Baffle - Vent - HV Battery (Reman)	0.15	Model 3
16905008	Battery Management System (BMS) (Reman)	0.45	Model 3
16905208	Spine - HV Battery (Reman)	1.45	Model 3
16906008	Modules - HV Battery - Inspection (Reman)	0.6	Model 3
16906208	Modules - HV Battery - Upper (Reman)	0.25	Model 3
16906408	Modules - HV Battery - Lower (Reman)	0.7	Model 3
17010000	Vehicle Electrical Isolation Procedure	0.2	Model 3
17010200	12V Power (Original Model 3) (Disconnect & Connect)	0.1	Model 3
17010400	12V Power (Lead Acid) (Heat Pump) (Disconnect & Connect)	0.05	Model 3
17010410	LV Power (Li-Ion) (Disconnect & Connect)	0.05	Model 3
17011002	Vent Hose - 12V Battery (Remove & Replace)	0.1	Model 3
17011202	Battery - 12V (Lead Acid) (Remove & Replace)	0.15	Model 3
17011232	Battery - LV (Li-Ion) (Remove & Replace)	0.15	Model 3
17012702	Beam - 12V Battery (RWD) (Remove & Replace)	0.6	Model 3
17012712	Beam - 12V Battery (Dual Motor) (Remove & Replace)	1.3	Model 3
17014002	Bracket - 12V Battery (RWD) (Remove & Replace)	0.5	Model 3
17014012	Bracket - 12V Battery (Dual Motor) (Remove & Replace)	1.3	Model 3
17014202	Strap - 12V Battery (Remove & Replace)	0.1	Model 3
17044828	ETC Remove and Replace for China	0.05	Model 3
17048099	ETC Installation for China	0.05	Model 3
17100008	Harness Connector - Reconnect	0.1	Model 3
17100010	Harness Connector - Repair (Does Not Include Access Labor)	0.5	Model 3
17100102	Harness - Front Door - LH (Remove & Replace)	0.75	Model 3
17100202	Harness - Front Door - RH (Remove & Replace)	0.75	Model 3
17100302	Harness - Center Console (Remove & Replace)	0.5	Model 3
17100602	Harness - Instrument Panel (Remove & Replace)	2.3	Model 3
17100622	Harness - Instrument Panel (RHD) (Remove & Replace)	2.25	Model 3
17100702	Harness - Main Front (Remove & Replace)	3.6	Model 3
17100712	Harness - Main Front (RHD) (Remove and Replace)	4.5	Model 3
17100722	Harness - Main Front (Info-Ryzen/Li-Ion) (Remove and Replace)	3.7	Model 3

17100802	Harness - Body - LH (Remove & Replace)	2.6	Model 3
17100852	Harness - Body - LH (RHD) (Remove & Replace)	2.7	Model 3
17100862	Harness - Body - LH (Busbar) (RHD) (Remove & Replace)	2.95	Model 3
17100902	Harness - Body - RH (Remove & Replace)	3.1	Model 3
17100952	Harness - Body - RH (RHD) (Remove & Replace)	3	Model 3
17101001	Harness - Windshield (Remove & Replace)	0.65	Model 3
17101002	Harness - Fascia - Front (Remove & Replace)	0.6	Model 3
17101102	Harness - Fascia - Rear (Remove & Replace)	0.5	Model 3
17101202	Harness - Drive Unit - Front (Remove & Replace)	0.35	Model 3
17101302	Harness - Thermal Beam (Remove & Replace)	0.45	Model 3
17101402	Harness - Front End Module (Remove & Replace)	0.5	Model 3
17101542	Harness - Sub Assembly - Thermal (Heat Pump) (Remove & Replace)	0.5	Model 3
17101802	Harness - Seat - Driver (Remove and Replace)	0.65	Model 3
17101902	Harness - Seat - Front Passenger (Remove and Replace)	0.65	Model 3
17102002	Harness - Subframe - Rear (Includes Alignment Check) (Remove & Replace)	0.85	Model 3
17102012	Jumper Harness - Trailer Hitch (Remove and Replace)	0.85	Model 3
17102402	Busbar - DCDC Ground (Remove & Replace)	0.2	Model 3
17102502	Harness - Headliner (Remove & Replace)	0.8	Model 3
17102802	Harness - Rear Door - LH (Remove & Replace)	0.35	Model 3
17102902	Harness - Rear Door - RH (Remove & Replace)	0.35	Model 3
17103402	Harness - Main Front- Active Hood (Remove & Replace)	2.55	Model 3
17104102	Harness - HVAC Assembly (Remove & Replace)	3.7	Model 3
17104502	Harness - Trunk (Remove & Replace)	0.4	Model 3
17105006	Wire - Electrical Harness (Does Not Include Access Labor) (Overlay)	0	Model 3
17105008	Wire - Electrical Harness (Does Not Include Access Labor) (Repair)	0	Model 3
17105102	Connector Housing - Electrical Harness (Does Not Include Access Labor) (Remove & Replace)	0.2	Model 3
17105208	Connector Terminal - Electrical Harness (Does Not Include Access Labor) (Repair)	0	Model 3
17105306	Coaxial Cable - Electrical Harness (Does Not Include Access Labor) (Overlay)	0	Model 3
17106002	Harness - 12V Battery + (Remove & Replace)	0.8	Model 3
17106202	Harness - 12V Battery Ground (Remove & Replace)	0.9	Model 3
17106602	Harness - Front Body Controller Module Ground (Remove & Replace)	0.1	Model 3
17106802	Harness - USB - Car Computer To Glove Box (Remove & Replace)	0.45	Model 3
17106852	Harness - USB - Car Computer To Glove Box (RHD) (Remove & Replace)	0.3	Model 3
17106902	Jumper Harness - Charge Port Inlet (Busbar Type) (Remove & Replace)	0.35	Model 3
17108100	Low Voltage Circuit Integrity Check	1	Model 3
17150006	Singapore Electronic Road Pricing System (Retrofit)	0.5	Model 3
17150016	Electronic Toll Collection System (Retrofit)	0.5	Model 3
17152102	Module - Body Controller - LH (Remove & Replace)	0.8	Model 3
17152112	Module - Body Controller - LH (Heat Pump) (Remove & Replace)	0.5	Model 3
17152122	Shield - Body Controller - Front (Heat Pump) (Remove & Replace)	0.15	Model 3
17152152	Module - Body Controller - LH (RHD) (Remove & Replace)	0.65	Model 3
17152202	Module - Body Controller - RH (Remove & Replace)	0.9	Model 3
17152212	Module - Body Controller - RH (Heat Pump) (Remove & Replace)	0.8	Model 3
17152252	Module - Body Controller - RH (RHD) (Remove and Replace)	0.7	Model 3
17152902	Module - Body Controller - Front (RWD) (Remove & Replace)	1.2	Model 3
17152912	Module - Body Controller - Front (Dual Motor) (Remove & Replace)	1.15	Model 3
17152952	Module - Body Controller - Front (Heat Pump) (Remove & Replace)	0.75	Model 3
17154202	Module - HomeLink Transmitter (Remove & Replace)	0.7	Model 3
17154802	Steering Controller (Remove & Replace)	0.35	Model 3
17201500	Sensor - Radar - Front (Calibration)	0.6	Model 3
17201502	Sensor - Radar - Front (Remove & Replace)	1.45	Model 3
17201802	Bracket - Radar - Front (Remove & Replace)	1.15	Model 3
17209106	Enable Autopilot Convenience Features (TB Article #13859)	0.4	Model 3
17209116	Enable Highway Autopilot	0	Model 3
17209126	Enable Basic Autopilot (TB Article #13859)	0	Model 3
17209136	Enable Enhanced Autopilot (TB Article #13859)	0	Model 3
17209146	Enable Full Self-Driving (TB Article #13859)	0	Model 3
17230500	Drive Cycle Calibration - Forward Facing Camera	0.5	Model 3
17230600	Camera - Forward Facing (Pitch Verification)	0.1	Model 3
17231002	Camera - Triple - Forward Facing (Remove & Replace)	0.3	Model 3

17241602	Camera - Occupant (Remove & Replace)	0.1	Model 3
17250102	Camera - Rear Facing (Remove & Replace)	0.1	Model 3
17271011	Sensor - Parking Distance - Inner - Front (Remove & Install)	0.55	Model 3
17271012	Sensor - Parking Distance - Inner - Front (Remove & Replace)	0.55	Model 3
17271021	Sensor - Parking Distance - Outer - Front (Remove & Install)	0.2	Model 3
17271022	Sensor - Parking Distance - Outer - Front (Remove & Replace)	0.2	Model 3
17271111	Sensor - Parking Distance - Inner - Rear (Remove & Install)	0.45	Model 3
17271112	Sensor - Parking Distance - Inner - Rear (Remove & Replace)	0.45	Model 3
17271121	Sensor - Parking Distance - Outer - Rear (Remove & Install)	0.05	Model 3
17271122	Sensor - Parking Distance - Outer - Rear (Remove & Replace)	0.1	Model 3
17272682	Retainer - Sensor - Park Assist (Remove & Replace)	0.5	Model 3
17300702	Switch - Steering Wheel - LH (Remove & Replace)	0.2	Model 3
17300802	Switch - Steering Wheel - RH (Remove & Replace)	0.2	Model 3
17303202	Power Socket 12V - Center Console (Remove and Replace)	0.3	Model 3
17331922	Intrusion Sensor Study - No Problem Found	0.2	Model 3
17333444	Intrusion Sensor Study - Replaced	0.2	Model 3
17351202	Puddle Light - Front Door - LH (Remove & Replace)	0.05	Model 3
17351302	Puddle Light - Front Door - RH (Remove & Replace)	0.05	Model 3
17351702	Puddle Light - Footwell Cover - RH (Remove & Replace)	0.1	Model 3
17352202	Puddle Light - Rear Door - LH (Remove & Replace)	0.1	Model 3
17352302	Puddle Light - Rear Door - RH (Remove & Replace)	0.1	Model 3
17354202	Light - Trunk (Remove & Replace)	0.05	Model 3
17400100	Headlights - Adjust	0.1	Model 3
17400101	Headlight - LH (Remove & Install)	0.45	Model 3
17400102	Headlight - LH (Remove & Replace)	0.85	Model 3
17400112	Bracket - Headlight - LH (Remove and Replace)	0.8	Model 3
17400150	Headlights - Adjust - NA (Tool Method)	0.55	Model 3
17400160	Headlights - Adjust - Global (Wall Method)	0.55	Model 3
17400170	Headlights - Adjust - Global (Tool Method)	0.15	Model 3
17400201	Headlight - RH (Remove & Install)	0.85	Model 3
17400202	Headlight - RH (Remove & Replace)	0.85	Model 3
17400212	Bracket - Headlight - RH (Remove and Replace)	0.8	Model 3
17400801	ECU - Headlight (Remove & Install)	1	Model 3
17400802	ECU - Headlight (Remove & Replace)	1.3	Model 3
17402001	Tail Light Assembly - LH (Remove & Install)	0.1	Model 3
17402002	Taillight - LH (Remove & Replace)	0.1	Model 3
17402201	Tail Light Assembly - RH (Remove & Install)	0.1	Model 3
17402202	Taillight - RH (Remove & Replace)	0.1	Model 3
17402502	Light - Brake - High Mounted (Remove & Replace)	0.6	Model 3
17402602	Light - License Plate (Remove & Replace)	0.1	Model 3
17402701	Light - Fog/Reverse - Rear - LH (Remove & Install)	0.1	Model 3
17402702	Light - Fog/Reverse - Rear - LH (Remove & Replace)	0.1	Model 3
17402801	Light - Fog/Reverse - Rear - RH (Remove & Install)	0.1	Model 3
17402802	Light - Fog/Reverse - Rear - RH (Remove & Replace)	0.1	Model 3
17403002	Light - Side Repeater - Front - LH (Remove & Replace)	0.15	Model 3
17403022	Trim - Light - Side Repeater - Front - LH (Remove & Replace)	0.15	Model 3
17403102	Light- Side Repeater - Front - RH (Remove & Replace)	0.15	Model 3
17403122	Trim - Light - Side Repeater - Front - RH (Remove & Replace)	0.15	Model 3
17403502	Reflector - Fascia - Rear - LH (Remove & Replace)	0.8	Model 3
17403602	Reflector - Fascia - Rear - RH (Remove & Replace)	0.8	Model 3
17404000	Lamps - Fog - Front - Adjust	0.1	Model 3
17404002	Light- Turn Signal/Fog - Front - LH (Remove & Replace)	0.3	Model 3
17404011	Cover - Fog Light - Front - LH (Remove and Install)	0.3	Model 3
17404012	Cover - Fog Light - Front - LH (Remove and Replace)	0.3	Model 3
17404102	Light- Turn Signal/Fog - Front - RH (Remove & Replace)	0.3	Model 3
17404111	Cover - Fog Light - Front - RH (Remove and Install)	0.3	Model 3
17404112	Cover - Fog Light - Front - RH (Remove and Replace)	0.3	Model 3
17404502	reflex lens - rear - RH (remove and replace)	0.05	Model 3
17407002	Switch - Hazard Warning (Remove & Replace)	1.25	Model 3
17409100	Headlight - Adjust - Europe	0.1	Model 3

17409150	Headlights - Adjust - EMEA (Tool Method)	0.15	Model 3
17450306	Replacement Keys - Program (No Keys Present)	0.05	Model 3
17450406	Additional Key - Program (Existing Key Present)	0.05	Model 3
17450802	Casing - Key Fob (Remove & Replace)	0.05	Model 3
17450902	Battery - Key Fob (Remove & Replace)	0.05	Model 3
17451002	Siren - Battery Backed (Remove & Replace)	0.1	Model 3
17451102	Antenna - Bluetooth Passive Entry - Front (Remove & Replace)	0.6	Model 3
17451802	Antenna - Bluetooth Passive Entry - Rear (Remove & Replace)	0.65	Model 3
17454002	Module - Body Controller - Security (Remove & Replace)	0.35	Model 3
17454012	Module - Body Controller - Security (2nd Generation) (Remove & Replace)	0.35	Model 3
17500302	Wiper Arm - LH (Remove & Replace)	0.05	Model 3
17500352	Wiper Arm - RH (Remove & Replace)	0.05	Model 3
17500805	Windshield Washer Fluid - Top Off	0	Model 3
17501002	Pump - Windshield Washer Reservoir (Remove & Replace)	0.6	Model 3
17501102	Reservoir - Windshield Washer (Remove & Replace)	0.6	Model 3
17501152	Reservoir Assembly - Windshield Washer (Remove and Replace)	0.55	Model 3
17501202	Cap - Reservoir - Windshield Washer (Remove and Replace)	0.05	Model 3
17501300	Nozzle Aim - Windshield Washer Jets	0.2	Model 3
17501352	Hose - Washer - Reservoir (RHD) (Remove & Replace)	0.55	Model 3
17501700	Wiper Blades (Adjust)	0.2	Model 3
17501702	Wiper Blades (Remove & Replace)	0.05	Model 3
17501802	Wiper Arms - Pair (Remove & Replace)	0.1	Model 3
17502502	Wiper Module (Remove & Replace)	0.3	Model 3
17503102	Filler Neck - Reservoir - Windshield Washer (RHD) (Remove and Replace)	0.05	Model 3
17504102	O-ring - Filler Neck - Reservoir - Windshield Washer (RHD) (Remove and Replace)	0.05	Model 3
17530102	Horn - High Tone (Remove & Replace)	0.6	Model 3
17530302	Horn - Low Tone (Remove & Replace)	0.6	Model 3
17531202	Horn Assembly (Remove and Replace)	0.05	Model 3
17541002	Speaker - Pedestrian Warning (Remove & Replace)	0.6	Model 3
17551002	Accelerator (Remove & Replace)	0.4	Model 3
18018163	Inspect the Air Conditioning Box Outlet, No More Action Required (CN Only)	0.35	Model 3
18019381	Inspect the Air Conditioning Box Outlet, Install Drain Pipe (CN Only)	0.6	Model 3
18019706	Inspect the Air Conditioning Box Outlet, Remove and Install the HVAC Assembly, Install Drain Pipe (CN Only)	3.75	Model 3
18035930	M3 - AC Pipe Insulation Rework	0.12	Model 3
18038927	AC Pipe Insulation Rework	0.12	Model 3
18039125	M3 - AC Pipe Insulation Rework EMEA	0.12	Model 3
18100102	Filter - Cabin (Remove & Replace)	0.15	Model 3
18101002	HVAC Assembly (Remove & Replace)	4.05	Model 3
18101012	HVAC Assembly (Heat Pump) (Remove & Replace)	3.95	Model 3
18101102	Thermistor - Duct - Upper - LH (Remove and Replace)	0.45	Model 3
18101202	Thermistor - Duct - Upper - RH (Remove and Replace)	0.15	Model 3
18102002	Actuator - Intake(Add Refrigerant Part if Needed) (Remove & Replace)	4.1	Model 3
18102012	Actuator - Intake (Heat Pump) (Remove & Replace)	3.65	Model 3
18102202	Actuator - Bleed - LH (Remove & Replace)	3.7	Model 3
18102212	Actuator - Bleed - LH (Heat Pump) (Remove & Replace)	2.75	Model 3
18102302	Actuator - Bleed - RH (Remove & Replace)	3.7	Model 3
18102312	Actuator - Bleed - RH (Heat Pump) (Remove & Replace)	2.75	Model 3
18102502	Actuator - Lower Mode (Remove & Replace)	0.5	Model 3
18102512	Actuator- Lower Mode (Heat Pump) (Remove & Replace)	0.45	Model 3
18102602	Actuator - Upper Mode (Remove & Replace)	0.5	Model 3
18102612	Actuator - Upper Mode (Heat Pump) (Remove & Replace)	0.4	Model 3
18103202	Blower Motor - HVAC (Remove & Replace)	4.1	Model 3
18103212	Blower Motor - HVAC (Heat Pump) (Remove & Replace)	3.65	Model 3
18103402	Actuator - Vent - LH (Remove & Replace)	0.25	Model 3
18103502	Actuator - Vent - RH (Remove & Replace)	0.25	Model 3
18104202	Thermistor - Duct - Lower - RH (Remove and Replace)	2.75	Model 3
18105302	Air Extractor - LH (Remove & Replace)	0.75	Model 3
18105322	Air Extractor - RH (Remove & Replace)	0.7	Model 3
18106302	Heater - PTC (Remove & Replace)	1	Model 3
18107202	Sensor - Ambient Air Temperature (Remove & Replace)	0.6	Model 3

18107212	Sensor - Ambient Air Temperature (Heat Pump) (Remove & Replace)	0.1	Model 3
18107502	Sensor - Cabin Temperature (Remove & Replace)	0.1	Model 3
18107602	Sensor - Temperature - Evaporator (Remove & Replace)	0.1	Model 3
18107802	Sensor - Temperature - LH (Remove & Replace)	0.1	Model 3
18107902	Sensor - Temperature - RH (Remove & Replace)	0.1	Model 3
18108002	Duct - Air Wave - LH (Remove & Replace)	2	Model 3
18108012	Duct - Air Wave - LH (RHD) (Remove & Replace)	0.25	Model 3
18108102	Duct - Air Wave - RH (Remove & Replace)	0.5	Model 3
18108112	Duct - Air Wave - RH (Heat Pump) (Remove & Replace)	0.35	Model 3
18108152	Duct - Air Wave - RH (RHD) (Remove & Replace)	1.5	Model 3
18108402	Duct - Cabin Intake (Remove & Replace)	0.1	Model 3
18108502	Duct - Fresh Intake (Remove & Replace)	0.1	Model 3
18108602	Duct - Footwell - LH (Remove & Replace)	0.3	Model 3
18108632	Duct - Footwell - LH (RHD) (Remove & Replace)	0.25	Model 3
18108642	Duct - Footwell - RH (RHD) (Remove & Replace)	0.1	Model 3
18108702	Duct - Footwell - RH (Remove & Replace)	0.3	Model 3
18109002	Duct - HVAC Plenum - Inner (Remove & Replace)	0.3	Model 3
18109102	Duct - HVAC Plenum - Outer (Remove & Replace)	0.1	Model 3
18200100	A/C Refrigerant - Check and Adjust Pressure (Add Refrigerant Part if Needed)	1	Model 3
18200102	A/C Refrigerant (Recovery & Recharge)	1.4	Model 3
18200122	A/C Refrigerant (Heat Pump) (Recovery & Recharge)	1.4	Model 3
18200200	Detecting Refrigerant Leaks (Add Refrigerant Part if Needed)	1.5	Model 3
18200408	Use HVAC Cleaning Machine	0.7	Model 3
18201002	Condenser (Add Refrigerant Part if Needed) (Remove & Replace)	2.25	Model 3
18201012	Evaporator (Pre-Heat Pump) (Remove & Replace)	4.7	Model 3
18201018	Use Evaporator Foam Cleaner, Replace Cabin Filters	0.45	Model 3
18201301	Module - Cooling Fan (Add Refrigerant Part if Needed) (Remove & Install)	1.8	Model 3
18201302	Module - Cooling Fan (Remove & Replace)	1.85	Model 3
18201311	Module - Cooling Fan (Heat Pump) (Remove and Install)	0.95	Model 3
18201312	Module - Cooling Fan (Heat Pump) (Remove and Replace)	0.95	Model 3
18201502	Fan - Condenser (Add Refrigerant Part if Needed) (Remove & Replace)	1.1	Model 3
18201702	A/C Line - Supermanifold to HVAC (Remove & Replace)	1.55	Model 3
18201902	A/C Line - Supermanifold to Compressor (Remove & Replace)	1.45	Model 3
18202002	Receiver Dryer and Desiccant (Add Refrigerant Part if Needed) (Remove & Replace)	1.3	Model 3
18202012	Receiver Dryer and Desiccant (Heat Pump) (Remove & Replace)	1.4	Model 3
18202202	Module - Condenser Fan Control - LH (Remove & Replace)		Model 3
18202302	Module - Condenser Fan Control - RH (Remove & Replace)		Model 3
18203202	Bracket - Compressor (Remove and Replace)	0.4	Model 3
18203212	Bracket - Compressor (Heat Pump) (Remove & Replace)	0.35	Model 3
18203502	Acoustic Blanket - Compressor (Remove & Replace)	0.75	Model 3
18203902	A/C Compressor (Remove & Replace)	1.85	Model 3
18203912	A/C Compressor (Heat Pump) (Remove & Replace)	1.8	Model 3
18204202	Pipe - High Pressure - A/C Compressor to Condenser (Add Refrigerant Part if Needed) (Remove & Replace)	1.3	Model 3
18204802	Pipes - Refrigerant - High/Low Pressure (Remove & Replace)	1.4	Model 3
18204902	Pipe - Low Pressure - Charge Port (Remove & Replace)	0.1	Model 3
18205002	TXV Valve- Evaporator (Add Refrigerant Part if Needed) (Remove & Replace)	1.25	Model 3
18205501	Sensor - Pressure and Temperature (PT) - High Pressure (Remove and Install))	1.2	Model 3
18205502	Sensor - Pressure and Temperature - High Pressure (Remove and Replace)	1.2	Model 3
18205601	Sensor - Pressure and Temperature (PT) - Low Pressure (Remove and Install)	0.9	Model 3
18205602	Sensor - Pressure and Temperature - Low Pressure (Remove and Replace)	0.9	Model 3
18205713	A/C Refrigerant Flush (manual) (CN)	0.6	Model 3
18206202	Chiller and EXV Assembly (Remove & Replace)	1.45	Model 3
18207630	Install Tube Protector for A/C Low Pressure Pipe (CN only)	0.15	Model 3
18300000	Cooling System - Partial Refill and Bleed	0.6	Model 3
18300012	Hose - Powertrain Supply - Supermanifold (Heat Pump) (Remove & Replace)	0.55	Model 3
18300100	Cooling System - (Drain & Refill)	0.9	Model 3
18300110	Cooling System (Heat Pump) (Drain & Refill)	0.85	Model 3
18300112	Hose - Inverter Inlet - Front Drive Unit (Remove & Replace)	0.9	Model 3
18300122	Hose - Inverter Inlet - Front Drive Unit (Heat Pump) (Remove & Replace)	0.5	Model 3
18300132	Hose - Inverter to Heat Exchanger - Front Drive Unit (Includes Alignment Check) (Remove & Replace)	0.75	Model 3

18300142	Hose - Inverter to Heat Exchanger - Front Drive Unit (Heat Pump) (Remove & Replace)	0.55	Model 3
18300172	Hose - Superbottle To Powertrain Supply (Remove & Replace)	0.85	Model 3
18300200	Coolant System - Check and Fill	0.25	Model 3
18300400	Cooling System - Vacuum Refill (Add Coolant 1029320-00 if Needed)	0.4	Model 3
18300410	Cooling System (Heat Pump) (Vacuum Refill)		Model 3
18300802	Hose - Front Drive Unit Heat Exchanger to Supermanifold (Heat Pump) (Remove & Replace)	0.55	Model 3
18300900	Thermal System Test	0.1	Model 3
18301001	Hose - Heat Exchanger to Superbottle - Front Drive Unit (Remove and Replace)	2.3	Model 3
18301002	Radiator (Remove & Replace)	2.3	Model 3
18301011	5-Way Valve (Remove & Install)		Model 3
18301022	Radiator (Heat Pump) (Remove & Replace)	1.05	Model 3
18301202	HOSE - CHILLER TO CAR COMPUTER AND HV BATTERY SUPPLY MANIFOLD (DUAL MOTOR) (REMOVE AND REPLACE)	3.8	Model 3
18301212	Hose - Chiller To Car Computer and HV Battery Supply Manifold (RHD) (Remove & Replace)	0.9	Model 3
18301502	Superbottle (Remove & Replace)	1.4	Model 3
18301512	Superbottle (Dual Motor) (Remove & Replace)	2.3	Model 3
18301702	Hose - Inlet - Inverter - Rear Drive Unit (Remove & Replace)	0.6	Model 3
18302302	Hose - Front Drive Unit Powertrain Bypass (Heat Pump) (RWD) (Remove & Replace)	0.55	Model 3
18302412	Hose - Chiller to HV Battery (Heat Pump) (Dual Motor) (Remove & Replace)	1.8	Model 3
18302422	Hose - HV Battery Return to Reservoir (Remove & Replace)	1.35	Model 3
18302502	Hose - Outlet - Rear Drive Unit (Remove & Replace)	0.75	Model 3
18302602	Hose - Inlet - Radiator (Remove & Replace)	0.01	Model 3
18302612	Hose - Inlet - Radiator (Heat Pump) (Remove & Replace)	0.55	Model 3
18302702	Hose - Outlet - Radiator (Remove & Replace)	0.5	Model 3
18302712	Hose - Outlet - Radiator (Heat Pump) (Remove & Replace)	0.5	Model 3
18303102	Hose - Return - Powertrain (Remove & Replace)	3.6	Model 3
18303112	Hose - Return - Powertrain (Heat Pump) (Remove & Replace)	3.1	Model 3
18303302	Hose - Supply - Powertrain (Remove & Replace)	3.6	Model 3
18303310	Insulate A/C Low Pressure Pipe and Install Harness Connector Cover (CN only)	0.35	Model 3
18303312	Hose - Supply - Powertrain (Heat Pump) (Remove & Replace)	3.2	Model 3
18303702	Hose - Return - HV Battery (Remove & Replace)	3.1	Model 3
18306302	Actuator - 5-Way Valve (Remove & Replace)	0.5	Model 3
18306312	Actuator - 5-Way Valve (Dual Motor) (Remove & Replace)	0.45	Model 3
18308102	Coolant Pump - Powertrain (RWD) (Remove and Replace)	0.75	Model 3
18308112	Coolant Pump - Powertrain (Dual Motor) (Remove and Replace)	0.7	Model 3
18308122	Coolant Pump - Powertrain (Heat Pump) (Remove & Replace)	0.65	Model 3
18308502	Coolant Pump - HV Battery (RWD) (Remove and Replace)	0.75	Model 3
18308512	Coolant Pump - HV Battery (Dual Motor) (Remove and Replace)	0.75	Model 3
18308522	Coolant Pump - HV Battery (Heat Pump) (Remove & Replace)	0.75	Model 3
18309302	Hose - Front Manifold - LH (Remove & Replace)	0.65	Model 3
18309345	Install Harness Connector Cover (CN Only)	0.3	Model 3
18309402	Hose - Front Manifold - RH (Remove & Replace)	0.6	Model 3
18400102	Supermanifold (Remove & Replace)	3.3	Model 3
18400106	Supermanifold 1.1 (Retrofit)	3.25	Model 3
18400202	Octovalve (Remove & Replace)	0.9	Model 3
18400302	Sensor - Pressure and Temperature (PT) - High Pressure (Remove & Replace)	1.5	Model 3
18400402	Sensor - Pressure and Temperature (PT) - Low Pressure (Remove & Replace)	1.45	Model 3
18400502	Sensor - Subcool - Pressure and Temperature (PT) - High Pressure (Remove & Replace)	1.45	Model 3
18400602	Valve Body - Octovalve (Remove & Replace)	0.9	Model 3
18400702	Actuator - Octovalve (Remove & Replace)	0.4	Model 3
18400902	Check Valve - Cabin Condenser (Remove & Replace)	1.55	Model 3
18401002	Check Valve - Evaporator (Remove & Replace)	1.45	Model 3
18401102	Check Valve - Liquid Cooled Condenser (Remove & Replace)	1.85	Model 3
18401202	Coil - EXV - Supermanifold (Remove & Replace)	1.85	Model 3
18401302	Valve Body - EXV - Supermanifold (Remove & Replace)	1.55	Model 3
18401402	Liquid Cooled Condenser (Remove & Replace)	1.9	Model 3
18401502	Shut Off Valve - Liquid Cooled Condenser (Remove & Replace)	1.55	Model 3
18401602	Chiller (Remove & Replace)	2.05	Model 3
18401702	Coolant Bottle (Remove & Replace)	0.8	Model 3
18500602	Active Grille Shutter (Remove & Replace)	0.9	Model 3
18500612	Active Grille Shutter (Heat Pump) (Remove & Replace)	0.9	Model 3

19010102	VIN Label - Windshield (Remove & Replace)	2.05	Model 3
19010202	Labels - Any (Remove & Replace)	0.2	Model 3
19010303	Labels - Battery Enclosure - Any	0.2	Model 3
19010401	VIN Label - Plate (Remove & Install)	0.05	Model 3
19011002	Replace Marketing Decal - Door - Front - LH (Remove & Replace)	0.5	Model 3
19011006	Install Marketing Decal - Door - Front - LH	0.3	Model 3
19011102	Replace Marketing Decal - Door - Front - RH (Remove & Replace)	0.5	Model 3
19011106	Install Marketing Decal - Door - Front - RH	0.3	Model 3
19011875	Print and Attach QC Compliance Label	0.05	Model 3
19013153	VIN Language Label - UAE Vehicles	0.1	Model 3
20010102	Airbag - Driver (Remove & Replace)	0.15	Model 3
20010201	Knee Airbag - Driver (Remove & Install)	0.3	Model 3
20010202	Knee Airbag - Driver (Remove & Replace)	0.3	Model 3
20010301	Airbag - Front Passenger (Remove & Install)	2	Model 3
20010302	Airbag - Front Passenger (Remove & Replace)	1.9	Model 3
20010402	Knee Airbag - Front Passenger (Remove & Replace)	0.3	Model 3
20010702	Side Airbag - Driver (Remove & Replace)	0.55	Model 3
20010707	Remove the Front Seat Airbag and Discard	0.1	Model 3
20010802	Side Airbag - Front Passenger (Remove & Replace)	0.55	Model 3
20012002	Curtain Airbag - LH (Remove & Replace)	1	Model 3
20012102	Curtain Airbag - RH (Remove & Replace)	1	Model 3
20013102	Harness - Airbag - Driver (Remove and Replace)	0.1	Model 3
20015002	Module - Restraint Control (Remove & Replace)	0.55	Model 3
20015012	Module - Restraint Control (Heat Pump) (Remove & Replace)	0.4	Model 3
20051001	Height Adjuster - Seat Belt (Remove & Install)	0.1	Model 3
20051102	Box Clip - Seat Belt Reminder - 1st Row - LH (Remove and Replace)	0.15	Model 3
20051202	Box Clip - Seat Belt Reminder - 1st Row - RH (Remove and Replace)	0.15	Model 3
20054102	Retractor - Seatbelt -1st Row - LH (Remove & Replace)	0.4	Model 3
20054202	Retractor - Seatbelt - 1st Row - RH (Remove & Replace)	0.4	Model 3
20054302	Webbing Guide Bar - Seatbelt - 1st Row - LH (Remove & Replace)	0.05	Model 3
20054702	Buckle - 1st Row - LH (Remove & Replace)	0.2	Model 3
20054802	Buckle - 1st Row - RH (Remove & Replace)	0.2	Model 3
20056102	Seatbelt - 2nd Row - LH (Remove & Replace)	0.3	Model 3
20056202	Seatbelt - 2nd Row - RH (Remove & Replace)	0.3	Model 3
20056302	Seatbelt - 2nd Row - Center (Remove & Replace)	0.5	Model 3
20057002	Buckle - 2nd Row - LH (Remove & Replace)	0.2	Model 3
20057102	Buckle - 2nd Row - RH (Remove & Replace)	0.2	Model 3
20057202	Buckle - 2nd Row - Center (Remove & Replace)	0.2	Model 3
20101002	Pretensioner - Outboard Lap - 1st Row - LH (Remove & Replace)	0.2	Model 3
20101102	Pretensioner - Outboard Lap - 1st Row - RH (Remove & Replace)	0.2	Model 3
20200102	Sensor - Pressure - Door - Front - LH (Remove and Replace)	0.3	Model 3
20200202	Sensor - Pressure - Door - Front - RH (Remove and Replace)	0.3	Model 3
20200302	Sensor - Airbag - Front - LH (Remove & Replace)	0.35	Model 3
20200402	Sensor - Airbag - Front - RH (Remove & Replace)	0.35	Model 3
20200502	Sensor - Airbag - B-Pillar - LH (Remove & Replace)	0.2	Model 3
20200602	Sensor - Airbag - B-Pillar - RH (Remove & Replace)	0.2	Model 3
20200702	Sensor - Airbag - C-Pillar - LH (Remove & Replace)	0.1	Model 3
20200802	Sensor - Airbag - C-Pillar - RH (Remove & Replace)	0.1	Model 3
20201002	Sensor - Airbag - Front (Remove & Replace)	0.2	Model 3
20202041	EMEA - RCM ODIN Fail Rectification	0.05	Model 3
20202102	Sensor - Resistive Occupancy - Front Seat - LH (Remove and Replace)	0.5	Model 3
20202202	Sensor - Resistive Occupancy - Front Seat - RH (Remove & Replace)	0.55	Model 3
20202693	Sensor - Ped Pro Pressure Tube (Remove and Replace)	0.4	Model 3
20203102	Sensor - Impact Accelerometer - Front Bumper - LH (Remove & Replace)	0.35	Model 3
20203202	Sensor - Impact Accelerometer - Front Bumper - RH (Remove and Replace)	0.1	Model 3
20203302	Sensor - Impact Accelerometer - Front Bumper - Center (Remove & Replace)	0.2	Model 3
20208491	Apply WD-40 to Actuator (CN only)	0.1	Model 3
20209274	EMEA - Restraint Control Module Installation	0.65	Model 3
20300102	Actuator - Pedestrian Protection - LH (Remove & Replace)	0.3	Model 3
20300202	Actuator - Pedestrian Protection - RH (Remove & Replace)	0.3	Model 3

20302102	Bracket - Corner - Active Hood - LH (Remove & Replace)	0.1	Model 3
20302202	Bracket - Corner - Active Hood - RH (Remove & Replace)	0.1	Model 3
20302302	Cover - HIInge - Active Hood - LH (Remove & Replace)	0.05	Model 3
20302402	Cover - HIInge - Active Hood - RH (Remove & Replace)	0.05	Model 3
21051000	Update Display Avatar	0.1	Model 3
21051202	Touchscreen (Remove & Replace)	0.3	Model 3
21051212	Service Panel - Instrument Panel (Remove & Replace)	0.05	Model 3
21062412	Non Tesla SIM Card (Install)	0	Model 3
21106948	Reflash Telit Modem	0.17	Model 3
21151002	Car Computer (Remove & Replace)	0.9	Model 3
21151011	Car Computer (Info-Ryzen) (Remove & Install)	1.35	Model 3
21151012	Car Computer (Info-Ryzen) (Remove & Replace)	1.4	Model 3
21151022	Visor - Car Computer (Info-Ryzen) (Remove & Replace)	1	Model 3
21151102	Car Computer (RHD) (Remove & Replace)	0.95	Model 3
21152002	SIM Card - Car Computer (Remove & Replace)	0.2	Model 3
21152102	SIM Card - Car Computer (HW3) (Remove & Replace)	0.2	Model 3
21152202	SIM Card - Car Computer (eCall) (Remove & Replace)	0.25	Model 3
21152402	SD Card - Car Computer (Remove & Replace)	1	Model 3
21152502	SD Card - Car Computer (HW3) (Remove & Replace)	0.2	Model 3
21152702	Connectivity Board - Car Computer (eCall) (Remove & Replace)	0.9	Model 3
21152802	Connectivity Board - Car Computer (HW2.5) (Remove & Replace)	0.4	Model 3
21152902	Connectivity Board - Car Computer (HW3) (Remove & Replace)	0.95	Model 3
21210102	Speaker - Front Door - LH (Remove & Replace)	0.2	Model 3
21210202	Speaker - Front Door - RH (Remove & Replace)	0.2	Model 3
21211002	Speaker - Rear Door - LH (Remove & Replace)	0.2	Model 3
21211102	Speaker - Rear Door - RH (Remove & Replace)	0.2	Model 3
21211502	Speaker - Dash - LH (Remove & Replace)	0.15	Model 3
21211602	Speaker - Dash - Center (Remove & Replace)	0.2	Model 3
21211702	Speaker - Dash - RH (Remove & Replace)	0.2	Model 3
21211802	Tweeter - Dash (Remove & Replace)	0.2	Model 3
21212002	Subwoofer (Remove & Replace)	0.4	Model 3
21212702	Tweeter - Front Door - LH (Remove & Replace)	0.1	Model 3
21212802	Tweeter - Front Door - RH (Remove & Replace)	0.1	Model 3
21213502	Amplifier - Audio - External (Remove & Replace)	0.45	Model 3
21213602	Speaker - Front Door- Upper - LH (Remove & Replace)	0.1	Model 3
21213702	Speaker - Front Door Upper - RH (Remove & Replace)	0.1	Model 3
21213802	Speaker - Parcel Shelf - LH (Remove & Replace)	0.4	Model 3
21213902	Speaker - Parcel Shelf - RH (Remove & Replace)	0.4	Model 3
21214002	Speaker - Emergency (Remove & Replace)	0.1	Model 3
21214302	Chime - Power Trunk (Remove & Replace)	0.1	Model 3
21214502	Speaker - Headliner - LH (Remove & Replace)	0.5	Model 3
21214602	Speaker - Headliner - RH (Remove & Replace)	0.5	Model 3
21220102	Tuner - FM / HD (Remove & Replace)	0.2	Model 3
21250102	Microphone - Bluetooth (Remove & Replace)	0.1	Model 3
21260402	USB Hub - Center Console - Front (Remove & Replace)	0.45	Model 3
21260412	USB Hub - Center Console - Front (2nd Generation) (Remove & Replace)	0.1	Model 3
21260502	USB Hub - Center Console (2nd Generation) (Remove & Replace)	0.45	Model 3
21260602	USB Hub - Center Console - Rear (Remove & Replace)	0.15	Model 3
21261002	USB-A Cable - Center Console (Remove & Replace)	0.1	Model 3
21300102	Antenna - AM/FM/RKE (Remove & Replace)	0.1	Model 3
21300402	Noise Filter - Ground (Remove & Replace)	0.15	Model 3
21300502	Noise Filter - 12V (Remove & Replace)	0.15	Model 3
21300702	Antenna Amplifier - FM2 (Remove & Replace)	0.1	Model 3
21300802	Antenna Amplifier - FM2/Satellite/DAB (Remove & Replace)	0.1	Model 3
21320102	Antenna - GPS (Remove & Replace)	0.15	Model 3
21330102	Antenna - Wi-Fi (Remove & Replace)	0.3	Model 3
21331102	Antenna - MIMO - LH (Remove and Replace)	0.3	Model 3
21341002	Antenna - eCall (Remove & Replace)	0.35	Model 3
21341012	Antenna - eCall (RHD) (Remove and Replace)	1.45	Model 3
30010201	Subframe Assembly - Rear (Includes Alignment Check) (Remove & Install)	2.85	Model 3

30010202	Subframe Assembly - Rear (Remove & Replace)	4.2	Model 3
30010301	Subframe Assembly - Front (RWD) (Includes Alignment Check) (Remove & Install)	2.45	Model 3
30010302	Subframe Assembly - Front (RWD) (Includes Alignment Check) (Remove & Replace)	2.25	Model 3
30010311	Subframe Assembly - Front (Dual Motor) (Includes Alignment Check) (Remove & Install)	2.55	Model 3
30010312	Subframe Assembly - Front (Dual Motor) (Includes Alignment Check) (Remove & Replace)	3.5	Model 3
30011001	Subframe Assembly - Front (Dual Motor) (Includes Alignment) (Remove & Install)	2.9	Model 3
30011012	Subframe Assembly - Front (Dual Motor) (Includes Alignment) (Remove & Replace)	2.9	Model 3
30011022	Isolator - Motor Mount - Front - LH (Remove and Replace)	3.7	Model 3
30012423	M10 Bolt Torque Check	0.1	Model 3
30013102	Rivnut - Underbody Panel - Rear Subframe (Remove & Replace)	0.3	Model 3
31000010	Mobile Inspection of SB-21-31-003 Performed; Bulletin Work To Be Performed At Service Center	0.2	Model 3
31000200	Four Wheel Alignment (Check And Adjust Camber Caster Toe) (Ballast Bags)	1.55	Model 3
31002100	Four Wheel Alignment (Check)	0.15	Model 3
31002200	Four Wheel Alignment (Adjust Toe)	0.55	Model 3
31010102	Knuckle - Suspension - Front - LH (Includes Alignment Check) (Remove & Replace)	0.85	Model 3
31010112	Knuckle - Suspension - Front - LH (Dual Motor) (Remove and Replace)	1.4	Model 3
31010202	Knuckle - Suspension - Front - RH (Includes Alignment Check) (Remove & Replace)	0.85	Model 3
31010212	Knuckle - Suspension - Front - RH (Dual Motor) (Remove & Replace)	0.95	Model 3
31010602	Hub - Front - LH (RWD) (Remove & Replace)	0.2	Model 3
31010702	Hub - Front - RH (RWD) (Remove & Replace)	0.2	Model 3
31010802	Hub - Front - LH (Dual Motor) (Remove & Replace)	0.35	Model 3
31010902	Hub - Front - RH (Dual Motor) (Remove & Replace)	0.35	Model 3
31011757	Inspect and Fasten Bolts in the Front Subframe X4 (China Only)	0.2	Model 3
31012002	Link - Stabilizer Bar - Front - LH (Remove & Replace)	0.15	Model 3
31012102	Link - Stabilizer Bar - Front - RH (Remove & Replace)	0.15	Model 3
31012202	Stabilizer Bar - Front (Remove & Replace)	0.5	Model 3
31012902	Link - Stabilizer Bar - Front - Pair (Remove & Replace)	0.25	Model 3
31013402	Link - Lateral - Lower - Front - LH (Remove & Replace)	0.5	Model 3
31013412	Links - Lateral - Lower - Front - LH/RH (Remove & Replace)	0.5	Model 3
31013502	Link - Lateral - Lower - Front - RH (Remove & Replace)	0.5	Model 3
31013602	Link - Compliance - Lower - Front - LH (Remove and Replace)	0.3	Model 3
31013642	Replace Bolts in the Lateral Link (China Only)	0.05	Model 3
31013702	Link - Compliance - Lower - Front - RH (Remove and Replace)	0.3	Model 3
31013802	Links - Compliance - Lower - Front - RH/LH (Remove and Replace)	0.45	Model 3
31014002	Control Arm - Upper - Front - LH (Includes Alignment Check) (Remove & Replace)	0.85	Model 3
31014032	Control Arm - Upper - Front - LH (Mobile Service) (Remove & Replace)	0.8	Model 3
31014042	Control Arm - Upper - Front - RH (Mobile Service) (Remove & Replace)	0.8	Model 3
31014052	Control Arm - Upper - Front - Pair (Includes Alignment Check) (Remove and Replace)	2.25	Model 3
31014102	Control Arm - Upper - Front - RH (Includes Alignment Check) (Remove & Replace)	1.15	Model 3
31015002	Front Upper Control Arm (FUCA) Mount - LH (Includes Alignment Check) (Remove & Replace)	0.85	Model 3
31015102	Front Upper Control Arm (FUCA) Mount - RH (Remove & Replace)	0.85	Model 3
31016102	Bushing Bracket - Stabilizer Bar - Front - LH (Remove and Replace)	0.4	Model 3
31016302	Bushing Bracket - Stabilizer Bar - Front - RH (Remove and Replace)	0.4	Model 3
31016862	Inspect Front Stabilizer Bar (CN Only)	0.05	Model 3
31017890	Inspect Bolts in the Lateral Link (China Only)	0.25	Model 3
31018097	Inspect Front Stabilizer Bar, Replace Front Stabilizer Bar (CN Only)	0.5	Model 3
31019000	Suspension - Front - Check Torque (Includes Alignment Check)	0.4	Model 3
31019016	Replace Bots in the Link X4	0.25	Model 3
31030102	Knuckle - Suspension - Rear - LH (Includes Alignment Check) (Remove & Replace)	1.9	Model 3
31030202	Knuckle - Suspension - Rear - RH (Includes Alignment Check) (Remove & Replace)	1.9	Model 3
31030602	Hub - Rear - RH (Remove & Replace)	0.75	Model 3
31030702	Hub - Rear - LH (Includes Alignment Check) (Remove & Replace)	0.75	Model 3
31031102	Control Arm Assembly - Rear - Lower - LH (Remove & Replace)	1.25	Model 3
31031202	Control Arm Assembly - Rear - Lower - RH (Remove & Replace)	1.25	Model 3
31031402	Link - Fore - Upper - Rear - LH (Includes Alignment Check) (Remove & Replace)	3.65	Model 3
31031502	Link - Fore - Upper - Rear - RH (Remove & Replace)	3.65	Model 3
31032001	Link - Fore Lower - Rear - LH (Includes Alignment Check) (Remove & Install)	1.2	Model 3
31032002	Toe Link Assembly - Rear - LH (Includes Alignment Check) (Remove & Replace)	1.2	Model 3
31032011	Cover - Rear Suspension - LH (Remove & Install)	0.1	Model 3
31032012	Cover - Rear Suspension - LH (Remove & Replace)	0.1	Model 3

31032021	Cover - Rear Suspension - RH (Remove & Install)	0.05	Model 3
31032022	Cover - Rear Suspension - RH (Remove & Replace)	0.05	Model 3
31032101	Link - Fore Lower - Rear - RH (Includes Alignment Check) (Remove & Install)	1.2	Model 3
31033102	Stabilizer Bar - Rear (Includes Alignment Check) (Remove & Replace)	0.4	Model 3
31033402	Drop Link - Stabilizer Bar - Rear - LH (Remove & Replace)	0.3	Model 3
31033602	Drop Link - Stabilizer Bar - Rear - RH (Remove & Replace)	0.3	Model 3
31033702	Toe Link Assembly - Rear - RH (Includes Alignment Check) (Remove & Replace)	1.2	Model 3
31035102	Link - Aft - Upper - Rear - LH (Remove & Replace)	1.1	Model 3
31035202	Link - Aft - Upper - Rear - RH (Remove & Replace)	1.1	Model 3
31036102	Sensor - Ride Height - Rear - LH (Remove & Replace)	0	Model 3
31036202	Sensor - Ride Height - Rear - RH (Remove & Replace)	0	Model 3
31039000	Suspension - Rear (Check Torque)	0.3	Model 3
31102802	Sensor - Ride Height - Front - LH (Remove & Replace)	0.15	Model 3
31102902	Sensor - Ride Height - Front - RH (Remove & Replace)	0	Model 3
31151002	Spring and Damper Assembly - Front - LH (Includes Alignment Check) (Remove & Replace)	0.45	Model 3
31151102	Spring and Damper Assembly - Front - RH (Remove & Replace)	0.45	Model 3
31153002	Spring - Rear Suspension - LH (Includes Alignment Check) (Remove & Replace)	1.3	Model 3
31153102	Spring - Rear Suspension - RH (Remove & Replace)	1.3	Model 3
31153602	Damper - Rear - LH (Remove & Replace)	0.4	Model 3
31153702	Damper - Rear - RH (Remove & Replace)	0.4	Model 3
32010102	Steering Rack (RWD) (Includes Alignment Check) (Remove & Replace)	1.35	Model 3
32010103	Steering Rack - Calibration	0.2	Model 3
32010302	Tie Rod End - LH (Includes Alignment Check) (Remove & Replace)	1	Model 3
32010402	Tie Rod End - RH (Includes Alignment Check) (Remove & Replace)	1	Model 3
32010802	Seal - Steering - Intermediate Shaft - Dash (Remove & Replace)	0.1	Model 3
32011002	Module - Steering Column Control (Remove & Replace)	0.3	Model 3
32012202	Steering Rack (Dual Motor) (Includes Alignment Check) (Remove & Replace)	1.35	Model 3
32012212	Steering Rack (Dual Motor RHD) (Remove & Replace)	3.5	Model 3
32050012	Horn - Steering Wheel (Remove & Replace)	0.15	Model 3
32051801	Steering Wheel (Remove & Install)	0.2	Model 3
32051802	Steering Wheel (Remove & Replace)	0.3	Model 3
32051902	Steering Column (Remove & Replace)	0.9	Model 3
32051912	Steering Column (RHD) (Remove & Replace)	0.75	Model 3
33010100	Brake Rotor - Front - LH (Measure Runout)	0.3	Model 3
33010102	Brake Rotor - Front - LH (Remove & Replace)	0.2	Model 3
33010122	ECU - ABS Modulator (Heat Pump) (Remove & Replace)	1.3	Model 3
33010200	Brake Rotor - Rear - LH (Measure Runout)	0.35	Model 3
33010202	Brake Rotor - Rear - LH (Remove & Replace)	0.5	Model 3
33010302	Brake Caliper - Front - LH (Remove & Replace)	0.75	Model 3
33010402	Brake Caliper - Front - RH (Remove & Replace)	0.75	Model 3
33010502	Brake Caliper - Rear - LH (Remove & Replace)	0.7	Model 3
33010602	Brake Caliper - Rear - RH (Remove & Replace)	0.7	Model 3
33010702	Brake Pad Kit - Front (Remove & Replace)	0.65	Model 3
33010712	Brake Pad Kit - Front (Sport Brakes) (Remove & Replace)	0.8	Model 3
33010802	Brake Pads - Rear - Set(Base Brakes)(Remove & Replace)	0.75	Model 3
33010812	Brake Pad Kit - Rear (Sport Brakes) (Remove & Replace)	0.75	Model 3
33010905	Brake Pads and Rotors - Front - Set	0.85	Model 3
33011005	Brake Pads and Rotors - Rear - Set	0.8	Model 3
33011100	Brake Rotor - Front - RH (Measure Runout)	0.3	Model 3
33011102	Brake Rotor - Front - RH (Remove & Replace)	0.2	Model 3
33011200	Brake Rotor - Rear - RH (Measure Runout)	0.35	Model 3
33011202	Brake Rotor - Rear - RH (Remove & Replace)	0.5	Model 3
33011302	Brake Rotors - Front - Set (Remove & Replace)	0.6	Model 3
33011402	Brake Rotors - Rear - Set (Remove & Replace)	0.6	Model 3
33011505	Brake Pads and Rotors - Vehicle - Set	1.65	Model 3
33011602	Shield - Dust - Brake - Front - LH (Remove & Replace)	0.3	Model 3
33011702	Shield - Dust - Brake - Front - RH (Remove & Replace)	0.3	Model 3
33011801	Shield - Dust - Brake - Rear - LH (Remove & Install)	0.25	Model 3
33011802	Shield - Dust - Brake - Rear - LH (Remove & Replace)	0.25	Model 3
33011806	Shield - Dust - Brake - Rear - LH/RH	0.8	Model 3

33011902	Shield - Dust - Brake - Rear - RH (Remove & Replace)	0.15	Model 3
33013000	Brake Pads - Burnishing	0.3	Model 3
33013345	Clean And Lubricate Brake Calipers (Non-Performance Brakes) (Requires Code 34012501)	0.35	Model 3
33013365	Clean And Lubricate Brake Calipers (Performance Brakes) (Requires Code 34012501)	0.3	Model 3
33014999	Brake pad NVH film installation - Front (set) (CN)	0.3	Model 3
33016750	Brake Pad NVH Film Installation - Rear (Set) (CN)	0.3	Model 3
33030202	Brake Hose - Flexible - Front - RH (Remove & Replace)	0.8	Model 3
33030302	Brake Hose - Flexible - Front - LH (Remove & Replace)	0.8	Model 3
33030402	Brake Hose - Flexible - Rear - RH (Remove & Replace)	0.6	Model 3
33030502	Brake Hose - Flexible - Rear - LH (Remove & Replace) (Add Brake Fluid 1060099-00A if Needed)	0.6	Model 3
33031102	Brake Fluid Bleed - One Caliper (Remove & Replace)	0.55	Model 3
33031200	Brake Fluid Check	0.1	Model 3
33031202	Brake Fluid Bleed/Flush (Remove & Replace) (Add Brake Fluid 1060099-00A if Needed)	0.9	Model 3
33033902	Brake Lines - 4 Tube Bundle - ABS to Wheels (RWD) (Remove & Replace)	2.5	Model 3
33033952	Brake Lines - 4 Tube Bundle - ABS to Wheels (Dual Motor) (Remove & Replace)	4.35	Model 3
33034002	Brake Lines - Master Cylinder to ABS (Remove & Replace)	1.8	Model 3
33034202	Brake Lines - Master Cylinder to ABS (RHD) (Remove & Replace)	2.9	Model 3
33034502	Brake Line - Master Cylinder to ABS (Dual Motor) (RHD) (Remove & Replace)	5.3	Model 3
33035002	Brake Lines - Front Bundle (Remove & Replace)	0.1	Model 3
33035102	Brake Lines - LH Sill (Remove & Replace)	3.75	Model 3
33035202	Brake Lines - Rear - LH to Sill (Remove & Replace)	0.8	Model 3
33035302	Brake Lines - Rear - RH to Sill (Includes Alignment Check) (Remove & Replace)	2.8	Model 3
33051005	Rear Park Brake Caliper - Caliper Seized/Motor Failure - Release	0.15	Model 3
33100102	ABS Modulator Assembly (Remove & Replace)	2.2	Model 3
33100112	ABS Modulator Assembly (Heat Pump) (Remove & Replace)	2.4	Model 3
33100202	ECU - ABS (RWD) (Remove & Replace)	1.1	Model 3
33100212	ECU - ABS (Dual Motor) (Remove & Replace)	2.45	Model 3
33100502	Sensor - Wheel Speed - ABS - Front - LH (Remove & Replace)	0.3	Model 3
33100602	Sensor - Wheel Speed - ABS - Front - RH (Remove & Replace)	0.3	Model 3
33100702	Sensor - Wheel Speed - ABS - Rear - LH (Remove & Replace)	0.2	Model 3
33100802	Sensor - Wheel Speed - ABS - Rear - RH (Remove & Replace)	0.2	Model 3
33201002	Electromechanical Brake Booster Assembly (Remove & Replace) (Add Brake Fluid 1060099-00A if Needed)	2.65	Model 3
33201012	Master Cylinder and Reservoir Assembly (Remove & Replace)	1.45	Model 3
33201102	Electromechanical Brake Booster Assembly (RHD) (Remove & Replace)	1.75	Model 3
33251002	Brake Pedal (Remove & Replace)	0.6	Model 3
33252002	Switch - Brake Light (Remove & Replace)	0.35	Model 3
34011000	Inspect Wheel (Cosmetic Inspection)	0.1	Model 3
34011106	Wheel Lock Set - Install	0.45	Model 3
34011302	Lug Nuts - Vehicle Set (Remove & Replace)	0.4	Model 3
34011402	Lug Nut Covers - Vehicle Set (Remove & Replace)	0.1	Model 3
34011748	Tire Package - Added Services - M3 18"	1	Model 3
34012401	Wheels - Axle Set (Remove & Install)	0.2	Model 3
34012501	Wheels - Vehicle - Set (Remove & Install)	0.2	Model 3
34012508	Wheels - Vehicle - Set (Cosmetic Refinish)	2	Model 3
34012510	Tire Package - Added Services - M3 20"	1	Model 3
34012902	Wheels and Tires - Vehicle - Set (Remove and Replace)	0.9	Model 3
34013000	Check Tire Tread Depth	0.05	Model 3
34013374	Inspect And Tighten Halfshaft Torque - Dual Motor (CN Only)	0.4	Model 3
34014005	Seasonal Wheel and Tire Set Swap	0.4	Model 3
34014105	Seasonal Tire Swap on Existing Wheels	1	Model 3
34014505	Accessory Wheel/Tire Package Assembly	1.1	Model 3
34015001	Wheel - Front - LH (Remove & Install)	0.1	Model 3
34015002	Wheel - Front - LH (Remove & Replace)	0.25	Model 3
34015008	Wheel - Front - LH (Cosmetic Refinish)	0.5	Model 3
34015011	Center Cap - Wheel (Remove and Replace)	0.05	Model 3
34015012	Cap - Wheel - 19 Inch Stiletto - Front - LH (Remove & Replace)	0.05	Model 3
34015021	Cover, Wheel, Front, LH (Remove & Install)	0.05	Model 3
34015022	Cap - Wheel - Front - LH (Remove & Replace)	0.05	Model 3
34015101	Wheel - Front - RH (Remove & Install)	0.1	Model 3
34015102	Wheel - Front - RH (Remove & Replace)	0.25	Model 3

34015108	Wheel – Front – RH (Cosmetic Refinish)	0.5	Model 3
34015112	Cap - Wheel - 19 Inch Stiletto - Front - RH (Remove & Replace)	0.05	Model 3
34015121	Cover, Wheel, Front, RH (Remove & Install)	0.05	Model 3
34015122	Cap - Wheel - Front - RH (Remove & Replace)	0.05	Model 3
34015201	Wheel - Rear - LH (Remove & Install)	0.1	Model 3
34015202	Wheel - Rear - LH (Remove & Replace)	0.25	Model 3
34015208	Wheel – Rear – LH (Cosmetic Refinish)	0.5	Model 3
34015212	Cap - Wheel - 19 Inch Stiletto - Rear - LH (Remove & Replace)	0.05	Model 3
34015221	Cover, Wheel, Rear, LH (Remove & Install)	0.05	Model 3
34015222	Cap - Wheel - Rear - LH (Remove & Replace)	0.05	Model 3
34015301	Wheel - Rear - RH (Remove & Install)	0.1	Model 3
34015302	Wheel - Rear - RH (Remove & Replace)	0.25	Model 3
34015308	Wheel – Rear – RH (Cosmetic Refinish)	0.5	Model 3
34015312	Cap - Wheel - 19 Inch Stiletto - Rear - RH (Remove & Replace)	0.05	Model 3
34015321	Cover, Wheel, Rear, RH (Remove & Install)	0.05	Model 3
34015322	Cap - Wheel - Rear - RH (Remove & Replace)	0.05	Model 3
34015401	Install Wheel Caps - Set	0.05	Model 3
34015629	Tire Package - Added Services - M3 19"	1	Model 3
34016000	Lug Nut - Check and Torque (All Wheels)	0.05	Model 3
34017352	Tire & Wheel - Winter Wheels - M3 18"	1	Model 3
34018176	Inspect And Tighten Halfshaft Torque - RWD (CN Only)	0.2	Model 3
34018421	Tire & Wheel - Winter Wheels - M3 20"	1	Model 3
34019796	Tire & Wheel - Winter Wheels - M3 19"	1	Model 3
34020010	Mobile Tire Service Performed	0	Model 3
34020020	Mobile Tire Service Performed – Roadside	0	Model 3
34020030	Mobile Tire Service Performed – Logistics	0	Model 3
34020105	Tire Rotation With Automatic TPMS Learn	0.2	Model 3
34020115	Tire Rotation With Manual TPMS Learn	0.4	Model 3
34020305	Rebalance 4 Tires	0.9	Model 3
34020505	Tire Rotation and Rebalance With Automatic TPMS Learn	0.6	Model 3
34020700	Set Tire Pressure	0.05	Model 3
34020800	Automated Tire Pressure Check	0	Model 3
34020900	Check and Adjust Tire Pressure	0.05	Model 3
34021002	Tire - Front - LH (Remove & Replace)	0.25	Model 3
34021102	Tire - Front - RH (Remove & Replace)	0.25	Model 3
34021202	Tire - Rear - LH (Remove & Replace)	0.25	Model 3
34021302	Tire - Rear - RH (Remove & Replace)	0.25	Model 3
34021405	Tires - Front - Set	0.5	Model 3
34021605	Tires - Rear - Set	0.5	Model 3
34021805	Tires - Vehicle - Set	1	Model 3
34021905	Wheel And New Tire Swap - Vehicle - Set	1	Model 3
34022005	Tire - Front - LH (Road Force) (Balance)	0.15	Model 3
34022015	Tire - Supplemental (Rebalance)	0.15	Model 3
34022025	Tire - Front - LH (Balance)	0.25	Model 3
34022105	Tire - Front - RH (Road Force) (Balance)	0.15	Model 3
34022125	Tire - Front - RH (Balance)	0.05	Model 3
34022205	Tire - Rear - LH (Road Force) (Balance)	0.15	Model 3
34022225	Tire - Rear - LH (Balance)	0.05	Model 3
34022305	Tire - Rear - RH (Road Force) (Balance)	0.15	Model 3
34022325	Tire - Rear - RH (Balance)	0.05	Model 3
34023008	Tire - Front - LH (Repair)	0.55	Model 3
34023108	Tire - Front - RH (Repair)	0.55	Model 3
34023208	Tire - Rear - LH (Repair)	0.55	Model 3
34023308	Tire - Rear - RH (Repair)	0.55	Model 3
34040006	Tire Pressure Monitoring System (TPMS) (Retrofit)	0.85	Model 3
34040202	Sensor - TPMS - Front - LH (Remove & Replace)	0.35	Model 3
34040302	Sensor - TPMS - Front - RH (Remove & Replace)	0.35	Model 3
34040402	Sensor - TPMS - Rear - LH (Remove & Replace)	0.35	Model 3
34040502	Sensor - TPMS - Rear - RH (Remove & Replace)	0.35	Model 3
34040602	Wheel Sensors - TPMS - Vehicle Set (Remove & Replace)	0.8	Model 3

34041100	Module - TPMS (Sensor ID Learn)	0.35	Model 3
34041150	TPMS (Sensor ID Drive Learn)	0.05	Model 3
34041200	TPMS (BLE Sensor Learn)	0.05	Model 3
34041300	TPMS - Set Thresholds	0.3	Model 3
34041400	TPMS (BLE Sensor Learn)	0.05	Model 3
34043002	Module - TPMS (Remove & Replace)	0.45	Model 3
34572735	Inspect Halfshaft Torque - Dual Motor (CN Only)	0.4	Model 3
34573181	Inspect Halfshaft Torque - RWD (CN Only)	0.2	Model 3
39011002	Ground Strap - Front Drive Unit (Remove & Replace)	0.6	Model 3
39011102	Bushing – Front Drive Unit – RH (Includes Alignment Check) (Remove & Replace)	4.35	Model 3
39011202	Bushing - Gearbox - Front Drive Unit (Includes Alignment Check) (Remove & Replace)	0.6	Model 3
39012101	Drive Unit - Front (1st Generation) (Includes Alignment Check) (Remove & Install)	4.65	Model 3
39012102	Drive Unit - Front (1st Generation) (Includes Alignment Check) (Remove & Replace)	3.35	Model 3
39012600	Mount - Front Drive Unit - LH (Includes Alignment Check)	4.3	Model 3
39019175	Replace Motor Oil (DM)	2.9	Model 3
39200602	Inverter - Front Drive Unit (Remove & Replace)	3.35	Model 3
39300100	Gearbox Fluid - Front Drive Unit (Check and Fill)	0.2	Model 3
39300102	Gearbox Fluid - Front Drive Unit (1st Generation) (Drain and Refill)	0.5	Model 3
39301002	Heat Exchanger - Front Drive Unit (Remove & Replace)	0.75	Model 3
39301012	Gearbox - Front Drive Unit (Remove & Replace)	5.55	Model 3
39301022	Seal - Oil - Differential to Halfshaft Assembly - Front Drive Unit - LH (Remove & Replace)	0.7	Model 3
39301032	Seal - Oil - Differential to Halfshaft Assembly - Front Drive Unit - RH (Remove & Replace)	0.7	Model 3
39301602	Oil Pump - Front Drive Unit (Remove & Replace)	0.5	Model 3
39302012	Halfshaft Assembly - Front - LH (Remove & Replace)	0.7	Model 3
39302112	Halfshaft Assembly - Front - RH (Remove & Replace)	0.7	Model 3
39302405	Halfshaft - Front Drive Unit - LH (Lubricate at Hub)	0.2	Model 3
39302415	Halfshaft - Front Drive Unit - RH (Lubricate at Hub)	0.2	Model 3
39304802	FILTER - OIL - FRONT DRIVE UNIT (REMOVE AND REPLACE)	0	Model 3
39305402	Breather - Front Drive Unit (Includes Alignment Check) (Remove & Replace)	0.4	Model 3
40011001	Drive Unit - Rear (Includes Alignment Check) (Remove & Install)	3.4	Model 3
40011002	Drive Unit - Rear (Includes Alignment Check) (Remove & Replace)	3.3	Model 3
40012002	Mount - Rear Drive Unit - LH (Includes Alignment Check) (Remove & Replace)	2.5	Model 3
40012202	Ground Strap - Rear Drive Unit (Remove & Replace)	0.55	Model 3
40012402	Bushing - Rear Drive Unit - RH (Includes Alignment Check) (Remove & Replace)	4.65	Model 3
40012537	Replace Motor Oil (RWD)	1.45	Model 3
40012602	Bushing - Rear Drive Unit - Rear (Includes Alignment Check) (Remove & Replace)	3.65	Model 3
40012802	Mount And Bushings Set - Rear Drive Unit (Remove & Replace)	3.9	Model 3
40013000	Drive Unit - Create Imprint of Side Serial Number	0.2	Model 3
40013100	Drive Unit - Create Imprint of Lower Serial Number	0.6	Model 3
40014002	Fluid Coupling (55 Degrees) - Rear Drive Unit (Remove & Replace)	0.6	Model 3
40014202	Fluid Coupling (Straight) - Rear Drive Unit (Includes Alignment Check) (Remove & Replace)	2.9	Model 3
40200202	Hose - Inverter to Heat Exchanger - Rear Drive Unit (Remove & Replace)	2.6	Model 3
40200602	Inverter - Rear Drive Unit (Includes Alignment Check) (Remove & Replace)	3.75	Model 3
40202000	Powertrain Coolant (Drain and Refill) (Add Coolant 1029320-00 if Needed)	0.1	Model 3
40202010	Inverter Coolant Leak Test (Add Coolant 1029320-00 if Needed)	0.1	Model 3
40202020	Inverter Air Leak Test	0.1	Model 3
40206302	HV Header - Inverter - Rear Drive Unit (Remove & Replace)	0.8	Model 3
40300102	Gearbox Fluid - Rear Drive Unit (Drain and Refill)	0.45	Model 3
40301002	Seal - Oil - Differential to Halfshaft Assembly - Rear Drive Unit - LH (Includes Alignment Check) (Remove & Replace)	1.05	Model 3
40301102	Seal - Axle - Rear Drive Unit - RH (Remove & Replace)	1.05	Model 3
40302002	Halfshaft Assembly - Rear - LH (Includes Alignment Check) (Remove & Replace)	1.05	Model 3
40302102	Halfshaft - Rear Drive Unit - RH (Remove & Replace)	1.05	Model 3
40302405	Halfshaft - Rear Drive Unit - LH (Lubricate at Hub)	0.2	Model 3
40302415	Halfshaft - Rear Drive Unit - RH (Lubricate at Hub)	0.2	Model 3
40304602	Oil Pump - Rear Drive Unit (Remove & Replace)	0.45	Model 3
40304802	Oil Filter - Rear Drive Unit (Remove & Replace)	0.4	Model 3
40305002	Oil Screen - Rear Drive Unit (Remove & Replace)	0.65	Model 3
40305202	Heat Exchanger - Rear Drive Unit (Includes Alignment Check) (Remove & Replace)	2.3	Model 3
40305402	Breather - Rear Drive Unit (Includes Alignment Check) (Remove & Replace)	1.8	Model 3
44010012	Actuator - Door Assembly - Charge Port (NA) (Remove & Replace)	0.75	Model 3

44010102	Sensor Target - Door - Charge Port (Remove & Replace)	0.2	Model 3
44011502	Door - Charge Port (Remove & Replace)	0.55	Model 3
44011602	Charge Port (Busbar Type) (Remove and Replace)	0.6	Model 3
44011652	Charge Port (Busbar) (3-Phase) (Remove & Replace)	0.5	Model 3
44011702	DOOR AND HINGE COVER - CHARGE PORT (REMOVE AND REPLACE)	0.15	Model 3
44011795	Deadfronts - Pin - Charge Port		Model 3
44011802	Retainer Bracket - Busbar - Charge Port to HV Battery (3-Phase) (Remove & Replace)	0.35	Model 3
44011902	Bracket - Busbar - Charge Port to HV Battery (3-Phase) (Remove & Replace)	0.5	Model 3
44012102	Carrier Assembly - Charge Port (Remove & Replace)	0.7	Model 3
44012112	Deadfronts - Pin - Charge Port (Remove & Replace)	0.2	Model 3
44012122	Sub-Assembly - Latch - Charge Port (EMEA) (Remove & Replace)	0.55	Model 3
44012712	Charge Port (China) (Busbar Type) (Remove & Replace)	0.5	Model 3
44013102	Busbars - Charge Port to HV Battery (Remove and Replace)	0.7	Model 3
44013112	Busbars - Charge Port to HV Battery (China) (Remove & Replace)	0.7	Model 3
44013152	Busbars - Charge Port to HV Battery (3-Phase) (Remove & Replace)	0.7	Model 3
44013202	Release Cable - Charge Port (Remove & Replace)	0.35	Model 3
44013205	Charge Port - Manual Release of Cable	0.15	Model 3
44014002	Latch Actuator - Charge Port (Remove & Replace)	0.7	Model 3
44014302	Door Assembly - Charge Port (China) (Remove and Replace)	0.5	Model 3
44015002	ECU - Charge Port (Remove & Replace)	0.15	Model 3
44015012	ECU - Charge Port (Busbar Type) (Remove & Replace)	0.35	Model 3
44015102	Safety Cap - Busbar - Charge Port to HV Battery (Remove & Replace)	0.3	Model 3
44015302	Door Assembly - Charge Port (EMEA) (Remove & Replace)	0.55	Model 3
44017102	Safety Cap - Busbar - Inlet - Charge Port (3-Phase) (Remove & Replace)	0	Model 3
44018202	Bracket - Retainer - Busbar - Charge Port to HV Battery (3-Phase) (Remove & Replace)	0.35	Model 3
44019566	Charge Port Lubrication	0.6	Model 3
44500502	Harness - HV Battery to Charge Port (Remove & Replace)	0.65	Model 3
44501102	HV Harness Assembly - Charge Port to HV Battery (Three-Phase) (Remove and Replace)	0.7	Model 3
44501302	Harness - Center Ski to A/C Compressor (Remove & Replace)	0.6	Model 3
44501402	AC Cable - Charge Port to HV Battery (3-Phase) (Remove & Replace)	0.35	Model 3
44502102	HARNES - HV BATTERY TO FRONT DRIVE UNIT (REMOVE AND REPLACE)	1.7	Model 3
44502202	Harness - HV Battery to Rear Drive Unit (Remove & Replace)	0.75	Model 3
44503002	Harness - HV Battery to PTC Heater and A/C Compressor (RWD) (Remove & Replace)	1.25	Model 3
44503012	HV Harness - HV Battery to PTC Heater and A/C Compressor (Dual Motor) (Remove and Replace)	1.7	Model 3
44508569	Harness - A/C Compressor (Remove & Replace)	0.6	Model 3
44509100	High Voltage Circuit Integrity Check	2	Model 3
45001100	NVH Adjustment - 0.25	0.25	Model 3
45001200	NVH Adjustment - 0.5	0.5	Model 3
45001400	Noise/Vibration: Verify And Inspect On-Site	0.3	Model 3
45001409	NVH Inspection - No Trouble Found	0.3	Model 3
45001500	NVH Inspection - Vehicle Familiarization	0.3	Model 3
46016297	Perform Coolant Air Purge Inspection, Need Further Repair (China Only)	0.5	Model 3
46017105	Perform Coolant Air Purge Inspection, No More Action Required (China Only)	0.5	Model 3
50010102	Mobile Connector - UMC (Remove & Replace)	0.1	Model 3
50010202	Remove Stuck Deadfront - Charge Handle	0.05	Model 3
50010206	Provide Mobile Connector Adapter	0.1	Model 3
50011003	Firmware Update - CHAdeMO Charging Adapter	0.1	Model 3
50011102	CHAdeMO Charging Adapter (Remove & Replace)	0.05	Model 3
50011106	Provide CHAdeMO Charging Adapter	0.05	Model 3
50020102	Fuses - Wall Connector (Remove & Replace)	0.5	Model 3
50020402	Cover - Wall Connector (Remove & Replace)	0.1	Model 3
50020702	Wall Connector (Remove & Replace)	0.7	Model 3
50020705	Wall Connector - Sublet	0	Model 3
50020706	Wall Connector Installation	0.9	Model 3
50022002	Handle and Cable Assembly - 80A Wall Connector (Remove & Replace)	0.4	Model 3
50023002	Replace Wall Connector and Reimburse Installation Cost (Remove & Replace)	0	Model 3
50024002	Handle and Cable Assembly - 40A Wall Connector (Remove & Replace)	0.4	Model 3
50030102	Supercharging Cable - Connector (Remove & Replace)	0.4	Model 3
50040102	Check House Current, Provide Mennekes Cable (Remove & Replace)	0.2	Model 3
50040406	Provide J1772 Adapter	0.1	Model 3

50041003	Firmware Update - GB DC Charging Adapter	0.1	Model 3
61010007	Tesla Body Repair - Paint Labor	0	Model 3
61011442	Tesla Body Painting--Car Wash	1	Model 3
61013828	EMEA - Vehicle Region Conversion	0.5	Model 3
61014373	Tesla Body Painting--Paint Polishing (China)		Model 3
61015612	Tesla Body Painting--Polishing	1	Model 3
61015962	Tesla Body Painting--Undercoat Polishing	1	Model 3
61016264	Tesla Body Painting--Painting	1	Model 3
61017157	Tesla Body Painting--Painting Preparation	1	Model 3
61019175	Tesla Body Painting--Spraying Undercoat	1	Model 3
70000105	Third Party Transport	1	Model 3
70000305	Miscellaneous Labor	0	Model 3
70000505	Tire Disposal	1	Model 3
70001405	Valet Service (Tech)	0	Model 3
70001605	Valet Service Declined	0	Model 3
70001805	Courtesy Inspection Declined	0	Model 3
70002005	Non-Tesla (Rental)	0	Model 3
70002405	Rental Car Declined	0	Model 3
70003005	Third-party shuttle service provided (+)	0	Model 3
70003105	Third-party shuttle service provided (-)	0	Model 3
70003205	Third-party shuttle service declined	0	Model 3
70003605	Airport/Train Station Shuttle Provided	0	Model 3
70003805	Tesla Airport Service	1	Model 3
70004105	No Labor Performed - Customer Did Not Authorize Repairs	0	Model 3
70004505	No Labor Performed - Part Replaced	0	Model 3
70004807	Window Tint Removal	2.15	Model 3
70004817	Window Tint Install (Charlotte Only)	1.45	Model 3
70005005	Rebuilt Vehicle Inspection Complete and Rebuild Approved	0	Model 3
70005505	Car Wash Declined	0	Model 3
70005600	Parts Counter Sales Outside of Network (Over the Counter Sales)	0	Model 3
70005700	Scrap Part Sale Over the Counter	0	Model 3
70005805	Payment Collection Required	1	Model 3
70006005	Body Repair Concierge Service (Japan)	0	Model 3
70007005	Extended Service Agreement (ESA) Plan Purchase	0	Model 3
70010200	Exterior Component/Panel/Glass Adjustment - 0.2	0.2	Model 3
70010400	Exterior Component/Panel/Glass Adjustment - 0.4	0.4	Model 3
70010600	Exterior Component/Panel/Glass Adjustment - 0.6	0.6	Model 3
70011050	Interior Component/Trim/Seal Adjustment - 0.05	0.05	Model 3
70011150	Interior Component/Trim/Seal Adjustment - 0.15	0.15	Model 3
70011300	Interior Component/Trim/Seal Adjustment - 0.3	0.3	Model 3
70012110	General Closures System Calibration	0.1	Model 3
70012180	General HVAC/Thermal System Calibration	0.1	Model 3
70014255	Additional Work Required - Corrosion Present - 0.25	0.25	Model 3
70014505	Additional Work Required - Corrosion Present - 0.5	0.5	Model 3
70014995	Additional Work Required - Corrosion Present - 1	1	Model 3
70015000	Test To Confirm Water Ingress No Longer Present	0.25	Model 3
70020105	Paint - Sublet	0	Model 3
70020205	Wheel Alignment - Sublet	0	Model 3
70020305	Upholstery - Sublet	0	Model 3
70020315	Seat Upholstery Repair (Internal)	1	Model 3
70020325	Seat Upholstery Steaming	0.25	Model 3
70020405	Accessory Installation - Sublet	0	Model 3
70020505	Wheel Refinish - Sublet	0	Model 3
70020805	Glass Repair / Replacement - Sublet	0	Model 3
70021005	Welding - Sublet	0	Model 3
70021105	Dent Repair - Sublet	0	Model 3
70021205	Hood Alignment - Sublet	0	Model 3
70021305	Liftgate Alignment - Sublet	0	Model 3
70021405	Door Alignment - Sublet	0	Model 3
70021505	Exterior Trim - Sublet	0	Model 3

70021605	Window Adjustment -Sublet	0	Model 3
70021705	Exterior Lighting - Sublet	0	Model 3
70021905	Windshield Wipers - Sublet	0	Model 3
70022005	Unsupported Vehicle Body Shop Inspection - Primary	1	Model 3
70022105	High Mounted Brake Lamp - Sublet	0	Model 3
70022205	Unsupported Vehicle Body Shop Inspection - Secondary	1	Model 3
70022305	Vehicle Detailing - Sublet	0	Model 3
70023005	RIV Inspection - Sublet	0	Model 3
70023105	Israel Ordinance 309 Inspection - Sublet	1.79	Model 3
70060005	Thread Repair	0	Model 3
72000005	Vehicle Loaner Late Return Fee	1	Model 3
73010008	Remarketing - Photos	0	Model 3
73020008	Remarketing - Detail	0	Model 3
74010008	Dubai Hailstorm Damage (Repair)	7	Model 3
91000004	Vehicle Familiarization	0.5	Model 3
91001005	Print And Attach Used Car Buyers Guide	0.05	Model 3
91020105	Car Wash (Hand Wash)	0.4	Model 3
91020115	Car Wash (Mechanical Wash)	0.2	Model 3
91020205	Detail I	0.9	Model 3
91020305	Detail II	1.4	Model 3
91020405	Detail III	3	Model 3
91020908	Vehicle Cleaning - General	0	Model 3
91021005	Seasonal Tires - Place in Trunk	0	Model 3
91021105	Seasonal Tires - Ship to Customer	0	Model 3
91021507	Replace Price Information Label	0.05	Model 3
91021517	Install Used Vehicle Label	0.2	Model 3
91022005	Charge Vehicle	0	Model 3
91022407	Vehicle Configuration Update	0.05	Model 3
91029006	Mobile Service Hub Repair	0	Model 3
91040105	Loaner Battery Installation	0	Model 3
91040205	Loaner Battery Removed/Returned	0	Model 3
91041002	Loaner Tire/Wheel (Remove & Replace)	0.2	Model 3
91041108	Loaner Wheel Reunite	0	Model 3
91041605	Loaner Drive Unit Installation	0	Model 3
91041705	Loaner Drive Unit Removed/Returned	0	Model 3
92030010	Factory Body - Fremont	0	Model 3
92050010	Factory Paint - Fremont	0	Model 3
92090010	Factory End Of Line (EOL) - Fremont	0	Model 3
97051766	NVH Package --Headliner Cotton	0.6	Model 3
97052932	NVH Package--Cotton Inside Rear Wheel Cavity	0.3	Model 3
97052994	NVH Package---C Pillar Cotton	0.35	Model 3
97057574	NVH Package--Cotton in Butyl Patch Parcel Shelf Hole	0.35	Model 3
97067227	NVH Package--Cotton in External Mirror Cover Guide Groove	0.5	Model 3
97067915	NVH Package--Cow Seal Improvement	0.05	Model 3
1601C2424	Charge vehicle to 100% maximum SOC	0.5	Model 3
44012100P2	Charge Port Voltage Check	0.15	Model 3
BD000001	China Vehicle Inspection - Tesla Green Service Day	0.2	Model 3
BD000002	Customer Follow-up Inspection (CN Only)	0.3	Model 3
manualline	Manual Line	1	Model 3
O110001	Inspection Only - Pinched heat pump harness between chassis and supermanifold	0.1	Model 3
O110002	Inspection and Rework - Pinched heat pump harness between chassis and supermanifold	0.2	Model 3
O61001	Perform Rear Wheel Arch Inspection; No Issues Found	0.1	Model 3
O82001	Rear Performance Caliper Slide Bolt Torque Check	0.35	Model 3
TCC-CC-MFA4	Reset Multi Factor Authentication / Passcode		Model 3
VRI-Automation-CC-1	PDI (Without Test Drive)	0.3	Model 3