



NETWORK CONNECTION PINOUT

Pin	Name	Description
1	TX DATA	Transmit data towards the Network
2, 4, 5, 7	GROUND	Frame Ground
3	RX DATA	Receive data from the Network
6, 8, 10, 12-15	UNUSED	—
9	TX DATA	Transmit data towards the Network
11	RX DATA	Receive data from the Network

REAR PANEL DESCRIPTIONS

Network Connector	Connection to E1 or FE1 circuit (DB-15)
MON Interface	Bantam jack provided for monitoring and testing
Control In/Out	Connection to a VT100 terminal
Nx 56/64 Connector	High-speed DTE interface
Power Switch	Turns power to the ESU LT on or off
Power Connection	Power cord IEC connection for a reliably grounded 90-240 VAC, 50-60 Hz (24A) power source

INSTALLATION INFORMATION

- A 120Ω DB-15 interface (labeled **NETWORK**) is provided to connect to the network E1 or FE1 circuit. The pinout is provided on this Quick Start Guide. See *Chapter 2, Installation*, of the ESU LT User Manual for more information.
- The rear panel contains a single DB-25 Nx 56/64 interface for connecting to DTE equipment. The pinouts for this interface are located in *Appendix C* of the ESU LT User Manual.
- When shipped from the factory, the ESU LT is uninitialized and set to factory default conditions. At the first application of power, the unit will automatically execute self-tests followed by an initialization sequence.
- The ESU LT can be configured and controlled using the local front panel of the unit or from ADTRAN's PC Control Program, T-Watch PRO™. A limited menu tree is provided on the back of this sheet. For more detailed menu information, refer to the ESU LT User Manual.
- Additional information can be found on the product CD which contains the ESU LT User Manual and Data Sheets.

MENU TREE - OVERVIEW

