

Panasonic

Advanced Hybrid System

KX-TA624-4

**Manual Addendum
for the
Caller ID Feature**

This Manual Addendum provides the additional information on Caller ID for the Panasonic Advanced Hybrid System, KX-TA624.

[913] Caller ID Call Waiting Assignment

Description

Enables or disables the Caller ID Call Waiting feature for outside (CO) lines which have contracted Caller ID Service with a Central Office.

Selection

- Outside (CO) line number: **1 – 6, *** (* = all outside (CO) lines)
- **Enable / Disable**

Default

All outside (CO) lines — Enable

Programming

1. Enter **913**.
Display: C.W CID Assign
2. Press **NEXT**.
Display: CO NO? →
3. Enter an **outside (CO) line number**.
Pressing **NEXT** also can enter outside (CO) line number 1.
Display example: CO 1:Enable
4. Keep pressing **SELECT** until the desired selection is displayed.
5. Press **STORE**.
6. To program another outside (CO) line, press **NEXT** or **PREV**, or **SELECT** and enter the desired **outside (CO) line number**.
7. Repeat steps 4 through 6.
8. Press **END**.

Conditions

- To assign all outside (CO) lines to the same selection, press the * key in step 3. In this case, the display will show: CO * :Mixed.
- When “Disable” is assigned in program [900] “Caller ID Assignment”, the Caller ID Call Waiting feature does not perform even if “Enable” is assigned in this program.

Feature References — in the Installation Manual

Caller ID Call Waiting

[914] Caller ID Call Waiting CAS Receive Time

Description

The telephone company calls the system "Customer Premise Equipment (CPE)". If you have a Caller ID Call Waiting during a conversation, the telephone company will send to the CPE a CAS (CPE Alerting Signal). If the CAS duration is too long or too short, the CAS is ignored. If the CAS is accepted, then the system will respond and the Caller ID Call Waiting feature will be performed.

This program assigns the allowable CAS duration. Normally, it should not be necessary to change the default setting.

Selection

- **Mode 1** (40 ms through 120 ms) / **Mode 2** (64 ms through 96 ms) / **Mode 3** (72 ms through 96 ms)

Default

Mode 3

Programming

1. Enter **914**.
Display: C.W CID Receive
2. Press **NEXT**.
Display example: Mode 3
3. Keep pressing **SELECT** until the desired selection is displayed.
4. Press **STORE**.
5. Press **END**.

Conditions

- This program is available when "Enable" is assigned in programs [900] "Caller ID Assignment" and [913] "Caller ID Call Waiting Assignment".

Feature References — in the Installation Manual

Caller ID Call Waiting

[915] Caller ID Checksum

Description

Enables or disables to select the checksum mode. Normally, it should not be necessary to change the default setting.

For further details on the checksum, consult your dealer.

Selection

- **Enable / Disable**

Default

Enable

Programming

1. Enter **915**.
Display: CID Check Sum
2. Press **NEXT**.
Display example: Enable
3. Keep pressing **SELECT** until the desired selection is displayed.
4. Press **STORE**.
5. Press **END**.

Conditions

None

Feature References — in the Installation Manual

Caller ID
Caller ID Call Waiting